

# Flexim FLUXUS G831ST-HT Ultrasonic Flowmeter





## Table of contents

<b>1</b>	<b>Introduction</b>	7
<b>2</b>	<b>Safety instructions</b>	8
2.1	General safety instructions	8
2.2	Intended use	8
2.3	Not intended use	9
2.4	Safety instructions for the user	9
2.5	Safety instructions for the operator	9
2.6	Safety instructions for electrical work	9
2.7	Safety instructions for transport	10
2.8	Recommended procedure in hazardous situations	10
<b>3</b>	<b>General principles</b>	11
3.1	Measurement principle	11
3.2	Measurement arrangements	13
3.3	Acoustic penetration	14
3.4	Undisturbed flow profile	14
<b>4</b>	<b>Product description</b>	17
4.1	Measuring system	17
4.2	Handling concept	17
4.3	Display	19
4.4	Keyboard	20
<b>5</b>	<b>Transport and storage</b>	21
5.1	Transport	21
5.2	Storage	21
<b>6</b>	<b>Mounting</b>	22
6.1	Transmitter	23
6.2	Transducers	28
6.3	Temperature probe	48
<b>7</b>	<b>Connection</b>	51
7.1	Transducers	54
7.2	SENSPROM	65
7.3	Power supply	67
7.4	Outputs	69
7.5	Inputs	73
7.6	Temperature probe	75
7.7	Service interface	77
<b>8</b>	<b>Start-up</b>	78
8.1	Start-up settings	79
8.2	Switching on	79
8.3	Language	80
8.4	Initialization	80
8.5	Date and time	81
8.6	Information regarding the transmitter	81

<b>9</b>	<b>Measurement</b>	82
9.1	Parameter input	82
9.2	Configuration of an output	88
9.3	Start of measurement	95
9.4	Display during the measurement	97
9.5	Execution of special functions	99
9.6	Stop of measurement	100
<b>10</b>	<b>Troubleshooting</b>	101
10.1	Problems with the measurement	102
10.2	Measuring point selection	102
10.3	Maximum acoustic contact	102
10.4	Application-specific problems	102
10.5	Significant deviations of the measured values	103
10.6	Problems with the totalizers	103
<b>11</b>	<b>Maintenance and cleaning</b>	104
11.1	Maintenance	105
11.2	Cleaning	105
11.3	Calibration	105
11.4	Examination of the O-ring	106
11.5	Examination of the thread on the flameproof enclosure housing	107
11.6	Examination of housing and sight glass	107
<b>12</b>	<b>Dismounting and disposal</b>	108
12.1	Dismounting	108
12.2	Disposal	108
<b>13</b>	<b>User modes</b>	109
13.1	StandardUser mode	110
13.2	ExpertUser mode	112
13.3	SuperUser mode and SuperUser ext. mode	114
<b>14</b>	<b>Outputs</b>	116
14.1	Configuration of a digital output as binary output	116
14.2	Configuration of a digital output as pulse output	119
14.3	Configuration of a digital output as frequency output	122
<b>15</b>	<b>Inputs</b>	125
15.1	Configuration of an input	125
15.2	Assignment of an input	129
<b>16</b>	<b>Data logger</b>	130
16.1	Configuration of the data logger	130
16.2	Deletion of the data logger	133
16.3	Information regarding the data logger	134
<b>17</b>	<b>Data transmission</b>	135
17.1	Service interface	135
17.2	Process interface	135

<b>18</b>	<b>Advanced functions</b>	136
18.1	Totalizers	136
18.2	Diagnosis with the help of the snap function	139
18.3	Modification of the limit for the inner pipe diameter	140
18.4	Remote functions	140
18.5	Event triggers	142
18.6	Event log	146
<b>19</b>	<b>Settings</b>	147
19.1	Dialogs and menus	147
19.2	Measurement settings	149
19.3	Units of measurement	150
19.4	Material scroll list	150
19.5	Working with parameter records	151
19.6	Contrast settings	152
19.7	HotCodes	152
19.8	Key lock	153

## Annex

<b>A</b>	<b>Menu structure</b>	155
<b>B</b>	<b>Units of measurement</b>	168
<b>C</b>	<b>Reference</b>	171
<b>D</b>	<b>Legal information – open source licenses</b>	172




# 1 Introduction


This operating instruction has been written for users operating the ultrasonic flowmeter FLUXUS. It contains important information about the measuring equipment, how to handle it correctly, and how to avoid damages. Read the safety instructions carefully. Make sure you have read and understood this operating instruction before using the measuring equipment.


Any work on the measuring equipment has to be carried out by authorized and qualified personnel in order to detect and avoid possible risks and dangers.

## Presentation of warnings

This operating instruction contains warnings marked as follows:

Danger!	
	<p><b>Type and source of danger</b> danger with high level of risk, which, if not avoided, can lead to death or serious injuries → measures of prevention</p>

Warning!	
	<p><b>Type and source of danger</b> danger with medium level of risk, which, if not avoided, can lead to serious or moderate injuries → measures of prevention</p>

Caution!	
	<p><b>Type and source of danger</b> danger with low level of risk, which, if not avoided, can lead to moderate or minor injuries → measures of prevention</p>

Important!	
This text contains important information which should be observed in order to avoid material damage.	

Notice!	
This text contains important information about the handling of the measuring equipment.	

## Storage of the operating instruction

The operating instruction must permanently be available at the place where the measuring equipment is used. It must be available to the user at all times.

## User comments

All reasonable effort has been made to ensure the correctness of the content of this operating instruction. If you, however, find some erroneous information or miss information, please inform us.

We will be grateful for any suggestions and comments regarding the concept and your experience when working with the measuring equipment. If you have any suggestions about improving the documentation and particularly this operating instruction, please let us know so that we can consider your comments for future reprints.

## Copyright

The contents of this operating instruction are subject to changes without prior notice. All rights reserved. No part of this operating instruction may be reproduced in any form without FLEXIM's written permission.

## Declaration of conformity

For EU declaration of conformity according to ATEX directive, see document SIFLUXUS.

## 2 Safety instructions








### 2.1 General safety instructions

Prior to any work, read the operating instruction carefully and in full.

Failure to comply with the instructions, in particular with the safety instructions, poses a risk to health and can lead to material damages. For further information, contact FLEXIM.

During installation and operation of the measuring equipment, observe the ambient and installation conditions specified in the documentation.

Explanation of symbols on the transmitter and accessories:

symbol	meaning
	direct current
	connection for equipotential bonding/grounding
	protective ground terminal
	Electric devices and batteries must be disposed of separately. If necessary, additional hazardous substances are indicated for disposal.
	Warning! Electric shock possible.
	Observe the operating instruction.
	Warning! Observe the safety instructions in the manufacturer's documentation.

The measuring equipment has to be checked for proper condition and operational safety before each use. If troubles or damages have occurred during installation or operation of the measuring equipment, please inform FLEXIM.

It is not allowed to make unauthorized modifications or alterations to the measuring equipment.

If the measuring point is within an explosive atmosphere, the danger zone and present explosive atmosphere have to be determined. The transmitter, transducers and accessories have to be appropriate and approved for the conditions within the corresponding zone.

Personnel has to be suitably trained and experienced for the work.

Observe the "Safety instructions for the use in explosive atmospheres" (see document SIFLUXUS). Observe the instructions for hazardous substances and the respective safety data sheets. Observe the regulations for the disposal of electrical equipment.

### 2.2 Intended use

The measuring equipment is intended for the measurement of fluid properties in closed pipes. The connected transducers measure the average flow velocity of the fluid.

The transmitter uses these values to calculate the sought quantities, e.g., volumetric flow rate and mass flow rate. Through comparison with the values stored in the transmitter further physical quantities can be determined. The physical quantities are provided via configurable outputs and the display.

- All instructions of this operating instruction have to be observed to ensure intended use.
- Any use beyond or other than the intended use is not covered by warranty and can present a danger. Any damage arising from not intended use shall be solely the liability of the operator or user.
- The measurement is carried out without direct contact to the fluid in the pipe. The flow profile is not influenced.
- The transducers are fixed to the pipe using the supplied transducer mounting fixture.



- If an extension cable is required to connect the transducers to the transmitter, a junction box can be used (optional). Observe the safety instructions in the operating instruction. For the technical data of the junction box, see technical specification.
- Observe the operating conditions, e.g., environment, voltage ranges. For the technical data of the transmitter, transducers and accessories, see technical specification.

## 2.3 Not intended use

Not intended use in terms of a misuse means:

- any work on the measuring equipment without observing all instructions in this operating instruction
- use of transmitter, transducer and accessory combinations not intended by FLEXIM
- installation of the transmitter, transducers and accessories in explosive atmospheres they are not approved for
- any work on the measuring equipment (e.g., installation, dismantling, connection, start-up, operation, service and maintenance) carried out by unauthorized and untrained personnel
- storage, installation and operation of the measuring equipment outside the specified ambient conditions (see technical specification)

## 2.4 Safety instructions for the user

Any work on the transmitter has to be carried out by authorized and qualified personnel only. Observe the safety instructions in the operating instruction. For the technical data of transmitter, transducers and accessories, see technical specification.

- Observe the safety and accident prevention regulations applicable on the site of operation.
- Only use the supplied mounting fixtures and transducers as well as the intended accessories.
- Always wear the required personal protective equipment.


## 2.5 Safety instructions for the operator

- The operator shall qualify the personnel to perform their assigned tasks. The operator shall provide the required personal protective equipment and oblige the personnel to wear it. It is recommended to risk assess the workplace.
- Besides the safety instructions in this operating instruction, the health, safety and environment regulations applicable for the range of application of the transmitter, transducers and accessories have to be observed.
- With the exceptions stated in chapter 11, the measuring equipment is maintenance-free. Any components and spare parts may only be replaced by FLEXIM. The operator shall carry out periodic checks for changes or damages that can present a danger. For further information, contact FLEXIM.
- Observe the specifications for the installation and connection of the transmitter, transducers and accessories.

## 2.6 Safety instructions for electrical work

- Prior to any work on the transmitter (e.g., installation, dismantling, connection, service and maintenance), the transmitter has to be disconnected from the power supply.
- Electrical work may only be carried out if there is enough space.
- Open the transmitter in safe ambient conditions only (e.g., air humidity < 90 %, no conductive pollution, no explosive atmosphere).
- The degree of protection of the transmitter is only ensured if all cables are tightly fitted using cable glands and the housing is firmly screwed.
- The condition and tight fit of the electrical connections have to be checked at regular intervals.
- When connecting the transmitter to the power supply, an appropriate equipment switch according to IEC 60947-1 and IEC 60947-3 has to be installed as disconnecting device. The equipment switch has to disconnect all live wires. The ground conductor connection must not be interrupted. The equipment switch has to be easily accessible and clearly marked as a disconnecting device for the transmitter. It should be located near the transmitter. If the transmitter is used in an explosive atmosphere, the equipment switch has to be installed outside the explosive atmosphere. If this is not possible, it has to be installed in the least hazardous area.
- The connection may only be made to networks up to overvoltage category II. When connecting the inputs and outputs as well as the power supply, observe the installation instructions, in particular the terminal assignment.
- The electronic module must not be removed from the housing. The transmitter does not contain any components to be maintained by the user. For repair and service work, please contact FLEXIM.
- Observe the safety and accident prevention regulations for electrical systems and equipment.

Fig. 2.1: Transmitter



## 2.7 Safety instructions for transport

### Caution!



#### Warning of injuries due to falling objects

- Unsecured and falling objects can lead to severe injuries.
- Secure all components against falling during transport.
  - Wear the required personal protective equipment.
  - Observe the applicable rules.

- If you detect a transport damage when unpacking the delivery, please contact the supplier or FLEXIM immediately.
- The transmitter is a sensitive electronic measuring instrument. Avoid shocks or impacts.
- Handle the transducer cable with care. Avoid excessive bending or buckling. Observe the ambient conditions.
- Select a solid surface to put the transmitter, transducers and accessories on.
- The transmitter, transducers and accessories have to be properly packed for transport:
  - Use, if possible, the original packaging by FLEXIM or an equivalent cardboard box.
  - Position the transmitter, transducers and accessories in the middle of the cardboard box.
  - Fill any voids with appropriate packaging material (e.g., paper, foam, bubble wrap).
  - Protect the cardboard box against humidity.

## 2.8 Recommended procedure in hazardous situations

### Fire fighting measures

- If possible, disconnect the transmitter from the power supply.
- Prior to extinguishing, protect any electrical parts that are not affected by the fire (e.g., using a cover).
- Select a suitable extinguishing agent. Avoid, if possible, conductive extinguishing agents.
- Observe the applicable minimum distances. The minimum distances differ depending on the used extinguishing agent.

## 3 General principles

In the ultrasonic flow measurement, the flow velocity of the fluid in a pipe is determined. Further physical quantities are derived from the flow velocity and from additional physical quantities, if necessary.

### 3.1 Measurement principle

#### 3.1.1 Terms

##### Flow profile

Distribution of flow velocities over the cross-sectional pipe area. For an optimal measurement, the flow profile has to be fully developed and axisymmetrical. The shape of the flow profile depends on whether the flow is laminar or turbulent and is influenced by the conditions at the inlet of the measuring point.

##### Reynolds number $Re$

Coefficient describing the turbulence behavior of a fluid in the pipe. The Reynolds number  $Re$  is calculated from the flow velocity, the kinematic viscosity of the fluid and the inner pipe diameter.

If the Reynolds number exceeds a critical value (usually approx. 2300, if the fluid flows in a pipe), a transition from a laminar flow to a turbulent flow takes place.

##### Laminar flow

A flow without any turbulence. There is no mixing between the parallel flowing layers of the fluid.

##### Turbulent flow

A flow with turbulences (swirling of the fluid). In technical applications, the flow in the pipe is mostly turbulent.

##### Transition range

The flow is partly laminar and partly turbulent.

##### Flow velocity $v$

Average value of all flow velocities of the fluid over the cross-sectional pipe area.

##### Fluid mechanics calibration factor $k_{Re}$

With the fluid mechanics calibration factor  $k_{Re}$ , the measured value of the flow velocity in the area of the sound beam is converted into the value of the flow velocity across the whole cross-sectional pipe area. In case of a fully developed flow profile, the fluid mechanics calibration factor only depends on the Reynolds number and the roughness of the inner pipe wall. The fluid mechanics calibration factor is recalculated by the transmitter for each new measurement.

##### Operating volumetric flow rate $\dot{V}$

$$\dot{V} = v \cdot A$$

The volume of the fluid that passes through the pipe per unit time. The operating volumetric flow rate is calculated from the product of the flow velocity  $v$  and the cross-sectional pipe area  $A$ .

##### Mass flow rate $\dot{m}$

$$\dot{m} = \dot{V} \cdot \rho$$

The mass of the fluid that passes through the pipe per unit time. The mass flow rate is calculated from the product of the volumetric flow rate  $\dot{V}$  and the density  $\rho$ .

### 3.1.2 Measurement of the flow velocity


The flow velocity of the fluid is measured using the correlation principle. 2 pairs of ultrasonic transducers of the same type are mounted one after the other at a distance  $\Delta x$  on the pipe which is completely filled with the fluid. The transducer pairs form the measuring barriers A and B. Ultrasonic signals are alternately emitted by the emitters  $A_1$  and  $B_1$  and received by the respective receivers  $A_2$  and  $B_2$ . The ultrasonic signals are modulated regarding amplitude and phase by the swirls of the turbulent flowing fluid. Since the swirls move with the flow, they pass the measuring barriers A and B with a time offset  $\Delta t$ , so that the modulation patterns of the ultrasonic signals of measuring barrier A and B are also offset by  $\Delta t$ . This time offset  $\Delta t$  is measured by means of cross correlation of the modulation signals. The average flow velocity can be calculated using the fluid mechanic calibration factor.

$$v = k_{Re} \cdot \frac{\Delta x}{\Delta t}$$

where


- $v$  – average flow velocity of the fluid
- $k_{Re}$  – fluid mechanic calibration factor
- $\Delta x$  – distance between the measuring barriers
- $\Delta t$  – time offset of the modulation patterns

Fig. 3.1: Measurement arrangement of the correlation principle



- $A_1$  – emitter of measuring barrier A
- $A_2$  – receiver of measuring barrier A
- $B_1$  – emitter of measuring barrier B
- $B_2$  – receiver of measuring barrier B
- $\Delta x$  – distance between measuring barriers

Fig. 3.2: Time offset of the modulation signals  $\Delta t$



- A – modulation signal of measuring barrier A
- B – modulation signal of measuring barrier B

### 3.2 Measurement arrangements

#### 3.2.1 Terms

The transducers of a measuring barrier are mounted on opposite sides of the pipe.


##### Sound path

The distance covered by the ultrasonic signal of a transducer pair after crossing the pipe once.

##### Distance between the measuring barriers

The measuring barrier distance is measured between the inner edges of the emitters and/or receivers of measuring barrier A and B.


Fig. 3.3: Diagonal arrangement with 2 parallel beams and 1 sound path each



$\Delta x$  – distance between measuring barriers  
a – transducer distance

##### Transducer distance


The transducer distance is measured between the inner edges of the transducers of a transducer pair.



**Sound beam plane**

Plane containing the sound paths of the measuring barriers.

Fig. 3.4: 2 sound paths in 1 plane



**3.3 Acoustic penetration**

The pipe has to be acoustically penetrable at the measuring point. The acoustic penetration is given when pipe and fluid do not attenuate the sound signal so strongly that it is completely absorbed before reaching the second transducer.

The attenuation caused by the pipe and the fluid depends on:

- kinematic viscosity of the fluid
- proportion of liquids and solids in the fluid
- deposits on the inner pipe wall
- pipe material

The following requirements have to be met at the measuring point:


- no solid deposits in the pipe
- no accumulation of liquid (condensate), e.g., before orifice plates or at pipe sections located lower

Observe the following notes on the selection of the measuring point:

**Horizontal pipe**


Select a measuring point where the transducers can be mounted laterally on the pipe, allowing the sound waves to propagate horizontally in the pipe. Thus, solids or liquid on the bottom of the pipe are prevented from influencing the propagation of the signal.

Fig. 3.5: Recommended transducer mounting position (laterally)



A – transducer pair A  
 B – transducer pair B

Fig. 3.6: Disadvantageous transducer mounting position (vertical)











**3.4 Undisturbed flow profile**

Some flow elements (e.g., elbows, valves, pumps, reducers) distort the flow profile in their vicinity. The axisymmetrical flow profile in the pipe needed for correct measurement is no longer given. A careful selection of the measuring point helps to reduce the impact of disturbances.

It is most important that the measuring point is chosen at a sufficient distance from any disturbances. Only then it can be assumed that the flow profile in the pipe is fully developed. The use of the disturbance correction (see section 13.2.2) allows a measurement even at smaller distances of min. 2 d.









The recommended straight inlet and outlet pipe lengths for different types of flow disturbances are shown in the following table.

Tab. 3.1: Recommended distance from disturbances  
 $d$  – inner pipe diameter at the measuring point  
 $l$  – recommended distance between disturbance and transducer position

<p>disturbance: 90° elbow</p> <p>inlet: <math>l \geq 10 d</math></p> 	<p>outlet: <math>l \geq 3 d</math></p> 
<p>disturbance: double elbow</p> <p>inlet: <math>l \geq 10 d</math></p> 	<p>outlet: <math>l \geq 3 d</math></p> 
<p>disturbance: double elbow out of plane</p> <p>inlet: <math>l \geq 40 d</math></p> 	<p>outlet: <math>l \geq 3 d</math></p> 
<p>disturbance: 45° elbow</p> <p>inlet: <math>l \geq 15 d</math></p> 	<p>outlet: <math>l \geq 3 d</math></p> 

A – transducer pair A  
 B – transducer pair B

Tab. 3.1: Recommended distance from disturbances  
 d – inner pipe diameter at the measuring point  
 l – recommended distance between disturbance and transducer position

disturbance: 45° double elbow	
inlet: $l \geq 15 d$	outlet: $l \geq 3 d$
	
disturbance: valve	
inlet: $l \geq 40 d$	outlet: $l \geq 3 d$
	
disturbance: reducer	
inlet: $l \geq 10 d$	outlet: $l \geq 3 d$
	
disturbance: compressor	
inlet: $l \geq 20 d$	outlet: $l \geq 3 d$
	

A – transducer pair A  
 B – transducer pair B




## 4 Product description

### 4.1 Measuring system

The measurement system consists of the transmitter, 2 pairs of ultrasonic transducers and the pipe on which the measurement is carried out.

Fig. 4.1: Example of a measurement arrangement



- 1 – transducer pair A
- 2 – transducer pair B
- 3 – pipe
- 4 – transmitter

### 4.2 Handling concept

The command panel is on the front side of the transmitter. The keys are operated using a magnetic pen with the housing being closed.



By pressing  or CLR the menus are displayed consecutively:

Fig. 4.2: Command panel of the transmitter



- 1 – LCD display (backlight)
- 2 – keyboard

Tab. 4.1: Description of the menus

menu	description
Parameters	input of sensor, pipe and fluid parameters
Installation	input of measuring point specific parameters
Start measurement	measurement start <sup>(1)</sup>
Show measurement	measured value display <sup>(2)</sup>
Stop measurement	measurement stop <sup>(2)</sup>
Inputs	configuration and assignment of inputs
Outputs	output configuration
Functions	configuration of event triggers and remote functions
Storage	configuration of the data logger and snaps
Calibration	definition of correction values to compensate unfavorable measuring conditions
Communication	configuration of communication interfaces (e.g. fieldbuses (option))
Miscellaneous	settings of system and measurement and changes in dialogs and menus

<sup>(1)</sup> will only be displayed if no measurement is running

<sup>(2)</sup> will only be displayed if a measurement is running

When starting up the transmitter for the first time, settings relating to the language, time, date and system of units have to be made. Afterwards the menu `Parameters` will be displayed.


At later start-ups the measured values will be displayed in case the measurement had not been stopped before the transmitter was disconnected from the power supply. If the measurement is stopped, the menu `Parameters` will be displayed.

After starting the measurement, the parameter settings or the configuration of the transmitter outputs can be displayed at any time without interrupting the measurement. A change of the parameter settings is not possible during the measurement. The measurement has to be stopped in order to change the parameter settings or configuration of the transmitter outputs.

### 4.3 Display

#### Structure

Fig. 4.3: Example: menu Parameters



- 1 – menu
- 2 – menu item currently edited
- 3 – area for scroll lists, selection fields or input fields


Tab. 4.2: Navigation

horizontal scroll list	vertical scroll list	input fields
<ul style="list-style-type: none"> <li>• scroll horizontally with  or CLR</li> </ul>	<ul style="list-style-type: none"> <li>• scroll vertically with  or </li> </ul>	<ul style="list-style-type: none"> <li>• input numbers or text with  or </li> <li>• delete with CLR</li> </ul>



#### Status indications

Several symbols are used for the status indications.

Fig. 4.4: Status indications (line 1)





## 4.4 Keyboard

The keyboard consists of the following keys: ENTER, BRK, CLR,  and . The keys are operated using a magnetic pen with the housing being closed.



Tab. 4.3: General functions

ENTER	confirmation of selection or input
BRK	during the parameter input: short press: return to the previous menu item long press (several seconds): return to the beginning of the menu during the measurement: return to the main menu, stop of measurement or parameter display



Tab. 4.4: Navigation

	scroll to the right or up through a scroll list
	scroll down through a scroll list
CLR	scroll to the left through a scroll list

Tab. 4.5: Input of numbers

	move the cursor to the right
	scroll through the numbers above the cursor
CLR	short press: move the cursor to the left long press (several seconds): reset the value to the previously stored one

Tab. 4.6: Input of text

	move the cursor to the right
	scroll through the characters above the cursor
CLR	short press: move the cursor to the left long press (several seconds): reset the text to the previously stored one

## 5 Transport and storage

### Caution!

**When packaging, the transmitter can fall down.**

There is a danger of crushing body parts or damaging the measuring equipment.

- Secure the transmitter against falling during packaging.
- Wear the required personal protective equipment.
- Observe the applicable rules.

### Caution!

**When lifting, the center of gravity of the transmitter can be displaced within the cardboard box. The transmitter can fall down.**

There is a danger of crushing body parts or damaging the measuring equipment.

- Secure the transmitter against falling during transport.
- Wear the required personal protective equipment.
- Observe the applicable rules.

### 5.1 Transport

The measuring equipment must be packaged properly for transport. For weight indications, see technical specification.

- Use, if possible, the original packaging by FLEXIM or an equivalent cardboard box.
- Position the transmitter, transducers and accessories in the middle of the cardboard box.
- Fill any voids with appropriate packaging material (e.g., paper, foam, bubble wrap).
- Protect the cardboard box against humidity.

### 5.2 Storage

- Store the measuring equipment within the original package.
- Do not store the measuring equipment outdoors.
- Seal all openings with blind plugs.
- Protect the measuring equipment against sunlight.
- Storage the measuring equipment in a dry place without dust and within the valid temperature range, see technical specification.

## 6 Mounting

### Danger!



#### Risk of explosion when using the measuring equipment in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ Observe the "Safety instructions for the use in explosive atmospheres".

### Warning!



#### Installation, connection and start-up by unauthorized and unqualified personnel

This may result in personal or material damage or dangerous situations.

→ Any work on the transmitter has to be carried out by authorized and qualified personnel.

### Warning!



#### Touching live parts

Electric shock or arc faults can led to severe injuries. The measuring equipment can be damaged.

→ Prior to any work on the transmitter (e.g., installation, dismantling, connection, start-up), the transmitter has to be disconnected from the power supply.

### Caution!



#### Safety and accident prevention regulations for electrical systems and equipment

Failure to observe these regulations may lead to severe injuries.

→ Observe the safety and accident prevention regulations for electrical systems and equipment.

### Caution!



#### Touching hot or cold surfaces

This may result in injuries (e.g., thermal damages).

→ Observe the ambient conditions at the measuring point during installation.

→ Wear the required personal protective equipment.

→ Observe the applicable rules.

### Important!

Remove all protective foils before using the measuring equipment in explosive atmospheres (see document SIFLUXUS).

## 6.1 Transmitter

### 6.1.1 Opening and closing the housings


**Important!**

Do not open the housings using objects which may damage the thread or housing gasket.

#### 6.1.1.1 Transmitter with aluminum housing

The transmitter has 3 set screws which have to be unscrewed before the housings can be opened. After the installation of the transmitter, make sure that the housings are closed correctly and that the set screws are tightened.

Fig. 6.1: Transmitter



1 – set screw

### 6.1.1.2 Transmitter with stainless steel housing


#### Housing

The transmitter has a countersunk screw which has to be unscrewed before the housing can be opened. The transmitter has to be mounted to the instrument mounting plate in case the housing is to be opened. Use a strap wrenches (not included in the delivery) to open and close the housing. After the installation, make sure that the housing is closed correctly and that the countersunk screw is tightened.

#### Cover plate

- Loosen the 4 screws of the cover plate.
- Remove the cover plate. Do not use tools that may damage the gasket. If necessary, lightly tap the cover plate with a plastic hammer.

Fig. 6.2: Transmitter and strap wrench



- 1 – housing
- 2 – cover plate
- 3 – countersunk screw
- 4 – instrument mounting plate
- 5 – strap wrench

### 6.1.2 Installation of the transmitter

#### Caution!



#### The transmitter can fall down during installation.

There is a danger of crushing body parts or damaging the measuring equipment.

- Secure the transmitter against falling.
- Wear the required personal protective equipment.
- Observe the applicable rules.

#### Caution!



#### The instrument mounting plate has sharp edges.

Risk of injury.

- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.




### 6.1.2.1 Wall mounting

#### Transmitter with aluminum housing

- Fix the instrument mounting plate to the wall using the 4 screws.
- Fix the transmitter to the instrument mounting plate.

Fig. 6.3: Wall mounting of the transmitter




1 – instrument mounting plate

#### Transmitter with stainless steel housing

- Fix the instrument mounting plate to the wall using the 4 screws.
- Slide the transmitter into the instrument mounting plate.
- Fix the transmitter support to the instrument mounting plate.

Fig. 6.4: Installation of the transmitter



1 – instrument mounting plate  
2 – support

### 6.1.2.2 Pipe mounting

#### Notice!

The pipe has to be sufficiently stable to withstand the pressure exerted by the transmitter and the shackles.

#### Transmitter with aluminum housing

##### Mounting on a 2" pipe

The instrument mounting plate is fixed to the pipe using the shackles.


- Fix the instrument mounting plate with the shackles to the pipe by tightening the nuts.
- Fix the transmitter to the instrument mounting plate.

##### Mounting on a pipe > 2"

The instrument mounting plate is fixed to the pipe using tension straps.

- Fix the instrument mounting plate to the pipe using the tension straps instead of the shackles.
- Fix the transmitter to the instrument mounting plate.

Fig. 6.5: Pipe mounting of the transmitter




- 1 – shackle
- 2 – instrument mounting plate
- 3 – nut
- 4 – tension strap

**Transmitter with stainless steel housing*****Mounting on a 2" pipe***

- Position the shackles on the pipe.
- Fix the instrument mounting plate with the shackles and the nuts to the pipe.
- Fix the transmitter support to the instrument mounting plate.

Fig. 6.6: Installation of the transmitter



- 1 – shackle
- 2 – instrument mounting plate
- 3 – nut
- 4 – support

## 6.2 Transducers

### Caution!



#### Warning of severe injuries from hot or cold components

Touching hot or cold components can lead to severe injuries (e.g., thermal damage).

- Any mounting, installation or connection work has to be concluded.
- Any work on the measuring point during the measurement is prohibited.
- Observe the ambient conditions at the measuring point during installation.
- Wear the required personal protective equipment.
- Observe the applicable rules.

### 6.2.1 Preparation

#### 6.2.1.1 Measuring point selection

The correct selection of the measuring point is crucial for achieving reliable measurement results and a high measurement accuracy.

A measurement on a pipe is possible if:

- the ultrasound propagates with a sufficiently high amplitude
- the flow profile is fully developed
- the influence of noise is sufficiently low

The correct selection of the measuring point and the correct transducer positioning guarantee that the sound signal will be received under optimum conditions and evaluated correctly.

Because of the variety of applications and the different factors that influence the measurement, there is no standard solution for the transducer positioning.

The measurement is influenced by the following factors:

- diameter, material, lining, wall thickness and shape of the pipe
- fluid
- Avoid measuring points in the vicinity of distorted or defective areas of the pipe or in the vicinity of welds.
- Avoid measuring points with deposit formation in the pipe.
- Make sure the pipe surface at the selected measuring point is even.
- Select the location of the transmitter within the transducer cable range.
- The temperature at the measuring point has to be within the specific ambient temperature range of the transmitter and the transducers (see technical specification).

If the measuring point is within an explosive atmosphere, possibly present danger zones and gases have to be determined. The transducers and the transmitter have to be appropriate for these conditions.

### 6.2.1.2 Pipe preparation

#### Caution!



#### Contact with grinding dust

This may result in injuries (e.g., breathing difficulties, skin reactions, eye irritations).

- Wear the required personal protective equipment.
- Observe the applicable rules.

#### Important!

The pipe has to be sufficiently stable to withstand the pressure exerted by the transducers and the fasteners.

#### Notice!

Observe the selection criteria of pipe and measuring point.

Rust, paint or deposits on the pipe absorb the sound signal. A good acoustic contact between the pipe and the transducers is obtained as follows:


- Clean the pipe at the selected measuring point.
  - If present, the paint layer has to be smoothed by grinding. The paint does not need to be removed completely.
  - Remove any rust or loose paint.
- Install the damping mats.

### 6.2.1.3 Measurement arrangement

The transducer pairs of both the measuring barriers are each mounted in diagonal arrangement with 1 sound path in the same sound beam plane.


If the measuring point is situated near an elbow, the following measurement arrangements are recommended for the selection of the sound beam plane.

#### Vertical pipe



- The sound beam plane is selected at an angle of  $90^\circ$  to the elbow plane. The elbow is upstream of the measuring point.

#### Horizontal pipe



- The sound beam plane is selected at an angle of  $90^\circ \pm 45^\circ$  to the elbow plane. The elbow is upstream of the measuring point.

## 6.2.2 Installation of the transducers


### 6.2.2.1 Orientation of the transducers and determination of the distance between the transducers and measuring barriers

Observe the orientation of the transducers. If the transducers of a transducer pair have been mounted properly, the engravings on them form an arrow pointing in the flow direction. The transducer cables show in opposite directions.

The transducer distance is measured between the inner edges of the transducers of a measuring barrier.

The measuring barrier distance is measured between the inner edges of the senders and/or receivers of measuring barrier A and B.

Fig. 6.7: Orientation and distance of the transducers




$\Delta x$  – distance between measuring barriers  
 $a$  – transducer distance

- Select the installation instructions of the supplied transducer mounting fixture.

### 6.2.2.2 Transducer arrangement

The transducers can be arranged in the mounting rails in different ways:

Fig. 6.8: Transducer arrangement in mounting rails



### 6.2.2.3 Order of transducer mounting

The transducers are mounted using the corresponding mounting fixtures. Observe the following steps:

- Mount the transducer pair A in diagonal arrangement with 1 sound path at the transducer distance  $a$  and with the arrows pointing in the flow direction.
- Mount the transducer pair B in diagonal arrangement with 1 sound path at the distance  $\Delta x$  from transducer pair A and with the arrows pointing in the flow direction.
  - Mount the transducer  $B_1$  at the distance  $\Delta x$  from transducer  $A_1$ , if possible with an accuracy of 1 mm.
  - Mount the transducer  $B_2$  at the distance  $\Delta x$  from transducer  $A_2$ , if possible with an accuracy of 1 mm.
  - Check whether the transducer distance of transducer pair B corresponds to the required distance  $a$ .


#### Notice!

In case the recommended distance between the measuring barriers displayed by the transmitter cannot be set because of the transducer size, mount the transducer pair B at the smallest possible distance to transducer pair A. Make sure to keep a few millimeters distance between the transducers of measuring barrier A and B. The transducers should not touch.

### 6.2.2.4 Mounting the transducers of type \*\*\*\*LI\*\*

If the nameplate of the transducers \*\*\*\*LI\*\* is removed from the transducer cable during installation, it has afterwards to be remounted and fixed to the transducer cable using the provided cable tie. The heat shrink tubing must not be reused.

Fig. 6.9: Nameplate on the transducer cable




### 6.2.2.5 Mounting with Variofix L (PermaRail)

#### Mounting

For measurements in diagonal arrangement, the transducer mounting fixtures are mounted on opposite sides of the pipe. Mounting the transducer pairs in one pair of rails is not possible when using Variofix L. In the following, the installation of 2 pairs of rails in diagonal arrangement is described (each transducer pair in its own pair of rails).

Fig. 6.10: Transducer mounting fixture Variofix L



#### Overview of mounting steps


- **step 1**  
disassembly of the transducer mounting fixture Variofix L
- **step 2**  
fixation of the clasps to the tension straps
- **step 3**  
fixation of the tension strap to the pipe
- **step 4**  
fixation of the rail to the pipe
- **step 5**  
installation of the transducers in the mounting fixture Variofix L



**Step 1: Disassembly of the transducer mounting fixture Variofix L**

- Disassemble the transducer mounting fixture Variofix L.

Fig. 6.11: Disassembly of the transducer mounting fixture Variofix L



**Step 2: Fixation of the clasps to the tension straps**

- Select the installation instruction of the supplied clasp:

***Band clamp clasp***

The clasp is fixed to the tension strap, see Fig. 6.12.

***Quick release clasp***

The clasp is fixed to the tension strap, see Fig. 6.13.

- Cut the tension strap to length (pipe circumference + at least 120 mm).

Fig. 6.12: Band clamp clasp with tension strap





Fig. 6.13: Quick release clasp with tension strap



### Ratchet clasp

- Cut the tension strap to length (pipe circumference + at least 120 mm).

#### Caution!




**The edge of the tension strap is very sharp.**

risk of injury

- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.

- Insert approx. 100 mm of the tension strap into part (1) and (2) of the ratchet clasp (see Fig. 6.14 a).
- Bend the tension strap.
- Insert the tension strap into part (1) of the ratchet clasp (see Fig. 6.14 b).
- Tighten the tension strap.
- Repeat the steps for the second tension strap.


Fig. 6.14: Ratchet clasp with tension strap



### Step 3: Fixation of the tension strap to the pipe

One tension strap is fixed to the pipe using 2 opposite tension strap clamps. The second tension strap will be mounted later.

Fig. 6.15: Tension strap with clamp and metal spring on the pipe



- 1 – tension strap clamp
- 2 – clasp
- 3 – metal spring

Select the installation instruction of the supplied clasp:

**Band clamp clasp**

- Insert the tension strap into 2 tension strap clamps, see Fig. 6.16.
- Position the clasp and the tension strap clamps on the pipe, see Fig. 6.15. On a horizontal pipe, mount the tension strap clamps laterally to the pipe, if possible.
- Place the tension strap around the pipe and insert it into the clasp, see Fig. 6.18.
- Make sure that the 2 tension strap clamps are as exactly as possible opposite each other. To do this, check whether the distance between the tension strap clamps is half the pipe circumference.
- Tighten the tension strap.
- Tighten the clasp screw.

**Quick release clasp**

- Insert the tension strap into its clamps and the metal spring, see Fig. 6.16 and Fig. 6.17.
- Position the clasp, the tension strap clamps and the metal spring on the pipe, see Fig. 6.15:
  - On a horizontal pipe, mount the tension strap clamps laterally to the pipe, if possible.
  - Mount the metal spring opposite the clasp.
- Make sure that the 2 tension strap clamps are as exactly as possible opposite each other. To do this, check whether the distance between the tension strap clamps is half the pipe circumference.

Fig. 6.16: Tension strap with clamp




Fig. 6.17: Tension strap with quick release clasp and metal spring




Fig. 6.18: Tension strap with band clamp clasp



- Place the tension strap around the pipe and insert it into the clasp, see Fig. 6.17.
- Tighten the tension strap.
- Tighten the clasp screw.

**Ratchet clasp**

- Insert the tension strap into its clamps and the metal spring, see Fig. 6.19.
- Position the ratchet clasp, the tension strap clamps and the metal spring on the pipe, see Fig. 6.15:
  - On a horizontal pipe, mount the tension strap clamps laterally to the pipe, if possible.
  - Mount the metal spring opposite the ratchet clasp.
- Make sure that the 2 tension strap clamps are as exactly as possible opposite each other. To do this, check whether the distance between the tension strap clamps is half the pipe circumference.
- Place the tension strap around the pipe and pass it through the slot of the clasp screw, see Fig. 6.20.
- Tighten the tension strap.
- Cut off the protruding tension strap, see Fig. 6.20.

**Caution!**



**The edge of the tension strap is very sharp.**

risk of injury

- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.

- Tighten the clasp screw.

**Notice!**


In order to release the screw and the tension strap, press the lever down (see Fig. 6.20).

Fig. 6.19: Tension strap with metal spring and clamp



- 1 – metal spring
- 2 – tension strap clamp

Fig. 6.20: Ratchet clasp with tension strap




- 1 – sense of rotation
- 2 – edge
- 3 – lever
- 4 – clasp screw with slot

**Step 4: Fixation of the rail to the pipe**


- Place the tension strap clamp (2) in the rail, see Fig. 6.21. Observe the orientation of the tension strap clamp.
- Slightly tighten the nut of the tension strap clamp (2).
- Screw the rail to tension strap clamp (1), see Fig. 6.22.
- Tighten the nut of tension strap clamp (1), but not too firmly in order not to damage the tension strap.

Fig. 6.21: Rail with tension strap clamp



- 1 – nut
- 2 – tension strap clamp

Fig. 6.22: Rail, fixed on one side to the pipe




- 1 – tension strap clamp
- 2 – tension strap clamp
- 3 – nut

- Repeat the steps to fix the second rail on the opposite side of the pipe. Make sure that the 2 tension strap clamps are as exactly as possible opposite each other. To do this, check whether the distance between the tension strap clamps is half the pipe circumference.
- Select the installation instruction of the supplied clasp:

#### **Band clamp clasp**

- Insert the tension strap into the tension strap clamp (2).
- Place the tension strap around the pipe and insert it into the tension strap clamp on the opposite side and the tension strap, see Fig. 6.23 and Fig. 6.24.
- Tighten the tension strap.
- Tighten the clasp screw.
- Tighten the nuts of the tension strap clamps (2), but not too firmly in order not to damage the tension strap.

Fig. 6.23: Rail on the pipe



- 1 – tension strap clamp
- 2 – tension strap clamp
- 3 – metal spring
- 4 – nut
- 5 – clasp

#### **Quick release clasp**


- Insert the tension strap into the tension strap clamp (2) and the metal spring.
- Place the tension strap around the pipe and insert it into the tension strap clamp on the opposite side and the tension strap, see Fig. 6.23 and Fig. 6.25.
- Position the metal spring opposite the clasp.
- Tighten the tension strap.
- Tighten the clasp screw.
- Tighten the nuts of the tension strap clamps (2), but not too firmly in order not to damage the tension strap.

Fig. 6.24: Tension strap with band clamp clasp



1 – clasp screw

Fig. 6.25: Tension strap with quick release clasp and metal spring



1 – clasp screw  
2 – metal spring

### Ratchet clasp

- Insert the tension strap into the tension strap clamp (2) and the metal spring, see Fig. 6.23 and Fig. 6.26.
- Place the tension strap around the pipe and insert it into the tension strap clamp on the opposite side and the slot of the clasp screw, see Fig. 6.27.
- Position the metal spring opposite the ratchet clasp.
- Tighten the tension strap.
- Cut off the protruding tension strap, see Fig. 6.27.

### Caution!



**The edge of the tension strap is very sharp.**

risk of injury



- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.

- Tighten the clasp screw.
- Tighten the nuts of the tension strap clamps (2), but not too firmly in order not to damage the tension strap, see Fig. 6.23.

### Notice!


In order to release the screw and the tension strap, press the lever down (see Fig. 6.20).

Fig. 6.26: Tension strap with metal spring and clamp



1 – metal spring  
2 – tension strap clamp


Fig. 6.27: Ratchet clasp with tension strap



- 1 – sense of rotation
- 2 – edge
- 3 – lever
- 4 – clasp screw with slot

- Repeat the steps for fixing the second pair of rails. When positioning the second pair of rails, observe the required distance between the measuring barriers.

Fig. 6.28: Pipe with 2 rails




**Step 5: Installation of the transducers in the mounting fixture Variofix L**

- Press the transducers firmly into their clamping fixtures in the covers until they are tightly fixed, see Fig. 6.29. Observe the correct orientation of the transducers. Emitter and receiver are mounted on opposite sides of the pipe.

**Notice!**  
The arrows on the transducers and the covers have to point in the same direction.


Fig. 6.29: Installation of the transducers in the covers



- 1 – cover
- 2 – transducer clamping fixture

- Adjust the transducer distance for transducer pair A displayed by the transmitter.
- Now position the transducers of measuring barrier B at the distance displayed by the transmitter, see Fig. 6.30.
- Check whether the transducer distance of transducer pair B corresponds to the value displayed by the transmitter.


Fig. 6.30: Adjustment of the distance between the measuring barriers



- 1 – cover
- 2 – equipotential bonding terminal
- $\Delta x$  – distance between measuring barriers

- Fix the transducer cables with the strain relief clamp to protect them from mechanical strain. Transducer cables with stainless steel conduit are fixed inside the housing, transducer cables with plastic conduit are fixed to the outside of the housing, see Fig. 6.31.
- Put coupling foil (or apply some coupling compound for a short-term installation) on the contact surface of the transducers. The coupling foil can be fixed to the contact surface with some coupling compound.
- Put the covers with the transducers on the rails.
- Correct the distance between the measuring barriers, if necessary. The distance has to be adjusted with an accuracy of 1 mm.

Fig. 6.31: Fixing the transducer cables



- 1 – strain relief clamp for transducer cable with stainless steel conduit
- 2 – strain relief clamp for transducer cable with plastic conduit


**Notice!**

Make sure that the coupling foil remains on the contact surface of the transducers. For information concerning the coupling foil, see the safety data sheet.

- Tighten the cover screws, see Fig. 6.32.



Fig. 6.32: Variofix L with transducers on the pipe



- 1 – equipotential bonding terminal
- 2 – cover screws

### 6.2.2.6 Mounting with Variofix C

#### Mounting


For measurements in diagonal arrangement, the transducer mounting fixtures are mounted on opposite sides of the pipe. Depending on the transducer distance  $a$  and the measuring barrier distance  $\Delta x$ , 1 or 2 pairs of rails have to be mounted. The distances  $a$  and  $\Delta x$  are either summed up (1 pair of rails) or considered separately (2 pairs of rails), see Tab. 6.1.

Tab. 6.1: Conditions for the selection of the proper rail configuration for Variofix C

transducer frequency (3rd character of the technical type)	1 pair of rails	2 pairs of rails	
	$a + \Delta x$ [mm]	$a$ [mm]	$\Delta x$ [mm]
G	< 241	< 241	> 560
K	< 241	< 241	> 560
M	< 272	< 272	> 460
P	< 272	< 272	> 460
Q	< 170	< 170	> 310

In the following, the mounting of 1 pair of rails in diagonal arrangement is described.

Fig. 6.33: Transducer mounting fixture Variofix C



#### Overview of the mounting steps

- **step 1**  
disassembly of the transducer mounting fixture Variofix C
- **step 2**  
mounting of the rail
- **step 3**  
installation of the transducers in the transducer mounting fixture Variofix C

### Step 1: Disassembly of the transducer mounting fixture Variofix C

- Disassemble the transducer mounting fixture Variofix C.

In order to remove the cover from the rail, bend the outer sides of the cover outwards.

In order to remove the spring clip from the rail, slide it over the indentations on the rail and lift it off.

Fig. 6.34: Removal of the cover





Fig. 6.35: Disassembly of the transducer mounting fixture Variofix C



- 1 – cover
- 2 – tensioning screw
- 3 – spring clip
- 4 – indentation
- 5 – spacing element
- 6 – rail
- 7 – tension strap clamp

### Step 2: Mounting of the rail

- Select the installation instruction of the supplied clasp:

#### **Mounting of the rail without a clasp**

- Cut the tension strap to length (pipe circumference + at least 120 mm).

#### **Caution!**




**The edge of the tension strap is very sharp.**

risk of injury

- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.


- Insert approx. 100 mm of the tension strap into one of the slots of the tension strap clamp and bend it, see Fig. 6.36.
- Insert the long end of the tension strap into the 2 tension strap clamp and the metal spring, see Fig. 6.37). Place the tension strap around the pipe, see Fig. 6.38.

Fig. 6.36: Tension strap with clamp



1 – tension strap clamp


Fig. 6.37: Tension strap with metal spring and clamp



1 – tension strap clamp  
2 – metal spring

- Position the tension strap clamps and the metal spring on the pipe:
  - On a horizontal pipe, mount the tension strap clamps laterally to the pipe, if possible.
  - Mount the metal spring on the bottom side of the pipe.
- Make sure that the 2 tension strap clamps are as exactly as possible opposite each other. To do this, check whether the distance between the tension strap clamps is half the pipe circumference.


Fig. 6.38: Tension strap and tension strap clamp on pipe



1 – tension strap clamp  
s = length of the rail - 33 mm

- Insert the long end of the tension strap into the second slot of the tension strap clamp (see Fig. 6.38 a).
- Tighten the tension strap and bend it.
- Bend both ends of the tension strap (see Fig. 6.38 b).
- Repeat the steps for the second tension strap.
- Position the tension straps at the distance s (see Fig. 6.38).
- Put the rails on the tension strap clamps.
- Fix the rails to the tension strap clamps using the screws (see Fig. 6.39).
- Tighten the screws.

Fig. 6.39: Rail on the pipe



1 – screws

**Mounting the rail with ratchet clasp**

- Cut the tension strap to length (pipe circumference + at least 120 mm).

**Caution!**




**The edge of the tension strap is very sharp.**

risk of injury

- Deburr sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.

- Insert approx. 100 mm of the tension strap into part (1) and (2) of the ratchet clasp (see Fig. 6.40 a).

Fig. 6.40: Ratchet clasp with tension strap



- Bend the tension strap.
- Insert the tension strap into part (1) of the ratchet clasp (see Fig. 6.40 b).
- Tighten the tension strap.
- Insert the long end of the tension strap into the clamps and the metal spring, see Fig. 6.41. Place the tension strap around the pipe.

Fig. 6.41: Tension strap with metal spring and clamp




- 1 – metal spring
- 2 – tension strap clamp

- Position the ratchet clasp, the tension strap clamps and the metal spring on the pipe:
  - On a horizontal pipe, mount the tension strap clamps laterally to the pipe, if possible.
  - Mount the metal spring opposite the ratchet clasp.
- Make sure that the 2 tension strap clamps are as exactly as possible opposite each other. To do this, check whether the distance between the tension strap clamps is half the pipe circumference.
- Insert the long end of the tension strap into the slot of the clasp screw (see Fig. 6.42).
- Tighten the tension strap.
- Cut off the protruding tension strap, see Fig. 6.42.
- Tighten the screw of the ratchet clasp.
- Repeat the steps for the second tension strap.

**Notice!**

In order to release the screw and the tension strap, press the lever down (see Fig. 6.42).


Fig. 6.42: Ratchet clasp with tension strap



- 1 – sense of rotation
- 2 – edge
- 3 – lever
- 4 – clasp screw with slot

- Put the rails on the tension strap clamps, see Fig. 6.43.
- Fix the rails to the tension strap clamps using the screws.
- Tighten the screws.

Fig. 6.43: Rail on the pipe



- 1 – screws

### Step 3: Installation of the transducers in the mounting fixture Variofix C

- Put coupling foil (or apply some coupling compound for a short-term installation) on the contact surface of the transducers. The coupling foil can be fixed to the contact surface with a small amount of coupling compound.


#### Notice!

For information concerning the coupling foil or coupling compound, see the safety data sheet.

- Position the emitter and the receiver of transducer pair A into the opposite rails.
- Adjust the transducer distance displayed by the transmitter (see Fig. 6.44).
- Slide the spring clips on the transducers.
- Fix the transducers by slightly tightening the tensioning screws. The end of the tensioning screw has to be placed above the hole in the respective transducer (see Fig. 6.44).
- Correct the transducer distance, if necessary.
- Tighten the tensioning screws.
- Fix the spacing elements on the rail to mark the transducer position.
- Position the emitter and the receiver of transducer pair B into the opposite rails. The transducer cables show in the same direction as the transducer cables of transducer pair A.
- Adjust the measuring barrier distance displayed by the transmitter between the emitters and receivers of transducer pair A and B. In case the recommended distance between the measuring barriers displayed by the transmitter cannot be set because of the transducer size, mount the transducer pair B at the smallest possible distance to transducer pair A. Make sure to keep a few millimeters distance between the transducers of measuring barrier A and B. The transducers should not touch.
- Slide the spring clips on the transducers of transducer pair B.
- Fix the transducers by slightly tightening the tensioning screws. The end of the tensioning screw has to be placed above the hole in the respective transducer.
- Correct the distance between the measuring barriers, if necessary. The distance has to be adjusted with an accuracy of 1 mm.


- Tighten the tensioning screws until the collar of the rivet nut is flush with the mounting bracket, see Fig. 6.45.
- Fix the spacing elements on the rail to mark the transducer position.
- Check whether the transducer distance of transducer pair B corresponds to the value displayed by the transmitter.
- Use a cable tie to fix the transducer cables in order to protect them from mechanical strain.
- Put the cover on the rail, see Fig. 6.46.
- Tighten the screws (2) on both sides of the cover, see Fig. 6.46.

Fig. 6.44: Transducers in rail




- 1 – equipotential bonding terminal
- 2 – spring clip
- 3 – spacing element
- 4 – tensioning screw
- 5 – cable tie
- $\Delta x$  – distance between measuring barriers

Fig. 6.45: Spring clip



- 1 – tensioning screw
- 2 – rivet nut
- 3 – mounting bracket

Fig. 6.46: Variofix C with transducers on the pipe




- 1 – screw
- 2 – cover

Remove the cover from the mounted transducer mounting fixture Variofix C as follows:

- Loosen the screws, see Fig. 6.46.
- Use a lever tool to remove the cover.
- Insert the lever tool in one of the 4 openings of the cover, see Fig. 6.47.
- Press the lever tool against the fixture.
- Bend the cover outwards and release it from the anchoring.
- Repeat the steps for the other 3 openings.
- Remove the cover from the rail.

Fig. 6.47: Cover removal




- 1 – lever tool
- 2 – support

### 6.2.2.7 Installation with Wavelnjector

The Wavelnjector is a transducer mounting fixture for the ultrasonic flow measurement at extreme temperatures.

Fig. 6.48: Transducer mounting fixture for Wavelnjector



For the installation of the Wavelnjector, see document SU\_WI-xxx.

## 6.3 Temperature probe

### 6.3.1 Pipe preparation

#### Caution!



#### Contact with grinding dust

This may result in injuries (e.g., breathing difficulties, skin reactions, eye irritations).

- Wear the required personal protective equipment.
- Observe the applicable rules.

#### Important!

The pipe has to be sufficiently stable to withstand the pressure exerted by the temperature probe.

Rust, paint or deposits on the pipe thermally insulate the measuring point. A good thermal contact between the pipe and the temperature probe is obtained as follows:

- Clean the pipe at the selected measuring point.
  - Remove any insulation material, rust or loose paint.
  - If present, the paint layer has to be smoothed by grinding. The paint does not need to be removed completely.
- Use coupling foil or apply a layer of thermal conductivity paste or coupling compound on the contact surface of the temperature probe. Observe the specific ambient temperature.
- Observe that there must be no air pockets between the contact surface of the temperature probe and the pipe wall.

### 6.3.2 Installation of the temperature probe (response time 50 s)

#### Notice!

The temperature probe has to be thermally insulated.

Select the installation instruction of the supplied clasp:

#### 6.3.2.1 Installation with clasp

#### Caution!



#### The edge of the tension strap is very sharp.

Risk of injury!

- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.

- Cut the tension strap to length (pipe circumference + at least 120 mm).
- Make sure that part (2) of the clasp is on top of part (1) (see Fig. 6.49 a). The hooks of part (2) have to be on the outer side of the clasp.
- Pull approx. 20 mm of the tension strap through the slot of the clasp to fix the clasp to the tension strap (see Fig. 6.49 b).
- Bend the end of the tension strap.
- Position the temperature probe on the pipe (see Fig. 6.50).
- Place the tension strap around the temperature probe and the pipe.
- Push the tension strap through part (2) and (1) of the clasp.
- Tighten the tension strap and engage it in the inner hook of the clasp.
- Tighten the screw of the clasp.



Fig. 6.49: Clasp





Fig. 6.50: Temperature probe on the pipe



### 6.3.2.2 Installation with FLEXIM clasp

#### Caution!




**The edge of the tension strap is very sharp.**

Risk of injury!

- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.

- Cut the tension strap to length (pipe circumference + at least 120 mm).
- Insert approx. 20 mm of the tension strap into the slot of the clasp.
- Bend the end of the tension strap.
- Position the temperature probe on the pipe (see Fig. 6.50).
- Place the tension strap around the temperature probe and the pipe.
- Push the tension strap through part (2) and (1) of the clasp.
- Tighten the tension strap and engage it in the inner hook of the clasp.
- Tighten the screw of the clasp.

Fig. 6.51: FLEXIM clasp



### 6.3.2.3 Installation with quick release clasp

#### Caution!



**The edge of the tension strap is very sharp.**

Risk of injury!

- Debur sharp edges.
- Wear the required personal protective equipment.
- Observe the applicable rules.

- Cut the tension strap to length (pipe circumference + at least 120 mm).
- Position the temperature probe on the pipe (see Fig. 6.50).
- Place the tension strap around the temperature probe and the pipe.
- Insert the tension strap into the clasp.
- Tighten the tension strap.
- Tighten the screw of the clasp.

Fig. 6.52: Quick release clasp



## 7 Connection

### Danger!



#### **Risk of explosion when using the measuring equipment in explosive atmospheres**

This may result in personal or material damage or dangerous situations.

→ Observe the "Safety instructions for the use in explosive atmospheres".

### Warning!



#### **Installation, connection and start-up by unauthorized and unqualified personnel**

This may result in personal or material damage or dangerous situations.

→ Any work on the transmitter has to be carried out by authorized and qualified personnel.

### Warning!



#### **Touching live parts**

Electric shock or arc faults can lead to severe injuries. The measuring equipment can be damaged.

→ Prior to any work on the transmitter (e.g., installation, dismantling, connection, start-up), the transmitter has to be disconnected from the power supply.

### Caution!



#### **Safety and accident prevention regulations for electrical systems and equipment**

Failure to observe these regulations may lead to severe injuries.

→ Observe the safety and accident prevention regulations for electrical systems and equipment.


**Transmitter with aluminum housing**

The transmitter has 2 housing. The terminals for the connection of the transducers are in the lower housing, the terminals for the connection of the outputs and of the power supply on the rear side of the upper housing.

**Important!**

Do not open the housings using objects which may damage the thread or housing gasket.

Fig. 7.1: Connections of the transmitter



- 1 – transducers (measuring channel A)
- 2 – transducers (measuring channel B)
- 3 – power supply
- 4 – inputs/outputs
- 5 – equipotential bonding terminal


### Transmitter with stainless steel housing

The transmitter has 1 housing. The terminals for the connection of transducers, outputs and power supply are on the rear side of the housing.

#### Important!

Do not open the housings using objects which may damage the thread or housing gasket.

Fig. 7.2: Connections of the transmitter



- 1 – transducers (measuring channel A)
- 2 – transducers (measuring channel B)
- 3 – power supply
- 4 – inputs/outputs
- 5 – equipotential bonding terminal

## 7.1 Transducers

The transmitter has 2 cable glands for the connection of the transducers. If the transmitter has only one measuring channel, one of the openings is closed with a blind plug.


It is recommended to run the cables from the measuring point to the transmitter before connecting the transducers to avoid load on the connectors.

### Notice!

If transducers are replaced or added, the SENSPROM has to be replaced or added as well.

### Transmitter with aluminum housing

Fig. 7.3: Connection of the transducers to the transmitter




- 1 – transducers (measuring channel A)
- 2 – transducers (measuring channel B)

**Transmitter with stainless steel housing**

- Loosen the 2 screws of the cover for the connection of the transducers.
- Remove the cover.
- When the transducers are connected, put the cover back in place.
- Tighten the screws of the cover.

Fig. 7.4: Connection of the transducers to the transmitter



- 1 – cover for the connection of the transducers
- 2 – screws of the cover for the connection of the transducers
- 3 – transducers (measuring channel A)
- 4 – transducers (measuring channel B)

**7.1.1 Connection of the transducer cable to the transmitter****Important!**

The degree of protection of the transmitter is only ensured if all cables are tightly fitted using cable glands and the housing is firmly screwed.

**7.1.1.1 Transducer cable with plastic jacket and stripped ends**

- Remove the blind plug for the connection of the transducer cable.
- Open the cable gland of the transducer cable. The compression part remains in the cap nut.
- Push the transducer cable through the cap nut and the compression part.
- Prepare the transducer cable.
- Cut the external shield to length and brush it back over the compression part.
- Screw the sealing ring side of the basic part into the transmitter housing.
- Insert the transducer cable into the housing.

**Notice!**

For good electromagnetic compatibility (EMC), it is important to ensure good electrical contact between the external shield and the cap nut (and thus the housing).

- Fix the cable gland by screwing the cap nut onto the basic part.
- Connect the transducer cable to the terminals of the transmitter.

Tab. 7.1: Terminal assignment






terminal	connection
xV	transducer  (core)
xVS	transducer  (internal shield)
xRS	transducer  (internal shield)
xR	transducer  (core)

Fig. 7.5: Connection of the transducer cable with plastic jacket and stripped ends to the transmitter



- 1 – cap nut
- 2 – compression part
- 3 – basic part
- 4 – external shield, brushed back



**7.1.1.2 Transducer cable with stainless steel conduit and stripped ends**

- Remove the blind plug for the connection of the transducer cable.
- Insert the transducer cable into the housing.
- Fix the transducer cable by tightening the cable gland.
- Connect the transducer cable to the terminals of the transmitter.

Tab. 7.2: Terminal assignment






terminal	connection
xV	transducer  (brown cable, marked white)
xVS	transducer  (red cable)
xRS	transducer  (red cable)
xR	transducer  (brown cable)

Fig. 7.6: Connection of the transducer cable with stainless steel conduit and stripped ends to the transmitter



### 7.1.2 Connection of the extension cable to the transmitter

The extension cable is connected to the transmitter via the transducer connection.

- Remove the blind plug for the connection of the transducer cable.
- Open the cable gland of the extension cable. The compression part remains in the cap nut.
- Push the extension cable through the cap nut and the compression part.
- Prepare the extension cable.
- Cut the external shield to length and brush it back over the compression part.
- Screw the sealing ring side of the basic part into the transmitter housing.
- Insert the extension cable into the housing.

#### Notice!


For good electromagnetic compatibility (EMC), it is important to ensure good electrical contact between the external shield and the cap nut (and thus the housing).

- Fix the cable gland by screwing the cap nut onto the basic part.
- Connect the extension cable to the terminals of the transmitter.

Tab. 7.3: Terminal assignment

terminal	connection
xV	white or marked cable (core)
xVS	white or marked cable (internal shield)
xRS	brown cable (internal shield)
xR	brown cable (core)

Fig. 7.7: Connection of the extension cable to the transmitter



- 1 – cap nut
- 2 – compression part
- 3 – basic part
- 4 – external shield, brushed back

### 7.1.3 Connection of the transducer cable to the junction box

#### 7.1.3.1 Transducer cable with plastic jacket and stripped ends

- Remove the blind plug for the connection of the transducer cable.
- Open the cable gland of the transducer cable. The compression part remains in the cap nut.
- Push the transducer cable through the cap nut and the compression part.
- Prepare the transducer cable.
- Shorten the external shield and brush it back over the compression part.
- Screw the gasket ring side of the basic part into the junction box.
- Insert the transducer cable into the junction box.

#### Notice!

For good electromagnetic compatibility (EMC), it is important to ensure good electrical contact between the external shield and the cap nut (and thus the housing).

- Fix the cable gland by screwing the cap nut onto the basic part.
- Connect the transducer cable to the terminals of the junction box.

Tab. 7.4: Terminal assignment






terminal	connection
V	transducer  (core)
VS	transducer  (internal shield)
RS	transducer  (internal shield)
R	transducer  (core)

Fig. 7.8: Connection of the transducer cable with plastic jacket and stripped ends



- 1 – cap nut
- 2 – compression part
- 3 – basic part
- 4 – external shield, brushed back

### 7.1.3.2 Transducer cable with stainless steel conduit and stripped ends

- Remove the blind plug for the connection of the transducer cable.
- Insert the transducer cable into the junction box.
- Fix the transducer cable by tightening the cable gland.
- Connect the transducer cable to the terminals of the junction box.

Tab. 7.5: Terminal assignment






terminal	connection
V	transducer  (brown cable, marked white)
VS	transducer  (red cable)
RS	transducer  (red cable)
R	transducer  (brown cable)

Fig. 7.9: Connection of the transducer cable with stainless steel conduit and stripped ends



1 – cable gland

## 7.1.4 Connection of the extension cable to the junction box

### 7.1.4.1 Connection without potential separation (standard)

The connection of the extension cable to the junction box without potential separation ensures that the transducer, junction box and transmitter are on the same potential. The extension cable should always be connected in this manner, especially if power current cables are nearby. If earthing on the same potential cannot be ensured, see section 7.1.4.2.

- Remove the blind plug for the connection of the extension cable.
- Open the cable gland of the extension cable. The compression part remains in the cap nut.
- Push the extension cable through the cap nut and the compression part.
- Prepare the extension cable.
- Shorten the external shield and brush it back over the compression part.
- Screw the gasket ring side of the basic part into the junction box.
- Insert the extension cable into the junction box.

#### Notice!


For good electromagnetic compatibility (EMC), it is important to ensure good electrical contact between the external shield and the cap nut (and thus the housing).

- Fix the cable gland by screwing the cap nut onto the basic part.
- Connect the extension cable to the terminals of the junction box.

Tab. 7.6: Terminal assignment

terminal	connection (extension cable)
TV	white or marked cable (core)
TVS	white or marked cable (internal shield)
TRS	brown cable (internal shield)
TR	brown cable (core)
cable gland	external shield

Fig. 7.10: Connection of the extension cable to the junction box (without potential separation)



- 1 – extension cable
- 2 – external shield, brushed back
- 3 – cap nut
- 4 – compression part
- 5 – basic part
- 6 – connection of the extension cable
- 7 – connection of the transducer cable

**7.1.4.2 Connection with potential separation**

If earthing on the same potential cannot be ensured, e.g., in measurement arrangements with long extension cables, the extension cable and the junction box have to be electrically insulated from each other. The junction box and the transducers have to be on the same potential. Thus, no compensation currents can flow to the transmitter via the extension cable.

For measurement arrangements where the junction box and the transducers have to be electrically insulated from each other see the document TIFLUXUS\_GalvSep.

- Remove the blind plug for the connection of the extension cable.
- Open the cable gland of the extension cable. The compression part remains in the cap nut.
- Push the extension cable through the cap nut, the compression part and the basic part.
- Insert the extension cable into the junction box.
- Prepare the extension cable.
- Cut the external shield and brush it back.
- Pull the extension cable back until the brushed-back external shield is below the shield terminal. The extension cable has to remain completely insulated up to the shield terminal.
- Screw the gasket ring side of the basic part into the junction box.
- Fix the cable gland by screwing the cap nut onto the basic part.

<b>Important!</b>
Observe the max. permissible voltage of 60 V DC between the earth potentials.


<b>Important!</b>
The external shield of the extension cable must not have electrical contact to the junction box. Therefore, the extension cable has to remain completely insulated up to the shield terminal.

- Fix the extension cable and the external shield to the shield terminal.
- Connect the extension cable to the terminals of the junction box.

Tab. 7.7: Terminal assignment

terminal	connection (extension cable)
TV	white or marked cable (core)
TVS	white or marked cable (internal shield)
TRS	brown cable (internal shield)
TR	brown cable (core)
shield terminal	external shield

Fig. 7.11: Connection of the extension cable to the junction box (with potential separation)



- 1 – extension cable
- 2 – external shield
- 3 – shield terminal
- 4 – cap nut
- 5 – compression part
- 6 – basic part
- 7 – connection of the extension cable
- 8 – connection of the transducer cable



## 7.2 SENSPROM

The SENSPROM contains important transducer data for the operation of the transmitter with the transducers. If transducers are replaced, the SENSPROM has to be replaced as well.


### Notice!

The serial numbers of the SENSPROM and the transducer have to be identical. A wrong or wrongly connected SENSPROM will lead to incorrect measured values or to a measurement failure.

#### Transmitter with aluminum housing

- Disconnect the transmitter from the power supply.
- Open the front side of the upper housing.
- Insert each SENSPROM into its socket.
- Close the housing.
- Make sure that the housing is closed correctly and that the set screws are tightened.
- Connect the transmitter to the power supply.
- Enter all parameters of the menu `Parameters`.
- Start the measurement.

Fig. 7.12: Connection of the SENSPROM




- 1 – SENSPROM of measuring channel A
- 2 – SENSPROM of measuring channel B

### Transmitter with stainless steel housing

- Disconnect the transmitter from the power supply.
- Open the housing (see section 6.1.1.2).
- Insert each SENSPROM into its socket.
- Close the housing.
- Make sure the housing is correctly closed.
- Connect the transmitter to the power supply.
- Enter all parameters of the menu *Parameters*.
- Start the measurement.

Fig. 7.13: Connection of the SENSPROM



- 1 – SENSPROM of measuring channel A
- 2 – SENSPROM of measuring channel B

### 7.3 Power supply

The installation of the power supply is carried out by the operator. The operator has to provide an overcurrent protector of max. 16 A (fuse or similar device) disconnecting all energizing wires in case of an inadmissible high current consumption. The impedance of the protective ground has to be low ohmic in order not to allow touch voltage pass the permissible limit. The equipotential bonding terminal serves as functional ground of the transmitter.


**Important!**

The degree of protection of the transmitter will only be guaranteed if the power cable fits firmly and tightly in the cable gland.

#### Transmitter with aluminum housing

- Connect the power cable to the transmitter (see section 7.3.1, Fig. 7.14 and Tab. 7.8).

Fig. 7.14: Connection of the power supply to the transmitter



- 1 – connection of the power supply
- 2 – equipotential bonding terminal


Tab. 7.8: Terminal assignment

terminal	connection AC	terminal	connection DC
L	outer conductor	(+)	DC
N	neutral conductor	(-)	GND
⊕	protective conductor	⊕	protective conductor

**Transmitter with stainless steel housing**

- Loosen the 2 screws of the cover for the connection of the power supply.
- Remove the cover.
- Connect the power cable to the transmitter, see section 7.3.1, Fig. 7.15 and Tab. 7.9.
- Inset the cover.
- Tighten the screws of the cover.

Fig. 7.15: Connection of the power supply to the transmitter



- 1 – cover for the connection of the power supply
- 2 – cover screws
- 3 – connection of the power supply
- 4 – equipotential bonding terminal

Tab. 7.9: Terminal assignment

terminal	connection AC	terminal	connection DC
L	outer conductor	(+)	DC
N	neutral conductor	(-)	GND
⊕	protective conductor	⊕	protective conductor


### 7.3.1 Cable connection

- Remove the blind plug to connect the cable to the transmitter.
- Prepare the cable with an M20 cable gland.

The used cable has to have a wire cross-section of 0.25...2.5 mm<sup>2</sup>.

- Push the cable through the cap nut, compression part and basic part of the cable gland.
- Insert the cable into the housing of the transmitter.
- Screw the sealing ring side of the basic part into the transmitter housing.
- Fix the cable gland by screwing the cap nut onto the basic part.
- Connect the cable to the terminals of the transmitter.

Fig. 7.16: Cable gland



- 1 – cap nut
- 2 – compression part
- 3 – basic part


### 7.4 Outputs

**Important!**

The max. permissible voltage between the outputs and against PE is 60 V DC (permanent).





- Connect the output cable to the transmitter (see section 7.3.1, Fig. 7.15 and section 7.4.1).

Fig. 7.17: Connection of the outputs to the transmitter







### 7.4.1 Output circuits



Tab. 7.10: Switchable current output Ix

transmitter		external circuit	remark
internal circuit	connection		
active			
	x+  x-		$R_{ext} = 250 \dots 530 \Omega$ $U_{opencircuit} = 28 \text{ V DC}$ adjustable fault current (no valid measured value, no measurement): 3.2...3.99 mA, 20.01...24 mA hardware fault current: 3.2 mA
passive			
	x+  x-		$U_{ext} = 9 \dots 30 \text{ V DC}$ , dependent on $R_{ext}$ ( $R_{ext} < 458 \Omega$ with 20 V) adjustable fault current (no valid measured value, no measurement): 3.2...3.99 mA, 20.01...24 mA hardware fault current: 3.2 mA



Tab. 7.11: Switchable current output Ix/HART

transmitter		external circuit	remark
internal circuit	connection		
active			
	x+  x-		$R_{ext} = 250 \dots 530 \Omega$ $U_{opencircuit} = 28 \text{ V DC}$ adjustable fault current (no valid measured value, no measurement): 3.5...3.99 mA, 20.01...22 mA hardware fault current: 3.2 mA
passive			
	x+  x-		$U_{ext} = 9 \dots 30 \text{ V DC}$ , dependent on $R_{ext}$ ( $R_{ext} = 250 \dots 458 \Omega$ with 20 V) adjustable fault current (no valid measured value, no measurement): 3.5...3.99 mA, 20.01...22 mA hardware fault current: 3.2 mA





Tab. 7.12: Current output Ix, intrinsically safe, passive

transmitter		external circuit	remark
internal circuit	connection		
	<p>x+</p> <p>x-</p>		<p><math>U_i = 29\text{ V}</math>  <math>I_i = 100\text{ mA}</math>  <math>P_i = 0.725\text{ W}</math>  <math>C_i = 1\text{ nF}</math>  <math>L_i = 50\text{ nH}</math>  <math>U_{ext} \leq 29\text{ V DC}</math>, dependent on <math>R_{ext}</math>                      (<math>R_{ext} &lt; 458\ \Omega</math> with 20 V)</p> <p>adjustable fault current (no valid measured value, no measurement):                      3.2...3.99 mA, 20.01...24 mA</p> <p>hardware fault current: 3.2 mA</p>





Tab. 7.13: Current output Ix/HART, intrinsically safe, passive

transmitter		external circuit	remark
internal circuit	connection		
	<p>x+</p> <p>x-</p>		<p><math>U_i = 29\text{ V}</math>  <math>I_i = 100\text{ mA}</math>  <math>P_i = 0.725\text{ W}</math>  <math>C_i = 1\text{ nF}</math>  <math>L_i = 50\text{ nH}</math>  <math>U_{ext} = 9...29\text{ V DC}</math>, dependent on <math>R_{ext}</math>                      (<math>R_{ext} = 250...458\ \Omega</math> with 20 V)</p> <p>adjustable fault current (no valid measured value, no measurement):                      3.5...3.99 mA, 20.01...22 mA</p> <p>hardware fault current: 3.2 mA</p>

Tab. 7.14: Digital output (according to IEC 60947-5-6 (NAMUR))

transmitter		external circuit	remark
internal circuit	connection		
circuit 1			
	x+  x-		$U_{ext} = 8.2 \text{ V}$ $I_{max} = 8 \text{ mA with } 29 \text{ V DC}$ $f = 2...10 \text{ kHz}$ $T_p = 0.05...1000 \text{ ms}$
circuit 2			
	x+  x-		

Tab. 7.15: Digital output, intrinsically safe (according to IEC 60947-5-6 (NAMUR))

transmitter		external circuit	remark
internal circuit	connection		
circuit 1			
	x+  x-		$U_i = 29 \text{ V}$ $I_i = 100 \text{ mA}$ $P_i = 0.725 \text{ W}$ $C_i = 1 \text{ nF}$ $L_i = 50 \text{ nH}$ $U_{ext} = 8.2 \text{ V}$ $I_{max} = 8 \text{ mA with } 29 \text{ V DC}$ $f = 2...10 \text{ kHz}$ $T_p = 0.05...1000 \text{ ms}$
circuit 2			
	x+  x-		


For all circuits apply:

- $R_{ext}$  is the sum of all ohmic resistances in the circuit (e.g., resistance of the conductors, resistance of the ammeter/voltmeter).
- The number, type and connections of the outputs depend on the order.
- The terminal assignment is displayed on the transmitter during configuration of the outputs.



## 7.5 Inputs

Fig. 7.18: Connection of the inputs to the transmitter







### 7.5.1 Circuits of the inputs

#### Important!



Observe the correct polarity in order to avoid damaging the current source. A permanent short circuit can destroy the current input.

For the connection of the input cable to the transmitter, see section 7.3.1 and Fig. 7.18.

Tab. 7.16: Switchable current input I<sub>x</sub>

transmitter		external circuit	remark
internal circuit	connection		
active			
	x+  x-		$R_{int} = 75 \Omega$ $I_{max} \leq 30 \text{ mA}$ $I = 0 \dots 20 \text{ mA}$ (measuring range) $U_{opencircuit} = 28 \text{ V}$ $U_{min} = 21.4 \text{ V}$ with 20 mA The current input is galvanically isolated from the transmitter.
passive			
	x-  x+		$R_{int} = 35 \Omega$ $U_{max} = 24 \text{ V}$ $I_{max} \leq 24 \text{ mA}$ $I = 0 \dots 20 \text{ mA}$ (measuring range) The current input is galvanically isolated from the transmitter.

Tab. 7.17: Current input I<sub>x</sub>, intrinsically safe, active

transmitter		external circuit	remark
internal circuit	connection		
	x+  x-		$U_o = 29.2 \text{ V}$ $I_o = 88 \text{ mA}$ $P_o = 0.64 \text{ W}$ $L_o = 4.1 \text{ mH}$ $C_o = 73 \text{ nF}$ $R_{int} \leq 385 \Omega$ $U_{int} < 20 \text{ V}$ $I_{max} \leq 40 \text{ mA}$ $U_{min} = 19.6 \text{ V} - (R_{int} \cdot I)$ $I = 0 \dots 20 \text{ mA}$ (measuring range) The current input is not galvanically isolated from the transmitter.


For all circuits apply:

- The number, type and connections of the inputs depend on the order.
- The terminal assignment is displayed on the transmitter during the configuration of the inputs.

### 7.6 Temperature probe

It is possible to connect the temperature probes Pt100/Pt1000 (4-wire) to the inputs of the transmitter (optional).

Fig. 7.19: Connection of the temperature probes to the transmitter





1 – temperature probe

#### 7.6.1 Circuit of the temperature inputs

Tab. 7.18: Temperature input – not intrinsically safe

transmitter		external circuit	explanation
internal circuit	connection		
	<p>6</p> <p>4</p> <p>3</p> <p>5</p>		<p>Pt100/Pt1000 (4-wire)</p> <p>The input is galvanically isolated from the transmitter.</p>


Tab. 7.19: Temperature input – intrinsically safe

transmitter		external circuit	remark
internal circuit	connection		
	6 4  3 5		$U_o = 9.2\text{ V}$ $I_o = 25\text{ mA}$ $P_o = 0.057\text{ W}$ $L_o = 57\text{ mH}$ $C_o = 4283\text{ nF}$ Pt100/Pt1000 (4-wire)

### 7.6.2 Direct connection of the temperature probe

- Remove the blind plug for the connection of the temperature probe.
- Open the cable gland of the temperature probe. The compression part remains in the cap nut.
- Push the cable of the temperature probe through the cap nut, the compression part, the basic part and the reducer.
- Prepare the cable.
- Insert the cable into the housing.
- Screw the sealing ring side of the reducer into the transmitter housing.
- Screw the basic part into the reducer.
- Fix the cable gland by screwing the cap nut onto the basic part.
- Connect the temperature probe to the terminals of the transmitter.

Fig. 7.20: Preparation of the temperature probe



- 1 – cap nut
- 2 – compression part
- 3 – basic part
- 4 – reducer
- 5 – sealing ring side


## 7.7 Service interface

### 7.7.1 USB interface

The transmitter can be connected directly to the PC via the USB interface. The USB interface may only be connected outside the explosive atmosphere (open housing).

- Connect the USB cable to the USB interface of the transmitter and to the PC.

Fig. 7.21: Connection of the USB cable



1 – USB interface

## 8 Start-up

### Danger!



#### Risk of explosion when using the measuring equipment in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ Observe the "Safety instructions for the use in explosive atmospheres".

### Warning!



#### Installation, connection and start-up by unauthorized and unqualified personnel

This may result in personal or material damage or dangerous situations.

→ Any work on the transmitter has to be carried out by authorized and qualified personnel.

### Warning!



#### Touching live parts

Electric shock or arc faults can lead to severe injuries. The measuring equipment can be damaged.

→ Prior to any work on the transmitter (e.g., installation, dismantling, connection, start-up), the transmitter has to be disconnected from the power supply.

### Caution!



#### Safety and accident prevention regulations for electrical systems and equipment

Failure to observe these regulations may lead to severe injuries.

→ Observe the safety and accident prevention regulations for electrical systems and equipment.

### Caution!



#### Warning of severe injuries from hot or cold components

Touching hot or cold components can lead to severe injuries (e.g., thermal damage).

- Any mounting, installation or connection work has to be concluded.
- Any work on the measuring point during the measurement is prohibited.
- Observe the ambient conditions at the measuring point during installation.
- Wear the required personal protective equipment.
- Observe the applicable rules.

### Notice!

The transmitter and transducers have to be checked to ensure proper condition and operational safety before each use. The transmitter housing must always be closed during operation. Observe that maintenance work must be concluded.

## 8.1 Start-up settings

When starting up the transmitter for the first time, the following settings are required:

- language
- time/date
- system of units

These displays will only be indicated when the transmitter is switched on for the first time or after an initialization.

### Language

The available transmitter languages are displayed.

- Select a language.
- Press ENTER.

The menus are displayed in the selected language.

### Set time

The current time is displayed.

- Press ENTER to confirm the time or set the current time via the numeric field.
- Press ENTER.

### Set date

The current date is displayed.

- Press ENTER to confirm the date or set the current date via the numeric field.
- Press ENTER.

### Units of measurement

- Select `Metric` or `Imperial`.
- Press ENTER.

### Region of Canada

- Select `Yes` if the transmitter is to be used in the region of Canada.
- Press ENTER.

This display will only be indicated if `Imperial` is selected.

## 8.2 Switching on

As soon as the transmitter is connected to the power supply, the menu is displayed in the adjusted language. The language can be changed.

### Notice!

The parameters cannot be changed during the measurement. The measurement has to be stopped in order to change the parameters.

If the transmitter was switched off during the measurement, the message `Measurement started` will be displayed after connecting the transmitter to the power supply. The measurement continues with the parameters set last.

By pressing BRK in the menu `Measurement` it is possible either to stop the measurement or to display the current parameter settings.

### Operation state indication

The operation state is indicated by LEDs above the display.

Tab. 8.1: Operation state of the transmitter

LED off	transmitter in idle state
LED lights green	signal quality of the measuring channel sufficient for a measurement
LED lights red	signal quality of the measuring channel not sufficient for a measurement

## 8.3 Language

Miscellaneous\System settings\Language

The language of the transmitter can be selected:

- Select the menu item `Language`.
- Press ENTER.
- Select the desired language from the scroll list.
- Press ENTER.

Afterwards the menu will be displayed in the selected language. The selected language remains activated when the transmitter is switched off and on again.

The language can also be changed by entering a HotCode.

### 8.4 Initialization

During an initialization (INIT) of the transmitter, all settings are reset to factory default. The initialization is started with the HotCode **909000**.

During an initialization it is tested whether the key lock is activated. If so, it has to be deactivated.

- Enter the 6-digit key lock code. For the input of numbers see section 4.4.
- Press ENTER.

If a measurement is running, it will be stopped.

It will be asked whether the initial settings are to be carried out.

Initial settings

If `Yes` is selected, the following setting dialogs will be displayed:

- `Language`
- `Date/time`
- `Units of measurement`
- `Delete meas. values`
- `Delete snaps`
- `Delete user subst.` (all customized materials and fluids which were stored after delivery will be deleted)
- `Reset totalizers`

The initialization can also be started with the HotCode **909000**.



## 8.5 Date and time

Miscellaneous\System settings>Date/time

The transmitter has a battery-powered clock. Measured values are automatically stored with date and time.

- Select the menu item `Date/time`.

The adjusted time is displayed.


- Enter the current time. For the input of numbers, see section 4.4.
- Press ENTER.

The adjusted date is displayed.

- Enter the current date. For the input of numbers, see section 4.4.
- Press ENTER.

## 8.6 Information regarding the transmitter

Miscellaneous\System settings\Transmitter info

- Select the menu item `Transmitter info`.
- Press ENTER.
- Press  to scroll through the list.
- Press BRK to return to the menu item `System settings`.

The following information relating to the transmitter is displayed:

display	description
Serial number	serial number of the transmitter
Firmware version	version number of the installed firmware
Firmware date	creation date of the installed firmware
Verification log	state of the verification logger

## 9 Measurement

### Danger!



#### Risk of explosion when using the measuring equipment in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ Observe the "Safety instructions for the use in explosive atmospheres".

### Caution!



#### Warning of severe injuries from hot or cold components

Touching hot or cold components can lead to severe injuries (e.g., thermal damage).

→ Any mounting, installation or connection work has to be concluded.

→ Any work on the measuring point during the measurement is prohibited.

→ Observe the ambient conditions at the measuring point during installation.


→ Wear the required personal protective equipment.

→ Observe the applicable rules.

## 9.1 Parameter input

### Notice!

Avoid a simultaneous parameter entry via the keyboard and the USB or process interface. The parameter records received via these interfaces will overwrite the current transmitter parametrization.



see annex A

The pipe and fluid parameters are entered for the selected measuring point. The parameter ranges are limited by the technical characteristics of the transducers and the transmitter.

- Select the menu `Parameters`.
- Press `ENTER`.

### 9.1.1 Input of the measuring point number

Parameters\Measuring point no.

- Enter the number of the measuring point.
- Press ENTER.

For the activation of text input see Miscellaneous\Dialogs/Menus\Measuring point no.

### 9.1.2 Transducer selection

#### Notice!

The transducers have to be selected depending on the application parameters (see technical specification).

Parameters\Connected transd.

- The transducer connected to the transmitter is displayed.
- Press ENTER.

The display will only be indicated if a SENSPROM is connected to the transmitter.

The display `Transducer not found` will be indicated if neither transducers nor SENSPROM are connected.

- Press ENTER.

Parameters>Select transducer

The following display appears: `Select transducer`. Standard sensors that are stored in the transmitter can be selected.

- Select the transducer.
- Press ENTER.

### 9.1.3 Input of pipe parameters

#### Outer pipe diameter

Parameters\Outer diameter

- Enter the outer pipe diameter.
- Press ENTER.

It is possible to enter the pipe circumference instead of the outer pipe diameter.

#### Pipe circumference

Parameters\Pipe circumference

- Activate the input of the pipe circumference in the menu item Miscellaneous\Dialogs/Menus\Pipe circumference.
- Enter zero in the menu item `Outer diameter`. The menu item `Pipe circumference` will be displayed.
- Enter the pipe circumference.
- Press ENTER.

If the outer pipe diameter is to be entered, enter zero. The menu item `Outer diameter` will be displayed.

## Pipe material

Parameters\Pipe material

The pipe material has to be selected to be able to determine the corresponding sound speed.  
The sound speeds for the materials in the scroll list are stored in the transmitter.

- Select the pipe material.
- If the material is not in the scroll list, select the list item `Other material`.
- Press ENTER.

### Sound speed of the pipe material

Parameters\Pipe material\Other material\c material

- Enter the sound speed of the pipe material.

#### Notice!

There are 2 sound speeds for pipe materials: the longitudinal and the transversal one. Enter the sound speed which is nearer to 2500 m/s.

- Press ENTER.
- Select `Transverse wave` or `Longitudinal wave`.
- Press ENTER.

These displays will only be indicated if `Other material` is selected.  
For the sound speed of some materials see annex C.

### Roughness of the pipe material

Parameters\Pipe material\Other material\Roughness

The flow profile of the fluid is influenced by the roughness of the inner pipe wall.  
The roughness is used for the calculation of the profile correction factor.  
In most cases, the pipe roughness cannot be exactly determined and must therefore be estimated.

- Press ENTER if the pipe has a lining. The roughness of the lining is included into the calculation.
- Enter the roughness of the pipe material in case the pipe has no lining. Press ENTER.

This display will only be indicated if `Other material` is selected.  
For the roughness of some materials see annex C.

### Wall thickness

Parameters\Pipe wall thickness

- Enter the pipe wall thickness.
- Press ENTER.

### Lining

Parameters\Lining

- Select `Yes` if the pipe has a lining. Select `No` if the pipe has no lining.
- Press ENTER.

## Lining material

Parameters\Lining material

- Select the lining material.
- Press ENTER.
- If the lining material is not included in the scroll list, select the list item `Other material`.
- Press ENTER.

This display will only be indicated if `Yes` is selected in the menu item `Lining`.

## Sound speed of the lining material

Parameters\Lining material\Other material\c material

- Enter the sound speed of the lining material.

### Notice!

For pipe materials there are 2 sound speeds, the longitudinal and the transversal one. Enter the sound speed which is nearer to 2500 m/s.

- Press ENTER.
- Select `Transverse wave` or `Longitudinal wave`.
- Press ENTER.

These displays will only be indicated if `Other material` is selected.

## Roughness of the lining material

Parameters\Lining material\Other material\Roughness

The flow profile of the fluid is influenced by the roughness of the inner pipe wall.

The roughness is used for the calculation of the profile correction factor.

In most cases, the pipe roughness cannot be exactly determined and must therefore be estimated.

- Enter the roughness of the lining material.
- Press ENTER.

This display will only be indicated if `Other material` is selected.

## Lining thickness

Parameters\Lining thickness

- Enter the thickness of the lining.
- Press ENTER.

This display will only be indicated if `Yes` is selected in the menu item `Lining`.

## Roughness

Parameters\Roughness

The flow profile of the fluid is influenced by the roughness of the inner pipe wall.

The roughness is used for the calculation of the profile correction factor.

In most cases, the pipe roughness cannot be exactly determined and must therefore be estimated.

- If `Automatic` is selected, the roughness values stored in the transmitter are used.
- If `Customized` is selected, a roughness value has to be entered.
- Press ENTER.

This display will not be indicated if `Other material` is selected in the menu item `Pipe material` or `Lining material`.

## 9.1.4 Measurement settings

### Selection of the physical quantity

```
Parameters\Physical quantity
```

The available physical quantities are displayed in a list.

- Select the physical quantity.
- Press ENTER.

### Selection of the unit of measurement

```
Parameters\Physical quantity\Flow velocity
```

For the selected physical quantity, a scroll list with the available units of measurement is displayed.

- Select the unit of measurement of the physical quantity.
- Press ENTER.

#### Notice!

If the physical quantity or the unit of measurement is changed, the settings of the outputs have to be checked.

## 9.1.5 Further parameters

### Fluid temperature

```
Parameters\Fluid temp.
```

The fluid temperature is used:

- at the beginning of the measurement for the interpolation of the sound speed and therefore for the calculation of the recommended transducer distance
- during the measurement for the interpolation of the density and the viscosity of the fluid

This value is only used, if the fluid temperature is not measured. The value has to be within the ambient temperature of the transducers.

- Enter the fluid temperature. In case of a temperature range, enter the average fluid temperature.

#### Notice!

If the relation between the sound speed and the temperature is not linear, see the sound speed-temperature curve.

- Press ENTER.

### Fluid pressure

```
Parameters\Fluid pressure
```

The fluid pressure is used for the interpolation of the sound speed and the gas compressibility coefficient.

- Enter the fluid pressure.
- Press ENTER.

**Extension cable**

Parameters\Extension cable

In case the transducer cable is extended (e.g., between junction box and transmitter), enter the length of the extension cable.

- Enter the length of the extension cable.
- Press ENTER.

**Input of the damping factor**

Parameters\Damping

Each displayed measured value is a floating average of the last x seconds, with x being the damping factor. If 0 s is entered as damping factor, no average is calculated.

The value of 10 s is appropriate for normal flow conditions. If the values fluctuate strongly, caused by a higher dynamic flow, a higher damping factor can be very useful.

- Enter the damping factor.
- Press ENTER.

**Dynamic damping**

If dynamic damping is activated, volatile changes in the measured values of the selected physical quantity are transmitted through the transmitter without any time lag.

**Important!**

The dynamic damping will only have impact on the selected physical quantity. All other physical quantities are not dynamically damped.

Parameters\Dynamic damping

- Select On to activate the dynamic damping.
- Press ENTER.

This display will only be indicated if dynamic damping has been activated in the menu item Miscellaneous\Measurement\Measurement settings\Dynamic damping.

Parameters\...\Dynamic threshold

- Enter the value for the dynamic threshold. If zero is entered, dynamic damping will be deactivated.
- Press ENTER.

Parameters\...\Transient damping

- Enter the damping factor for the temporary damping.
- Press ENTER.

**Notice!**

If another physical quantity is selected, the dynamic damping has to be entered again.

### Input of the error delay

Parameters\Error delay

The error delay is the time interval after which the error value is transmitted to the output.

This display will only be indicated if the list item `Edit` is selected in the menu item `Miscellaneous\Dialogs/Menus/Error delay`.

If no error delay is entered, the damping factor will be used.


- Enter a value for the error delay.
- Press ENTER.

## 9.2 Configuration of an output

If a current output has to be operated according to NAMUR NE43, this function has to be enabled.

Outputs\Current output modes\NAMUR NE43

- Select the list item `Current output modes` in the menu item `Outputs`.
- Press ENTER until the menu item `NAMUR NE43` is displayed.
- Select `Yes` to enable NAMUR NE43.
- Press ENTER.



If the transmitter is equipped with outputs, they have to be configured. The measured value, the status value or an event value can be transmitted via the different outputs.

In the following the configuration of the current output is described.

- Select the menu `Outputs`.
- Press ENTER.

The scroll list contains all available outputs of the transmitter.

Outputs\Current I1(-)

- Select an output (here: `Current I1 (-)`).
- Press ENTER.

If the output has already been enabled, it is displayed as follows: `I1 (✓)`.

Outputs\Current I1\I1 Enable

- Select `Yes` to change the settings for an already enabled output.
- Select `No` to cancel the assignment and to return to the previous menu item.
- Press ENTER.

### Assignment of a source item

A source item has to be assigned to each selected output.

Outputs\...\Source item

- Select a source item whose measured value, status value or event value is to be transmitted to the output.
- Press ENTER.



Tab. 9.1: Configuration of the outputs


source item	list item	output
Flow quantities	Flow velocity	flow velocity
	Operation vol. flow	operating volumetric flow rate
	Mass flow rate	mass flow rate
Totalizers	Volume (+)	totalizer for the volumetric flow rate in positive flow direction
	Volume (-)	totalizer for the volumetric flow rate in negative flow direction
	Volume ( $\Delta$ )	difference of the totalizers for the positive and negative flow direction
	Mass (+)	totalizer for the mass flow rate in positive flow direction
	Mass (-)	totalizer for the mass flow rate in negative flow direction
	Mass ( $\Delta$ )	difference of the totalizers for the positive and negative flow direction
Fluid properties	Fluid temp.	fluid temperature
	Fluid pressure	fluid pressure
	Fluid density	fluid density
	Kin. viscosity	kinematic viscosity
	Dyn. viscosity	dynamic viscosity
	Compress. coeff.	gas compressibility coefficient
Event trigger	R1	limit message (Event trigger R1)
	R2	limit message (Event trigger R2)
	R3	limit message (Event trigger R3)
	R4	limit message (Event trigger R4)
Diagnostic values	Crest factor	signal-to-noise ratio for the cross correlation function
	Transducer temp.	transducer temperature
Miscellaneous	Custom. Input 1	measured values of input quantities (e.g., temperature, density) which are not used for calculation  In the menu item Inputs\Assign inputs it is possible to assign configured inputs to customized inputs.
	Custom. Input 2	
	Custom. Input 3	
	Custom. Input 4	

Depending on the selected source item, it is possible to output measured values, status values or event values.

Tab. 9.2: Output of measured values, status values or event values

	source item	measured value		event value
		value	status	
physical quantities	Flow quantities	x	x	
	Totalizers	x	x	
	Fluid properties	x	x	
	Miscellaneous	x	x	
	Diagnostic values (except Pig detection)	x		
events	Diagnostic values\ Pig detection			x
	Event trigger			x

### 9.2.1 Output of a measured value



- Select the list item `Outputs\...\Values`.
- Press ENTER.

#### Output range

`Outputs\...\Output range`

- Select a list item.
  - 4...20 mA
  - Other range

- Press ENTER.

If `Other range` is selected, enter the values `Output MIN` and `Output MAX`.

The output range has to be > 10 % of the max. output value (`Output MAX`). If the output range is smaller, an error message will be displayed.

If the function `NAMUR NE43` is activated in the menu item `Outputs\Current output modes`, only the output range 4...20 mA applies.

#### Error output

`Outputs\...\Error value`


An error value can be defined which is output if the source item cannot be measured.

- Select a list item for the error output.
- Press ENTER.
- If `Other value` is selected or the function `NAMUR NE43` is activated, enter an error value. The value has to be outside the output range. If the entered value is not valid, an error message and the permissible range will be displayed.
- Press ENTER.

**Example**

source item: volumetric flow rate  
 output: current output  
 output range: 4...20 mA  
 error delay:  $t_d > 0$

The volumetric flow rate cannot be measured during the time interval  $t_0...t_1$ . The error value will be output.



Tab. 9.3: Examples for the error output (output range: 4...20 mA)

list item	output signal
4.0 mA	
Last value	
20.0 mA	
Other value error value = 3.5 mA	

### Measuring range

The sign of the measured value and the measuring range are determined.

```
Outputs\...\Measured values\Absolute value
```

- Select `Sign` if the sign of the measured values is to be considered for the output.
- Select `Absolute value` if the sign of the measured values is not to be considered for the output.

```
Outputs\...\Start of meas. range
```

- Enter the lowest expected measured value. The unit of measurement of the source item will be displayed.
- `Start of meas. range` is the value assigned to the value `Output MIN` of the output range.

```
Outputs\...\End of meas. range
```

- Enter the highest expected measured value. The unit of measurement of the source item will be displayed.
- `End of meas. range` is the value assigned to the value `Output MAX` of the output range.

### Terminal assignment

```
Outputs\...\Output info
```

The terminals for the connection of the output are displayed.

By pressing  or  further information is displayed.

- Press ENTER.

### Output function test

The function of the output can now be tested.

- Connect an external measuring instrument to the terminals of the installed output.

```
Outputs\...\Test signal
```

- Select `Yes` to test the output. Select `No` to display the next menu item.
- Press ENTER.

```
Outputs\...\Enter test value
```

- Enter a test value. It has to be within the output range.
- Press ENTER.

If the external measuring instrument displays the entered value, the output functions correctly.

- Select `Repeat` to repeat the test or `Finish` to display the next menu item.
- Press ENTER.

```
Outputs\...\Test measuring range
```

- Select `Yes` to test the assignment of the measured value to the output signal. Select `No` to display the next menu item.
- Press ENTER.


Outputs\...\Enter test value

- Select **Active** or **Passive** from the scroll list.
- Press **ENTER**.

If the external measuring instrument displays the value (min. output value for **Passive**, max. output value for **Active**), the output functions correctly.

- Select **Repeat** to repeat the test. Select **Finish** to display the next menu item.
- Press **ENTER**.

### 9.2.2 Output of a status/event value



- Select the list item **Outputs\...\Status**.
- Press **ENTER**.

#### Output range

Outputs\...\Output range

- Select a list item.
  - 4...20 mA
  - Other range
- Press **ENTER**.

If **Other range** is selected, enter the values **Output MIN** and **Output MAX**.

The output range has to be > 10 % of the max. output value (**Output MAX**). If the output range is smaller, an error message will be displayed. The next possible value will be displayed.

status value – status OK	event value – idle state
The status of the output signal is defined which is to be output when measuring a measured value.	The status of the output signal is defined which is to be output if no event occurs.
<ul style="list-style-type: none"> <li>• Select the value for status OK from the scroll list.</li> <li>• Press <b>ENTER</b>.</li> </ul>	<ul style="list-style-type: none"> <li>• Select the value for the idle state.</li> <li>• Press <b>ENTER</b>.</li> </ul>

#### Terminal assignment

Outputs\...\Output info

The terminals for the connection of the output are displayed.

By pressing  or  further information is displayed.

- Press **ENTER**.

### Output function test

The function of the output can now be tested.

- Connect an external measuring instrument to the terminals of the installed output.

```
Outputs\...\Test signal
```

- Select `Yes` to test the output. Select `No` to display the next menu item.
- Press `ENTER`.

```
Outputs\...\Enter test value
```

- Enter a test value. It has to be within the output range.
- Press `ENTER`.

If the external measuring instrument displays the entered value, the output functions correctly.

- Select `Repeat` to repeat the test or `Finish` to display the next menu item.
- Press `ENTER`.

```
Outputs\...\Test measuring range
```

- Select `Yes` to test the status of the output signal. Select `No` to display the next menu item.
- Press `ENTER`.


```
Outputs\...\Enter test value
```

- Select a list item as test value.
- Press `ENTER`.

status value	event value
<code>Status OK</code> or <code>Status error</code> If the external measuring instrument displays the value (min. output value for <code>Status error</code> , max. output value for <code>Status OK</code> ), the output functions correctly.	<code>Active</code> or <code>Passive</code> If the external measuring instrument displays the value (min. output value for <code>Passive</code> , max. output value for <code>Active</code> ), the output functions correctly.

- Select `Repeat` to repeat the test. Select `Finish` to display the next menu item.
- Press `ENTER`.

### 9.2.3 Operating mode for current outputs



If the transmitter has current outputs that can be operated actively or passively, it must be specified in which operating mode the current outputs are to operate.


- Select the list item `Outputs` in the menu `Current output modes`.
- Press ENTER.

```
Outputs\Current output modes
```

- Select `Active` or `Passive` to operate the current outputs in the corresponding mode.
- Press ENTER.

The selected setting always applies to all available current outputs.

## 9.3 Start of measurement



Before starting the measurement, the measuring point has to be parameterized. If another measurement has already been performed using the same measuring point parameters, the measurement can be started immediately.

- Select the menu `Start measurement`.
- Press ENTER.

The measurement is started. The measured values are displayed.

In case parameters or the measurement arrangement have changed, the measurement has to be started via the menu `Installation`.

- Select the menu `Installation`.
- Press ENTER.

### 9.3.1 Parameter input for the measuring point

#### Input of the max. flow

```
Installation\...\Expected max. flow
```

The expected max. flow is needed to calculate the recommended distance between the measuring barriers.

- Enter the expected max. flow.
- Press ENTER.

### Adjustment of the transducer distance for transducer pair A

Installation\...\Transducer distance

The recommended transducer distance for transducer pair A will be displayed. The transducer distance is measured between the inner edges of the transducers. On very small pipes, a negative transducer distance is possible.

#### Notice!

The accuracy of the recommended transducer distance depends on the accuracy of the entered pipe and fluid parameters.

- Mount the transducers of transducer pair A on the pipe and adjust the transducer distance.
- Press ENTER.

### Adjustment of the distance between the measuring barriers

Installation\...\Barrier distance

The recommended distance between measuring barriers will be displayed. The measuring barrier distance is the distance between the transducers of the transducer pairs A and B.

- Mount the transducers of transducer pair B on the pipe. Position the transducers according to the displayed distance between the measuring barriers. The distance has to be adjusted with an accuracy of 1 mm. In case the recommended distance between the measuring barriers displayed by the transmitter cannot be set because of the transducer size, mount the transducer pair B at the smallest possible distance to transducer pair A. Make sure to keep a few millimeters distance between the transducers of measuring barrier A and B. The transducers should not touch.
- Enter the distance between the measuring barriers.
- Press ENTER.

### Check of the transducer distance for transducer pair B

Installation\...\Transducer distance


The recommended transducer distance for transducer pair B will be displayed.

- Check whether the transducer distance of transducer pair B corresponds to the value displayed by the transmitter. The transducer distances of transducer pair A and B have to be equal.
- Correct the transducer distance, if necessary.
- Press ENTER.

### Parameter search

Before starting the measurement, the transmitter performs a parameter search. This process takes about 10 minutes. The remaining time is displayed.

Fig. 9.1: Parameter search



After completion of the parameter search, the measurement is started. The measured values are displayed.




## 9.4 Display during the measurement

### 9.4.1 Measured value

The measured values are displayed during the measurement as follows:

Fig. 9.2: Display of measured values



- 1 – menu, status indications
- 2 – display toggling between physical quantity and fluid
- 3 – measured value
- 4 – further physical quantity
- 5 – further physical quantity

By pressing or , additional physical quantities can be displayed during the measurement.

- Press to display the measured values in line 5. The designation of the physical quantity is displayed in line 4 by pressing for several seconds.
- Press to display the measured values in line 4. The designation of the physical quantity is displayed in line 5 by pressing for several seconds.

### 9.4.2 Diagnostic values

By pressing ENTER, the following diagnostic values can be displayed during the measurement:

Tab. 9.4: Diagnostic values

display	description
CrestFactor	signal-to-noise ratio for the cross correlation function, reliability measure of the signal evaluation The measured value is valid if the crest factor is higher than the defined threshold value (default: crest factor > 6).
PeakWidth	width of the correlation peak For a reliable signal evaluation, the peak width has to be between 3 and 30.
GainSymm	quality measure of the measuring setup 0 dB: raw signals of A and B are equal ±100 dB: raw signals differ considerably The value should be around 0 dB. Significant deviations can indicate problems regarding the transducer coupling or pipe wall signals.

### 9.4.3 Parameter

#### Transducer temperature

In the `SuperUser` and `SuperUser ext.` modes it is possible to display the transducer temperature during the measurement.



By pressing  during the measurement, it is possible to scroll to the transducer temperature display.

Fig. 9.3: Display of the transducer temperature



#### Notice!

If the compliance of the specified transducer temperature has to be monitored, an event trigger can be set on the temperature value.


#### Parameter settings

The parameter settings can be displayed during the measurement.


- Press BRK during the measurement.

The transmitter returns to the main menu.

Fig. 9.4: Display of the main menu during the measurement



1 – status indication

The measurement is running in the background. The symbol  is displayed in the status indication.

- Press  or CLR to select the corresponding menu to display the parameters.

#### Notice!

The parameters cannot be changed during the measurement. When attempting to change the parameters, the message `Read-only mode` will be displayed.

The measurement has to be stopped in order to change the parameters.

### Information regarding the data logger

Information regarding the data logger can be displayed during the measurement.


- Press  until the following is displayed:

Fig. 9.5: Information regarding the data logger

Measurement	←→
Volumetric flow rate	
m <sup>3</sup> /h	<b>3.69</b>
Log←→: 6d 21h 9m	
Capacity (time)	

If the ringbuffer is deactivated, line 4 indicates when the data logger will be full in case all settings are kept.

If the ringbuffer is activated, line 4 indicates how long measurement data can still be stored without losing older measurement data.

The information regarding the data logger can also be displayed using the function `Show parameters`.

```
Storage\Data logger\Data logger info
```

- Press BRK during the measurement.
- Select the list item `Data logger\Data logger info` in the menu `Storage`.
- Press ENTER.

The information regarding the data logger are displayed.

#### 9.4.4 Change to the display of measured values

- Press and hold BRK to return to the main menu.
- Select the menu `Show measurement`.
- Press ENTER.

The measured values are displayed.

### 9.5 Execution of special functions

During a measurement, the keyboard can be used to carry out special functions.

Tab. 9.5: Special functions

key	function
BRK	display of scroll list in the menu item <code>Measurement</code>
ENTER	display of the diagnostic window
CLR	display of the menu item <code>Execute command</code>

- Press and hold CLR until the menu item `Execute command` is displayed.

### Totalizers

Measurement\Execute command\Totalizers

- Select the list item Totalizers.
- Press ENTER.

The following scroll list appears:

display	description
Reset totalizers	reset the totalizer to zero
Freeze display	display the measured value of the totalizer for several seconds
Reset error	reset the totalizer error
Stop/clear totalizers	stop totalizer and reset it to zero
Start totalizers	start totalizer

### Taking a snap

Measurement\Execute command\Take a snap

- Select the list item Take a snap.
- Press ENTER.

A snap is taken.

### Reset the event trigger to idle state


Measurement\Execute command\Clear alarms

- Select the list item Clear alarms.
- Press ENTER.

This display will only be indicated if an event trigger has been parameterized and at least one event trigger has also been triggered.

## 9.6 Stop of measurement

- Press and hold BRK to return to the main menu.
- Select the menu Stop measurement.



- Press ENTER.
- Select Yes to stop the measurement.
- Press ENTER.

The measurement is stopped. The main menu will be displayed.

## 10 Troubleshooting

### Danger!



#### Risk of explosion when using the measuring equipment in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ Observe the "Safety instructions for the use in explosive atmospheres".

### Warning!



#### Service works by unauthorized and unqualified personnel

This may result in personal or material damage or dangerous situations.

→ Any work on the transmitter has to be carried out by authorized and qualified personnel.

### Caution!



#### Safety and accident prevention regulations for electrical systems and equipment

Failure to observe these regulations may lead to severe injuries.

→ Observe the safety and accident prevention regulations for electrical systems and equipment.

### Warning!



#### Touching live parts

Electric shock or arc faults can lead to severe injuries. The measuring equipment can be damaged.

→ Prior to any work on the transmitter (e.g., installation, dismantling, connection, start-up), the transmitter has to be disconnected from the power supply.

### Caution!



#### Touching hot or cold surfaces

This may result in injuries (e.g., thermal damages).

→ Observe the ambient conditions at the measuring point during installation.

→ Wear the required personal protective equipment.

→ Observe the applicable rules.

If any problem appears which cannot be solved with the help of this operating instruction, contact our sales office and give a precise description of the problem. Specify the type, the serial number and the firmware version of the transmitter.

#### The display does not work at all or fails regularly.

- Check the contrast setting of the transmitter or enter the HotCode **555000** to set the display to medium contrast.
- Make sure that the correct voltage is available at the terminals. The destined transmitter voltage is indicated on the nameplate below the outer right terminal strip.
- If the power supply is OK, the transducers or an internal component of the transmitter are defective. The transducers and the transmitter have to be sent to FLEXIM for repair.

**An error is displayed in the status indication (symbol ).**

- Press BRK to return to the main menu.
- Select the menu item `Storage\Event log`.
- Press ENTER.

The error message list will be displayed.

**Date and time are wrong, the measured values are deleted when the transmitter is switched off.**

- If the date and the time are reset or wrong or the measured values are deleted after the transmitter has been switched off and on again, the data backup battery has to be replaced. Send the transmitter to FLEXIM.

**An output does not work.**

- Make sure that the outputs are configured correctly. Check the function of the output. If the output is defective, contact FLEXIM.

## 10.1 Problems with the measurement

**The measuring signal is received but no measured values can be obtained.**

- If the defined upper limit of the flow velocity is exceeded or the lower limit is below, `UNDEF` and after the physical quantity an exclamation point will be displayed. The measured values are marked as invalid. The limit has to be adapted to the measuring conditions.
- If no exclamation point is displayed, a measurement at the selected measuring point is impossible.

**The signal is lost during the measurement.**

- If the pipe was without any pressure and afterwards no measuring signal has been received, contact FLEXIM.
- Wait a moment until the acoustic contact is reestablished. The measurement can be interrupted by a temporarily high portion of liquid and solids in the fluid.

**The measured values substantially differ from the expected values.**

- Wrong measured values are often caused by wrong parameters. Make sure that the parameters entered for the measuring point are correct.

## 10.2 Measuring point selection

- Make sure that the recommended min. distance to any disturbance is observed.
- Avoid measuring points with deposit formation in the pipe.
- Avoid measuring points in the vicinity of deformations and defects on the pipe as well as welds.
- Make sure the pipe surface at the selected measuring point is even.
- Measure the temperature at the measuring point and make sure that the transducers are suitable for this temperature.
- Make sure that the outer pipe diameter is within the measuring range of the transducers.
- When measuring on a horizontal pipe, the transducers have to be mounted laterally on the pipe.

## 10.3 Maximum acoustic contact

- see section 6.2

## 10.4 Application-specific problems

**The entered pipe roughness is not appropriate.**

- Check the entered value considering the pipe condition.

**The pipe lining may cause problems during the measurement if it is not firmly attached to the inner pipe wall or consists of an acoustically absorbing material.**

- Try to measure on a section of the pipe free from lining.

## 10.5 Significant deviations of the measured values

### The defined upper limit of the flow velocity is too low.

- All measured flow velocities that are greater than the upper limit will be ignored and marked as invalid. All quantities deviated from the flow velocity will also be indicated as invalid. If several correct measured values are ignored, the totalizer values will be too low.

### The entered cut-off flow is too high.

- All flow velocities below the cut-off flow are set to zero. All derived quantities are also set to zero. The cut-off flow has to be set to a low value to be able to measure at low flow velocities (default: 2.5 cm/s).

### The entered pipe roughness is not appropriate.

### The flow velocity of the fluid is outside the measuring range of the transmitter.

### The measuring point is not appropriate.

- Check whether a different measuring point provides better results. Because pipes are never rotationally symmetric and the flow profile is affected.

## 10.6 Problems with the totalizers

### The values of the totalizers are too small.

- One of the totalizers has reached the upper limit and has to be reset to zero manually.

### The sum of the totalizers is not correct.

- The sum of both totalizers (throughput  $\Sigma Q$ ) transmitted via an output is not valid after one of the totalizers has overflowed for the first time.

### An interrogation point is displayed after the value of the totalizer.

- The measurement was temporarily impossible, therefore the totalizer value can be wrong.

## 11 Maintenance and cleaning

### Danger!



#### Risk of explosion when using the measuring equipment in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ Observe the "Safety instructions for the use in explosive atmospheres".

### Warning!



#### Service works by unauthorized and unqualified personnel

This may result in personal or material damage or dangerous situations.

→ Any work on the transmitter has to be carried out by authorized and qualified personnel.

### Warning!



#### Touching live parts

Electric shock or arc faults can lead to severe injuries. The measuring equipment can be damaged.

→ Prior to any work on the transmitter (e.g., installation, dismantling, connection, start-up), the transmitter has to be disconnected from the power supply.

### Caution!



#### Safety and accident prevention regulations for electrical systems and equipment

Failure to observe these regulations may lead to severe injuries.

→ Observe the safety and accident prevention regulations for electrical systems and equipment.

### Caution!



#### Touching hot or cold surfaces

This may result in injuries (e.g., thermal damages).

→ Observe the ambient conditions at the measuring point during installation.

→ Wear the required personal protective equipment.

→ Observe the applicable rules.



## 11.1 Maintenance

The transmitter and the transducers are practically maintenance-free. In order to ensure security, the following maintenance intervals are recommended:

item	maintenance step	interval	measure
stainless steel housing • junction box • transducer mounting fixture	visual inspection for corrosion and damages	annually	cleaning
	visual inspection for contamination	annually or more frequently, depending on the ambient conditions	
aluminum housing • transmitter	visual inspection for contamination	annually or more frequently, depending on the ambient conditions	
transducers	check of the transducer coupling on the pipe	annually	replacement of coupling foil, if necessary
O-rings	visual inspection for fissures	annually	see section 11.4
transmitter	check for firmware updates	annually	update, if necessary
transmitter	functional test	annually	reading of measured and diagnostic values
transmitter and transducers	calibration	-	see section 11.3

## 11.2 Cleaning

### Stainless steel housing

- Clean the housing with a soft cloth and care and cleaning spray for stainless steel.

### Aluminum housing

- Clean the housing with a soft cloth. Do not use detergents.

### Transducers

- Remove traces of coupling compound from the transducers with a soft paper towel.

## 11.3 Calibration

If installed as recommended in an appropriate location, used cautiously and serviced conscientiously, no troubles should appear.

The transmitter has been calibrated at factory and, usually, a recalibration is not necessary.

A recalibration is recommended if:

- the contact surfaces of the transducers show visible wear
- the transducers were used for a prolonged period at high temperatures (several months > 200 °C for high temperature transducers)

In order to realize a recalibration under reference conditions, either the transmitter, the transducers or both have to be sent to FLEXIM.

## 11.4 Examination of the O-ring

### Danger!



#### Risk of explosion when using the transmitter in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ The O-rings form part of the ignition protection and have to ensure tightness of the housing to guarantee explosion protection.

The O-rings on the transmitter and on the cable glands have to be checked for possible damages regularly and each time the housing is opened. Porous or damaged O-rings have to be replaced. Cable glands with defective O-rings have to be replaced.

Use original spare parts only. Store the O-ring replacement in a hermetically sealed and dark place.


#### Housing with increased safety

Defective O-rings have to be replaced.

### Important!


O-rings of increased safety housings may be replaced by qualified FLEXIM personnel only.

Fig. 11.1: Transmitter with aluminum housing



- 1 – O-ring of transmitter
- 2 – thread gap (Ex db)
- 3 – housing cover
- 4 – sight glass

Fig. 11.2: Transmitter with stainless steel housing



- 1 – O-ring of the transmitter
- 2 – thread gap (Ex db)
- 3 – housing cover
- 4 – sight glass

## 11.5 Examination of the thread on the flameproof enclosure housing

### Danger!



#### Risk of explosion when using the transmitter in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ In order to maintain ignition protection, the thread gap of the flameproof enclosure housing has to meet the specifications of the manufacturer. Damages or changes on the thread are not permitted.

The thread of the housing cover ensures a flameproof thread gap. Before closing the housing, the thread has to be checked for damages. Housings with damaged threads have to be replaced.

## 11.6 Examination of housing and sight glass

### Danger!



#### Risk of explosion when using the transmitter in explosive atmospheres

This may result in personal or material damage or dangerous situations.

→ In order to ensure ignition protection, the housing and the sight glass have always to comply with the regulations.

Modifications on the housing must only be realized by FLEXIM. The housing and the sight glass must be regularly checked for damages. Cracked or scratched sight glasses or damaged housings have to be replaced by FLEXIM personnel immediately.

## 12 Dismounting and disposal

### Danger!



#### **Risk of explosion when using the measuring equipment in explosive atmospheres**

This may result in personal or material damage or dangerous situations.

→ Observe the "Safety instructions for the use in explosive atmospheres".

### Warning!



#### **Installation, connection and start-up by unauthorized and unqualified personnel**

This may result in personal or material damage or dangerous situations.

→ Any work on the transmitter has to be carried out by authorized and qualified personnel.

### Warning!



#### **Touching live parts**

Electric shock or arc faults can lead to severe injuries. The measuring equipment can be damaged.

→ Prior to any work on the transmitter (e.g., installation, dismantling, connection, start-up), the transmitter has to be disconnected from the power supply.

### Caution!



#### **Safety and accident prevention regulations for electrical systems and equipment**

Failure to observe these regulations may lead to severe injuries.

→ Observe the safety and accident prevention regulations for electrical systems and equipment.

### 12.1 Dismounting

Dismounting is carried out in reverse order to the installation.

### 12.2 Disposal

The measuring equipment has to be disposed of in accordance with the applicable regulations.

### Important!


#### **Proper disposal of components of the transmitter and accessories that are no longer required avoids environmental damage and conserves resources.**

Depending on the material, the corresponding parts have to be disposed of in residual or special waste or recycled in accordance with the applicable regulations.

Batteries must be disposed of separately from electrical or electronic equipment. For this purpose, remove the batteries from the device and take them to the designated disposal system.

The components are taken back free of charge by FLEXIM in accordance with national regulations. Contact FLEXIM.

## 13 User modes



The user modes allow extended diagnostics of signals and measured values as well as the definition of additional parameters adapted to the application.

The following user modes can be selected:

- StandardUser
- ExpertUser
- SuperUser
- SuperUser ext.

Depending on the selected user mode, different menu items are displayed within the menu Calibration and the menu item Miscellaneous\Special settings:

Tab. 13.1: Menu items of the user modes

menu item	StandardUser	ExpertUser	SuperUser	SuperUser ext.	default
in menu item Miscellaneous\Special settings					
Signal search range	x	x	x	x	20 %
High voltage	x	x	x	x	Automatic
Advanced search run	x	x	x	x	Off
Averaging factor	x	x	x	x	
Crest factor threshold		x	x	x	
Use satur. steam curve	x	x	x	x	No
in menu Calibration					
Cut-off flow	x	x	x	x	On
Flow velocity limit		x	x	x	Off
Linear calibration			x	x	Off
Profile correction		x	x	x	kRe 2.0
Multi-point calibration (if enabled in Miscellaneous\ Measurement\Measurement settings)	x	x	x	x	

### User mode selection

Miscellaneous\System settings\User mode

- Select the menu item User mode.
- Press ENTER.
- Select a list item.
- Press ENTER.

## 13.1 StandardUser mode

In the StandardUser mode, all measurements can be carried out for the corresponding application. At the first start-up the transmitter operates in the StandardUser mode.

### 13.1.1 Parameter search range

The transmitter calculates the expected transit time of the ultrasonic signal from the defined fluid sound speed. Before the measurement starts, the signal is searched in a range before and after the expected time. The search time can be shortened by reducing the range. If the range of the parameter search is too small, no signal may be found. In case of strong pressure or temperature fluctuations, the range should not be reduced.

Miscellaneous\Special settings\Signal search range

- Select the menu item `Special settings` in the menu `Miscellaneous`.
- Press ENTER until the menu item `Signal search range` is displayed.
- Enter a value for the search range up to a maximum of 40 % (default: 20 %).
- Press ENTER.

### 13.1.2 High voltage

High voltage increases the excitation voltage of the transducers.

Miscellaneous\Special settings\High voltage

- Select the menu item `Special settings` in the menu `Miscellaneous`.
- Press ENTER until the menu item `High voltage` is displayed.
- Select `On` to increase the excitation voltage of the transducers (default: `Automatic`).
- Select `Automatic` if the signal search is to be carried out with low or high excitation voltage. The transmitter then uses the excitation voltage with which a higher crest factor is obtained.
- Select `Off` if the excitation voltage is not to be increased.
- Press ENTER.

### 13.1.3 Advanced search run

The function `Advanced search run` optimizes the signal search after a measurement failure. If this function is activated, the search run is carried out after a measurement failure with low and high excitation voltage. The transmitter then uses the excitation voltage with which a higher crest factor is obtained.

If this function is deactivated, the search run is first carried out with the excitation voltage used before measurement failure. If a valid signal is found, the transmitter switches back to the measuring mode with this excitation voltage. If no valid signal is found, the search run is carried out again with another excitation voltage.

In order to keep the search run as short as possible, this function is deactivated by default.

Miscellaneous\Special settings\Advanced search run

- Select the menu item `Special settings` in the menu `Miscellaneous`.
  - Press ENTER until the menu item `Advanced search run` is displayed.
- This display will only be indicated if the list item `Automatic` is selected in the menu item `High voltage`.
- Select `On` to activate `Advanced search run`. Select `Off` to deactivate it (default: `Off`).
  - Press ENTER.

### 13.1.4 Averaging factor of the measurement

The averaging factor of the measurement defines a time range in which the values are averaged for calculation. A high factor increases the measurement stability, but also the response time to changed measured values.

```
Miscellaneous\Special settings\Averaging factor
```

- Select the menu item `Special settings` in the menu `Miscellaneous`.
- Press ENTER until the menu item `Averaging factor` is displayed.
- Enter the averaging factor (default: 5). The value should be between 3 and 7.
- Press ENTER.

### 13.1.5 Settings for steam measurement

In the menu item `Use satur. steam curve` it is possible to select whether the saturation pressure is to be calculated from the temperature or the saturation temperature from the pressure during the steam measurement.

```
Miscellaneous\Special settings\Use satur. steam curve
```

- Select the menu item `Miscellaneous\Special settings`.
- Press ENTER until the menu item `Use satur. steam curve` is displayed.
- Select `Tf -> Pf`, if the fluid pressure has to be calculated from the fluid temperature. Select `Pf -> Tf`, if the fluid temperature has to be calculated from the fluid pressure. Select `No` if the pressure and temperature are independently available.
- Press ENTER.

If `Tf -> Pf` or `Pf -> Tf` is selected, the information concerning the calculated quantity will be displayed in the menu `Parameters` after the fluid temperature or fluid pressure has been entered.

### 13.1.6 Cut-off flow

The cut-off flow is a lower limit for the flow velocity. All measured flow velocities that are below the limit are set to zero. The cut-off flow can depend on the flow direction.

```
Calibration\Cut-off flow
```

- Select the menu item `Calibration\Cut-off flow`.
- Press ENTER.
- Select `Off` if no value is to be entered for the cut-off flow.
- Select `Default` if no customized inputs are to be made (default:  $\pm 25$  mm/s).
- Select `Customized` to define the values of the cut-off flow for the positive and negative flow direction.
- Press ENTER.

```
Calibration\Cut-off flow\Customized\+Cut-off flow
```

All values of the flow velocity for the positive flow direction below this limit are set to zero.

- Enter the cut-off flow.
- Press ENTER.

```
Calibration\Cut-off flow\Customized\ -Cut-off flow
```

All values of the flow velocity for the negative flow direction (as absolute value) below this absolute limit are set to zero.

- Enter the cut-off flow as absolute value.
- Press ENTER.

### 13.1.7 Multi-point calibration

It is possible to enter a series of measured values in order to define a calibration curve for the flow velocity.

Record of a series of measured values:

- Start a measurement with the transmitter and a reference flowmeter.
- Gradually increase the value of the flow velocity. The measuring range of values has to be identical with the eventual operating range.
- Note or store the measured values.

Input of a series of measured values:

- Activate the multi-point calibration in the menu item `Miscellaneous\Measurement\Measurement settings`.
- Select the menu item `Multi-point calibration` in the menu `Calibration`.
- Press ENTER.

```
Calibration\Multi-point calibration
```

- Select `Yes` to define the calibration curve. Select `No` to measure without calibration.
- Press ENTER.

```
Calibration\Multi-point calibration\Calibration points
```

- Enter the number of pairs of measured values.
- Press ENTER.

```
Calibration\Multi-point calibration\Point x=act. value
```

- Enter the measured value of the transmitter.
- Press ENTER.

```
Calibration\Multi-point calibration\Point x=set value
```

- Enter the measured values of the reference flowmeter.
- Press ENTER.
- Repeat the input for all pairs of measured values.
- Press ENTER after each input.

```
Calibration\Multi-point calibration\Bidirectional use
```

- Select `Yes` to apply the calibration curve for negative flow velocities as well. Select `No` if it is not to be used for negative flow velocities.

## 13.2 ExpertUser mode

Some menu items that are not visible in the StandardUser mode are displayed.

### Notice!

The ExpertUser mode is intended for experienced users with advanced application knowledge. Changed parameters can affect the StandardUser mode and lead to wrong measured values or to a measurement failure when setting up a new measuring point.

### Notice!

Some of the defined parameters remain activated when switching to the StandardUser mode. These parameters are displayed but cannot be changed.



### 13.2.1 Threshold value for valid measurement

Miscellaneous\Special settings\Crest factor threshold

- Select the menu item `Special settings` in the menu `Miscellaneous`.
- Press ENTER until the menu item `Crest factor threshold` is displayed.
- Enter the threshold value (default: 6).
- Press ENTER.

#### Notice!

A reduced threshold value allows for measurements under difficult conditions, but increases the risk of measurement errors.

### 13.2.2 Profile correction

It is possible to select the following versions for the calculation of the fluid mechanic calibration factor  $k_{Re}$ :

- `kRe 1.0`: profile correction (previous version)
- `kRe 2.0`: improved profile correction (current version, default)

#### Selection of the version

Miscellaneous\Measurement\Measurement settings\Profile correction

- Select the menu item `Measurement settings` in the menu `Miscellaneous`.
- Press ENTER until the menu item `Profile correction` is displayed.
- Select a list item (default: `kRe 2.0`).
- Press ENTER.

### 13.2.3 Limit of the flow velocity

Single outliers caused by heavily disturbed surroundings can appear among the measured values of the flow velocity. If these outliers are not ignored, they will affect all derived physical quantities, which will be unsuitable for the integration (e.g., pulse outputs).

In the ExpertUser mode it is possible to enter a limit for the flow velocity.

It is possible to ignore all measured flow velocities higher or lower than the preset limit. In this case an error will be output.

Calibration\Flow velocity limit

- Select the menu item `Flow velocity limit` in the menu `Calibration`.
- Press ENTER.
- Select `Off` if no limit for the flow velocity is to be used.
- Select `Default` if no customized inputs are to be made.
- Select `Customized` to define a limit for the flow velocity.
- Press ENTER.

Calibration\+Flow velocity limit

- Enter a limit of the flow velocity for the measurement in flow direction.
- Press ENTER.

If the flow velocity is higher than this limit, it will be marked as invalid. The physical quantity cannot be determined. UNDEF will be displayed.

Calibration\ -Flow velocity limit


- Enter a limit of the flow velocity for the measurement against the flow direction.
- Press ENTER.

If the flow velocity is lower than this limit, it will be marked as invalid. The physical quantity cannot be determined. UNDEF will be displayed.

**Notice!**

If the limit of the flow velocity +Flow velocity limit is too low or -Flow velocity limit is too high, a measurement might be impossible because most of the measured values will be marked as invalid.

Fig. 13.1: Flow velocity outside the valid range



- 1 – physical quantity
- 2 – flow velocity

### 13.3 SuperUser mode and SuperUser ext. mode

Some menu items that are not visible in the StandardUser or ExpertUser mode are now displayed.

In the SuperUser ext. mode it is not possible to carry out any plausibility test of the entered parameters.

**Notice!**

The SuperUser and SuperUser ext. mode is intended for experienced users with advanced application knowledge. Changed parameters can affect the StandardUser mode and lead to wrong measured values or to a failure of the measurement when setting up a new measuring point.

**Notice!**

Some of the defined parameters remain activated when switching to the StandardUser mode. These parameters are displayed but cannot be changed.

### 13.3.1 Linear calibration

It is possible to define a correction of the flow velocity:

$$v_{\text{cor}} = m \cdot v + n$$

where

- v – measured flow velocity
- m – factor, range: -2...+2
- n – offset, range: -12...+12 cm/s
- $v_{\text{cor}}$  – corrected flow velocity

All quantities derived from the flow velocity will be calculated with the corrected flow velocity.

#### Notice!

It will not be displayed during the measurement that the correction of the flow velocity is activated.

#### Calibration\Linear calibration

- Select the menu item `Linear calibration` in the menu `Calibration`.
- Press ENTER.
- Select `Off` to measure without linear calibration.
- Select `Default` if no customized inputs are to be made.
- Select `On` to define the values for the calibration.
- Press ENTER.

#### Calibration\Factor

- Enter the factor for the linear calibration.
- Press ENTER.

#### Calibration\Offset

- Enter the offset for the linear calibration.
- Press ENTER.

#### Example

factor: 1.1

offset: -10 cm/s = -0.1 m/s

If a flow velocity  $v = 5$  m/s is measured, before the calculation of the derived quantities it will be corrected as follows:

$$v_{\text{cor}} = 1.1 \cdot 5 \text{ m/s} - 0.1 \text{ m/s} = 5.4 \text{ m/s}$$


#### Example

factor: -1

offset: 0

Only the sign of the measured values changes.

# 14 Outputs



If the transmitter is equipped with outputs, they have to be configured. For the configuration of the analog output, see section 9.2.

The transmitter can also be equipped with digital outputs. A digital output combines the functions of the following outputs:

- binary output (output of binary switching conditions)
- pulse output (integrating output of quantities)
- frequency output (scaled output of flow quantities)

These functions depend on the selected physical quantity.

Tab. 14.1: Output via digital outputs

	source item	binary output		pulse output	frequency output
		status value	event value		
physical quantities	Flow quantities	x			x
	Totalizers	x			x
	Pulse			x	
	Fluid properties	x			x
	Diagnostic values				x
	Miscellaneous	x			x
events	Event trigger		x		

## 14.1 Configuration of a digital output as binary output

A binary output switches if one of the following switching conditions is met:

- the measured value exceeds or falls below a limit
- the measured value lays within or outside a defined range
- a measurement is not possible
- an event occurs

### Enabling the output

If the output has to be used, it has to be enabled.

```
Outputs\Digital output B1(-)
```

- Select the menu item `Outputs\Digital output B1(-)`.
- Press ENTER.

If the output has already been enabled, it is displayed as follows: `Digital output B1 (√)`.

```
Outputs\Digital output B1\B1 Enable
```

- Select `Yes` to enable the output or to change the settings.
- Select `No` to cancel the enabling and to return to the previous menu item.
- Press ENTER.

**Assignment of a source item**

A source item has to be assigned to each selected output.

```
Outputs\Source item
```

Tab. 14.2: Output of status values or event values

	source item	status value	event value
physical quantities	Flow quantities	x	
	Fluid properties	x	
	Miscellaneous	x	
	Totalizers	x	
events	Event trigger		x

- Select the source item.
- Press ENTER.
- Select the list item Status.
- Press ENTER.

If Event trigger is selected as source item, Idle state will be displayed as property of the binary output.

**14.1.1 Definition of the switching function for the status/event value**

- Select the switching function for the output of the status/event value.
- Press ENTER.

Tab. 14.3: Selection of the switching condition

property	switching function	description
Status OK (status value)	NC	<ul style="list-style-type: none"> <li>• valid measured value: binary output is closed</li> <li>• invalid measured value: binary output is open</li> </ul>
	NO	<ul style="list-style-type: none"> <li>• valid measured value: binary output is open</li> <li>• invalid measured value: binary output is closed</li> </ul>
Idle state (event value)	NO	<ul style="list-style-type: none"> <li>• event occurs: binary output is closed</li> <li>• event has not occurred yet: binary output is open</li> </ul>
	NC	<ul style="list-style-type: none"> <li>• event occurs: binary output is open</li> <li>• event has not occurred yet: binary output is closed</li> </ul>

If no measurement is carried out, all binary outputs are open (de-energized), independent of the set switching condition.

**Terminal assignment**

```
Outputs\Digital output B1\...\Output info
```

The terminals for the connection of the output are displayed.

By pressing  or  further information is displayed.

- Press ENTER.

**Output function test**

The function of the output can now be tested.

- Connect a multimeter to the output.

Outputs\...\B1 Test signal

- Select *Yes* to test the output. Select *No* to display the next menu item.
- Press ENTER.

Outputs\...\B1 Enter test value

- Select a list item as test value.
- Press ENTER.

Tab. 14.4: Output function test – signal

list item	description
NC	<ul style="list-style-type: none"> <li>• binary output is energized</li> <li>• measured value has to be low ohmic</li> </ul>
NO	<ul style="list-style-type: none"> <li>• binary output is de-energized</li> <li>• measured value has to be high ohmic</li> </ul>

- Select *Repeat* to repeat the test or *Finish* to display the next menu item.
- Press ENTER.

Outputs\...\B1 Test measuring range

- Select *Yes* to test the status of the output signal. Select *No* to display the next menu item.
- Press ENTER.

Outputs\...\B1 Enter test value

- Select a list item as test value.
- Press ENTER.

Tab. 14.5: Output function test – measuring range

list item	switching function	test value	description
Status OK (status value)	NC	Status OK	<ul style="list-style-type: none"> <li>• binary output is energized</li> <li>• measured value has to be low ohmic</li> </ul>
		Status error	<ul style="list-style-type: none"> <li>• binary output is de-energized</li> <li>• measured value has to be high ohmic</li> </ul>
	NO	Status OK	<ul style="list-style-type: none"> <li>• binary output is de-energized</li> <li>• measured value has to be high ohmic</li> </ul>
		Status error	<ul style="list-style-type: none"> <li>• binary output is energized</li> <li>• measured value has to be low ohmic</li> </ul>
Idle state (event value)	NC	Passive	<ul style="list-style-type: none"> <li>• binary output is energized</li> <li>• measured value has to be low ohmic</li> </ul>
		Active	<ul style="list-style-type: none"> <li>• binary output is de-energized</li> <li>• measured value has to be high ohmic</li> </ul>
	NO	Passive	<ul style="list-style-type: none"> <li>• binary output is de-energized</li> <li>• measured value has to be high ohmic</li> </ul>
		Active	<ul style="list-style-type: none"> <li>• binary output is energized</li> <li>• measured value has to be low ohmic</li> </ul>

- Select Repeat to repeat the test or Finish to display the next menu item.
- Press ENTER.

## 14.2 Configuration of a digital output as pulse output

A pulse output is an integrating output which emits a pulse when the volume or the mass of the fluid which has passed the measuring point reaches a certain value (pulse value).

The integrated quantity is the selected physical quantity. The integration is restarted as soon as the pulse is emitted. Before the activation, the digital output has to be configured.

```
Outputs\Digital output B1\Source item
```

- Select the menu item Outputs\Digital output B1\Source item.
- Press ENTER.

### Assignment of a source item

```
Outputs\Source item\Pulse
```

- Select Pulse as source item.
- Press ENTER.

```
Outputs\Pulse\Pulse +V
```

- Select a list item (here: Pulse +V).
- Press ENTER.

Tab. 14.6: Selection of the physical quantity

source item	list item	output
Pulse	Pulse  V	pulse without considering the sign of the volumetric flow rate
	Pulse +V	pulse for positive measured values of the volumetric flow rate
	Pulse -V	pulse for negative measured values of the volumetric flow rate
	Pulse  m	pulse without considering the sign of the mass flow rate
	Pulse +m	pulse for the positive measured values of the mass flow rate
	Pulse -m	pulse for the negative measured values of the mas flow rate

### 14.2.1 Pulse output by defining the pulse value

Outputs\Pulse output

- Select the list item `Pulse value`.
- Press ENTER.

The pulse output can be operated in 2 modes:

mode	description
Continuous pulses	<ul style="list-style-type: none"> <li>• output of a continuous pulse sequence, reproducing the temporal behavior of the corresponding flow quantity (volumetric flow rate, mass flow rate), at simultaneous totalizing</li> <li>• smallest pulse break = pulse width at max. pulse rate (pulse width is constant)</li> </ul>
Burst pulses	<ul style="list-style-type: none"> <li>• output of a discontinuous pulse sequence, reproducing the behavior of the totalizer</li> <li>• several pulses can arise intermittently with equidistant pulse distances (pulse break = pulse width)</li> <li>• serves exclusively for totalizing</li> <li>• max. pulse rate (depends on the pulse width that is constant)</li> </ul>

- Select a list item.
- Press ENTER.

Outputs\Pulse value

- Enter the pulse value.

The unit of measurement will be displayed according to the actual physical quantity.

When the counted physical quantity reaches the entered pulse value, a pulse will be transmitted.

- Press ENTER.

Outputs\Pulse width

- Enter the pulse width.

The range of possible pulse widths depends on the specification of the instrument (e.g., counter, PLC) that is to be connected to the output.

- Press ENTER.



### 14.2.2 Pulse output by defining pulses per unit

Outputs\Pulse output

- Select the list item `Pulses per unit`.
- Press ENTER.

Outputs\Output range

- Select a list item:
  - `0...1 kHz`
  - `0...5 kHz`
  - `Other range`

- Press ENTER.

If `Other range` is selected, enter a value for `Output MAX`.

Outputs\Pulses per unit

- Enter the number of pulses per unit.
- Press ENTER.

The unit of measurement will be displayed according to the actual physical quantity.

### 14.2.3 Output options

Outputs\Idle state

- Select the setting of the idle state:

setting	description
NO	The pulse output is energized if a pulse is emitted and de-energized if no pulse is emitted (idle state).
NC	The pulse output is de-energized if a pulse is emitted and energized if no pulse is emitted (idle state).

If no measurement is carried out, all pulse outputs are open (de-energized), independent of the set switching condition.

#### Terminal assignment

Outputs\...\Output info

The terminals for the connection of the output are displayed.

By pressing  or  further information is displayed.

- Press ENTER.

**Output function test**

Outputs\...\B1 Test signal

- Select *Yes* to test the status of the output signal. Select *No* to display the next menu item.
- Press ENTER.

Outputs\...\B1 Enter test value

- Select a list item as test value.
- Press ENTER.

Tab. 14.7: Output function test – signal

output mode	test value	description
Pulses per unit	The entered test value has to be within the output range.	If the external measuring instrument displays the entered value, the output functions correctly.
Pulse value	NO	<ul style="list-style-type: none"> <li>• pulse output is de-energized</li> <li>• measured value has to be high ohmic</li> </ul>
	NC	<ul style="list-style-type: none"> <li>• pulse output is energized</li> <li>• measured value has to be low ohmic</li> </ul>

**14.3 Configuration of a digital output as frequency output**

The frequency output emits a square wave signal with a frequency which is proportional to the source item sent to the output.

Outputs\Digital output B1\Source item

- Select the menu item *Outputs\Digital output B1\Source item*.
- Press ENTER.

**Assignment of a source item**

- Select one of the following source items:
  - Flow quantities
  - Totalizers
  - Fluid properties
  - Diagnostic values
  - Miscellaneous
  - Sound speed

Outputs\Flow quantities

- Select a list item (here: *Flow quantities*).
- Press ENTER.

Outputs\Volumetric flow rate

- Select a list item (here: *Volumetric flow rate*).
- Press ENTER.
- Select the list item *Values*.
- Press ENTER.

## Output range

```
Outputs\...\Output range
```

- Select a list item.

- 0...1 kHz
- 0...10 kHz
- Other range

- Press ENTER.

If `Other range` is selected, enter the values `Output MIN` and `Output MAX`.

## Error output

```
Outputs\...\Error value
```

An error value can be defined which is output if the source item cannot be measured.

- Select a list item for the error output.
- Press ENTER.

## Measuring range

The sign of the measured value and the measuring range are determined.

```
Outputs\...\Measured values\Absolute value
```

- Select `Sign` if the sign of the measured values is to be considered for the output.
- Select `Absolute value` if the sign of the measured values is not to be considered for the output.

```
Outputs\...\Start of meas. range
```

- Enter the lowest expected measured value. The unit of measurement of the source item will be displayed.
- `Start of meas. range` is the value assigned to the value `Output MIN` of the output range.

```
Outputs\...\End of meas. range
```

- Enter the highest expected measured value. The unit of measurement of the source item will be displayed.
- `End of meas. range` is the value assigned to the value `Output MAX` of the output range.

## Idle state

The idle state is the status of the output signal to be output when no measured value is measured.

- Select a list item for the idle state.
- Press ENTER.

## Terminal assignment

```
Outputs\...\Output info
```

The terminals for the connection of the output are displayed.

By pressing  or  further information is displayed.

- Press ENTER.

**Output function test**

The function of the output can now be tested.

- Connect an external measuring instrument to the terminals of the installed output.

```
Outputs\...\Test signal
```

- Select **Yes** to test the output. Select **No** to display the next menu item.
- Press **ENTER**.

```
Outputs\...\Enter test value
```

- Enter a test value. It has to be within the output range.
- Press **ENTER**.

If the external measuring instrument displays the entered value, the output functions correctly.

- Select **Repeat** to repeat the test or **Finish** to display the next menu item.
- Press **ENTER**.

```
Outputs\...\Test measuring range
```

- Select **Yes** to test the assignment of the measured value to the output signal. Select **No** to display the next menu item.
- Press **ENTER**.


```
Outputs\...\Enter test value
```

- Enter a test value. It has to be within the output range.
- Press **ENTER**.

If the external measuring instrument displays the entered value, the output functions correctly.

- Select **Repeat** to repeat the test and **Finish** to finish it.
- Press **ENTER**.

## 15 Inputs



### 15.1 Configuration of an input

If the transmitter is equipped with inputs, they have to be configured.

- Select the menu item `Configure inputs` in the menu `Inputs`.
- Press `ENTER`.

```
Inputs\Configure inputs
```

- Select the input to be configured.
- Press `ENTER`.

The scroll list contains all available inputs.

- `Current Ix (-)`
- `Temperature Tx (-)`

If the input has already been configured, it is displayed as follows: `Current I1 (✓)`.

#### Enabling the input

To use the input, it has to be enabled (here: `Current I1`).

```
Inputs\Configure inputs\Current I1\I1 Enable
```

- Select `Yes` to enable an input or change the settings for an already enabled input.
- Select `No` to uninstall an already configured input and to return to the previous menu item.
- Press `ENTER`.

#### 15.1.1 Current inputs

When configuring the current inputs, the source item can now be selected and the input and measuring range is defined.

##### Selection of the source item

```
Inputs\...\Source item
```

- Select the source item.

##### Input range

```
Inputs\...\Input range
```

- Select a list item:

- `0...20 mA`
- `4...20 mA`
- `Other range`

- Press `ENTER`.

If `Other range` is selected, enter the values `Input MIN` and `Input MAX`.

## Measuring range

```
Inputs\...\Start of meas. range
```

- Enter the lowest expected measured value. The unit of measurement of the source item will be displayed. `Start of meas. range` is the physical quantity assigned to the lower limit of the input range (`Input MIN`).
- Enter the highest expected measured value. The unit of measurement of the source item will be displayed. `End of meas. range` is the physical quantity assigned to the higher limit of the input range (`Input MAX`).

## Input of an error value

```
Inputs\...\Error value
```

It is possible to define an error value which is output if the source item is not available.

- Select `Yes` if an error value is to be defined.
- Press ENTER.
- Enter the error value.
- Press ENTER.

### 15.1.2 Temperature inputs

When configuring a temperature input, the temperature probe can now be selected.

#### Selection of the temperature probe

```
Inputs\Configure inputs\Temperature Tx\Pt100/Pt1000
```

- Select the temperature probe:
  - Pt100
  - Pt1000

#### Activation of the temperature correction

A temperature correction (offset) can be set for each temperature input. This function is activated in the menu item `Miscellaneous\Dialogs/Menus/Tx temperature offset`.

```
Miscellaneous\Dialogs/Menus/Tx temperature offset
```

- Select the menu item `Miscellaneous\Dialogs/Menus`.
- Press ENTER until the menu item `Tx temperature offset` is displayed.
- Select `Yes` to activate the temperature correction. Select `No` to deactivate it.
- Press ENTER.

#### Notice!

The entered correction value for each temperature input will be stored and displayed when the temperature correction is activated again.

The correction value is automatically added to the measured temperature. It is used e.g., if the characteristic curves of the two temperature probes differ considerably from each other or a known and constant temperature gradient exists between the measured temperature and the actual temperature.

## Input of the temperature correction

```
Inputs\Temperature offset
```

- Select **Yes** to enter an offset for the temperature input.
- Press **ENTER**.
- Enter the offset for the temperature input.
- Press **ENTER**.

### 15.1.3 Definition of a switching condition

If a transmitter function is to be performed by remote control, a switching condition has to be defined.

```
Inputs\...\Trigger value
```

- Select **Yes** if a switching condition is to be defined. Select **No** to display the next menu item.
- Press **ENTER**.

```
Inputs\...\Function
```

- Select a list item:
  - **MAX** ( $x > \text{limit}$ ): the switching condition is met when the measured value exceeds the limit
  - **MIN** ( $x < \text{limit}$ ): the switching condition is met when the measured value falls below the limit
  - **ERR** ( $x = \text{fail}$ ): the switching condition is met when a measurement is not possible
  - **Within range**: the switching condition is met when the measured value is within the defined range
  - **Out of range**: the switching condition is met when the measured value is outside the defined range
- Press **ENTER**.

```
Inputs\...\Trigger value
```

- Enter the limit for the switching condition.
  - Press **ENTER**.
- This display will only be indicated if **MAX** ( $x > \text{limit}$ ) or **MIN** ( $x < \text{limit}$ ) is selected.

```
Inputs\...\Hysteresis
```

It is possible to define a hysteresis to avoid constant switching of the event trigger.

The event trigger is activated when the measured value exceeds the upper limit and deactivated when it falls below the lower limit.

- Enter the value for the hysteresis.
- If zero is entered, no hysteresis is used.
- Press **ENTER**.

This display will only be indicated if **MAX** ( $x > \text{limit}$ ) or **MIN** ( $x < \text{limit}$ ) is selected.

```
Inputs\...\Range center
```

- Enter the center of the switching range.
  - Press **ENTER**.
- This display will only be indicated if **Within range** or **Out of range** is selected.

```
Inputs\...\Range width
```

- Enter the width of the switching range.
  - Press **ENTER**.
- This display will only be indicated if **Within range** or **Out of range** is selected.

```
Inputs\...\Glitch interval
```

- Enter a time interval at the end of which the event trigger has to switch.
- Press ENTER.

#### 15.1.4 Terminal assignment

```
Inputs\...\Input info
```

The terminals for the connection of the input are displayed.

By pressing  or  further information is displayed.

- Press ENTER.

#### 15.1.5 Function test of the input

The function of the installed input can now be tested.

##### Analog input

- Connect the signal source to the input.

```
Inputs\...\Test signal I1
```

- Select **Yes** to test the input signal. Select **No** to display the next menu item.
- Press ENTER.

```
Inputs\...\Test signal I1\Current
```

- If the transmitter displays a value (here: **Current**), the input functions correctly.
- Press ENTER.
- Select **Repeat** to repeat the test or **Finish** to display the next menu item.
- Press ENTER.

```
Inputs\...\Test measuring range I1
```

- Select **Yes** to test the assignment of the measured value to the input signal. Select **No** to display the next menu item.
- Press ENTER.

```
Inputs\...\Test measuring range I1\Current
```

- If the transmitter displays a value (here: **Current**), the input functions correctly.
- Press ENTER.
- Select **Repeat** to repeat the test or **Finish** to display the next menu item.
- Press ENTER.
- Press BRK to return to the main menu.




## 15.2 Assignment of an input

- Select the menu item `Assign inputs` in the menu `Inputs`.
- Press ENTER.

```
Inputs\Assign inputs
```

- Select a physical quantity in the scroll list.
- Press ENTER.
- Select the input via which the physical quantity is to be entered. Only configured inputs are displayed in the scroll list.
- Select the list item `No linkage` if no input is to be assigned to the physical quantity.
- Press ENTER.

## 16 Data logger



The transmitter has a data logger which stores the measured values during the measurement.

**Notice!**  
In order to store measured data, the data logger has to be configured.

The following data can be stored:

- date
- time
- measuring point number
- pipe parameters
- fluid parameters
- transducer data
- physical quantity
- unit of measurement
- measured values

Measured values transmitted via the outputs are also stored in the data logger.

If the pulse values are transmitted via an output, the corresponding flow quantity and the totalizer value are stored in the data logger. In case of absolute pulse values, the values of both totalizers are stored.

### 16.1 Configuration of the data logger

#### Enabling the data logger

Storage\Data logger\Configuration\Enable logger

- Select the menu item `Data logger\Configuration` in the menu `Storage`.
- Press ENTER.
- Select `Yes` to enable the data logger.
- Press ENTER.

#### Starting time

Storage\Data logger\Configuration\Start storing

It is possible to set a starting time if it is necessary to synchronize the storing of measured values for several transmitters.

- Select the menu item `Storage\Data logger\Configuration`.
- Press ENTER until the menu item `Start storing` is displayed.
- Select the moment at which to start the storing.
- Press ENTER.

display	description
Immediately	The storing starts immediately.
Full 5 minutes	The storing starts in the next full 5 minutes.
Full 10 minutes	The storing starts in the next full 10 minutes.
Full 15 minutes	The storing starts in the next full 15 minutes.
Full 30 minutes	The storing starts in the next full 30 minutes.
Full hour	The storing starts in the next full 60 minutes.
Event-based	The storing starts when a defined event occurs.


### Example

actual time: 09:06 am  
 setting: Full 10 minutes  
 The storing starts at 09:10 am.

### Notice!

Make sure that the time of all transmitters is synchronized.

### Event-based starting time



Storage\Data logger\Configuration\Start storing\Event-based

If it is necessary to start the storing of measured values at a particular event, select the list item `Event-based` as starting time.

The event is signaled via an input or event trigger. All configured inputs and event triggers are displayed in the scroll list.

- Select the input or the event trigger through which the event is to be signaled.
- Press ENTER.

Storage\Data logger\Configuration\Start storing\Event-based\Storage rate w/o trig.

The storage rate is the frequency to transmit or store measured values.

- Select in the scroll list a storage rate for storing the measured values in case the event does not occur.
- Press ENTER.
- Select `Off` if no measured values are to be stored, as long as the event does not occur.
- Press ENTER.

```
Storage\Data logger\Configuration\Start storing\Event-based\Storage rate (trig.)
```

- Select in the scroll list a storage rate for storing the measured values in case the event occurs.
- Press ENTER.

```
Storage\Data logger\Configuration\Start storing\Event-based\Buffer time ->Π
```

- Enter the time interval for the measured values to be stored before the event occurs.
- Press ENTER.

```
Storage\Data logger\Configuration\Start storing\Event-based\Buffer time Π->
```

- Enter the time interval for the measured values to be stored if the event is no longer activated.
- Press ENTER.

### Storage rate

```
Storage\Data logger\Configuration\Storage rate
```

The storage rate is the frequency to transmit or store measured values. If a start time for storing the measured values is defined, a storage rate has to be entered.

- Select the menu item `Storage\Data logger\Configuration`.
- Press ENTER until the menu item `Storage rate` is displayed.
- Select a storage rate from the scroll list.
- Press ENTER.
- If `Customized` is selected, enter the storage rate.
- Press ENTER.

### Ringbuffer

```
Storage\Data logger\Configuration\Ringbuffer
```

The data logger can be configured as linear logger or ringbuffer. If the ringbuffer is deactivated and the data logger is full, the storing of measured values will be terminated. It can be continued after clearing the data logger. If the ringbuffer is activated and the data logger is full, the oldest measured values will be overwritten. In ringbuffer mode, the remaining capacity of the data logger is displayed during the measurement, e.g.:

Log→ : 1d 6h 57m is displayed, if no measured values have been overwritten.

Log|←| : 1d 6h 57m is displayed, if the old measured values have been overwritten.

- Select the menu item `Storage\Data logger\Configuration`.
- Press ENTER until the menu item `Ringbuffer` is displayed.
- Select `On` to activate the ringbuffer.
- Press ENTER.

If the ringbuffer is deactivated and the data logger is full, the storing of measured values will be terminated.

- Select `Off` to deactivate the ringbuffer.
- Press ENTER.

## Storage mode

```
Storage\Data logger\Configuration\Storage mode
```

- Select the menu item `Storage\Data logger\Configuration`.
- Press ENTER until the menu item `Storage mode` is displayed.
- Press ENTER.
- Select `Sample` to store the current measured value.
- Select `Average` if the average of all undamped measured values of a storage interval is to be stored.

### Notice!

The storage mode does not affect the outputs.

### Notice!

Storage mode = Average

The average of the physical quantity and of other quantities, e.g., the measured temperature, will be calculated.

If a storage rate < 5 s is selected, `Sample` is used.

If no average could be calculated over the complete storage interval, the value is marked as invalid.

## Further parameters for storing

It can be defined whether the following parameters are to be stored together with the measured values.

Tab. 16.1: Parameters for storing

display	description of the parameters
Store totalizers	values of the totalizers
Store diagnost. values	diagnostic values
Store transd. temp.	transducer temperature

- Select `Yes` to store the value. Select `No` in order not to store the value.

## 16.2 Deletion of the data logger

```
Storage\Data logger>Delete meas. values
```

- Select the menu item `Storage\Data logger>Delete meas. values`.
- Press ENTER.
- Select `Yes` to delete the measured values.
- Press ENTER.

## 16.3 Information regarding the data logger

Storage\Data logger\Data logger info

- Select the menu item Storage\Data logger\Data logger info.
- Press ENTER.

The following information regarding the data logger is displayed:

display	description
Activated	data logger is activated/deactivated This display will only be indicated if the measurement has started and the data logger is activated.
Full (date)	date on which the data logger will be full This display will only be indicated if the measurement has started and the ringbuffer is deactivated.
Full (time)	time at which the data logger will be full This display will only be indicated if the measurement has started, the ringbuffer is deactivated and the data logger is not full yet.
Overflow (date)	date from which the oldest measured values will be overwritten This display will only be indicated if the measurement has started, the ringbuffer is activated and the data logger is not full yet.
Capacity (time)	time of remaining data logger capacity This display will only be indicated if the measurement has started and the ringbuffer is activated.
Ringbuffer	ringbuffer is activated/deactivated
Meas. val. Series	number of stored series of measured values

## 17 Data transmission

The data is transmitted via the service interface (USB) or the process interface (option) of the transmitter.

### 17.1 Service interface

The service interface (USB) allows data to be transmitted from the transmitter to the PC using the FluxDiagReader program.

The FluxDiagReader program is used for further processing of the data.

It allows to:

- read measured values, setup settings and snaps from the transmitter and store them to files on the PC
- send files to FLEXIM to support the service
- monitor the measurement

For the operation of FluxDiagReader see the help function of this program.

#### Notice!

To transmit data from the PC to the transmitter, the program FluxDiag has to be used.

### 17.2 Process interface

The transmitter can be equipped with a process interface (e.g., Profibus, Modbus). For the connection of the process interface to the transmitter see supplement to operating instruction.

#### RS485 interface

```
Communication\RS485
```

- Select the menu item RS485 to change the settings of the transmission parameters.
- Press ENTER.

This display will only be indicated if the transmitter has an interface RS485.

default: 9600 bit/s, 8 data bits, no parity, 1 stop bit

- Set the transmission parameters in the scroll lists.
  - Baud (baud rate)
  - Data bits
  - Stop bits
  - Parity
  - Data flow control
- Press ENTER.

```
Communication\Info RS485
```

The terminals for the connection of the RS485 interface are displayed.

- Press ENTER.

## 18 Advanced functions

### 18.1 Totalizers

The total volume or total mass of the fluid at the measuring point can be determined.

There are 2 totalizers, one for the positive and the other for the negative flow direction. The unit of measurement used for totalizing corresponds to the volume or mass unit selected for the physical quantity.

The totalizer values can be displayed in the status line during the measurement.

- Press and hold CLR until the menu item `Execute command` is displayed:

Measurement\Execute command\Totalizers

- Select the list item `Totalizers`.
- Press ENTER.

The following scroll list appears:

display	description
Start totalizers	start and stop totalizer
Reset totalizers	reset the totalizer to zero
Freeze display	display the measured value of the totalizer for several seconds
Reset error	reset the totalizer error
Stop/clear totalizers	stop totalizer and reset it to zero

By pressing  $\rightarrow$  or  $\downarrow$ , the totalizers for the positive and the negative flow direction can be displayed during the measurement.

#### 18.1.1 Number of decimal places

The values of the totalizers can be displayed with up to 11 places, e.g., 74890046.03. The number of decimal places (max. 4) can be defined.

Storage\Totalizers

- Select the menu item `Totalizers` in the menu `Storage`.
- Press ENTER.
- Select `Automatic` if the number of decimal places has to be adjusted automatically.
- Press ENTER.

Low totalizer values will initially be displayed with 3 decimal places. If the values of the totalizers are higher, the number of decimal places will be reduced.

max. value	display
$< 10^6$	$\pm 0.000$ ... $\pm 999999.999$
$< 10^7$	$\pm 1000000.00$ ... $\pm 9999999.99$
$< 10^8$	$\pm 10000000.0$ ... $\pm 99999999.9$
$< 10^{10}$	$\pm 1000000000$ ... $\pm 9999999999$

- Select the number of decimal places.
- Press ENTER.

The number of decimal places is constant. The max. value of the totalizers decreases with an increasing number of decimal places.



decimal places	max. value	max. display
0	$< 10^{10}$	±9999999999
1	$< 10^8$	±99999999.9
2	$< 10^7$	±9999999.99
3	$< 10^6$	±999999.999
4	$< 10^5$	±99999.9999

**Notice!**

The number of decimal places and the max. value of the totalizers only affect the display.

**18.1.2 Detection of long measurement failures**

If there are no valid measured values during a long time interval, the totalizers remain unchanged. Behind this value an interrogation point will be displayed.

The time interval can be defined.

```
Storage\Totalizers\Totalizer timeout
```

- Select the menu item `Totalizers` in the menu `Storage`.
- Press `ENTER` until the menu item `Totalizer timeout` is displayed.
- Select `Default` if no customized inputs are to be carried out and the default value of 30 s is to be used.
- Press `ENTER`.
- Select `Customized` if the time interval is to be defined.
- Press `ENTER`.
- Enter the time interval.
- Press `ENTER`.

**18.1.3 Totalizer overflow**

The overflow behavior of the totalizers can be set:

**Without overflow**

- The totalizer value increases up to the internal limit of  $10^{38}$ .
- The values will be displayed as exponential numbers ( $\pm 1.00000E10$ ), if necessary. The totalizer can only be reset to zero manually.

**With overflow**

The totalizer will be automatically reset to zero when reaching  $\pm 9999999999$ .

```
Storage\Totalizers\Overflow behavior
```

- Select the menu item `Totalizers` in the menu `Storage`.
- Press `ENTER` until the menu item `Overflow behavior` is displayed.
- Select `Yes` to work with overflow. Select `No` to work without overflow.
- Press `ENTER`.

Independent of the setting, the totalizers can be reset to zero manually.

**Notice!**

The overflow of a totalizer influences all output channels, e.g., the data logger and the online transmission of data. The sum of both totalizers (throughput  $\Sigma Q$ ) transmitted via an output is no longer valid after one of the totalizers has overflowed for the first time.

#### 18.1.4 Totalizer behavior after the measurement is stopped

It is possible to define the totalizer behavior after the measurement is stopped or after a reset of the transmitter.

```
Storage\Totalizers\Keep totalizers
```

- Select the menu item `Totalizers` in the menu `Storage`.
- Press ENTER until the menu item `Keep totalizers` is displayed.
- Select `Yes` if the values of the totalizers are to be stored and used for the next measurement. Select `No` if the totalizers are to be set to zero.
- Press ENTER.

#### 18.1.5 Totalizer sum

The sum of the totalizers for both flow directions can be displayed in the status line during the measurement.

```
Storage\Totalizers\Show ΣQ
```

- Select the menu item `Totalizers` in the menu `Storage`.
- Press ENTER until the menu item `Show ΣQ` is displayed.
- Select `Yes` to display the totalizer sum. Select `No` if it is not to be displayed.
- Press ENTER.

#### 18.1.6 Totalizer storing

The totalizer values can be stored now.

```
Storage\Data logger\Configuration
```

- Select the menu item `Storage\Data logger\Configuration`.
- Press ENTER until the menu item `Store totalizers` is displayed.
- Select `Yes`.
- Press ENTER.

## 18.2 Diagnosis with the help of the snap function

### 18.2.1 Configuration

By means of the snap function it is possible to store measuring parameters which are useful for the evaluation of measuring results or for diagnostic purposes. The snap function can be configured.

```
Storage\Snap\Configuration
```

- Select the menu item `Snap\Configuration` in the menu `Storage`.
- Press ENTER.

```
Storage\Snap\Configuration\Snap ringbuffer
```

- Select `Yes` to activate the snap ringbuffer.
- If the snap ringbuffer is activated, after taking the 51th snap, the oldest snaps are overwritten. If the ringbuffer is deactivated, up to 50 snaps can be stored.
- Press ENTER.

```
Storage\Snap\Configuration\Auto snap
```

- Select `Yes` if the auto snap has to be activated.
- If the auto snap is activated, snaps are automatically stored during a measurement failure.
- Press ENTER.

```
Storage\Snap\Configuration\Snap on R1
```

- Select `Yes` if an event that releases a snap has been parameterized for the event trigger R1.
- Press ENTER.

### 18.2.2 Taking a snap

```
Measurement\Execute command\Take a snap
```

- Press and hold CLR during the measurement until the menu item `Execute command` is displayed.
  - Select the list item `Take a snap`.
  - Press ENTER.
- A snap is taken.

### 18.2.3 Information concerning snaps

```
Storage\Snap\Snap info
```

- Select the menu item `Snap\Snap info` in the menu `Storage`.
- Press ENTER.

The following information is displayed:

display	description
Stored snaps	number of stored snaps
Snaps left	number of snaps that can still be stored
Ringbuffer	snap ringbuffer activated

### 18.2.4 Deletion of snaps

Storage\Snap>Delete snaps

- Select the menu item `Snap>Delete snaps` in the menu `Storage`.
- Press `ENTER`.
- Select `Yes` or `No`.
- Press `ENTER`.

### 18.3 Modification of the limit for the inner pipe diameter

It is possible to modify the lower limit of the inner pipe diameter for a given transducer type.


Miscellaneous\Pipe diameter MIN

- Select the menu item `Pipe diameter MIN` in the menu `Miscellaneous`.
  - Press `ENTER`.
- It is possible to define a min. pipe diameter for all relevant transducer frequencies.
- Select `Default` if no customized inputs are to be made and the default values are to be used.
  - Press `ENTER`.
  - Select `Customized` if a min. pipe diameter is to be defined.
  - Press `ENTER`.
  - Enter the pipe diameter in mm.
  - Press `ENTER`.

#### Notice!

If a transducer is used below its recommended inner pipe diameter, a measurement might be impossible.

### 18.4 Remote functions



Remote functions can be triggered by triggerable analog inputs or event triggers.

In order to define an input for a remote function, it has to be enabled in the menu `Inputs`.

In order to define an event trigger for a remote function, it has to be enabled in the menu item `Functions\Event trigger`.

It is possible to trigger one or more of the following remote functions:

- reset of measured values
- reset of totalizers
- stop of totalizers

### 18.4.1 Configuration of the remote function

Functions\Remote functions

- Select the menu item `Remote functions` in the menu `Functions`.
- Press ENTER.

In the scroll list of the functions it is displayed whether, and if so, which input or event trigger is assigned to a function.

- Select a list item:
  - `Reset meas. val. (-)`
  - `Reset totalizers (-)`
  - `Stop totalizers (-)`

If an input or event trigger has already been assigned to this function, this is displayed as follows: `Reset meas. val. (R1)`.

#### Reset of measured values

- Select the list item `Reset meas. val.`
- Press ENTER.

The measured value output simulates a reposing application for the duration of the signal. The actual measured flow velocity is ignored and the measured value is set to zero. All values of the physical quantity derived from the flow velocity also yield zero.

The transmitter continues the measurement if the condition of the remote function is no longer met.

- Select the input which is to be used to trigger the selected remote function.
- Press ENTER.
- Select `No linkage` in order to deactivate the remote function.
- Press ENTER.

#### Reset of totalizers

- Select the list item `Reset totalizers.`
- Press ENTER.

The totalizers are set to zero. The totalizers are deactivated for the duration of the signal.

Totalizing starts at zero again, as soon as the condition for the remote function is no longer met.

When the totalizers are reset to zero with the remote function, the character `H` is displayed next to the measured value during the measurement.

- Select the input which is to be used to trigger the selected remote function.
- Press ENTER.
- Select `No linkage` in order to deactivate the remote function.
- Press ENTER.

#### Stop of totalizers


- Select the list item `Stop totalizers.`
- Press ENTER.

The totalizers are stopped for the duration of the signal.

Totalizing will be continued with the last registered totalizer value if the condition of the remote function is no longer met.

- Select the input which is to be used to trigger the selected remote function.
- Press ENTER.
- Select `No linkage` in order to deactivate the remote function.
- Press ENTER.

## 18.5 Event triggers



It is possible to configure max. 4 independent event trigger R1, R2, R3, R4.

The event triggers can be used, e.g., to:

- output information about the running measurement
- trigger special remote functions
- switch on/off pumps and motors

Functions\Event trigger

- Select the menu item `Event trigger` in the menu `Functions`.
- Press `ENTER`.

Functions\Event trigger\Rx(-)

- Select an event trigger.
- Press `ENTER`.

If an event trigger has already been installed, it is displayed as follows: `Rx (√)`.

Functions\Event trigger\Enable Rx

- Select `Yes` to change the settings for an already assigned event trigger or to assign a new one.
- Select `No` to cancel the assignment and to return to the previous menu item.
- Press `ENTER`.

Functions\Event trigger\Enable Rx\Source item

- Select the source item (physical quantity) for which a condition has to be defined.

Tab. 18.1: Source items

source item	list item	output
Flow quantities	Flow velocity	flow velocity
	Operation vol. flow	operating volumetric flow rate
	Mass flow rate	mass flow rate
Totalizers	Volume (+)	totalizer for the volumetric flow rate in positive flow direction
	Volume (-)	totalizer for the volumetric flow rate in negative flow direction
	Volume (Δ)	difference of the totalizers for the positive and negative flow direction
	Mass (+)	totalizer for the mass flow rate in positive flow direction
	Mass (-)	totalizer for the mass flow rate in negative flow direction
	Mass (Δ)	difference of the totalizers for the positive and negative flow direction

Tab. 18.1: Source items

source item	list item	output
Fluid properties	Fluid temp.	fluid temperature
	Fluid pressure	fluid pressure
	Fluid density	fluid density
	Kin. viscosity	kinematic viscosity
	Dyn. viscosity	dynamic viscosity
	Compress. coeff.	gas compressibility coefficient
Diagnostic values	Crest factor	signal-to-noise ratio for the cross correlation function
	Transducer temp.	transducer temperature
Miscellaneous	Custom. Input 1	measured values of input quantities (e.g., temperature, density) which are not used for calculation  In the menu item Inputs\Assign inputs it is possible to assign configured inputs to customized inputs.
	Custom. Input 2	
	Custom. Input 3	
	Custom. Input 4	

Afterwards the properties of the event trigger are defined.

Tab. 18.2: Properties of the event trigger

property	setting	description
Function (switching condition)	MAX (x>limit)	The event trigger switches when the measured value exceeds the upper limit.
	MIN (x<limit)	The event trigger switches when the measured value falls below the lower limit.
	ERR (x=fail)	The event trigger switches when a measurement is not possible.
	Within range	The event trigger switches when the measured value is within the defined range.
	Out of range	The event trigger switches when the measured value is outside the defined range.
Type (holding behavior)	Non-hold	When the switching condition is no longer met, the event trigger returns to the idle state after approx. 1 s.
	Hold	The event trigger remains activated even when the switching condition is no longer met.
	Hold for a while	The event trigger remains activated during a defined time even when the switching condition is no longer met.

**Definition of the switching condition**

Functions\Event trigger\Enable Rx\Source item\...\Function

- Select the switching condition.
- Press ENTER.

**Definition of the holding behavior**

Functions\Event trigger\Enable Rx\Source item\...\Type

- Select the type of the holding behavior.
- Press ENTER.

### Definition of trigger limits

```
Functions\Event trigger\Enable Rx\Source item...\Trigger value
```

The limits are to be entered at which the event trigger has to switch.

- Enter the upper limit MAX ( $x > \text{limit}$ ).
- Press ENTER.
- Enter the lower limit MIN ( $x < \text{limit}$ ).
- Press ENTER.

```
Functions\Event trigger\Enable Rx\Source item...\Hysteresis
```

It is possible to define a hysteresis to avoid constant switching of the event trigger.

The event trigger is activated when the measured values exceed the upper limit. It is deactivated when the measured values fall below the lower limit.

- Enter the value for the hysteresis.
- If zero is entered, no hysteresis is used.
- Press ENTER.

#### Example

```
MAX ( $x > \text{limit}$ ): 30 m3/h
```

```
Hysteresis: 1 m3/h
```

The event trigger is activated for measured values  $> 30.5 \text{ m}^3/\text{h}$  and deactivated for measured values  $< 29.5 \text{ m}^3/\text{h}$ .

```
Functions\Event trigger\Enable Rx\Source item...\Range center
```

- Enter the center of the range in which the event trigger has to be switched.
- Press ENTER.

```
Functions\Event trigger\Enable Rx\Source item...\Range width
```

- Enter the width of the range in which the event trigger has to be switched.
- Press ENTER.

#### Example

```
Function: Out of range
```

```
Range center: 100 m3/h
```

```
Range width: 40 m3/h
```

The event trigger will switch if the measured value is below  $80 \text{ m}^3/\text{h}$  or above  $120 \text{ m}^3/\text{h}$ .

### Definition of the switching delay

```
Functions\Event trigger\Enable Rx\Source item...\Glitch interval
```

- Enter a time interval after which the event trigger has to switch in case the event occurred.
- Press ENTER.

```
Functions\Event trigger\Enable Rx\Source item...\Failure delay
```

- Enter a time interval after which the event trigger has to be deactivated in case of a measurement failure.
- Press ENTER.



### 18.5.1 Apparent switching delay

The measured values and totalizer values will be displayed rounded according to the set number of decimal places. The limits, however, will be compared to the non-rounded measured values. This might cause an apparent switching delay when the measured value changes marginally (less than the visualized decimal places). In this case, the switching accuracy of the event trigger is higher than the accuracy of the display.

### 18.5.2 Reset and initialization of the event triggers

After an initialization of the transmitter all event triggers are deactivated.

Event triggers whose switching condition is still met will be activated again after 1 s. This function is used to reset event triggers of the type `HOLD` if the switching condition is no longer met.

If a measurement is stopped, all event triggers will be deactivated and the corresponding process outputs will be de-energized, independently of the programmed idle state.

### 18.5.3 Event trigger during the measurement

An event trigger with the switching condition `MAX (x>limit)`, `MIN (x<limit)`, `Within range` or `Out of range` is updated max. once per second to avoid a constant switching of the event trigger (in case the measured values fluctuate around the value of the switching condition).

An event trigger with switching condition `ERR (x=fail)` is activated during a measurement failure.

An event trigger of the type `Non-hold` is activated when the switching condition is met. It is deactivated when the switching condition is no longer met. But it remains activated for at least 1 s even when the switching condition is met for a shorter period of time.


An event trigger of the type `Hold` is activated when the switching condition is met. It remains activated even when the switching condition is no longer met.

An event trigger of the type `Hold for a while` is activated when the switching condition is met. The time after which the deactivation takes place is defined in the menu item `Hold interval`.





### 18.5.4 Status display of the event triggers

<b>Notice!</b>
There is no visual or acoustic indication of event trigger switching.















The state of the event triggers is displayed during the measurement.

- Press  to scroll through the second line from below until the event trigger status is displayed.


The status display of the event triggers is structured as follows.

R<sub>x</sub> =    with X being the number of the event trigger and  a pictogram according to Tab. 18.3.


Tab. 18.3: Pictograms for the status display of the event triggers

	no.		Function (switching condition)	Type (holding behavior)	current state
<b>R</b>		=			
	1		 MAX (x>limit)	 Non-hold	 deactivated (false state)
	2		 MIN (x<limit)	 Hold	 activated (true state)
	3		 Within range	 Hold for a while	
	4		 Out of range		
			 ERR (x=fail)		


### Example

R1 = 

## 18.6 Event log

If an error occurs, an error message will be displayed in the first line indicating the symbol . The error message can be displayed.

Storage\Event log

- Select the menu item `Event log` in the menu `Storage`.
  - Press ENTER.
- A list is displayed containing all error messages since the last time the transmitter was switched on.
- Press  to select an error message.
  - Press ENTER.

The display indicates the cause of the error.

### Notice!

After reading out the event protocol the error message symbol will be deleted on the display, even if the error has not been eliminated yet.

The event protocol will be deleted after a restart of the transmitter.

## 19 Settings

### 19.1 Dialogs and menus

Miscellaneous\Dialogs/Menu

- Select the menu item `Dialogs/Menu` in the menu `Miscellaneous`.
- Press ENTER.

#### Pipe circumference

Miscellaneous\Dialogs/Menu\Pipe circumference

- Press ENTER until the menu item `Pipe circumference` is displayed.
- Select `Yes` if the pipe circumference is to be entered instead of the pipe diameter in the menu `Parameters`.
- Press ENTER.

If `Yes` is selected for `Pipe circumference`, the outer pipe diameter will still be requested in the menu `Parameters`.

- Enter zero. The menu item `Pipe circumference` will be displayed.
- Press ENTER.

The value displayed in the menu item `Pipe circumference` is calculated from the last displayed outer pipe diameter.

Example:  $100 \text{ mm} \cdot \pi = 314.2 \text{ mm}$

- Enter the pipe circumference. The limits for the pipe circumference are calculated on the basis of the limits for the outer pipe diameter.
- Press ENTER.

During the next scroll through the menu `Parameters`, the outer pipe diameter that corresponds to the entered pipe circumference will be displayed.

Example:  $180 \text{ mm} : \pi = 57.3 \text{ mm}$

#### Coating

If the pipe has a coating, the material parameters of the coating have to be entered in the menu `Parameters`.

Miscellaneous\Dialogs/Menu>Edit coating

- Press ENTER until the menu item `Edit coating` is displayed.
- Select `Yes` if the pipe has a coating.
- Press ENTER.

#### Lining 2

If the pipe has a second lining, the material parameters of the second lining have to be entered in the menu `Parameters`.

Miscellaneous\Dialogs/Menu>Edit Lining 2

- Press ENTER until the menu item `Edit Lining 2` is displayed.
- Select `Yes` if the pipe has 2 linings.
- Press ENTER.

#### Measuring point number

Miscellaneous\Dialogs/Menu\Measuring point no.

- Press ENTER until the menu item `Measuring point no.` is displayed.
- Select `Number` if the measuring point number should only consist of numeric characters. Select `Text` if the measuring point number should only consist of alphabetic characters.
- Press ENTER.

### Error delay

The error delay is the time after which an error value will be sent to an output if no valid measured values are available.

```
Miscellaneous\Dialogs/Menus/Error delay
```

- Press ENTER until the menu item `Error delay` is displayed.
- Select `Edit` to enter an error delay. Select `Damping` if the damping factor is to be used as the error delay.
- Press ENTER.

### Temperature correction

```
Miscellaneous\Dialogs/Menus/Tx temperature offset
```

- Press ENTER until the menu item `Tx temperature offset` is displayed.
- Select `Yes` to enable the input of a temperature correction for each temperature input.
- Press ENTER.

### Transducer distance

```
Miscellaneous\Dialogs/Menus/Transducer distance
```

- Press ENTER until the menu item `Transducer distance` is displayed.
- Select `Customized` if the measuring point is always the same. Select `Automatic` if the measuring point often changes.
- Press ENTER.

In the menu `Measurement`, the recommended transducer distance will be displayed in parenthesis, below the entered transducer distance.

### Display of the last value

```
Miscellaneous\Dialogs/Menus/Display last value
```

- Press ENTER until the menu item `Display last value` is displayed.
- Select `Yes` to display the last valid value.
- Press ENTER.

If `Yes` is selected and no valid measured value can be displayed during the measurement, the last valid value will be displayed. Behind this value an interrogation point will be displayed.

### Primary display value

```
Miscellaneous\Dialogs/Menus/Primary display value
```

- Press ENTER until the menu item `Primary display value` is displayed.
- Select `Flow quantity` to display the selected physical quantity value as primary value during the measurement. Select `Totalizer` to display the totalizer value as primary value during the measurement.
- Press ENTER.

### Switching off the display backlight

```
Miscellaneous\Dialogs/Menus/Light autom. off
```

- Press ENTER until the menu item `Light autom. off` is displayed.
- Select `Yes` to activate the automatic switch-off.
- Press ENTER.

If the automatic switch-off of the display backlight is activated, the backlight is switched off after about 30 s. When pressing a key or connecting a USB cable, the backlight is switched on again.

## 19.2 Measurement settings

Miscellaneous\Measurement\Measurement settings

- Select the menu item `Measurement` in the menu `Miscellaneous`.
- Press `ENTER`.
- Select the menu item `Measurement settings`.
- Press `ENTER`.

### Multi-point calibration

A multi-point calibration allows a very precise output of measuring results. It is based on calibration curves of series of measured values

Miscellaneous\Measurement\Measurement settings\Multi-point calibration

- Press `ENTER` until the menu item `Multi-point calibration` is displayed.
- Select `On` to activate the multi-point calibration. Select `Off` to deactivate it (default: `Off`).
- Press `ENTER`.

If `On` is selected, a series of measured values has to be entered in the menu item `Calibration\Multi-point calibration`.

### Swift damping

If `Swift damping` is activated, each displayed measured value is a floating average of the last `x` seconds, with `x` being the damping factor. The display thus requires `x` seconds to fully respond to flow rate changes.

If `Swift damping` is deactivated, the damping is calculated as first order low-pass filter, i.e. changes of measured values become effective in form of an exponential time course in the measuring result.

Miscellaneous\Measurement\Measurement settings\Swift damping

- Press `ENTER` until the menu item `Swift damping` is displayed.
- Select `Off` to deactivate the swift damping. Select `On` to activate it (default: `On`).
- Press `ENTER`.

### Dynamic damping

If dynamic damping is activated, volatile changes in the measured values of the selected physical quantity are transmitted through the transmitter without any time lag.

#### Important!

The dynamic damping will only have impact on the selected physical quantity. All other physical quantities are not dynamically damped.

Miscellaneous\Measurement\Measurement settings\Dynamic damping

- Press `ENTER` until the menu item `Dynamic damping` is displayed.
- Select `On` to activate the dynamic damping. Select `Off` to deactivate it (default: `Off`).
- Press `ENTER`.

If `On` is selected, the dynamic damping has to be parameterized in the menu item `Parameters\Dynamic damping`.

## 19.3 Units of measurement

It is possible to set the global units of measurement for length, temperature, pressure, sound speed, density and kinematic viscosity.

Miscellaneous\Units of measurement

- Select the menu item `Units of measurement` in the menu `Miscellaneous`.
- Press ENTER.
- Select a unit of measurement for all quantities.
- Press ENTER.

Miscellaneous\Units of measurement\Unit prefix

For better differentiation between the operating volumetric flow rate and the standard volumetric flow rate, the units of measurement can be displayed with a prefix. The unit of measurement of the operating volumetric flow rate is displayed with an A, the unit of measurement of the standard volumetric flow rate with an N or S.

- Select a list item for the setting of the prefix.
- Press ENTER.

Miscellaneous\Units of measurement\Barrel type

In this menu item it is possible to define which barrel type is to be displayed as unit of measurement for the operating volumetric flow rate.



- Select a barrel type.
- Press ENTER.

## 19.4 Material scroll list

At delivery, all stored materials are displayed in a scroll list in the menu item `Parameters\Pipe material`. For the sake of clarity, materials can be removed from the scroll list. Removed materials can be added at any time.

### Addition or removal of a material

Miscellaneous\Libraries\Use material list

- Select the menu item `Miscellaneous\Libraries\Use material list`.
- Press ENTER.
- Select `Yes` if a material is to be added to or removed from the material scroll list.
- Press ENTER.
- Press  to scroll through the list.
- Press  to add (+) or remove (-) a material.
- Press ENTER.

### Addition of all materials

Miscellaneous\Libraries\Use material list

- Select the menu item `Miscellaneous\Libraries\Use material list`.
- Press ENTER.
- Select `No` if all materials are to be displayed in the material scroll list.
- Press ENTER.

## 19.5 Working with parameter records

### 19.5.1 Introduction

Parameter records are data sets that contain all information necessary to perform a certain measurement task:

- pipe parameters
- transducer parameters
- fluid parameters
- output options

Working with parameter records will make repeated measurement tasks easier and faster. The transmitter can store max. 20 parameter records.

#### Notice!

No parameter records are stored in the delivery state. Parameter records have to be entered manually.

The parameters have first to be entered in the following menus `Parameters` and `Miscellaneous`. Afterwards, they can be stored as parameter record.

```
Miscellaneous\Param. record memo.
```

- Select the menu item `Param. record memo.` in the menu `Miscellaneous`.
- Press ENTER.
- Select the menu item `Save current record.`
- Press ENTER.

```
Miscellaneous\Param. record name
```

- Enter the name the parameter record has to be stored with.
- Press ENTER.

### 19.5.2 Load of a parameter record

Stored parameter records can be loaded and used for measurement.

```
Miscellaneous\Param. record memo.\Load param. record
```

- Select the menu item `Load param. record.`
- Press ENTER.
- Select the parameter record to be loaded.
- Press ENTER.

### 19.5.3 Deletion of parameter records

```
Miscellaneous\Param. record memo.\Delete param. record
```

- Select the menu item `Delete param. record.`
- Press ENTER.
- Select the parameter record to be deleted.
- Press ENTER.

## 19.6 Contrast settings

Miscellaneous\System settings\Display contrast

- Select the menu item `System settings` in the menu `Miscellaneous`.
- Press ENTER.
- Select the menu item `Display contrast`.
- Press ENTER.

The display contrast can be adjusted with the following keys:

- increase contrast
- CLR reduce contrast

- Press ENTER.

### Notice!

After an initialization of the transmitter, the display is reset to medium contrast.

## 19.7 HotCodes

Miscellaneous\System settings\HotCode

- Select the menu item `Miscellaneous` in the menu `System settings`.
- Press ENTER.
- Select the menu item `HotCode`.
- Press ENTER.
- Enter the `HotCode` via the keyboard. For the input of numbers see section 4.4.
- Press ENTER.

function	HotCode
display setting to medium contrast	555000
language selection	9090xx
initialization	909000
activation/deactivation of the flow direction detection	007026
display of totalizers in the lower line as well	007032



### Language selection

The language selection can either be carried out via the menu `Miscellaneous\System settings\Language` or a HotCode:

language	HotCode
English	909044
German	909049
French	909033
Spanish	909034
Dutch	909031
Russian	909007
Polish	909048
Turkish	909090
Italian	909039
Chinese	909086

After the last digit has been entered, the main menu is displayed in the selected language. The selected language remains activated when the transmitter is switched off and on again.

## 19.8 Key lock

An ongoing measurement can be protected from an inadvertent intervention by means of a key lock.

### Definition of a key lock code

- Select the menu item `System settings` in the menu `Miscellaneous`.
- Press ENTER.

`Miscellaneous\System settings\Key lock`

- Select the menu item `Key lock`.
- Press ENTER.
- Enter a 6-digit key lock code. For the input of numbers see section 4.4.
- Press ENTER.

### Notice!

Do not forget the key lock code!

### Deactivation of the key lock

`Miscellaneous\System settings\Key lock`

- Select the menu item `Miscellaneous` in the menu `System settings`.
- Press ENTER.
- Select the list item `Key lock`.
- Press ENTER.
- Enter a 6-digit key lock code. For the input of numbers see section 4.4.
- Press ENTER.

### Intervention in the measurement

If the key lock is activated, the message `Key lock activated` will be displayed for a few seconds when pressing a key. In order to interrupt a measurement, the key lock has to be deactivated.

- Press BRK.
- Select `Show parameters`.
- Press ENTER.
- Deactivate the key lock.


### Disabled functions with activated key lock

The following table gives an overview of the transmitter functions that are not available when the key lock is activated.


measurement not started	measurement started
<ul style="list-style-type: none"><li>• parameter input</li><li>• modification of settings (e.g., measuring modes)</li><li>• deletion of the data logger</li><li>• setting of time/date</li><li>• start of the measurement (start-up)</li></ul>	<ul style="list-style-type: none"><li>• modification of settings that can be changed during the measurement (e.g., language selection)</li><li>• triggering of snaps</li><li>• stop of totalizers</li><li>• reset of totalizers</li><li>• stop of measurement</li></ul>

# Annex

## A Menu structure




## Parameter input



**Legend**  
[1] only if enabled in the menu item Miscellaneous\Dialogs\Menus


## Data logger




**Legend**

[1] list of parameterized triggerable inputs and event triggers

### Measurement start




## Output configuration



**Legend**


- [1] only available for digital outputs supporting pulse output
- [2] requested only if the physical quantity can adopt a negative value
- [3] only if switchable current outputs are available

# Inputs




**Legend**  
[1] only if enabled in the menu item Miscellaneous\Dialogs/Menu





## Special settings




**Legend**

- [1] only in ExpertUser, SuperUser and SuperUser ext. mode
- [2] only with steam measurement

## Calibration

If Channel-based param. is selected for the configuration of the measuring point, the settings can be made individually for each measuring channel.




**Legend**


- [1] only if enabled in the menu item Miscellaneous\Measurement\Measurement settings
- [2] only in ExpertUser, SuperUser and SuperUser ext. mode
- [3] only in SuperUser and SuperUser ext. mode

## Results – overview


### Trigger




### Condition



### Action




## Definition of event triggers




Legend  
[1] depending on the selected function

## Remote functions


### 1 Trigger



### Condition



### 2 Action




**Legend**


- [1] depending on the selected function
- [2] only controllable via inputs
- [3] list of parameterized triggerable inputs and event triggers

## Event-based storing of measured values


### 1 Trigger



### Condition



### 2 Action



**Legend**

[1] depending on the selected function

## B Units of measurement

### Length/roughness

unit of measurement	description
mm	millimeter
in	inch

### Temperature

unit of measurement	description
°C	degree Celsius
°F	degree Fahrenheit

### Pressure

unit of measurement	description
bar (a)	bar (absolute)
bar (g)	bar (relative)
psi (a)	pound per square inch (absolute)
psi (g)	pound per square inch (relative)

### Density

unit of measurement	description
g/cm <sup>3</sup>	gram per cubic centimeter
kg/cm <sup>3</sup>	kilogram per cubic centimeter

### Sound speed

unit of measurement	description
m/s	meter per second
fps (ft/s)	foot per second

### Kinematic viscosity

unit of measurement	description
mm <sup>2</sup> /s	square millimeter per second

1 mm<sup>2</sup>/s = 1 cSt

### Flow velocity

unit of measurement	description
m/s	meter per second
cm/s	centimeter per second
in/s	inch per second
fps (ft/s)	foot per second



## Operating volumetric flow rate

unit of measurement	description	operating volume (totalized) <sup>(1)</sup>
m <sup>3</sup> /d	cubic meter per day	m <sup>3</sup>
m <sup>3</sup> /h	cubic meter per hour	m <sup>3</sup>
m <sup>3</sup> /min	cubic meter per minute	m <sup>3</sup>
m <sup>3</sup> /s	cubic meter per second	m <sup>3</sup>
km <sup>3</sup> /h	cubic kilometer per hour	km <sup>3</sup>
ml/min	milliliter per minute	l
l/h	liter per hour	l
l/min	liter per minute	l
l/s	liter per second	l
hl/h	hectoliter per hour	hl
hl/min	hectoliter per minute	hl
hl/s	hectoliter per second	hl
Ml/d (Megalit/d)	megaliter per day	Ml
bbbl/d <sup>(4)</sup>	barrel per day	bbbl
bbbl/h <sup>(4)</sup>	barrel per hour	bbbl
bbbl/m <sup>(4)</sup>	barrel per minute	bbbl
bbbl/s <sup>(4)</sup>	barrel per second	bbbl
USgpd (US-gal/d)	gallon per day	gal
USgph (US-gal/h)	gallon per hour	gal
USgpm (US-gal/m)	gallon per minute	gal
USgps (US-gal/s)	gallon per second	gal
KGPM (US-Kgal/m)	kilogallon per minute	kgal
MGD (US-Mgal/d)	million gallons per day	Mgal
CFD	cubic foot per day	cft <sup>(2)</sup>
CFH	cubic foot per hour	cft
CFM	cubic foot per minute	cft
CFS	cubic foot per second	aft <sup>(3)</sup>
MMCFD	million cubic feet per day	MMCF

<sup>(1)</sup> selection in the menu item Parameters\Units of measurement

<sup>(2)</sup> cft: cubic foot

<sup>(3)</sup> aft: acre foot

<sup>(4)</sup> In the menu item Miscellaneous\Units of measurement\Barrel type the barrel type to be displayed when setting the units of measurement for the operating volumetric flow rate and the totalized operating volume can be defined. If the barrel type Imperial (UK) is selected, imperial (UK) gallons instead of US gallons are used.

1 US-gal = 3.78541 l

1 UK-gal = 4.54609 l

US Barrel Oil = 42.0 US-gal ≈ 159 l

US Barrel Wine = 31.5 US-gal ≈ 119 l

US Barrel Beer = 31.0 US-gal ≈ 117 l

Imperial (UK) Barrel = 36.0 UK-gal ≈ 164 l

unit of measurement	description	operating volume (totalized) <sup>(1)</sup>
MMCFH	million cubic feet per hour	MMCF
Igpd (Imp-gal/d)	gallon per day	Igal
Igph (Imp-gal/h)	gallon per hour	Igal
Igpm (Imp-gal/m)	gallon per minute	Igal
Igps (Imp-gal/s)	gallon per second	Igal
IKGM (Imp-Kgal/m)	imperial kilogallon per minute	IKG
IMGD (Imp-Mgal/d)	million imperial gallons per day	IMG

- (1) selection in the menu item Parameters\Units of measurement
- (2) cft: cubic foot
- (3) aft: acre foot
- (4) In the menu item Miscellaneous\Units of measurement\Barrel type the barrel type to be displayed when setting the units of measurement for the operating volumetric flow rate and the totalized operating volume can be defined. If the barrel type Imperial (UK) is selected, imperial (UK) gallons instead of US gallons are used.

1 US-gal = 3.78541 l  
 1 UK-gal = 4.54609 l  
 US Barrel Oil = 42.0 US-gal ≈ 159 l  
 US Barrel Wine = 31.5 US-gal ≈ 119 l  
 US Barrel Beer = 31.0 US-gal ≈ 117 l  
 Imperial (UK) Barrel = 36.0 UK-gal ≈ 164 l

**Mass flow rate**

unit of measurement	description	mass (totalized)
t/h	ton per hour	t
t/d	ton per day	t
kg/h	kilogram per hour	kg
kg/min	kilogram per minute	kg
kg/s	kilogram per second	kg
g/s	gram per second	g
lb/d	pound per day	lb
lb/h	pound per hour	lb
lb/m	pound per minute	lb
lb/s	pound per second	lb
klb/h	kilopound per hour	klb
klb/m	kilopound per minute	klb

1 lb = 453.59237 g  
 1 t = 1000 kg

## C Reference

The following tables provide assistance for the user. The accuracy of the data depends on the composition, temperature and processing of the material. FLEXIM does not assume liability for any inaccuracies.

### C.1 Sound speed of selected pipe and lining materials at 20 °C

The values of some of these materials are stored in the internal database of the transmitter. Column  $c_{\text{flow}}$  shows the type of sound wave (longitudinal or transversal) used for the flow measurement.

material (display)	explanation	$c_{\text{trans}}$ [m/s]	$c_{\text{long}}$ [m/s]	$c_{\text{flow}}$
Carbon steel	steel, normal	3230	5930	trans
Stainless steel	steel, stainless	3100	5790	trans
DUPLEx	duplex stainless steel	3272	5720	trans
Titanium	titanium	3067	5955	trans
Copper	copper	2260	4700	trans
Aluminum	aluminum	3100	6300	trans
Cu-Ni-Fe	copper-nickel-iron alloy	2510	4900	trans

The sound speed depends on the composition and processing of the material. The sound speed of alloys and cast materials fluctuates strongly. The values only serve as an orientation.

### C.2 Typical roughness values of pipes

The values are based on experience and measurements.

material	absolute roughness [mm]
drawn pipes of non-ferrous metal, glass, plastics and light metal	0...0.0015
drawn steel pipes	0.01...0.05
fine-planed, polished surface	max. 0.01
planed surface	0.01...0.04
rough-planed surface	0.05...0.1
welded steel pipes, new	0.05...0.1
after long use, cleaned	0.15...0.2
moderately rusted, slightly encrusted	max. 0.4
heavily encrusted	max. 3
cast iron pipes:	
bitumen lining	> 0.12
new, without lining	0.25...1
rusted	1...1.5
encrusted	1.5...3

## D Legal information – open source licenses

The software of this product contains the following open-source software which is subject to the Apache license version 2.0 dated January 2004:

### 1. uC-TCP-IP

<https://github.com/weston-embedded/uC-TCP-IP/tree/v3.06.01>

<https://github.com/weston-embedded/uC-TCP-IP/blob/v3.06.01/LICENSE>

<https://github.com/weston-embedded/uC-TCP-IP/blob/v3.06.01/NOTICE>

ATTENTION ALL USERS OF THIS REPOSITORY:

The original work found in this repository is provided by Silicon Labs under the Apache License, Version 2.0.

Any third party may contribute derivative works to the original work in which modifications are clearly identified as being licensed under:

- (1) the Apache License, Version 2.0 or a compatible open source license; or
- (2) under a proprietary license with a copy of such license deposited.

All posted derivative works must clearly identify which license choice has been elected.

No such posted derivative works will be considered to be a "Contribution" under the Apache License, Version 2.0.

SILICON LABS MAKES NO WARRANTY WITH RESPECT TO ALL POSTED THIRD PARTY CONTENT AND DISCLAIMS ALL OTHER WARRANTIES OR LIABILITIES, INCLUDING ALL WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, OWNERSHIP, NON-INFRINGEMENT, AND NON-MISAPPROPRIATION.

In the event a derivative work is desired to be submitted to Silicon Labs as a "Contribution" under the Apache License, Version 2.0, a "Contributor" must give written email notice to [micrium@weston-embedded.com](mailto:micrium@weston-embedded.com). Unless an email response in the affirmative to accept the derivative work as a "Contribution", such email submission should be considered to have not been incorporated into the original work.

### 2. uC-Common

<https://github.com/weston-embedded/uC-Common/tree/v1.02.01>

<https://github.com/weston-embedded/uC-Common/blob/v1.02.01/LICENSE>

<https://github.com/weston-embedded/uC-Common/blob/v1.02.01/NOTICE>

ATTENTION ALL USERS OF THIS REPOSITORY:

The original work found in this repository is provided by Silicon Labs under the Apache License, Version 2.0.

Any third party may contribute derivative works to the original work in which modifications are clearly identified as being licensed under:

- (1) the Apache License, Version 2.0 or a compatible open source license; or
- (2) under a proprietary license with a copy of such license deposited.

All posted derivative works must clearly identify which license choice has been elected.

No such posted derivative works will be considered to be a "Contribution" under the Apache License, Version 2.0.

SILICON LABS MAKES NO WARRANTY WITH RESPECT TO ALL POSTED THIRD PARTY CONTENT AND DISCLAIMS ALL OTHER WARRANTIES OR LIABILITIES, INCLUDING ALL WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, OWNERSHIP, NON-INFRINGEMENT, AND NON-MISAPPROPRIATION.

In the event a derivative work is desired to be submitted to Silicon Labs as a "Contribution" under the Apache License, Version 2.0, a "Contributor" must give written email notice to [micrium@weston-embedded.com](mailto:micrium@weston-embedded.com). Unless an email response in the affirmative to accept the derivative work as a "Contribution", such email submission should be considered to have not been incorporated into the original work.

### 3. uC-DHCPc

<https://github.com/weston-embedded/uC-DHCPc/tree/v2.11.01>

<https://github.com/weston-embedded/uC-DHCPc/blob/v2.11.01/LICENSE>

<https://github.com/weston-embedded/uC-DHCPc/blob/v2.11.01/NOTICE>

ATTENTION ALL USERS OF THIS REPOSITORY:

The original work found in this repository is provided by Silicon Labs under the Apache License, Version 2.0.

Any third party may contribute derivative works to the original work in which modifications are clearly identified as being licensed under:

- (1) the Apache License, Version 2.0 or a compatible open source license; or
- (2) under a proprietary license with a copy of such license deposited.

All posted derivative works must clearly identify which license choice has been elected.

No such posted derivative works will be considered to be a "Contribution" under the Apache License, Version 2.0.

SILICON LABS MAKES NO WARRANTY WITH RESPECT TO ALL POSTED THIRD PARTY CONTENT AND DISCLAIMS ALL OTHER WARRANTIES OR LIABILITIES, INCLUDING ALL WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, OWNERSHIP, NON-INFRINGEMENT, AND NON-MISAPPROPRIATION.

In the event a derivative work is desired to be submitted to Silicon Labs as a "Contribution" under the Apache License, Version 2.0, a "Contributor" must give written email notice to [micrium@weston-embedded.com](mailto:micrium@weston-embedded.com). Unless an email response in the affirmative to accept the derivative work as a "Contribution", such email submission should be considered to have not been incorporated into the original work.

### 4. uC-LIB

<https://github.com/weston-embedded/uC-LIB/tree/v1.39.01>

<https://github.com/weston-embedded/uC-LIB/blob/v1.39.01/LICENSE>

<https://github.com/weston-embedded/uC-LIB/blob/v1.39.01/NOTICE>

ATTENTION ALL USERS OF THIS REPOSITORY:

The original work found in this repository is provided by Silicon Labs under the Apache License, Version 2.0.

Any third party may contribute derivative works to the original work in which modifications are clearly identified as being licensed under:

- (1) the Apache License, Version 2.0 or a compatible open source license; or
- (2) under a proprietary license with a copy of such license deposited.

All posted derivative works must clearly identify which license choice has been elected.

No such posted derivative works will be considered to be a "Contribution" under the Apache License, Version 2.0.

SILICON LABS MAKES NO WARRANTY WITH RESPECT TO ALL POSTED THIRD PARTY CONTENT AND DISCLAIMS ALL OTHER WARRANTIES OR LIABILITIES, INCLUDING ALL WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, OWNERSHIP, NON-INFRINGEMENT, AND NON-MISAPPROPRIATION.

In the event a derivative work is desired to be submitted to Silicon Labs as a "Contribution" under the Apache License, Version 2.0, a "Contributor" must give written email notice to [micrium@weston-embedded.com](mailto:micrium@weston-embedded.com). Unless an email response in the affirmative to accept the derivative work as a "Contribution", such email submission should be considered to have not been incorporated into the original work.

Apache License

Version 2.0, January 2004

<http://www.apache.org/licenses/>

## TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

## 1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50 %) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner. For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

2. Grant of Copyright License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.
3. Grant of Patent License. Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.
4. Redistribution. You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:
  - (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
  - (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
  - (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and

(d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

5. **Submission of Contributions.** Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.
6. **Trademarks.** This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.
7. **Disclaimer of Warranty.** Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.
8. **Limitation of Liability.** In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.
9. **Accepting Warranty or Additional Liability.** While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

## END OF TERMS AND CONDITIONS

### APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "[]" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright [yyyy] [name of copyright owner]

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.

See the License for the specific language governing permissions and limitations under the License.

For more information: **Emerson.com**

© 2024 Emerson. All rights reserved.

Emerson Terms and Conditions of Sale are available upon request.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Flexim is a mark of one of the Emerson family of companies. All other marks are the property of their respective owners.