

# Micro Motion® Marine Bunker Transfer Package

Certified Marine Bunker Measurement Solution



### Micro Motion customer service

Email:

- Worldwide: [flow.support@emerson.com](mailto:flow.support@emerson.com)
- Asia-Pacific: [APflow.support@emerson.com](mailto:APflow.support@emerson.com)

Telephone:

North and South America		Europe and Middle East		Asia Pacific	
United States	800-522-6277	U.K.	0870 240 1978	Australia	800 158 727
Canada	+1 303-527-5200	The Netherlands	+31 (0) 318 495 555	New Zealand	099 128 804
Mexico	+41 (0) 41 7686 111	France	0800 917 901	India	800 440 1468
Argentina	+54 11 4837 7000	Germany	0800 182 5347	Pakistan	888 550 2682
Brazil	+55 15 3413 8000	Italy	8008 77334	China	+86 21 2892 9000
Venezuela	+58 26 1731 3446	Central & Eastern	+41 (0) 41 7686 111	Japan	+81 3 5769 6803
		Russia/CIS	+7 495 981 9811	South Korea	+82 2 3438 4600
		Egypt	0800 000 0015	Singapore	+65 6 777 8211
		Oman	800 70101	Thailand	001 800 441 6426
		Qatar	431 0044	Malaysia	800 814 008
		Kuwait	663 299 01		
		South Africa	800 991 390		
		Saudia Arabia	800 844 9564		
		UAE	800 0444 0684		

# Contents

<b>Chapter 1</b>	<b>Orientation and planning</b> .....	<b>1</b>
1.1	About this application manual .....	1
1.2	Overview of the Micro Motion Certified Marine Bunker Measurement Solution .....	1
1.3	System types and requirements for the Marine Bunker Transfer Package .....	5
1.4	Additional documentation .....	9
<b>Chapter 2</b>	<b>Install the Series 3000 transmitter with the Marine Bunker Transfer Package</b> .....	<b>11</b>
2.1	System options and installation instructions .....	11
2.2	Install the Basic system .....	11
2.3	Install the Basic/MID system .....	15
2.4	Install the Profile system .....	18
2.5	Install the Profile/MID system .....	23
2.6	Install ferrite beads in transmitter wiring (if required) .....	28
<b>Chapter 3</b>	<b>Start up the system</b> .....	<b>31</b>
3.1	Power up the system .....	31
3.2	Perform optional startup tasks .....	32
<b>Chapter 4</b>	<b>Configure the system using the transmitter display</b> .....	<b>33</b>
4.1	Configure auxiliary devices .....	33
4.2	Configure basic flowmeter parameters .....	34
4.3	Configure bunker ticket options using the transmitter display .....	38
4.4	Configure communications .....	41
4.5	Secure and seal the transmitter .....	44
<b>Chapter 5</b>	<b>Operate the system from the transmitter display</b> .....	<b>47</b>
5.1	Transfer a bunker and print a ticket .....	47
5.2	Transfer a bunker, collect profile data, and print a ticket and/or a profile report .....	50
5.3	Marine Bunkering dashboard during bunker transfer .....	53
5.4	Process variables during a bunker transfer .....	54
5.5	Process noise due to vibration .....	55
5.6	Contents of bunker ticket for Basic and Profile systems .....	55
5.7	Contents of bunker ticket for Basic/MID and Profile/MID systems .....	61
5.8	Retrieve and reprint bunker tickets using the transmitter display .....	68
<b>Chapter 6</b>	<b>Use ProLink II with the Marine Bunkering Transfer Package</b> .....	<b>69</b>
6.1	Configure bunker ticket options using ProLink II .....	69
6.2	Transfer a bunker using ProLink II .....	72
6.3	Print or reprint a bunker ticket using ProLink II .....	74
6.4	View bunker transfer history .....	75
6.5	Contents of profile report .....	76
6.6	Print or export bunker transfer data using ProLink II .....	80
6.7	Maintain bunker transfer history .....	80
<b>Appendices and reference</b>		
<b>Appendix A</b>	<b>Integrated wiring diagrams</b> .....	<b>83</b>
A.1	Integrated wiring diagrams for Basic systems .....	83
A.2	Integrated wiring diagrams for Basic/MID systems .....	88

A.3	Integrated wiring diagrams for Profile systems .....	93
A.4	Integrated wiring diagrams for Profile/MID systems .....	98
<b>Appendix B</b>	<b>Printer setup .....</b>	<b>103</b>
B.1	Communications settings for the ticket printer .....	103
<b>Index</b> .....		<b>105</b>

# 1 Orientation and planning

## Topics covered in this chapter:

- [About this application manual](#)
- [Overview of the Micro Motion Certified Marine Bunker Measurement Solution](#)
- [System types and requirements for the Marine Bunker Transfer Package](#)
- [Additional documentation](#)

## 1.1 About this application manual

This application manual provides information required to install and operate the Series 3000 transmitter with the Marine Bunker Transfer Package.

This application manual is designed for use with the following manual: *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual*.

This application manual assumes that the transmitter display is used as the primary configuration and operation method. However, ProLink II can be used for most configuration and operation tasks. ProLink II also provides additional reporting and history features. Use of ProLink II is documented in [Chapter 6](#).

---

### Important

Use this application manual as your main guide for installation, configuration, and operation. You will be referred to other documentation for specific tasks and information.

---

## 1.2 Overview of the Micro Motion Certified Marine Bunker Measurement Solution

The Micro Motion Certified Marine Bunker Measurement Solution is a system that provides a complete solution for the measurement of marine fuel delivery. The system monitors aeration (entrained gas or entrained air), and supplies a bunker ticket with time and date, total amount transferred, and other relevant data.

The Certified Marine Bunker Measurement Solution includes an approved sensor, a Series 3000 transmitter, the Marine Bunker Transfer Package application running on the transmitter, the appropriate components from the Marine Bunker Instruments offering, and Micro Motion field services.

## 1.2.1 Marine Bunker Transfer Package

The Marine Bunker Transfer Package is a software application installed on a Series 3000 transmitter. The Marine Bunker Transfer Package manages the specialized measurement, monitoring, and ticket printing functions of the Certified Marine Bunker Measurement Solution. For Profile and Profile/MID systems, the Marine Bunker Transfer Package also handles communication with ProLink II.

### Measurement

The Marine Bunker Transfer Package provides flow measurement data that complies with OIML R117-1 and MID 2004/22/EC Annex MI-005. If the appropriate security hardware is installed, the system has been accredited by a certified technician, and OIML/MID-approved procedures are followed, the bunker ticket can be used as a legal (Weights & Measures) document.

### OIML R117-1 compliance

The Marine Bunker Transfer Package is designed to comply with measurement and operational requirements established by OIML. After the initial startup and certification, OIML R117-1 compliance includes four factors, or checks. For bunker transfer measurement data to meet OIML R117-1 requirements, the bunker transfer must pass all four checks.

The four checks are as follows:

- **MMQ check:** The size of the bunker transfer is above the threshold defined by Minimum Measured Quantity (MMQ). MMQ is specified during system certification.
- **Max Aeration check:** The potential measurement error due to aeration (entrained gas or entrained air), in combination with other sources of measurement error, is within MID limits as defined in MID 2004/22/EC Annex MI-005. The *Aeration Limit* diagnostic is used to monitor this factor.
- **Power check:** Power was continuous during the transfer (no power interrupt).
- **Alarm check:** No “bunker-critical” alarms have occurred since the last time a bunker ticket was printed.

If the bunker transfer fails one or more of these checks, the bunker transfer measurement data does not meet OIML R117-1 requirements and the ticket will show Overall OIML R117-1: Fail.

---

#### Note

*Aeration Limit* is always calculated and the four checks are always applied, whether or not an OIML/MID-compliant system was purchased and installed. If the system is not OIML/MID-compliant, there is no system performance traceability regardless of overall bunker pass/fail results.

---

### Minimum Measured Quantity (MMQ)

Minimum Measured Quantity (MMQ) defines the minimum quantity of fuel in a bunker transfer that is necessary to meet OIML/MID requirements.

MMQ is used to ensure that the bunker is sized appropriately for the sensor, and also to ensure that various factors related to starting and stopping flow do not have a significant effect on measurement accuracy. During initial system configuration, the service technician calculates and configures a site-specific value for MMQ. This value is typically not changed unless the piping is changed.

---

**Tip**

If you need to change the value of MMQ, contact Micro Motion customer service.

---

If the mass total of a bunker transfer meets or exceeds MMQ, the bunker transfer passes the MMQ check.

### Aeration and *Aeration Limit*

Aeration refers to entrained gas or entrained air in the process fluid. *Aeration Limit* is a real-time diagnostic that monitors the potential measurement error due to aeration and other factors, and compares the real-time value to the maximum allowable measurement error as defined by MID 2004/22/EC Annex MI-005. *Aeration Limit* is expressed as a percentage of the MID limit. If the value of *Aeration Limit* at the end of the bunker transfer is below 100%, the bunker measurement passes the Max Aeration check.

*Aeration Limit* is calculated continuously. During a bunker transfer, *Aeration Limit* can increase, decrease, or even exceed 100%. The current value of *Aeration Limit* is reported as follows:

- When the transfer total reaches 20% of Minimum Measured Quantity (MMQ), the display reports:

Medium Aeration Limit: <On> or <Off>

High Aeration Limit: <On> or <Off>

The thresholds for medium and high aeration are determined by the HI PV values assigned to Discrete Event 1 and Discrete Event 2. Default settings are 20 and 75 (i.e., 20% of the maximum allowable aeration and 75% of the maximum allowable aeration).

- When the transfer total reaches 100% of MMQ, the display reports one of the following:
  - Aeration Limit Pass (xxx%)
  - Aeration Limit Fail (xxx%)

where xxx is the current value of *Aeration Limit*.

The display is updated continuously, allowing the operator to take corrective action as required.

### Bunker-critical alarms

If a bunker-critical alarm occurs during a bunker transfer, the transfer fails the Alarm check and the measurement cannot be used to meet OIML/MID requirements. Not all alarms are bunker-critical.

**Table 1-1: Bunker-critical alarms and descriptions**

<b>Alarm code</b>	<b>Description</b>
A001	EEPROM Error (Core Processor)
A002	RAM Error (Core Processor)
A003	No Sensor Response
A004	Temperature Overrange
A005	Mass Flow Rate Overrange
A006	Characterization Required
A008	Density Overrange
A009	Transmitter Initializing/Warming Up
A014	Transmitter Failure
A016	Sensor RTD Failure
A017	T-Series RTD Failure
A018	EEPROM Error (Transmitter)
A019	RAM Error (Transmitter)
A020	No Flow Cal Value
A021	Incorrect Sensor Type (K1)
A022	Configuration Database Corrupt (Core Processor)
A023	Internal Totals Corrupt (Core Processor)
A024	Program Corrupt (Core Processor)
A025	Boot Sector Fault (Core Processor)
A026	Sensor/Transmitter Communications Failure
A027	Security Breach
A028	Core Processor Write Failure
A031	Low Power
A032	Meter Verification in Progress: Outputs to Fault
A033	Insufficient Right/Left Pickoff Signal
A103	Data Loss Possible (Totals and Inventories)
A107	Power Reset Occurred
A115	No External Input or Polled Data
A129	Internal Error (Display)
A133	Integrity Breach
A134	Memory Error (Display)
A135	Transmitter/Display Communications Error



## 1.2.2 Location

The Certified Marine Bunker Measurement Solution can be installed on a fuel barge or a vessel, or at a terminal.

## 1.3 System types and requirements for the Marine Bunker Transfer Package

The Marine Bunker Transfer Package can be set up in four different system types. Requirements depend on the type chosen during purchase.

**Table 1-2: Marine Bunker Transfer Package system types**

System type	Description	Requirements list
Basic system	Measure the bunker transfer and print bunker tickets only. The flow measurement and bunker tickets are not OIML/MID-approved.	See <a href="#">Table 1-3</a>
Basic/MID system	Measure the bunker transfer and print bunker tickets only. The flow measurement and bunker tickets are OIML/MID-approved.	See <a href="#">Table 1-4</a>
Profile system	Measure the bunker transfer and print bunker tickets and profile reports. The flow measurement and bunker tickets are not OIML/MID-approved. The profile report is not OIML/MID-approved.	See <a href="#">Table 1-5</a>
Profile/MID system	Measure the bunker transfer and print bunker tickets and profile reports. The flow measurement and bunker tickets are OIML/MID-approved. The profile report is not OIML/MID-approved.	See <a href="#">Table 1-6</a>

**Table 1-3: System requirements: Basic system**

Requirement	Component	Notes
Platform	Model 3500 or Model 3700 transmitter: <ul style="list-style-type: none"> <li>3500***3*****(F or H)**</li> <li>3700***3*****(F or H)**</li> </ul>	Not available with the Model 3300 or Model 3350 controller. For marine approvals, Model 3700 required.
Ticket printing	Non-MID-Approved Printer Option (Marine Bunker Instruments) <sup>(1)</sup>	Includes: <ul style="list-style-type: none"> <li>Standard ticket printer</li> <li>RS-485 to RS-232 signal converter</li> </ul>
Configuration tool	Local display ProLink II v2.94 or higher (optional) (Micro Motion Part PLK****)	
Operator interface	Local display ProLink II v2.94 or higher (optional) (Micro Motion Part PLK****)	

**Table 1-3: System requirements: Basic system (continued)**

Requirement	Component	Notes
Additional devices (Marine Bunker Instruments)	Pressure instrument	Included automatically with order.
	Temperature instrument	Included automatically with order. Used only to correct volume measurements to reference temperature, and not required for MID approval.
	Level switches	One or two, depending on sensor orientation. Included automatically with order.
	Check valve	Included automatically with order if Vessel option is selected.
Micro Motion field services		<ul style="list-style-type: none"> <li>• Site survey</li> <li>• Startup services</li> </ul>

(1) Not required if you do not need to print bunker tickets.

**Table 1-4: System requirements: Basic/MID system**

Requirement	Component	Notes
Platform	Model 3500 or Model 3700 transmitter: <ul style="list-style-type: none"> <li>• 3500***3*****(F or H)**</li> <li>• 3700***3*****(F or H)**</li> </ul>	Not available with the Model 3300 or Model 3350 controller. For marine approvals, Model 3700 required.
Ticket printing	MID-Approved Printer Option (Marine Bunker Instruments)	Includes: <ul style="list-style-type: none"> <li>• MID-approved ticket printer</li> <li>• MID-approved RS-485 to RS-232 signal converter</li> </ul>
Configuration tool	Local display ProLink II v2.94 or higher (optional) (Micro Motion Part PLK****)	
Operator interface	Local display ProLink II v2.94 or higher (optional) (Micro Motion Part PLK****)	
MID calibration for sensor		MID Calibration order option (BB appended to sensor model code).
Additional devices (Marine Bunker Instruments)	Pressure instrument	Included automatically with order.
	Temperature instrument	Included automatically with order. Used only to correct volume measurements to reference temperature, and not required for MID approval.
	Level switches	One or two, depending on sensor orientation. Included automatically with order.

**Table 1-4: System requirements: Basic/MID system (continued)**

Requirement	Component	Notes
	Check valve	Included automatically with order if Vessel option is selected.
Micro Motion field services		<ul style="list-style-type: none"> <li>• MID-specific site survey</li> <li>• MID-specific startup services (include system check and sealing)</li> </ul>

**Table 1-5: System requirements: Profile system**

Requirement	Component	Notes
Platform	Model 3500 or Model 3700 transmitter: <ul style="list-style-type: none"> <li>• 3500***3*****(F or H)**</li> <li>• 3700***3*****(F or H)**</li> </ul>	Not available with the Model 3300 or Model 3350 controller. For marine approvals, Model 3700 required.
Printing	Profile Printing Option (Marine Bunker Instruments)	Printer Interface Component. Includes: <ul style="list-style-type: none"> <li>• NEMA-approved enclosure</li> <li>• Factory-mounted relay and relay power supply</li> </ul>
	Non-MID-Approved Printer Option (Marine Bunker Instruments) <sup>(1)</sup>	Includes: <ul style="list-style-type: none"> <li>• Standard ticket printer</li> <li>• RS-485 to RS-232 signal converter</li> </ul>
	PC (customer-supplied) ProLink II v2.94 or higher (Micro Motion Part PLK****) RS-485 connection to relay (converter included) System printer (customer-supplied)	
Configuration tool	Local display ProLink II v2.94 or higher (Micro Motion Part PLK****)	
Operator interface	Local display ProLink II v2.94 or higher (Micro Motion Part PLK****)	
Additional devices (Marine Bunker Instruments)	Pressure instrument	Included automatically with order.
	Temperature instrument	Included automatically with order. Used only to correct volume measurements to reference temperature, and not required for MID approval.
	Level switches	One or two, depending on sensor orientation. Included automatically with order.

**Table 1-5: System requirements: Profile system (continued)**

Requirement	Component	Notes
	Check valve	Included automatically with order if Vessel option is selected.
Micro Motion field services		<ul style="list-style-type: none"> <li>• Site survey</li> <li>• Startup services</li> </ul>

(1) Not required if you do not need to print bunker tickets.

**Table 1-6: System requirements: Profile/MID system**

Requirement	Component	Notes
Platform	Model 3500 or Model 3700 transmitter: <ul style="list-style-type: none"> <li>• 3500***3*****(F or H)**</li> <li>• 3700***3*****(F or H)**</li> </ul>	Not available with the Model 3300 or Model 3350 controller. For marine approvals, Model 3700 required.
Printing	Profile Printing Option (Marine Bunker Instruments)	Printer Interface Component. Includes: <ul style="list-style-type: none"> <li>• NEMA-approved enclosure</li> <li>• Factory-mounted relay and relay power supply</li> </ul>
	MID-Approved Printer Option (Marine Bunker Instruments)	Includes: <ul style="list-style-type: none"> <li>• MID-approved ticket printer</li> <li>• MID-approved RS-485 to RS-232 signal converter</li> </ul>
	PC (customer-supplied) ProLink II v2.94 or higher (Micro Motion Part PLK****) RS-485 connection to relay (converter included) System printer (customer-supplied)	
Configuration tool	Local display ProLink II v2.94 or higher (Micro Motion Part PLK****)	
Operator interface	Local display ProLink II v2.94 or higher (Micro Motion Part PLK****)	
Additional devices (Marine Bunker Instruments)	Pressure instrument	Included automatically with order.
	Temperature instrument	Included automatically with order. Used only to correct volume measurements to reference temperature, and not required for MID approval.

**Table 1-6: System requirements: Profile/MID system (continued)**

Requirement	Component	Notes
	Level switches	One or two, depending on sensor orientation. Included automatically with order.
	Check valve	Included automatically with order if Vessel option is selected.
MID calibration for sensor		MID Calibration order option (BB appended to sensor model code).
Micro Motion field services		<ul style="list-style-type: none"> <li>• MID-specific site survey</li> <li>• MID-specific startup services (include system check and sealing)</li> </ul>

## 1.4 Additional documentation

**Table 1-7: Required and recommended documentation for the Certified Marine Bunker Measurement Solution**

Document	Use	Notes
Sensor installation manual	Basic installation instructions for the sensor	
Quick Reference Guide for your Series 3000 transmitter	Basic installation instructions for the transmitter	
<i>Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual</i>	Additional installation information for the transmitter General configuration, operation, and maintenance information	Provides information on configuring and operating the Series 3000 transmitter that is not specific to the Marine Bunkering Transfer Package.
ProLink II manual	General installation, connection, and operation information	Provides information on installing ProLink II and connecting to the transmitter. Also provides general information on using the ProLink II interface.
Vendor documentation for auxiliary devices	General installation, configuration, and operation information	



## 2 Install the Series 3000 transmitter with the Marine Bunker Transfer Package

### Topics covered in this chapter:

- *System options and installation instructions*
- *Install the Basic system*
- *Install the Basic/MID system*
- *Install the Profile system*
- *Install the Profile/MID system*
- *Install ferrite beads in transmitter wiring (if required)*


### 2.1 System options and installation instructions

The Series 3000 transmitter with the Marine Bunker Transfer Package is available in four system options. Follow the installation instructions for your system.

### 2.2 Install the Basic system

This procedure provides installation instructions for a system that measures the bunker delivery and prints bunker tickets. The bunker tickets are not OIML/MID-approved. If you do not need to print bunker tickets, the ticket printer is not required.

**Figure 2-1: Schematic of Basic system**



**Note**

*Model 3700 transmitter shown. If marine approvals are not required, the Model 3500 transmitter may also be used.*

### Prerequisites

Ensure that the sensor is correctly installed and ready for wiring.

Ensure that the auxiliary devices (level switches, pressure transmitter, and temperature transmitter) are correctly installed and ready for wiring to the Series 3000 transmitter.

Have the following available:

- Documentation:
  - *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual*
  - The Quick Reference Guide for your transmitter
  - Vendor documentation for all components
- Cable:
  - Power cable
  - Standard twisted-pair shielded signal cable

Locate all components to meet the following requirements:

- The maximum distance between the sensor and the core processor is 60 feet (20 meters). In a typical installation, the core processor is mounted directly on the sensor.
- The maximum distance between the core processor and the transmitter is 1000 feet (300 meters).
- The maximum length of an RS-485 connection is 3600 feet (1000 meters) at 9600 baud.
- The maximum length of an RS-232 connection is 15 feet (5 meters).
- The ticket printer and signal converter must be installed in a safe area.

Review power requirements for all components and ensure that you will be able to supply enough power.

---

### Important

For marine approvals (available only with the Model 3700 transmitter, and only if the Marine Approvals option was ordered), additional requirements apply to the following:

- Wiring between the sensor and the transmitter
- Transmitter I/O wiring
- Transmitter power wiring

See [Section 2.6](#) and incorporate the additional steps into your installation tasks.

---

### Important

During installation, refer to the appropriate integrated wiring diagram. See [Section A.1](#):

- For sensors mounted in a vertical pipe (Flag orientation), see [page 84](#).
  - For sensors mounted in a horizontal pipe (Tubes-down orientation), see [page 86](#).
-



## Procedure

1. Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* and the appropriate Quick Reference Guide to perform the following installation tasks:
  - a. Mount the transmitter.
  - b. Wire the transmitter to the sensor.
  - c. Wire the transmitter's secondary mA output and frequency output (if they will be used).
  - d. Wire power to the transmitter.
  - e. Ground the transmitter.
2. Wire the level switch (or switches) to Discrete Input 1 and to power.

When Discrete Input 1 is assigned to Start/Stop Totalizers (during configuration), it will start totalizers when there is liquid in the pipeline, and stop totalizers when there is no liquid in the pipeline.

3. (Optional) Set up an integrity detection loop and wire it to Discrete Input 2.

The integrity detection loop may be used to detect leaks, cable breakage, short circuits, and so on. Any preferred method or device can be used.
4. Set up a HART loop that connects the primary mA output to the external pressure transmitter and the external temperature transmitter.

---

## Notes

- The temperature transmitter is used only to correct volume measurements to reference temperature. It may not be required in your installation.
  - The Field Communicator can be connected to this loop.
- 

5. (Optional) Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* to wire Discrete Output 1 and Discrete Output 2 to signal devices such as lights or horns.

---

## Tip

When the Marine Bunker Transfer Package is installed, a special default configuration is implemented for Discrete Output 1, Discrete Output 2, Discrete Event 1, and Discrete Event 2:

- Discrete Event 1 is activated if *Aeration Limit* reaches 20% (medium aeration).
- Discrete Event 2 is activated if *Aeration Limit* reaches 75% (high aeration).
- Discrete Output 1 is assigned to Discrete Event 1.
- Discrete Output 2 is assigned to Discrete Event 2.

If this default configuration is retained and Discrete Output 1 and Discrete Output 2 are wired to signal devices, the signal devices will alert the operator if *Aeration Limit* reaches the 20% or 75% threshold. You can change the thresholds defined for medium and high aeration by changing the HI PV values for Discrete Event 1 and Discrete Event 2.

---

6. (Optional) Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* and the appropriate Quick Reference Guide to wire Discrete Output 3 as desired.
7. Install the ticket printer.
  - a. Connect the printer to power according to the instructions in the vendor documentation.
  - b. Set the DIP switches on the printer as shown in the following table.

**Table 2-1: DIP switch settings for Epson TM-U295 printer**

DIP switch	Setting	Printer communication parameters
1	OFF	Baud: 9600 Parity: Even Data bits: 8 Stop bits: 1 Characters per second: 32 Buffer size: 512
2	OFF	
3	OFF	
4	OFF	
5	ON	
6	ON	
7	OFF	
8	OFF	
9	OFF	
10	OFF	

- c. Attach the adapter to the signal converter.
 

An RS-485 to RS-232 signal converter and a DB9 to DB25 adapter were supplied with the system.
- d. Plug the adapter into the terminal block on the printer.
- e. Connect the RS-485 terminals on the signal converter to the RS-485 terminals on the transmitter.


**Table 2-2: RS-485 connections between signal converter and transmitter**

RS-485 terminal	Signal converter terminals	Transmitter terminals		
		Model 3700	Model 3500 with screw-type or solder terminals	Model 3500 with I/O cables
RS-485/A	Terminal 1	12	a32	25
RS-485/B	Terminal 2	11	c32	24

## 2.3 Install the Basic/MID system

This procedure provides installation instructions for a system that measures the bunker delivery and prints bunker tickets. The bunker tickets are OIML/MID-approved.

**Figure 2-2: Schematic of Basic/MID system**



### Note

Model 3700 transmitter shown. If marine approvals are not required, the Model 3500 transmitter may also be used.

### Prerequisites

Ensure that the sensor is correctly installed and ready for wiring.

Ensure that the auxiliary devices (level switches, pressure transmitter, and temperature transmitter) are correctly installed and ready for wiring to the Series 3000 transmitter.

Have the following available:

- Documentation:
  - *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual*
  - The Quick Reference Guide for your transmitter
  - Vendor documentation for all components
- Cable:
  - Power cable
  - Standard twisted-pair shielded signal cable

Locate all components to meet the following requirements:

- The maximum distance between the sensor and the core processor is 60 feet (20 meters). In a typical installation, the core processor is mounted directly on the sensor.
- The maximum distance between the core processor and the transmitter is 1000 feet (300 meters).
- The maximum length of an RS-485 connection is 3600 feet (1000 meters) at 9600 baud.

- The maximum length of an RS-232 connection is 15 feet (5 meters).
- The ticket printer and signal converter must be installed in a safe area.

Review power requirements for all components and ensure that you will be able to supply enough power.

---

#### **Important**

For marine approvals (available only with the Model 3700 transmitter, and only if the Marine Approvals option was ordered), additional requirements apply to the following:

- Wiring between the sensor and the transmitter
- Transmitter I/O wiring
- Transmitter power wiring

See [Section 2.6](#) and incorporate the additional steps into your installation tasks.

---

#### **Important**

During installation, refer to the appropriate integrated wiring diagram. See [Section A.2](#):

- For sensors mounted in a vertical pipe (Flag orientation), see [page 89](#).
  - For sensors mounted in a horizontal pipe (Tubes-down orientation), see [page 91](#).
- 

#### **Procedure**

1. Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* and the appropriate Quick Reference Guide to perform the following installation tasks:
  - a. Mount the transmitter.
  - b. Wire the transmitter to the sensor.
  - c. Wire the transmitter's secondary mA output and frequency output (if they will be used).
  - d. Wire power to the transmitter.
  - e. Ground the transmitter.
2. Wire the level switch (or switches) to Discrete Input 1 and to power.

When Discrete Input 1 is assigned to Start/Stop Totalizers (during configuration), it will start totalizers when there is liquid in the pipeline, and stop totalizers when there is no liquid in the pipeline.

3. (Optional) Set up an integrity detection loop and wire it to Discrete Input 2.

The integrity detection loop may be used to detect leaks, cable breakage, short circuits, and so on. Any preferred method or device can be used.
4. Set up a HART loop that connects the primary mA output to the external pressure transmitter and the external temperature transmitter.

**Notes**

- The temperature transmitter is used only to correct volume measurements to reference temperature. It may not be required in your installation.
- The Field Communicator can be connected to this loop.

5. (Optional) Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* to wire Discrete Output 1 and Discrete Output 2 to signal devices such as lights or horns.

**Tip**

When the Marine Bunker Transfer Package is installed, a special default configuration is implemented for Discrete Output 1, Discrete Output 2, Discrete Event 1, and Discrete Event 2:

- Discrete Event 1 is activated if *Aeration Limit* reaches 20% (medium aeration).
- Discrete Event 2 is activated if *Aeration Limit* reaches 75% (high aeration).
- Discrete Output 1 is assigned to Discrete Event 1.
- Discrete Output 2 is assigned to Discrete Event 2.

If this default configuration is retained and Discrete Output 1 and Discrete Output 2 are wired to signal devices, the signal devices will alert the operator if *Aeration Limit* reaches the 20% or 75% threshold. You can change the thresholds defined for medium and high aeration by changing the HI PV values for Discrete Event 1 and Discrete Event 2.

6. (Optional) Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* and the appropriate Quick Reference Guide to wire Discrete Output 3 as desired.
7. Install the ticket printer.
- Connect the printer to power according to the instructions in the vendor documentation.
  - Set the DIP switches on the printer as shown in the following table.

**⚠ CAUTION!**

**The DIP switches are on the bottom of the printer, under the DIP switch cover. Power down the printer before removing the DIP switch cover.**

**Table 2-3: DIP switch settings for Epson TM-T88V printer**

Switch bank	DIP switch settings		Printer communication parameters
DSW1	Switch 1-1	OFF	Baud: 38400
	Switch 1-2	OFF	Parity: Even
	Switch 1-3	OFF	Data bits: 8
	Switch 1-4	OFF	Stop bits: 1
	Switch 1-5	ON	Characters per second: 400
	Switch 1-6	ON	Buffer size: 1024

**Table 2-3: DIP switch settings for Epson TM-T88V printer (continued)**

Switch bank	DIP switch settings		Printer communication parameters
	Switch 1-7	ON	
	Switch 1-8	ON	
DSW2	Switch 2-1	OFF	
	Switches 2-2 through 2-8	As desired	


- c. Attach the adapter to the signal converter.  
An RS-485 to RS-232 signal converter and a DB9 to DB25 adapter were supplied with the system.
- d. Plug the adapter into the terminal block on the printer.
- e. Connect the RS-485 terminals on the signal converter to the RS-485 terminals on the transmitter as shown in the following table.

**Table 2-4: RS-485 connections between signal converter and transmitter**

RS-485 terminal	Signal converter terminals	Transmitter terminals		
		Model 3700	Model 3500 with screw-type or solder terminals	Model 3500 with I/O cables
RS-485/A	Terminal 1	12	a32	25
RS-485/B	Terminal 2	11	c32	24

## 2.4 Install the Profile system

This procedure provides installation instructions for a system that measures the bunker delivery and prints bunker tickets and profile reports. The bunker tickets are not OIML/MID-approved. The profile report is not OIML/MID-approved. If you do not need to print bunker tickets, the ticket printer is not required.

**Figure 2-3: Schematic of Profile system****Note**

Model 3700 transmitter shown. If marine approvals are not required, the Model 3500 transmitter may also be used.

**Prerequisites**

Ensure that the sensor is correctly installed and ready for wiring.

Ensure that the auxiliary devices (level switches, pressure transmitter, and temperature transmitter) are correctly installed and ready for wiring to the Series 3000 transmitter.

Ensure that ProLink II v2.94 is installed on the PC you will use for bunkering, and that you have the appropriate ProLink II installation kit.

Have the following available:

- Documentation:
  - *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual*
  - The Quick Reference Guide for your transmitter
  - Vendor documentation for all components
- Cable:
  - Power cable
  - Standard twisted-pair shielded signal cable

Locate all components to meet the following requirements:

- The maximum distance between the sensor and the core processor is 60 feet (20 meters). In a typical installation, the core processor is mounted directly on the sensor.
- The maximum distance between the core processor and the transmitter is 1000 feet (300 meters).
- The maximum length of an RS-485 connection is 3600 feet (1000 meters) at 9600 baud.
- The maximum length of an RS-232 connection is 15 feet (5 meters).
- The Printer Interface Component must be installed in a safe area.
- The ticket printer and signal converter must be installed in a safe area.
- The PC and system printer must be installed in a safe area.

Review power requirements for all components and ensure that you will be able to supply enough power.

---

### Important

For marine approvals (available only with the Model 3700 transmitter, and only if the Marine Approvals option was ordered), additional requirements apply to the following:

- Wiring between the sensor and the transmitter
- Transmitter I/O wiring
- Transmitter power wiring

See [Section 2.6](#) and incorporate the additional steps into your installation tasks.

---

### Important


During installation, refer to the appropriate integrated wiring diagram. See [Section A.3](#):

- For sensors mounted in a vertical pipe (Flag orientation), see [page 94](#).
  - For sensors mounted in a horizontal pipe (Tubes-down orientation), see [page 96](#).
- 

### Procedure

1. Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* and the appropriate Quick Reference Guide to perform the following installation tasks:
  - a. Mount the transmitter.
  - b. Wire the transmitter to the sensor.
  - c. Wire the transmitter's secondary mA output and frequency output (if they will be used).
  - d. Wire power to the transmitter.
  - e. Ground the transmitter.
2. Mount the Printer Interface Component to any flat surface. See the following figure for mounting dimensions.



**Figure 2-4: Mounting dimensions for Printer Interface Component**

- A. Front view, width: 7.464 in (189.58 mm)
- B. Front view, height: 9.360 in (237.73 mm)
- C. Side view, width: 6.199 in (157.45 mm)
- D. Mounting plate, width: 2× 0.250 in (6.35 mm)
- E. Back view, height: 9.625 in (244.48 mm)
- F. Back view, space between mounting holes: 8.875 in (225.42 mm)
- G. Back view, width: 4.000 in (101.60 mm)
- H. Back view, space between mounting holes: 5.000 in (127.00 mm)
- I. Back view, size of mounting holes: 4× Ø0.308 in thru (7.81 mm)

3. Wire the level switch (or switches) to Discrete Input 1 and to power.

When Discrete Input 1 is assigned to Start/Stop Totalizers (during configuration), it will start totalizers when there is liquid in the pipeline, and stop totalizers when there is no liquid in the pipeline.

4. (Optional) Set up an integrity detection loop and wire it to Discrete Input 2.

The integrity detection loop may be used to detect leaks, cable breakage, short circuits, and so on. Any preferred method or device can be used.

5. Set up a HART loop that connects the primary mA output to the external pressure transmitter and the external temperature transmitter.

#### Notes

- The temperature transmitter is used only to correct volume measurements to reference temperature. It may not be required in your installation.
- The Field Communicator can be connected to this loop.

6. (Optional) Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* to wire Discrete Output 1 and Discrete Output 2 to signal devices such as lights or horns.

**Tip**

When the Marine Bunker Transfer Package is installed, a special default configuration is implemented for Discrete Output 1, Discrete Output 2, Discrete Event 1, and Discrete Event 2:

- Discrete Event 1 is activated if *Aeration Limit* reaches 20% (medium aeration).
- Discrete Event 2 is activated if *Aeration Limit* reaches 75% (high aeration).
- Discrete Output 1 is assigned to Discrete Event 1.
- Discrete Output 2 is assigned to Discrete Event 2.

If this default configuration is retained and Discrete Output 1 and Discrete Output 2 are wired to signal devices, the signal devices will alert the operator if *Aeration Limit* reaches the 20% or 75% threshold. You can change the thresholds defined for medium and high aeration by changing the HI PV values for Discrete Event 1 and Discrete Event 2.

7. Install the ticket printer.
  - a. Connect the printer to power according to the instructions in the vendor documentation.
  - b. Set the DIP switches on the printer as shown in the following table.

**Table 2-5: DIP switch settings for Epson TM-U295 printer**

DIP switch	Setting	Printer communication parameters
1	OFF	Baud: 9600 Parity: Even Data bits: 8 Stop bits: 1 Characters per second: 32 Buffer size: 128
2	OFF	
3	OFF	
4	OFF	
5	ON	
6	ON	
7	OFF	
8	OFF	
9	OFF	
10	OFF	

- c. Attach the adapter to the signal converter.
 

An RS-485 to RS-232 signal converter and a DB9 to DB25 adapter were supplied with the system.
    - d. Plug the adapter into the terminal block on the printer.
8. Wire the Printer Interface Component.
  - a. Open the Printer Interface Component.
  - b. Wire power to the relay power supply according to the instructions in the vendor documentation.
  - c. Wire the relay to Discrete Output 3 on the transmitter.

- d. Wire one set of RS-485 terminals on the relay to the RS-485 terminals on the transmitter.

**Table 2-6: RS-485 connections between transmitter and relay**

RS-485 terminal	Relay terminals	Transmitter terminals		
		Model 3700	Model 3500 with screw-type or solder terminals	Model 3500 with I/O cables
RS-485/A	Terminal 21	12	a32	25
RS-485/B	Terminal 11	11	c32	24

- e. Wire one set of RS-485 terminals on the relay to the RS-485 terminals on the signal converter.

**Table 2-7: RS-485 connections between signal converter and relay**


RS-485 terminal	Relay terminals	Signal converter terminals
RS-485/A	24	Terminal 1
RS-485/B	14	Terminal 2

- f. Close the Printer Interface Component.
9. Ensure that the PC is connected to the printer that you will use to print the profile report, and that this printer is defined as the default printer.

## 2.5 Install the Profile/MID system

This procedure provides installation instructions for a system that measures the bunker delivery and prints bunker tickets and profile reports. The bunker tickets are OIML/MID-approved. The profile reports are not OIML/MID-approved.

**Figure 2-5: Schematic of Profile/MID system**



**Note**

Model 3700 transmitter shown. If marine approvals are not required, the Model 3500 transmitter may also be used.

**Prerequisites**

Ensure that the sensor is correctly installed and ready for wiring.

Ensure that the auxiliary devices (level switches, pressure transmitter, and temperature transmitter) are correctly installed and ready for wiring to the Series 3000 transmitter.

Ensure that ProLink II v2.94 is installed on the PC you will use for bunkering, and that you have the appropriate ProLink II installation kit.

Have the following available:

- Documentation:
  - *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual*
  - The Quick Reference Guide for your transmitter
  - Vendor documentation for all components
- Cable:
  - Power cable
  - Standard twisted-pair shielded signal cable

Locate all components to meet the following requirements:

- The maximum distance between the sensor and the core processor is 60 feet (20 meters). In a typical installation, the core processor is mounted directly on the sensor.
- The maximum distance between the core processor and the transmitter is 1000 feet (300 meters).
- The maximum length of an RS-485 connection is 3600 feet (1000 meters) at 9600 baud.
- The maximum length of an RS-232 connection is 15 feet (5 meters).
- The Printer Interface Component must be installed in a safe area.
- The ticket printer and signal converter must be installed in a safe area.
- The PC and system printer must be installed in a safe area.

Review power requirements for all components and ensure that you will be able to supply enough power.

---

### Important

For marine approvals (available only with the Model 3700 transmitter, and only if the Marine Approvals option was ordered), additional requirements apply to the following:

- Wiring between the sensor and the transmitter
- Transmitter I/O wiring
- Transmitter power wiring

See [Section 2.6](#) and incorporate the additional steps into your installation tasks.

---

### Important


During installation, refer to the appropriate integrated wiring diagram. See [Section A.4](#):

- For sensors mounted in a vertical pipe (Flag orientation), see [page 99](#).
  - For sensors mounted in a horizontal pipe (Tubes-down orientation), see [page 101](#).
- 

### Procedure

1. Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* and the appropriate Quick Reference Guide to perform the following installation tasks:
  - a. Mount the transmitter.
  - b. Wire the transmitter to the sensor.
  - c. Wire the transmitter's secondary mA output and frequency output (if they will be used).
  - d. Wire power to the transmitter.
  - e. Ground the transmitter.
2. Mount the Printer Interface Component to any flat surface. See the following figure for mounting dimensions.

**Figure 2-6: Mounting dimensions for Printer Interface Component**



- A. Front view, width: 7.464 in (189.58 mm)
- B. Front view, height: 9.360 in (237.73 mm)
- C. Side view, width: 6.199 in (157.45 mm)
- D. Mounting plate, width: 2× 0.250 in (6.35 mm)
- E. Back view, height: 9.625 in (244.48 mm)
- F. Back view, space between mounting holes: 8.875 in (225.42 mm)
- G. Back view, width: 4.000 in (101.60 mm)
- H. Back view, space between mounting holes: 5.000 in (127.00 mm)
- I. Back view, size of mounting holes: 4× Ø0.308 in thru (7.81 mm)

3. Wire the level switch (or switches) to Discrete Input 1 and to power.

When Discrete Input 1 is assigned to Start/Stop Totalizers (during configuration), it will start totalizers when there is liquid in the pipeline, and stop totalizers when there is no liquid in the pipeline.

4. (Optional) Set up an integrity detection loop and wire it to Discrete Input 2.

The integrity detection loop may be used to detect leaks, cable breakage, short circuits, and so on. Any preferred method or device can be used.

5. Set up a HART loop that connects the primary mA output to the external pressure transmitter and the external temperature transmitter.

#### Notes

- The temperature transmitter is used only to correct volume measurements to reference temperature. It may not be required in your installation.
- The Field Communicator can be connected to this loop.

6. (Optional) Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* to wire Discrete Output 1 and Discrete Output 2 to signal devices such as lights or horns.

**Tip**

When the Marine Bunker Transfer Package is installed, a special default configuration is implemented for Discrete Output 1, Discrete Output 2, Discrete Event 1, and Discrete Event 2:

- Discrete Event 1 is activated if *Aeration Limit* reaches 20% (medium aeration).
- Discrete Event 2 is activated if *Aeration Limit* reaches 75% (high aeration).
- Discrete Output 1 is assigned to Discrete Event 1.
- Discrete Output 2 is assigned to Discrete Event 2.

If this default configuration is retained and Discrete Output 1 and Discrete Output 2 are wired to signal devices, the signal devices will alert the operator if *Aeration Limit* reaches the 20% or 75% threshold. You can change the thresholds defined for medium and high aeration by changing the HI PV values for Discrete Event 1 and Discrete Event 2.

7. Install the ticket printer.
  - a. Connect the printer to power according to the instructions in the vendor documentation.
  - b. Set the DIP switches on the printer as shown in the following table.

**⚠ CAUTION!**

**The DIP switches are on the bottom of the printer, under the DIP switch cover. Power down the printer before removing the DIP switch cover.**

**Table 2-8: DIP switch settings for Epson TM-T88V printer**

Switch bank	DIP switch settings		Printer communication parameters
DSW1	Switch 1-1	OFF	Baud: 38400
	Switch 1-2	OFF	Parity: Even
	Switch 1-3	OFF	Data bits: 8
	Switch 1-4	OFF	Stop bits: 1
	Switch 1-5	ON	Characters per second: 400
	Switch 1-6	ON	Buffer size: 1024
	Switch 1-7	ON	
	Switch 1-8	ON	
DSW2	Switch 2-1	OFF	
	Switches 2-2 through 2-8	As desired	

- c. Attach the adapter to the signal converter.
 

An RS-485 to RS-232 signal converter and a DB9 to DB25 adapter were supplied with the system.
    - d. Plug the adapter into the terminal block on the printer.

8. Wire the Printer Interface Component.
  - a. Open the Printer Interface Component.
  - b. Wire power to the relay power supply according to the instructions in the vendor documentation.
  - c. Wire the relay to Discrete Output 3 on the transmitter.
  - d. Wire one set of RS-485 terminals on the relay to the RS-485 terminals on the transmitter.

**Table 2-9: RS-485 connections between transmitter and relay**

RS-485 terminal	Relay terminals	Transmitter terminals		
		Model 3700	Model 3500 with screw-type or solder terminals	Model 3500 with I/O cables
RS-485/A	Terminal 21	12	a32	25
RS-485/B	Terminal 11	11	c32	24

- e. Wire one set of RS-485 terminals on the relay to the RS-485 terminals on the signal converter.

**Table 2-10: RS-485 connections between signal converter and relay**

RS-485 terminal	Relay terminals	Signal converter terminals
RS-485/A	24	Terminal 1
RS-485/B	14	Terminal 2

- f. Close the Printer Interface Component.
9. Ensure that the PC is connected to the printer that you will use to print the profile report, and that this printer is defined as the default printer.

## 2.6 Install ferrite beads in transmitter wiring (if required)

To comply with the RF (radio frequency) emissions limits specified in IACS E10 and Lloyd's Register Test Specification Number 1 (2002), ferrite beads must be installed on all cables connected to the Model 3700 transmitter. If the Marine Approvals option is ordered, Micro Motion supplies a set of ferrite beads to be used for this purpose.

### Restriction

This requirement applies only to installations that require marine approvals [i.e., Lloyd's Register, Bureau Veritas (BV), Det Norske Veritas (DNV), American Bureau of Shipping (ABS)]. For these installations, the Model 3700 transmitter is required.



---

### Prerequisites


- The set of four ferrite beads supplied with the Marine Approvals option: three small beads and one large bead
- Heat shrink (optional)

### Procedure

1. When wiring the transmitter to the sensor, loop all four wires through the large ferrite bead, and repeat, so that the wires form two complete loops around the bead. Position the bead close to the conduit openings on the transmitter, while leaving some slack in the wires.

---


**Figure 2-7: Large ferrite bead in sensor-to-transmitter wiring**



2. When wiring the transmitter to the power supply, loop all wires (two or three, depending on installation) through one of the small ferrite beads, so that the wires form one complete loop around the bead. Position the bead close to the conduit openings on the transmitter, while leaving some slack in the wires.

---

**Figure 2-8: Small ferrite bead in power wiring**



3. When wiring the transmitter to inputs and outputs, pass the I/O wires through one of the small ferrite beads. You may use one or two beads, as convenient. Position the bead close to the conduit openings on the transmitter, while leaving some slack in the wires.

---

### Tip

Micro Motion recommends looping the I/O wires, but loops are not required in this location.


---

**Figure 2-9: Small ferrite beads in I/O wiring**



4. (Optional) Apply heat shrink to stabilize the wires in the beads.
  5. Tuck the beads and wires into the available space inside the transmitter wiring compartment.
- 

**Figure 2-10: Ferrite beads in transmitter wiring compartment**



## 3 Start up the system

### Topics covered in this chapter:

- [Power up the system](#)
- [Perform optional startup tasks](#)

### 3.1 Power up the system

You must power up the transmitter, the ticket printer, and the relay power supply in the Printer Interface Component (when applicable).

1. Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* to power up the transmitter.

After the standard start-up sequence, the transmitter displays the Marine Bunkering dashboard. The Security Breach banner is displayed at the top of the screen.

2. Follow the instructions in the vendor documentation to power up the ticket printer.
3. (Optional) Power up the relay power supply in the Printer Interface Component.

#### 3.1.1 Marine Bunkering dashboard at system startup

The Marine Bunkering dashboard contains the display menus and controls that are used to configure the bunker ticket, perform a bunker transfer, and print the bunker ticket.

#### Options on the Marine Bunkering dashboard at system startup

If the Marine Bunker Transfer Package is installed, the transmitter automatically displays the Marine Bunkering dashboard when the system is first powered up.

The Marine Bunkering dashboard offers the following menu options:

- Bunker Operations
- Bunker Ticket Log (not displayed until a bunker transfer has been performed)
- Format Ticket

#### Exiting and returning to the Marine Bunkering dashboard

To access other areas of the display and menu system from the Marine Bunkering dashboard:

- Press the Exit button to access the View menu.
- Press the Security button to access the Management menu.

## 3.2 Perform optional startup tasks

Zeroing the flowmeter can be used to adjust measurement to local conditions. Testing the inputs and outputs ensures that signals are being sent and received. Trimming the mA outputs calibrates the mA output to the mA receiving device.

---

### Tip

In most cases, these tasks will be performed by the service technician who performs the system startup.

---

### Prerequisites

To perform these tasks, the transmitter must be unsecured.

---

### Important

If you send the transmitter to a calibration facility to perform a water calibration, either during startup or any time thereafter, LD Optimization must be disabled. To do this: Navigate to the Management menu, then select Configuration > Inputs > Core Processor > Sensor Cal Data . Scroll to LD Optimization and disable the feature (change Yes to No). When you have completed the calibration, re-enable LD Optimization.

---

### Procedure

1. At the transmitter, navigate to the Management menu.

---

### Tip

If you are at the Marine Bunkering dashboard, press the Security button.

---

2. Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* to perform these tasks, if appropriate.
  - a. Zero the flowmeter.
  - b. Perform loop tests on the mA outputs, frequency output, discrete outputs, and discrete inputs.
  - c. Trim the mA outputs.
3. Press the Exit button to return to the Marine Bunkering dashboard.

# 4 Configure the system using the transmitter display

## Topics covered in this chapter:

- *Configure auxiliary devices*
- *Configure basic flowmeter parameters*
- *Configure bunker ticket options using the transmitter display*
- *Configure communications*
- *Secure and seal the transmitter*

---

### Tip

In most cases, these tasks will be performed by the service technician who performs the system startup.

---

## 4.1 Configure auxiliary devices

The pressure transmitter, temperature transmitter, level switches, and integrity detection devices (if present) must be configured for use by the Series 3000 transmitter.

1. At the pressure transmitter:
  - a. Define a HART tag for polling.
  - b. Set the pressure unit to the unit to be used by the Series 3000 transmitter.
2. At the temperature transmitter:
  - a. Define a HART tag for polling.
  - b. Set the temperature unit to the unit to be used by the Series 3000 transmitter.
3. At the level switch (or switches):
  - a. Set Mode Switch to Wet On.
  - b. Set Switching Time Delay to 0.3 seconds.
4. (Optional) If your installation includes an integrity detection loop, configure the integrity detection devices as required to report leakage, broken cables, short circuits, or other malfunction.

## 4.2 Configure basic flowmeter parameters

Basic flowmeter parameters include the parameters that are part of standard transmitter configuration. Some parameters are configured automatically by the Marine Bunker Transfer Package. Some parameters are not applicable to systems with the Marine Bunker Transfer Package. You can configure the remaining parameters as appropriate for your installation.

### Prerequisites

Refer to *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* for detailed configuration instructions and access to menus.

To configure the transmitter, the transmitter must be unsecured.

When the Marine Bunker Transfer Package is installed, certain parameters are set specifically for marine bunkering installations (see [Section 4.2.1](#)). All other parameters are set to the transmitter defaults.

### Procedure

1. At the transmitter, navigate to the Management menu.

---

#### Tip

If you are at the Marine Bunkering dashboard, press the Security button.

---

2. Configure security and language.
  - a. Configure the maintenance and configuration passwords, and enable or disable them as desired.
  - b. Configure the language used on the display.

---

#### Restriction

The language selection does not apply to the Marine Bunker Transfer Package menus and displays. English is used for all Marine Bunker Transfer Package screens.

---

- c. Do not configure the Weights & Measures application.
  - d. Do not enable write-protection.
3. Configure system data and alarm severity.
  4. Enable core processor inputs.
  5. Configure process variables as desired.
  6. Configure sensor calibration data and sensor information for your sensor.
  7. Set Flow Direction.

Option	Description
Forward Only	Bunker transfers will be measured in one direction only: either loading or unloading. The Flow Direction arrow on the sensor matches the direction of flow.
Negate Forward Only	Bunker transfers will be measured in one direction only: either loading or unloading. The Flow Direction arrow on the sensor is opposite to the direction of flow.
Bi-Directional	Bunker transfers will be measured in two directions: both loading and unloading.

**Tip**

Forward Only and Negate Forward Only are typically used by shore facilities and vessels. Bi-Directional is used only by barges.

**Important**

If you set Flow Direction to Bi-Directional, ensure that the Mass Total value shown at the beginning of each transfer is 0.0. If it is not, contact Micro Motion.

8. Configure Discrete Input 1 for use with the level switch or switches.
  - a. Set Discrete Input 1 Polarity to Active Low.
  - b. Assign Start/Stop Totalizers to Discrete Input 1.

If the system is wired as recommended, totalizers will start when liquid is detected in the pipeline, and stop when no liquid is detected.
9. (Optional) Configure Discrete Input 2 for use in the integrity detection loop, if present in your installation.
  - a. Set Discrete Input 2 Polarity as required by the integrity detection device and the wiring.
  - b. Assign Integrity Breach to Discrete Input 2.

The transmitter will post Alarm 133: Integrity Detection if a problem with flow or wiring is detected.
10. (Optional) Configure Discrete Events 3, 4, and 5.
11. Configure polling for temperature.
 

Set External Tag to the tag defined at the temperature device.
12. Configure polling for pressure.
 

Set External Tag to the tag defined at the pressure device.
13. Configure other input parameters as desired.
14. Configure outputs.

- a. If Discrete Output 3 is wired to a relay to enable printing both bunker tickets and profile reports (Profile or Profile/MID systems), set the source variable to RS485 Dual Function.
- b. Configure all other outputs as desired.

---

**Tip**

When the Marine Bunker Transfer Package is installed, a special default configuration is implemented for Discrete Output 1, Discrete Output 2, Discrete Event 1, and Discrete Event 2:

- Discrete Event 1 is activated if *Aeration Limit* reaches 20% (medium aeration).
- Discrete Event 2 is activated if *Aeration Limit* reaches 75% (high aeration).
- Discrete Output 1 is assigned to Discrete Event 1.
- Discrete Output 2 is assigned to Discrete Event 2.

If this default configuration is retained and Discrete Output 1 and Discrete Output 2 are wired to signal devices, the signal devices will alert the operator if *Aeration Limit* reaches the 20% or 75% threshold. You can change the thresholds defined for medium and high aeration by changing the HI PV values for Discrete Event 1 and Discrete Event 2.

---

15. (Optional) Follow the instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* to configure the process monitor.

---

**Tip**

You can configure *Aeration Limit* as a display variable. Use this approach if you want to monitor *Aeration Limit* along with other variables that are not on the Marine Bunkering dashboard.

---

16. Press the Exit button to return to the Marine Bunkering dashboard.

## 4.2.1 Default parameter settings for the Marine Bunker Transfer Package

When the Marine Bunker Transfer Package is installed, the default values for certain parameters are different from the standard transmitter defaults.

Parameters that have different default values are listed in the following table. All other parameters have the standard defaults.

**Table 4-1: Parameters for Marine Bunker Transfer Package**

Parameter	Default values set by Marine Bunker Transfer Package	User configuration
Mass Flow Cutoff	8 tonnes/hr to 36 tonnes/hr, depending on sensor	As desired.
Mass Flow Measurement Unit	metric tonnes per hour	As desired.
Volume Flow Type	Liquid	As desired.
Volume Flow Measurement Unit	m3/hr	As desired.



**Table 4-1: Parameters for Marine Bunker Transfer Package (continued)**

Parameter	Default values set by Marine Bunker Transfer Package	User configuration
Volume Flow Cutoff	8 m <sup>3</sup> /hr to 37.5 m <sup>3</sup> /hr, depending on sensor	
Density Measurement Unit	kg/m <sup>3</sup>	As desired.
Slug High Limit	1.01 g/cm <sup>3</sup>	As desired
Slug Low Limit	0.2 g/cm <sup>3</sup>	As desired.
Slug Duration	0.1 second	As desired.
Density Cutoff	200 kg/m <sup>3</sup>	As desired.
API Table Type and other petroleum measurement parameters	23B	As desired.
Discrete Event 1	Process Variable = Aeration Limit Type = HI HI PV = 20	Micro Motion recommends leaving this at the default.
Discrete Event 2	Process Variable = Aeration Limit Type = HI HI PV = 75	Micro Motion recommends leaving this at the default.
Discrete Output 1	Assignment = Discrete Event 1	Micro Motion recommends leaving this at the default.
Discrete Output 2	Assignment = Discrete Event 2	Micro Motion recommends leaving this at the default.
Discrete Output 3	Assignment = None	<ul style="list-style-type: none"> <li>For Basic and Basic/MID systems, available for customer assignment.</li> <li>For Profile and Profile/MID systems, must be set to RS485 Dual Function.</li> </ul>
Protocol	Printer	
Printer	Epson TMT88	As appropriate for installed ticket printer.
Baud Rate	38400	As appropriate for installed ticket printer.
Parity	Even	Micro Motion recommends leaving this at the default.
Data Bits	8	Micro Motion recommends leaving this at the default.
Stop Bits	1	Micro Motion recommends leaving this at the default.
Characters Per Second	400	As appropriate for installed ticket printer.
Print Buffer Size	1024	As appropriate for installed ticket printer.

**Table 4-1: Parameters for Marine Bunker Transfer Package (continued)**

Parameter	Default values set by Marine Bunker Transfer Package	User configuration
Print Condition	No Flow	Required setting. Do not change.

## 4.3 Configure bunker ticket options using the transmitter display

The bunker ticket contains a standard set of process and bunker data, and can be configured to include additional process and bunker data. You can print one, two, or three tickets automatically.

### Prerequisites

To configure bunker ticket options, the transmitter must be unsecured.

### Procedure

1. Navigate to the Format Ticket menu.
2. Define Header 1, Header 2, and Footer as desired.

---

### Tip

You can change the header and footer parameters while the transmitter is secured. This allows you to use them for bunker-specific information if desired (for example, vessel name, purchaser name, and so on).

3. Choose Item Display Options and select the items to be printed on the ticket.

---

### Important

If you will be measuring bunker transfers in both directions (loading and unloading), you must enable Mass Inventory.

Option	Description
Mass Inventory	Total mass of all bunkers transferred since the last inventory reset, plus the two forward inventories and the two reverse inventories. Labels and values depend on the setting of the Mass In Air option.
Average Temperature	Temperature of the process fluid, averaged across the entire bunker and expressed as a batch-weighted average with the configured volume unit used as the batch.
Average API Density	Average density of the bunker, at reference temperature.
Aeration Limit	Value of <i>Aeration Limit</i> at the end of the bunker transfer.

Option	Description
Bunker Result <sup>(1)</sup>	Pass: The bunker transfer passed all four OIML/MID checks. Fail: The bunker transfer failed one or more of the four OIML/MID checks.
Bunker Result Details	Individual results for the four OIML/MID checks: <ul style="list-style-type: none"> <li>• MMQ check</li> <li>• Max Aeration check</li> <li>• Alarm check</li> <li>• Power check</li> </ul> These are printed only if Bunker Result = Fail.
Mass In Air	OFF: The total and inventory values on the ticket represent “true mass,” or “mass in vacuum.” The following labels are used: <ul style="list-style-type: none"> <li>• Mass Total</li> <li>• Bunker Begin Fwd Inv</li> <li>• Bunker End Fwd Inv</li> <li>• Bunker Begin Rev Inv</li> <li>• Bunker End Rev Inv</li> </ul> ON: The total and inventory values on the ticket represent “mass in air,” and the Mass in Air conversion factor is printed on the ticket. The following labels are used: <ul style="list-style-type: none"> <li>• Mass in Air</li> <li>• Begin Fwd Inv Air</li> <li>• End Fwd Inv Air</li> <li>• Begin Rev Inv Air</li> <li>• End Rev Inv Air</li> </ul>
Gross Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker at process temperature. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Net Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker, corrected to 15 °C. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.

Option	Description
SPRING TC Parameters	<p>ON: All ticket data is printed as configured.</p> <p>OFF: The following items are not printed, whether or not they were configured:</p> <ul style="list-style-type: none"> <li>• “Approved Measurement” banner</li> <li>• Gross Volume Total</li> <li>• Net Volume Total</li> <li>• Average API Density</li> <li>• Average Temperature</li> <li>• Aeration Limit</li> <li>• Bunker Result</li> <li>• Bunker Result Details</li> <li>• MID Certificate Number</li> <li>• Measurement accuracy statement</li> </ul> <p>If SPRING TC Parameters is set to OFF, the bunker ticket cannot be used as a legal receipt.</p>

(1) For Basic/MID and Profile/MID systems, Bunker Results is enabled and cannot be disabled.

**Note**

Certain items are always included on the ticket, and cannot be disabled.

4. Set Number of Tickets to the number of tickets to be printed by a single PRINT command.

The default value is 3. The range is 1 to 3.

On the first ticket, the word “Original” is printed at the bottom of the ticket. On the second and third tickets, the word “Copy” is printed at the bottom of the ticket.

**Tip**

You can change the Number of Tickets setting while the transmitter is secured.

### 4.3.1 Mass in air

Micro Motion flowmeters provide a “true mass” or “mass in vacuum” value for mass measurement. Weigh scales provide a “mass in air” value. Due to the buoyancy effect of the air around the object being weighed, the “mass in air” value is lower than the “mass in vacuum” value.

If Mass In Air is enabled, the transmitter will calculate the “mass in air” value, and print the “mass in air” total on the bunker ticket instead of the Mass Total (“mass in vacuum”) value.

To calculate “mass in air”, the transmitter multiplies the Mass Total value by the Mass in Air conversion factor: 0.998925. This constant is based on environmental conditions at sea level.

**Note**

The actual conversion factor varies according to current environmental conditions. However, the effect of this variability is extremely small and can be ignored for all practical purposes.

## 4.4 Configure communications

If you have a Basic or Basic/MID system, you must configure communications between the transmitter and the ticket printer. If you have a Profile or Profile/MID system, you must configure communications between the transmitter and the ticket printer and between the transmitter and ProLink II.

### 4.4.1 Configure communications for a Basic or Basic/MID system

This configuration allows you to print bunker tickets on the ticket printer.

**Prerequisites**

The transmitter must be unsecured.

**Procedure**

1. At the transmitter, navigate to the Management menu.

**Tip**

If you are at the Marine Bunkering dashboard, press the Security button.

2. Choose Configuration > Digital Communication .
3. Set Protocol to Printer.
4. Choose Configure Printer and set Printer Selection as required:

Option	Description
Epson TMU295	Standard ticket printer. Does not meet OIML/MID requirements. Use this option for Basic or Profile systems.
Epson TMT88	MID-approved ticket printer. Use this option for Basic/MID or Profile/MID systems.

5. Set other parameters as shown in the following table.

Parameter	Basic and Profile systems	Basic/MID and Profile/MID systems
Baud Rate	9600	38400
Parity	Even	Even
Data Bits	8	8

Parameter	Basic and Profile systems	Basic/MID and Profile/MID systems
Stop Bits	1	1
Characters Per Second	32	400
Print Buffer Size	128	1024
Lines Per Page	25 (not configurable)	25 (not configurable)

**Note**

Header Line 1, Header Line 2, and Footer were configured during ticket configuration. The display shows the configured values.

- (Optional) To test ticket printing, press EXIT to return to the previous menu, then press Printer Test.

**Need help?** If the ticket fails to print:

- Verify that the communications parameters in the transmitter are set appropriately for your printer.
- Verify that the DIP switches on the printer are set as recommended. See [Appendix B](#).
- Verify that the DIP switches on the signal converter are set as recommended. See [Appendix B](#).
- Verify all wiring between the transmitter and the printer. See [Appendix A](#).

## 4.4.2 Configure communications for a Profile or Profile/MID system

This configuration allows you to print bunker tickets on the ticket printer, to send data to the ProLink II bunkering database, and to print profile reports on the PC printer.

**Prerequisites**

The transmitter must be unsecured.

**Procedure**

- At the transmitter, navigate to the Management menu.

**Tip**

If you are at the Marine Bunkering dashboard, press the Security button.

- Choose Configuration > Digital Communication .
- Set Protocol to Printer.
- Choose Configure Printer and set Printer Selection as required:

Option	Description
Epson TMU295	Standard ticket printer. Does not meet OIML/MID requirements. Use this option for Basic or Profile systems.
Epson TMT88	MID-approved ticket printer. Use this option for Basic/MID or Profile/MID systems.

5. Set other parameters as shown in the following table.

Parameter	Basic and Profile systems	Basic/MID and Profile/MID systems
Baud Rate	9600	38400
Parity	Even	Even
Data Bits	8	8
Stop Bits	1	1
Characters Per Second	32	400
Print Buffer Size	128	1024
Lines Per Page	25 (not configurable)	25 (not configurable)

---

**Note**

Header Line 1, Header Line 2, and Footer were configured during ticket configuration. The display shows the configured values.

---

6. (Optional) To test ticket printing, press EXIT to return to the previous menu, then press Printer Test.

**Need help?** If the ticket fails to print:

- Verify that the communications parameters in the transmitter are set appropriately for your printer.
- Verify that the DIP switches on the printer are set as recommended. See [Appendix B](#).
- Verify that the DIP switches on the signal converter are set as recommended. See [Appendix B](#).
- Verify all wiring between the transmitter and the printer. See [Appendix A](#).

7. Set Protocol to Modbus RTU.

This is required because the ProLink II connection will be made before any tickets are printed. The system runs in RS-485 mode, and switches to Printer protocol automatically when printing tickets. After the ticket has printed, the system switches back to RS-485 mode.

8. (Optional) If you want to change the transmitter's address from the default (1), choose Configure Protocol and set Polling Address to the desired address.
9. (Optional) To test the connection from ProLink II:
- a. Start ProLink II and choose Connection > Connect to Device.

- b. In the ProLink II Connection dialog box, set Baud Rate, Parity, Stop Bits, and Address to the values that you set in the transmitter. Set Serial Port to the PC port that you are using for the connection. Then click Connect.
- c. Using the transmitter display, fix Discrete Output 3 ( Management > Maintenance > Diagnostics > Simulate Outputs > Discrete Outputs > Discrete Output 3 > On ).

The ProLink II connection will be broken, as shown in the ProLink II menu bar.

- d. Using the transmitter display, unfix Discrete Output 3.

ProLink II should reconnect automatically.

10. At the PC where ProLink II is installed, change the power options so that Windows will not turn off the monitor or the hard disks or go into standby mode during a bunker transfer.

To change the power options, use the Windows Control Panel.

---

**Tip**

Micro Motion recommends setting the PC power options to Never.

---

## 4.5 Secure and seal the transmitter

Securing the transfer protects it from accidental or unauthorized configuration changes. To meet Weights & Measures requirements (Basic/MID or Profile/MID systems), the transmitter must be sealed after it is secured.

### Prerequisites

Before securing the transmitter, ensure that all parameters are configured correctly, all required tests and calibrations have been performed, and that the system is performing correctly. After the transmitter has been secured, only basic operational procedures can be performed.

If you are setting up a Basic/MID or Profile/MID system, review the sealing instructions in *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* and arrange for a site visit from a certified Weights & Measures inspector.

### Procedure

1. To secure the transmitter, set the security switch on the transmitter to ON.

See *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* for detailed instructions on securing the transmitter.

---

**Note**

Although you can perform bunker transfers while the transmitter is unsecured, the ticket will contain a Security Breach banner, and the transfer will not meet OIML/MID requirements.

---



2. (Optional) To seal the transmitter, a wire seal must be installed in the designated location on the transmitter housing.

See *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual* for detailed instructions on sealing the transmitter. This function is typically performed by the Micro Motion service technician.

---

**Note**

You do not need to seal the transmitter to perform bunker transfers. Sealing the transmitter is required only if the bunker transfer must meet Weights & Measures requirements (Basic/MID or Profile/MID systems).

---



# 5 Operate the system from the transmitter display

## Topics covered in this chapter:

- *Transfer a bunker and print a ticket*
- *Transfer a bunker, collect profile data, and print a ticket and/or a profile report*
- *Marine Bunkering dashboard during bunker transfer*
- *Process variables during a bunker transfer*
- *Process noise due to vibration*
- *Contents of bunker ticket for Basic and Profile systems*
- *Contents of bunker ticket for Basic/MID and Profile/MID systems*
- *Retrieve and reprint bunker tickets using the transmitter display*

## 5.1 Transfer a bunker and print a ticket

This procedure guides you through transferring a bunker and printing a bunker ticket. For Basic systems, ticket printing is optional. For Basic/MID systems, ticket printing is required.

---

### Tip

If you want to print bunker-specific information on the bunker ticket, e.g., the vessel name, you can change the settings of Header 1, Header 2, and Footer while the transmitter is secured. You can also change the setting of Number of Tickets while the transmitter is secured.

---

### Prerequisites

Ensure that the transmitter is secured.

Ensure that you are complying with all other applicable procedures, e.g., procedures for your barge or vessel, procedures for OIML/MID compliance, etc.

Ensure that Mass Flow Rate is 0.0.

Check startup values:

- Shore facilities and vessels: Ensure that Mass Total is 0.0, or the site-specific Systemic Holdup value that was configured for your system during commissioning. If it is not, press the Print button to reset the totals.
- Barges: Ensure that Mass Total is 0.0. If it is not, press the Print button to reset the totals. If this does not correct the problem, contact Micro Motion.

---

### Tip

If your system does not include a ticket printer, a Reset button is displayed instead of the Print button. Press Reset to reset the totals.

---

Take appropriate precautions to ensure that flow occurs in only one direction during the bunker transfer. Small amounts of backflow due to valve action or other mechanical issues are insignificant, but larger amounts will affect measurement accuracy.

During the bunker transfer, take appropriate steps to ensure that Mass Flow Rate does not hover around 0. Very low values for Mass Flow Rate can affect measurement accuracy. Low values for Mass Flow Rate at the beginning and end of the bunker transfer have insignificant effects.

### Procedure

1. At the Marine Bunkering dashboard, select Bunker Operations.

---

#### Tip

If you are not at the Marine Bunkering dashboard, press the Exit button as required until the Marine Bunkering dashboard is displayed.

---

2. Start flow and totalizers.

If you have installed and configured the system as recommended, totalizers will be started automatically when liquid is detected in the pipeline. If a transmitter power cycle has occurred, totalizing does not begin until system startup procedures are complete.

3. At the Marine Bunkering dashboard, monitor bunker delivery and aeration. If necessary, take appropriate steps to reduce aeration.

---

#### Tips

- At 20% of Maximum Measured Quantity (MMQ), the display reports conditions of medium and high aeration. At 100% of MMQ, the display reports the current value of *Aeration Limit*.
  - During the bunker transfer, you can stop and restart flow as required. If you have installed and configured the system as recommended, totalizers will be stopped and restarted automatically.
- 

4. To end the bunker transfer:

- a. Stop flow.
- b. Press the Print button on the transmitter.

---

#### Important

- For systems without a ticket printer, a Reset button is displayed instead of the Print button. Use the Reset button to end the transfer.
- The Print button (or Reset button) is not available until Mass Flow Rate is 0 and the totals are non-zero.
- If the ticket queue in the transmitter contains unprinted tickets, transfer data will be lost when additional tickets are printed. Print the current ticket, then print all unprinted tickets before performing another bunker transfer. If this is the case, the transmitter displays an informational message.

- If the value Mass Total contains more digits than the display can handle, the transmitter shows 0 R (where “R” is the rollover indicator). However, because the underlying value is non-zero, the Print button is available.

The bunker ticket is printed on the ticket printer. If you have configured the system for multiple tickets, all tickets are printed at this time. All totals are automatically reset in preparation for the next bunker transfer. If Systemic Holdup is non-zero, it is applied now.

5. To view transfer data, see the bunker ticket. To determine the total amount transferred, see the following table.

**Table 5-1: Bunker transfer total from bunker ticket**

Installation	Flow Direction setting	Bunker transfer total	
Shore facility or vessel	Forward Only or Negate Forward	Any of the following: <ul style="list-style-type: none"> <li>• Mass Total</li> <li>• Mass in Air</li> <li>• Bunker End Forward Inv – Bunker Begin Forward Inv</li> <li>• End Fwd Inv Air – Begin Fwd Inv Air</li> </ul>	
Barge	Bi-directional	Transfer in same direction as Flow Direction arrow on sensor	Bunker End Forward Inv – Bunker Begin Forward Inv or End Fwd Inv Air – Begin Fwd Inv Air
		Transfer in opposite direction from Flow Direction arrow on sensor	Bunker End Reverse Inv – Bunker Begin Reverse Inv or End Rev Inv Air – Begin Rev Inv Air

### 5.1.1 Systemic Holdup

Systemic Holdup is a site-specific value that is calculated and configured during commissioning by the Micro Motion technician. It represents the amount of process fluid that may exist between the meter and the transfer point, or in the pipeworks, that cannot be measured by the meter because it has not flowed through the sensor.

When totals are reset at the end of a bunker transfer, in preparation for the next transfer, the Mass Total value is adjusted by the configured value of Systemic Holdup. Therefore, the value of Mass Total at the beginning of the transfer may not be 0.0.

#### Restriction

Systemic Holdup is not applicable to installations that use bi-directional measurement. These installations are typically barges. For all installations of this type, the value of Mass Total at the beginning of the transfer should always be 0.0.

The need for Systemic Holdup can be eliminated by good bunkering practices: Always have the pipeworks in the same state before and after the bunker transfer: either full/full or empty/empty.

---

**Important**

If you need to change the setting of Systemic Holdup, or if you want to change your bunkering procedures in a way that affects the fullness of the pipeworks before or after a bunker transfer, contact Micro Motion.

---

## 5.2 Transfer a bunker, collect profile data, and print a ticket and/or a profile report

This procedure guides you through transferring a bunker, collecting profile data, and printing a bunker ticket and/or a profile report, using the transmitter display. For Profile systems, ticket printing is optional. For Profile/MID systems, ticket printing is required.

---

**Tip**

If you want to print bunker-specific information on the bunker ticket, e.g., the vessel name, you can change the settings of Header 1, Header 2, and Footer while the transmitter is secured. You can also change the setting of Number of Tickets while the transmitter is secured.

---

**Prerequisites**

To print a bunker ticket, your system must include a ticket printer.

Ensure that the transmitter is secured.

Ensure that you are complying with all other applicable procedures, e.g., procedures for your barge or vessel, procedures for OIML/MID compliance, etc.

Ensure that Mass Flow Rate is 0.0.

Check startup values:

- Shore facilities and vessels: Ensure that Mass Total is 0.0, or the site-specific Systemic Holdup value that was configured for your system during commissioning. If it is not, press the Print button to reset the totals.
- Barges: Ensure that Mass Total is 0.0. If it is not, press the Print button to reset the totals. If this does not correct the problem, contact Micro Motion.

---

**Tip**

If your system does not include a ticket printer, a Reset button is displayed instead of the Print button. Press Reset to reset the totals.

---

Take appropriate precautions to ensure that flow occurs in only one direction during the bunker transfer. Small amounts of backflow due to valve action or other mechanical issues are insignificant, but larger amounts will affect measurement accuracy.

During the bunker transfer, take appropriate steps to ensure that Mass Flow Rate does not hover around 0. Very low values for Mass Flow Rate can affect measurement accuracy. Low values for Mass Flow Rate at the beginning and end of the bunker transfer have insignificant effects.

The transmitter must be ready to accept a connection from ProLink II. If you have trouble making the connection:

- Ensure that communications have been configured for a Profile or Profile/MID system.
- Ensure that the RS-485 terminals are in RS-485 mode, rather than service port mode.

### Procedure

1. Connect from ProLink II to the transmitter.
  - a. Start ProLink II.
  - b. Click Connection > Connect to Device .
  - c. Set Protocol, Baud Rate, Parity, and Stop Bits to the values configured in the transmitter.
  - d. Set Serial Port to the PC port you are using for the connection.
  - e. Set Address to the value configured for the transmitter. The default address is 1.
  - f. Click Connect.

If the connection is successful, the Marine Bunkering window is displayed.

---

#### Tip

To open the Marine Bunkering window, if you have closed it, choose Tools > Marine Bunker Transfer.

---

---

#### Important

For best results, ensure that ProLink II is connected to the transmitter for the entire bunker transfer. If the connection is dropped, data in the profile report and the ProLink II bunkering database will be incomplete. Check the power options on the PC and ensure that Windows will not turn off the monitor or the hard disks or go into standby mode during the bunker transfer.

---

2. Start flow and totalizers.

If you have installed and configured the system as recommended, totalizers will be started automatically when liquid is detected in the pipeline. If a transmitter power cycle has occurred, totalizing does not begin until system startup procedures are complete.

3. At the Marine Bunkering dashboard, monitor bunker delivery and aeration. If necessary, take appropriate steps to reduce aeration.

---

**Tips**

- At 20% of Maximum Measured Quantity (MMQ), the display reports conditions of medium and high aeration. At 100% of MMQ, the display reports the current value of *Aeration Limit*.
  - During the bunker transfer, you can stop and restart flow as required. If you have installed and configured the system as recommended, totalizers will be stopped and restarted automatically.
- 

4. To end the bunker transfer:
  - a. Stop flow.
  - b. Press the Print button, then select Print Ticket or Print Ticket & Report.

---

**Important**

- For systems without a ticket printer, a Reset button is displayed instead of the Print button. Use the Reset button to end the transfer.
  - The Print button (or Reset button) is not available until Mass Flow Rate is 0 and the totals are non-zero.
  - If the ticket queue in the transmitter contains unprinted tickets, transfer data will be lost when additional tickets are printed. Print the current ticket, then print all unprinted tickets before performing another bunker transfer. If this is the case, the transmitter displays an informational message.
  - If the value Mass Total contains more digits than the display can handle, the transmitter shows 0 R (where “R” is the rollover indicator). However, because the underlying value is non-zero, the Print button is available.
- 

The bunker ticket is printed on the ticket printer. If you have configured the system for multiple tickets, all tickets are printed at this time. The profile report is printed through ProLink II, and will appear on the default printer for the PC. All totals are automatically reset in preparation for the next bunker transfer. If Systemic Holdup is non-zero, it is applied now.

5. To view transfer data, see the bunker ticket. To determine the total amount transferred, see the following table.

**Table 5-2: Bunker transfer total from bunker ticket**

<b>Installation</b>	<b>Flow Direction setting</b>	<b>Bunker transfer total</b>	
Shore facility or vessel	Forward Only or Negate Forward	Any of the following: <ul style="list-style-type: none"> <li>• Mass Total</li> <li>• Mass in Air</li> <li>• Bunker End Forward Inv – Bunker Begin Forward Inv</li> <li>• End Fwd Inv Air – Begin Fwd Inv Air</li> </ul>	
Barge	Bi-directional	Transfer in same direction as Flow Direction arrow on sensor	Bunker End Forward Inv – Bunker Begin Forward Inv or End Fwd Inv Air – Begin Fwd Inv Air



**Table 5-2: Bunker transfer total from bunker ticket (continued)**

Installation	Flow Direction setting	Bunker transfer total	
		Transfer in opposite direction from Flow Direction arrow on sensor	Bunker End Reverse Inv – Bunker Begin Reverse Inv or End Rev Inv Air – Begin Rev Inv Air

## 5.2.1 Systemic Holdup

Systemic Holdup is a site-specific value that is calculated and configured during commissioning by the Micro Motion technician. It represents the amount of process fluid that may exist between the meter and the transfer point, or in the pipeworks, that cannot be measured by the meter because it has not flowed through the sensor.

When totals are reset at the end of a bunker transfer, in preparation for the next transfer, the Mass Total value is adjusted by the configured value of Systemic Holdup. Therefore, the value of Mass Total at the beginning of the transfer may not be 0.0.

### Restriction

Systemic Holdup is not applicable to installations that use bi-directional measurement. These installations are typically barges. For all installations of this type, the value of Mass Total at the beginning of the transfer should always be 0.0.

The need for Systemic Holdup can be eliminated by good bunkering practices: Always have the pipeworks in the same state before and after the bunker transfer: either full/full or empty/empty.

### Important

If you need to change the setting of Systemic Holdup, or if you want to change your bunkering procedures in a way that affects the fullness of the pipeworks before or after a bunker transfer, contact Micro Motion.

## 5.3 Marine Bunkering dashboard during bunker transfer

During a bunker transfer, the Marine Bunkering dashboard displays process variables that track the transfer.

**Table 5-3: Process variables on Marine Bunkering dashboard**

Parameter	Description	Comments
Mass Flow Rate	Current value of the process variable	

**Table 5-3: Process variables on Marine Bunkering dashboard (continued)**

Parameter	Description	Comments
Mass Total	Current value of the process variable	Measured since the last time the totals were reset (totals are reset automatically when an original ticket is printed or the Reset button is pressed).
Aeration Limit Fail	Measurement accuracy value for the current mass total, expressed as a percentage of the maximum allowable measurement error as defined by OIML/MID	Not displayed until the transfer reaches Minimum Measured Quantity (MMQ).
Medium Aeration Limit	<ul style="list-style-type: none"> <li>ON: The current value of Aeration Limit is above 20%</li> <li>OFF: The current value of Aeration Limit is below 20%</li> </ul>	20% is the default value. It can be changed by changing the value of HI PV defined for Discrete Event 1.
High Aeration Limit	<ul style="list-style-type: none"> <li>ON: The current value of Aeration Limit is above 75%</li> <li>OFF: The current value of Aeration Limit is below 75%</li> </ul>	75% is the default value. It can be changed by changing the value of HI PV defined for Discrete Event 2.
API Density	Current value of the process variable	
Temperature	Current value of the process variable	
Drive Gain	Current value of the diagnostic variable	
Field Verify Zero	Current value of the diagnostic variable	

## 5.4 Process variables during a bunker transfer

Due to the algorithms used to calculate the marine bunkering process variables, the transmitter may temporarily display values that do not reflect the current process.

### Aeration Limit

*Aeration Limit* is not shown on the transmitter display until the transfer total reaches 20% of MMQ.

At the beginning of the transfer, the end of the transfer, and any time that the flow rate is near 0, *Aeration Limit* may be very high. The overall effect on measurement accuracy is insignificant unless the flow rate was near 0 for extended periods.

### Volume totals and inventories

Volume Inventory is calculated from the real-time density data, and the inventory starts counting when the bunker starts.

Volume Total, Gross Volume Total, and Net Volume Total are calculated from average density data. Average density data is not calculated until the first ton of fluid has been measured. Until that time, these process variables are reported as 0. After one ton of fluid has been measured, the totalizer starts counting, applying the average density data to the measured mass and continuing forward.

## 5.5 Process noise due to vibration

Vibration generated by an external influence (for example, a pump) can influence the current meter measurement. Overall bunker accuracy and long-term measurement accuracy are not affected.

There are isolated instances when a specific vibration generated from an external influence (a pump, for instance) can influence the meter measurement. The interference causes a sinusoidal noise on the meter signal, although it does not affect the long-term accuracy of the meter.

If the interference is present, it is easily diagnosed by logging the mass flow rate using ProLink II, ProLink III, or a similar tool. Instead of a very stable mass flow signal, you will see a signal that has a very distinct sinusoidal characteristic. The amplitude of the noise will be less than approximately 1% of nominal flow rate. (For nominal flow rates, refer to the product data sheet for your sensor.)

If you observe measurement disturbances that may be caused by external vibration, consult the factory for assistance.

## 5.6 Contents of bunker ticket for Basic and Profile systems

---

### Note

Some items are optional and are printed only if selected during ticket configuration.

---

**Table 5-4: Contents of bunker ticket for Basic and Profile systems**

Ticket item	Description
Micro Motion Inc, Business Unit of Emerson	Banner printed at top of ticket
Header 1	User-defined text
Header 2	User-defined text
Transmitter Tag Name	User-configured string
System ID	HART software tag configured in the transmitter
BOL Number	Bill of Lading number, assigned automatically by the transmitter
Reset Time	Date and time that totals were reset, either by printing an original ticket or by pressing Reset
Print Time	Date and time that the original ticket was printed
Bunker Begin Time	Date and time that the transmitter started bunker measurement
Bunker End Time	Date and time that the transmitter stopped bunker measurement
Mass Total	Total mass of bunker, as measured by transmitter
Mass in Air	Total mass of bunker multiplied by the Mass in Air conversion factor
Mass Inventory	Total mass of all bunkers transferred since the last inventory reset

**Table 5-4: Contents of bunker ticket for Basic and Profile systems (continued)**

<b>Ticket item</b>	<b>Description</b>
Bunker Begin Forward Inventory	Value of Mass Forward Inventory at the beginning of the bunker transfer
Bunker End Forward Inventory	Value of Mass Forward Inventory at the end of the bunker transfer
Bunker Begin Reverse Inventory	Value of Mass Reverse Inventory at the beginning of the bunker transfer
Bunker End Reverse Inventory	Value of Mass Reverse Inventory at the end of the bunker transfer
Begin Forward Inventory Air	Value of Mass Forward Inventory at the beginning of the bunker transfer, multiplied by the Mass in Air conversion factor
End Forward Inventory Air	Value of Mass Forward Inventory at the end of the bunker transfer, multiplied by the Mass in Air conversion factor
Begin Reverse Inventory Air	Value of Mass Reverse Inventory at the beginning of the bunker transfer, multiplied by the Mass in Air conversion factor
End Reverse Inventory Air	Value of Mass Reverse Inventory at the end of the bunker transfer, multiplied by the Mass in Air conversion factor
Gross Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker at process temperature. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Net Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker, corrected to 15 °C. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Average Temperature	Average temperature of bunker, calculated as batch-weighted average with the configured volume unit used as the batch
Average API Density	Average density of the bunker, corrected to reference temperature
Aeration Limit	Value of <i>Aeration Limit</i> at the end of the bunker transfer
Alarm Occurred	<ul style="list-style-type: none"> <li>• Yes: One or more bunker-critical alarms was posted during the bunker transfer</li> <li>• No: No bunker-critical alarm was posted during the bunker transfer</li> </ul>
Aeration Limit	<ul style="list-style-type: none"> <li>• Pass: The value of <i>Aeration Limit</i> at the end of the transfer was within good-practice limits</li> <li>• Fail: The value of <i>Aeration Limit</i> at the end of the transfer was not within good-practice limits</li> </ul>
Minimum Quantity	<ul style="list-style-type: none"> <li>• Pass: <math>Mass\ Total \geq MMQ</math> (Minimum Measured Quantity)</li> <li>• Fail: <math>Mass\ Total &lt; MMQ</math></li> </ul>
No Power Interrupt	<ul style="list-style-type: none"> <li>• Pass: No power reset occurred during bunker transfer</li> <li>• Fail: Power reset occurred during bunker transfer</li> </ul>
Overall Bunker Results	Represents the combined results of the four OIML/MID checks: <ul style="list-style-type: none"> <li>• Pass: The bunker transfer measurement passed all four checks, and meets good-practice requirements.</li> <li>• Fail: The bunker transfer measurement failed one or more checks, and does not meet good-practice requirements.</li> </ul>

**Table 5-4: Contents of bunker ticket for Basic and Profile systems (continued)**

Ticket item	Description
Mass in Air footer	Statement of the Mass in Air conversion factor
IMPORTANT: Attach this ticket to BDN Report	Banner printed at bottom of ticket
Footer	User-defined text
Original	Printed automatically on the first printed ticket
Copy	Printed automatically on the second or third ticket
Duplicate Receipt	Printed automatically on all duplicate (reprinted) tickets
SECURITY BREACH Not A Legal Receipt	Banner printed at bottom of ticket if a security breach occurred during the transfer

## 5.6.1 Sample bunker tickets for Basic and Profile systems

These examples show bunker tickets for Basic and Profile systems, under different configurations and different Pass/Fail conditions. The date and time values are based on the transmitter date and time.

### Example: Basic or Profile ticket: Print no optional items

In the following sample ticket, the system is configured to print no optional items. The SPRING TC parameters are enabled.

#### Note

The ticket does not indicate whether the bunker transfer passed or failed any of the four checks. This may or may not be significant in your installation.

```

Micro Motion Inc, Business Unit of Emerson
[Header 1]
[Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time
26-MAR-2011 17:14:49

Print Time
26-MAR-2011 17:17:46

Bunker Begin Time
26-MAR-2011 17:15:21

Bunker End Time
26-MAR-2011 18:17:17

```

Mass Total  
32.9801 t

IMPORTANT: Attach this  
ticket to BDN Report  
[Footer]  
Original

**Example: Basic or Profile ticket: Print Mass Inventory**

In the following sample ticket, the system is configured to print Mass Inventory. The SPRING TC parameters are enabled. The forward and reverse inventories are printed automatically. A small amount of reverse flow occurred.

---

**Note**

The ticket does not indicate whether the bunker transfer passed or failed any of the four checks. This may or may not be significant in your installation.

---

Micro Motion Inc, Business Unit of Emerson  
[Header 1]  
[Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time  
26-MAR-2011 17:14:49

Print Time  
26-MAR-2011 17:17:46

Bunker Begin Time  
26-MAR-2011 17:15:21

Bunker End Time  
26-MAR-2011 18:17:17

Mass Total  
32.9801 t

Mass Inventory  
1432.2420 t

Bunker Begin Fwd Inv  
1420.3915 t

Bunker End Fwd Inv  
1452.3817 t

Bunker Begin Rev Inv  
1403.6547 t

Bunker End Rev Inv  
1403.6710 t

IMPORTANT: Attach this

ticket to BDN Report  
 [Footer]  
 Original

### Example: Basic or Profile ticket: Print all optional items; bunker transfer passed

In the following sample ticket, the system is configured to print all optional items. The SPRING TC parameters are enabled. The bunker transfer passed all four checks.

Micro Motion Inc, Business Unit of Emerson  
 [Header 1]  
 [Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time  
 26-MAR-2011 17:14:49

Print Time  
 26-MAR-2011 17:17:46

Bunker Begin Time  
 26-MAR-2011 17:15:21

Bunker End Time  
 26-MAR-2011 18:17:17

Mass in Air  
 32.9446 t

Mass Inventory  
 1432.2420 t

Begin Fwd Inv Air  
 1420.3915 t

End Fwd Inv Air  
 1452.3817 t

Begin Rev Inv Air  
 1403.6547 t

End Rev Inv Air  
 1403.6710 t

Gross Volume Total  
 32.9801 t

Net Volume Total  
 32.7492 t

Average Temperature  
 98.35 degF

Average API Density  
 0.93132 g/cm<sup>3</sup>

Aeration Limit  
 0.0029 %

Overall Bunker: Pass

The mass vacuum to mass air  
 conversion factor is: 0.998925

IMPORTANT: Attach this  
ticket to BDN Report  
[Footer]  
Original

**Example: Basic or Profile ticket: Print all optional items; bunker transfer failed**

In the following sample ticket, the system is configured to print all optional items. The SPRING TC parameters are enabled. The bunker transfer failed one of the four checks (the MMQ check).

Micro Motion Inc, Business Unit of Emerson  
[Header 1]  
[Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time  
26-MAR-2011 17:14:49

Print Time  
26-MAR-2011 17:17:46

Bunker Begin Time  
26-MAR-2011 17:15:21

Bunker End Time  
26-MAR-2011 18:17:17

Mass in Air  
32.9446 t

Mass Inventory  
1432.2420 t

Begin Fwd Inv Air  
1420.3915 t

End Fwd Inv Air  
1452.3817 t

Begin Rev Inv Air  
1403.6547 t

End Rev Inv Air  
1403.6710 t

Gross Volume Total  
32.9801 t

Net Volume Total  
32.7492 t

Average Temperature  
98.35 degF

Average API Density  
0.93132 g/cm3

Alarm Occurred: No

Aeration Limit: Pass

Minimum Quantity: Fail



No Power Interrupt: Pass  
Overall Bunker: Fail

The mass vacuum to mass air  
conversion factor is: 0.998925

IMPORTANT: Attach this  
ticket to BDN Report  
[Footer]  
Original

## 5.7 Contents of bunker ticket for Basic/MID and Profile/MID systems

### Note

Some items are optional and are printed only if selected during ticket configuration.

**Table 5-5: Contents of bunker ticket for Basic/MID and Profile/MID systems**

Ticket item	Description
*Approved Measurement*	Banner printed at top and bottom of ticket if Overall Bunker = Pass
Micro Motion Inc, Business Unit of Emerson	Banner printed at top of ticket
Header 1	User-defined text
Header 2	User-defined text
Transmitter Tag Name	User-configured string
System ID	HART software tag configured in the transmitter
BOL Number	Bill of Lading number, assigned automatically by the transmitter
Reset Time	Date and time that totals were reset, either by printing an original ticket or by pressing Reset
Print Time	Date and time that the original ticket was printed
Bunker Begin Time	Date and time that the transmitter started bunker measurement
Bunker End Time	Date and time that the transmitter stopped bunker measurement
Mass Total	Total mass of bunker, as measured by transmitter
Mass in Air	Total mass of bunker multiplied by the Mass in Air conversion factor
Mass Inventory	Total mass of all bunkers transferred since the last inventory reset
Bunker Begin Forward Inventory	Value of Mass Forward Inventory at the beginning of the bunker transfer
Bunker End Forward Inventory	Value of Mass Forward Inventory at the end of the bunker transfer
Bunker Begin Reverse Inventory	Value of Mass Reverse Inventory at the beginning of the bunker transfer
Bunker End Reverse Inventory	Value of Mass Reverse Inventory at the end of the bunker transfer
Begin Forward Inventory Air	Value of Mass Forward Inventory at the beginning of the bunker transfer, multiplied by the Mass in Air conversion factor

**Table 5-5: Contents of bunker ticket for Basic/MID and Profile/MID systems (continued)**

<b>Ticket item</b>	<b>Description</b>
End Forward Inventory Air	Value of Mass Forward Inventory at the end of the bunker transfer, multiplied by the Mass in Air conversion factor
Begin Reverse Inventory Air	Value of Mass Reverse Inventory at the beginning of the bunker transfer, multiplied by the Mass in Air conversion factor
End Reverse Inventory Air	Value of Mass Reverse Inventory at the end of the bunker transfer, multiplied by the Mass in Air conversion factor
Gross Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker at process temperature. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Net Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker, corrected to 15 °C. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Average Temperature	Average temperature of bunker, calculated as batch-weighted average with the configured volume unit used as the batch
Average API Density	Average density of the bunker, corrected to reference temperature
Aeration Limit	Value of <i>Aeration Limit</i> at the end of the bunker transfer
Alarm Occurred	<ul style="list-style-type: none"> <li>• Yes: One or more bunker-critical alarms was posted during the bunker transfer</li> <li>• No: No bunker-critical alarm was posted during the bunker transfer</li> </ul>
Aeration Limit	<ul style="list-style-type: none"> <li>• Pass: The value of <i>Aeration Limit</i> at the end of the transfer was within OIML/MID limits</li> <li>• Fail: The value of <i>Aeration Limit</i> at the end of the transfer was not within OIML/MID limits</li> </ul>
Minimum Quantity	<ul style="list-style-type: none"> <li>• Pass: <i>Mass Total</i> <math>\geq</math> MMQ (Minimum Measured Quantity)</li> <li>• Fail: <i>Mass Total</i> <math>&lt;</math> MMQ</li> </ul>
No Power Interrupt	<ul style="list-style-type: none"> <li>• Pass: No power reset occurred during bunker transfer</li> <li>• Fail: Power reset occurred during bunker transfer</li> </ul>
Overall OIML R117-1 Accuracy	Represents the combined results of the four OIML/MID checks: <ul style="list-style-type: none"> <li>• Pass: The bunker transfer measurement passed all four checks, and meets OIML/MID requirements.</li> <li>• Fail: The bunker transfer measurement failed one or more checks, and does not meet OIML/MID requirements.</li> </ul>
"Accuracy within x.x%"	Statement of measurement accuracy for the bunker transfer
MID Certificate #	Certificate number for this Micro Motion system, obtained and configured during commissioning
Mass in Air footer	Statement of the Mass in Air conversion factor
IMPORTANT: Attach this ticket to BDN Report	Banner printed at bottom of ticket

**Table 5-5: Contents of bunker ticket for Basic/MID and Profile/MID systems (continued)**

Ticket item	Description
Footer	User-defined text
Original	Printed automatically on the first printed ticket
Copy	Printed automatically on the second or third ticket
Duplicate Receipt	Printed automatically on all duplicate (reprinted) tickets
SECURITY BREACH Not A Legal Receipt	Banner printed at bottom of ticket if a security breach occurred during the transfer

## 5.7.1 Sample bunker tickets for Basic/MID and Profile/MID systems

These examples show bunker tickets for Basic/MID and Profile/MID systems, under different configurations and different Pass/Fail conditions. The date and time values are based on the transmitter date and time.

### Example: Basic/MID and Profile/MID tickets: Print no optional items; bunker transfer passed; no security breach occurred

In the following sample ticket, the system is configured to print no optional items. The SPRING TC parameters are enabled. The bunker transfer met OIIML/MID requirements, and no security breach occurred.

```
*Approved Measurement*
Micro Motion Inc, Business Unit of Emerson
[Header 1]
[Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time
10-JAN-2012 9:48:53

Print Time
10-JAN-2012 9:51:37

Bunker Begin Time
10-JAN-2012 9:51:14

Bunker End Time
10-JAN-2012 9:51:30

Mass Total
*7.1317 t*

MID Cert#: xxxx
```

\*Approved Measurement\*  
IMPORTANT: Attach this  
ticket to BDN Report  
[Footer]  
Original

**Example: Basic/MID and Profile/MID tickets: Print Mass Inventory; bunker transfer passed; no security breach occurred**

In the following sample ticket, the system is configured to print Mass Inventory. The SPRING TC parameters are enabled. The forward and reverse inventories are printed automatically. No reverse flow occurred. The bunker transfer met OIML/MID requirements, and no security breach occurred.

\*Approved Measurement\*  
Micro Motion Inc, Business Unit of Emerson  
[Header 1]  
[Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time  
10-JAN-2012 9:48:53

Print Time  
10-JAN-2012 9:51:37

Bunker Begin Time  
10-JAN-2012 9:51:14

Bunker End Time  
10-JAN-2012 9:51:30

Mass Total  
\*6.2995 t\*

Mass Inventory  
6034.5977 t  
Bunker Begin Fwd Inv  
6218.1221 t  
Bunker End Fwd Inv  
6224.4219 t  
Bunker Begin Rev Inv  
196.3344 t  
Bunker End Rev Inv  
196.3344 t

MID Cert#: xxxx

\*Approved Measurement\*  
IMPORTANT: Attach this

ticket to BDN Report  
 [Footer]  
 Original

**Example: Basic/MID and Profile/MID tickets: Print no optional items; security breach occurred**

In the following sample ticket, the system is configured to print no optional items. The SPRING TC parameters are enabled. A security breach occurred.

Micro Motion Inc, Business Unit of Emerson  
 [Header 1]  
 [Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time  
 10-JAN-2012 9:51:49

Print Time  
 10-JAN-2012 9:52:40

Bunker Begin Time  
 10-JAN-2012 9:52:17

Bunker End Time  
 10-JAN-2012 9:52:33

Mass Total  
 7.2606 t

MID Cert#: xxxx  
 IMPORTANT: Attach this  
 ticket to BDN Report  
 [Footer]

Original  
 SECURITY BREACH  
 Not A Legal Receipt

**Example: Basic/MID and Profile/MID tickets: Print all optional items; bunker transfer passed; no security breach**

In the following sample ticket, the system is configured to print all optional items. The SPRING TC parameters are enabled. The bunker transfer met OIML/MID requirements and no security breach occurred. No reverse flow occurred.

\*Approved Measurement\*  
 Micro Motion Inc, Business Unit of Emerson  
 [Header 1]  
 [Header 2]

[Transmitter Tag]  
System ID: [HART ID]  
BOL Number: [xx]  
Reset Time  
10-JAN-2012 9:52:52  
Print Time  
10-JAN-2012 9:54:36  
Bunker Begin Time  
10-JAN-2012 17:15:21  
Bunker End Time  
10-JAN-2012 18:17:17  
Mass in Air  
6.2995 t  
Mass Inventory  
6034.5977 t  
Begin Fwd Inv Air  
6218.1221 t  
End Fwd Inv Air  
6224.4219 t  
Begin Rev Inv Air  
196.3344 t  
End Rev Inv Air  
196.3344 t  
Gross Volume Total  
0.0000 m3  
Net Volume Total  
6034.4111 m3  
Average Temperature  
98.63 degF  
Average API Density  
0.93132 g/cm3  
Aeration Limit  
71.42876 %  
Overall OIML R117-1 Accuracy: Pass  
\*Accuracy within 0.5%  
MID Cert#: xxxx  
The mass vacuum to mass air  
conversion factor is: 0.998925  
\*Approved Measurement\*  
IMPORTANT: Attach this  
ticket to BDN Report  
[Footer]  
Original

**Example: Basic/MID and Profile/MID tickets: Print all optional items; bunker transfer failed; no security breach**

In the following sample ticket, the system is configured to print all optional items. The SPRING TC parameters are enabled. No reverse flow occurred. The bunker transfer failed one of the four checks (the MMQ check) and did not meet OIML/MID requirements.

Micro Motion Inc, Business Unit of Emerson

[Header 1]

[Header 2]

[Transmitter Tag]

System ID: [HART ID]

BOL Number: [xx]

Reset Time  
10-JAN-2012 9:54:51

Print Time  
10-JAN-2012 9:55:42

Bunker Begin Time  
10-JAN-2012 09:55:30

Bunker End Time  
10-JAN-2012 9:55:35

Mass in Air  
32.9446 t

Mass Inventory  
6036.6841 t

Begin Fwd Inv Air  
6224.4219 t

End Fwd Inv Air  
6226.5063 t

Begin Rev Inv Air  
196.3344 t

End Rev Inv Air  
196.3344 t

Gross Volume Total  
0.0000 m3

Net Volume Total  
6036.4980 m3

Average Temperature  
98.63 degF

Average API Density  
0.93132 g/cm3

Aeration Limit  
71.4286 %

Alarm Occurred: No

Aeration Limit: Pass

Minimum Quantity: Fail

No Power Interrupt: Pass

Overall OIML R117-1 Accuracy: Fail

MID Cert#: xxxx

The mass vacuum to mass air  
conversion factor is: 0.998925

IMPORTANT: Attach this  
ticket to BDN Report

[Footer]  
Original

## 5.8 Retrieve and reprint bunker tickets using the transmitter display

Ticket data for the five previous bunker transfers is stored on the transmitter. You can retrieve the data for viewing, and you can print duplicate tickets. You can also use this function to recover from print failures.

1. At the Marine Bunkering dashboard, choose Bunker Ticket Log.

---

### Tip

If you are not at the Marine Bunkering dashboard, press the Exit button as required until the Marine Bunkering dashboard is displayed.

---

Up to five tickets are listed, by BOL number. The most recent is listed first. For each ticket:

- (P): The ticket has been printed successfully.
  - (F): The ticket has not been printed successfully.
2. Select a ticket.
  3. Use the Up Arrow and Down Arrow buttons to view all ticket data.
  4. If desired, press Print to print the selected ticket. If profile data was collected during the bunker transfer and ProLink II is currently connected, you can also print a duplicate profile report.

If the ticket has previously been printed, the new ticket will be a duplicate ticket and the “Duplicate Receipt” banner is automatically added to the ticket. If the ticket has not been previously printed, the banner is not added to the ticket.

---

### Important

- The ticket will be printed with the current settings for Header, Footer, and Number of Tickets.
  - The ticket will be printed according to the currently configured bunker ticket options (Bunker Result, Bunker Result Details, Mass In Air, etc.).
-



# 6 Use ProLink II with the Marine Bunkering Transfer Package

## Topics covered in this chapter:

- *Configure bunker ticket options using ProLink II*
- *Transfer a bunker using ProLink II*
- *Print or reprint a bunker ticket using ProLink II*
- *View bunker transfer history*
- *Contents of profile report*
- *Print or export bunker transfer data using ProLink II*
- *Maintain bunker transfer history*

## 6.1 Configure bunker ticket options using ProLink II

You can use ProLink II to configure the bunker ticket contents and printing options. The configuration parameters are stored in the transmitter, and will overwrite the existing ticket configuration.

---

### Tip

These parameters are typically set during system startup and should not require changing.

---

### Prerequisites

To configure bunker ticket options, the transmitter must be unsecured.

The transmitter must be ready to accept a connection from ProLink II. If you have trouble making the connection:

- Ensure that communications have been configured for a Profile or Profile/MID system.
- Ensure that the RS-485 terminals are in RS-485 mode, rather than service port mode.

### Procedure

1. Connect from ProLink II to the transmitter.
  - a. Start ProLink II.
  - b. Click Connection > Connect to Device .
  - c. Set Protocol, Baud Rate, Parity, and Stop Bits to the values configured in the transmitter.

- d. Set Serial Port to the PC port you are using for the connection.
- e. Set Address to the value configured for the transmitter. The default address is 1.
- f. Click Connect.

If the connection is successful, the Marine Bunkering window is displayed.

---

**Tip**

To open the Marine Bunkering window, if you have closed it, choose Tools > Marine Bunker Transfer.

---

2. Select the Configuration panel in the Marine Bunkering window.
3. In the Ticket Process Information group, select all items that you want to be included on the ticket.

Option	Description
Aeration Limit	Value of <i>Aeration Limit</i> at the end of the bunker transfer.
Bunker Result <sup>(1)</sup>	Pass: The bunker transfer passed all four OIML/MID checks. Fail: The bunker transfer failed one or more of the four OIML/MID checks.
Gross Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker at process temperature. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Mass Inventory	Total mass of all bunkers transferred since the last inventory reset, plus the two forward inventories and the two reverse inventories. Labels and values depend on the setting of the Mass In Air option.
Bunker Result Details	Individual results for the four OIML/MID checks: <ul style="list-style-type: none"> <li>• MMQ check</li> <li>• Max Aeration check</li> <li>• Alarm check</li> <li>• Power check</li> </ul> These are printed only if Bunker Result = Fail.
Net Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker, corrected to 15 °C. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Average Temperature	Temperature of the process fluid, averaged across the entire bunker and expressed as a batch-weighted average with the configured volume unit used as the batch.

Option	Description
Mass In Air	<p>ON: The total and inventory values on the ticket represent “mass in air,” and the Mass in Air conversion factor is printed on the ticket. The following labels are used:</p> <ul style="list-style-type: none"> <li>• Mass in Air</li> <li>• Begin Fwd Inv Air</li> <li>• End Fwd Inv Air</li> <li>• Begin Rev Inv Air</li> <li>• End Rev Inv Air</li> </ul> <p>OFF: The total and inventory values on the ticket represent “true mass,” or “mass in vacuum.” The following labels are used:</p> <ul style="list-style-type: none"> <li>• Mass Total</li> <li>• Bunker Begin Fwd Inv</li> <li>• Bunker End Fwd Inv</li> <li>• Bunker Begin Rev Inv</li> <li>• Bunker End Rev Inv</li> </ul>
Average API Density	Average density of the bunker, at reference temperature.
SPRING TC Parameters	<p>ON: All ticket data is printed as configured.</p> <p>OFF: The following items are not printed, whether or not they were configured:</p> <ul style="list-style-type: none"> <li>• “Approved Measurement” banner</li> <li>• Gross Volume Total</li> <li>• Net Volume Total</li> <li>• Average API Density</li> <li>• Average Temperature</li> <li>• Aeration Limit</li> <li>• Bunker Result</li> <li>• Bunker Result Details</li> <li>• MID Certificate Number</li> <li>• Measurement accuracy statement</li> </ul> <p>If SPRING TC Parameters is set to OFF, the bunker ticket cannot be used as a legal receipt.</p>

(1) For Basic/MID and Profile/MID systems, Bunker Results is enabled and cannot be disabled.

---

#### Note

Certain items are always included on the ticket, and cannot be disabled.

---

4. Configure headers, footers, and related parameters.
  - a. In the Header and Footer group, configure Header Line 1, Header Line 2, and Footer to the text to be printed on the ticket.
  - b. Set Header Font Size and Footer Font Size to the font height to be used on the ticket.

---

**Tip**

You can change the header and footer parameters while the transmitter is secured. This allows you to use them for bunker-specific information if desired (for example, vessel name, purchaser name, and so on).

---

5. Set Number of Tickets to the number of tickets to be printed with one print command.

The default value is 3. The range is 1 to 3.

On the first ticket, the word “Original” is printed at the bottom of the ticket. On the second and third tickets, the word “Copy” is printed at the bottom of the ticket.

---

**Tip**

You can change the Number of Tickets setting while the transmitter is secured.

---

## 6.2 Transfer a bunker using ProLink II

This procedure guides you through transferring a bunker, collecting profile data, and printing a bunker ticket and/or a profile report, using ProLink II. For Profile systems, ticket printing is optional. For Profile/MID systems, ticket printing is required. You can also print a line graph of four process variables.

---

**Tip**

If you want to print bunker-specific information on the bunker ticket, e.g., the vessel name, you can change the settings of Header 1, Header 2, and Footer while the transmitter is secured. You can also change the setting of Number of Tickets while the transmitter is secured.

---

### Prerequisites

To print a bunker ticket, your system must include a ticket printer.

Ensure that the transmitter is secured.

Ensure that you are complying with all other applicable procedures, e.g., procedures for your barge or vessel, procedures for OIML/MID compliance, etc.

Ensure that Mass Flow Rate is 0.0.

Check startup values:

- Shore facilities and vessels: Ensure that Mass Total is 0.0, or the site-specific Systemic Holdup value that was configured for your system during commissioning. If it is not, press the Print button to reset the totals.
- Barges: Ensure that Mass Total is 0.0. If it is not, press the Print button to reset the totals. If this does not correct the problem, contact Micro Motion.

---

**Tip**

If your system does not include a ticket printer, a Reset button is displayed instead of the Print button. Press Reset to reset the totals.

---

Take appropriate precautions to ensure that flow occurs in only one direction during the bunker transfer. Small amounts of backflow due to valve action or other mechanical issues are insignificant, but larger amounts will affect measurement accuracy.

During the bunker transfer, take appropriate steps to ensure that Mass Flow Rate does not hover around 0. Very low values for Mass Flow Rate can affect measurement accuracy. Low values for Mass Flow Rate at the beginning and end of the bunker transfer have insignificant effects.

The transmitter must be ready to accept a connection from ProLink II. If you have trouble making the connection:

- Ensure that communications have been configured for a Profile or Profile/MID system.
- Ensure that the RS-485 terminals are in RS-485 mode, rather than service port mode.

### Procedure

1. Connect from ProLink II to the transmitter.
  - a. Start ProLink II.
  - b. Click Connection > Connect to Device .
  - c. Set Protocol, Baud Rate, Parity, and Stop Bits to the values configured in the transmitter.
  - d. Set Serial Port to the PC port you are using for the connection.
  - e. Set Address to the value configured for the transmitter. The default address is 1.
  - f. Click Connect.

If the connection is successful, the Marine Bunkering window is displayed.

---

#### Tip

To open the Marine Bunkering window, if you have closed it, choose Tools > Marine Bunker Transfer.

---

2. Start flow and totalizers.

If you have installed and configured the system as recommended, totalizers will be started automatically when liquid is detected in the pipeline. If a transmitter power cycle has occurred, totalizing does not begin until system startup procedures are complete.

3. Use the Monitor panel in the Marine Bunkering window to observe process data.

The Monitor panel displays current values of six process variables, and a line graph of four process variables.

---

#### Tip

You can use *Drive Gain* to track aeration (entrained gas or entrained air) during the bunker transfer. *Drive Gain* is a measure of the energy required to vibrate the sensor tubes to full amplitude. When aeration is present, more energy is required and the drive gain increases

dramatically. The maximum value of *Drive Gain* is 100%. Note that other process and equipment conditions can cause result in higher *Drive Gain* values. For more information, see *Micro Motion Series 3000 MVD Transmitters and Controllers: Configuration and Use Manual*.

---

4. (Optional) To print the line graph from the Marine Bunkering window while a bunker transfer is in progress, click Print Graph.
5. To end the bunker transfer:
  - a. Stop flow.
  - b. Click the Print Ticket button on the Monitor panel.

If your system does not include a ticket printer, a Reset button is displayed instead of the Print Ticket button. Click Reset to end the transfer.

The Print Ticket and Reset buttons in ProLink II have the same functions as the Print and Reset buttons on the face of the transmitter. Totals are reset and a bunker ticket is printed (if a ticket printer is available). If Systemic Holdup is non-zero, it is applied now.

6. (Optional) To preview or print a profile report, click the Preview button or the Print Report button on the Monitor panel.

These buttons are not available until a ticket has been printed. You may need to wait a few seconds after clicking Print Ticket.

## 6.3 Print or reprint a bunker ticket using ProLink II

You can print or reprint the bunker ticket for any bunker transfer in the ProLink II bunkering database. You can use this function to recover from print failures.

1. Connect ProLink II to the transmitter.
2. Select the History panel in the Marine Bunkering window.
3. Select the desired transfer record from Historical Transfer Log Index.

Transfer records are ordered by timestamp. Historical Transfer 1 is the most recent bunker transfer.

4. Click Print Ticket to print or reprint a ticket.

If the ticket has previously been printed, the new ticket will be a duplicate ticket and the “Duplicate Receipt” banner is automatically added to the ticket. If the ticket has not been previously printed, the banner is not added to the ticket.

---

### Important

- The ticket will be printed with the current settings for Header, Footer, and Number of Tickets.
  - The ticket will be printed according to the currently configured bunker ticket options (Bunker Result, Bunker Result Details, Mass In Air, etc.).
-

## 6.4 View bunker transfer history

You can view history data for all bunker transfers that are recorded in the ProLink II bunkering database. The bunkering database can store data for up to five bunker transfers.

### Prerequisites

The transmitter must be ready to accept a connection from ProLink II. If you have trouble making the connection:

- Ensure that communications have been configured for a Profile or Profile/MID system.
- Ensure that the RS-485 terminals are in RS-485 mode, rather than service port mode.

### Procedure

1. Connect from ProLink II to the transmitter.
  - a. Start ProLink II.
  - b. Click Connection > Connect to Device .
  - c. Set Protocol, Baud Rate, Parity, and Stop Bits to the values configured in the transmitter.
  - d. Set Serial Port to the PC port you are using for the connection.
  - e. Set Address to the value configured for the transmitter. The default address is 1.
  - f. Click Connect.

If the connection is successful, the Marine Bunkering window is displayed.

---

#### Tip

To open the Marine Bunkering window, if you have closed it, choose Tools > Marine Bunker Transfer.

---

2. Select the History panel.
3. Select the desired transfer record from Historical Transfer Log Index.

Transfer records are ordered by timestamp. Historical Transfer 1 is the most recent bunker transfer.

The History panel is updated with data from the selected transfer record.
4. (Optional) Click Preview or Print to preview or print the profile report for the currently selected bunker transfer.

## 6.5 Contents of profile report

**Table 6-1: Contents of profile report**

Item	Description
Header 1	User-defined text
Header 2	User-defined text
BOL Number	Bill of Lading number, assigned automatically by the transmitter
Reset Time	Date and time that totals were reset, either by printing an original ticket or by pressing Reset
Print Time	Date and time that the original ticket was printed
Bunker Begin Time	Date and time that the transmitter started bunker measurement
Bunker End Time	Date and time that the transmitter stopped bunker measurement
Mass in Air	Total mass of bunker multiplied by the Mass in Air conversion factor
Mass Total	Total mass of bunker, as measured by transmitter
Mass Inventory	Total mass of all bunkers transferred since the last inventory reset
Bunker Begin Forward Inventory	Value of Mass Forward Inventory at the beginning of the bunker transfer
Bunker End Forward Inventory	Value of Mass Forward Inventory at the end of the bunker transfer
Bunker Begin Reverse Inventory	Value of Mass Reverse Inventory at the beginning of the bunker transfer
Bunker End Reverse Inventory	Value of Mass Reverse Inventory at the end of the bunker transfer
Gross Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker at process temperature. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Net Volume Total	Total volume of the bunker, calculated from the mass total and the average density of the bunker, corrected to 15 °C. The mass total is based on both aerated and non-aerated flow. The average density is based on non-aerated flow. For this calculation, aerated flow is defined as any flow occurring while drive gain exceeds a preset limit or density exceeds preset limits.
Average Temperature	Average temperature of bunker, calculated as batch-weighted average with the configured volume unit used as the batch
Average API Density	Average density of the bunker, corrected to reference temperature
Aeration Limit	Value of <i>Aeration Limit</i> at the end of the bunker transfer <ul style="list-style-type: none"> <li>• Pass: The value of <i>Aeration Limit</i> at the end of the transfer was within OIML/MID limits</li> <li>• Fail: The value of <i>Aeration Limit</i> at the end of the transfer was not within OIML/MID limits</li> </ul>
Alarm Occurred	<ul style="list-style-type: none"> <li>• Yes: One or more bunker-critical alarms was posted during the bunker transfer</li> <li>• No: No bunker-critical alarm was posted during the bunker transfer</li> </ul>
Minimum Quantity	<ul style="list-style-type: none"> <li>• Pass: <math>Mass\ Total \geq MMQ</math> (Minimum Measured Quantity)</li> <li>• Fail: <math>Mass\ Total &lt; MMQ</math></li> </ul>



**Table 6-1: Contents of profile report (continued)**

Item	Description
No Power Interrupt	<ul style="list-style-type: none"> <li>• Pass: No power reset occurred during bunker transfer</li> <li>• Fail: Power reset occurred during bunker transfer</li> </ul>
Overall Bunker Results	Represents the combined results of the four OIML/MID checks: <ul style="list-style-type: none"> <li>• Pass: The bunker transfer measurement passed all four checks, and meets good-practice requirements.</li> <li>• Fail: The bunker transfer measurement failed one or more checks, and does not meet good-practice requirements.</li> </ul>
Meter Verification Test Results	<ul style="list-style-type: none"> <li>• Pass: The flowmeter passed the most recent meter verification test.</li> <li>• Fail: The flowmeter failed the most recent meter verification test.</li> </ul> If the Meter Verification application is not present on the transmitter, this item is blank.
Bunker Profile graph	Line graph of <i>Mass Flow Rate, Average Density at Reference Temperature, Temperature, and Drive Gain</i> during the bunker transfer
MID Certificate #	Certificate number for this Micro Motion system, obtained and configured during commissioning
Mass in Air footer	Statement of the Mass in Air conversion factor
Footer	User-defined text


## 6.5.1 Sample profile reports

Figure 6-1: Sample profile report for Profile systems



**Bunker Delivery Verification**  
**Micro Motion Inc., Business Unit of Emerson**  
**FUEL OIL**  
**v8.10**

**BOL Number:** 257  
**Reset Time:** 19-Jan-12 15:07:37  
**Print Time:** 19-Jan-12 15:11:36  
**Bunker Begin Time:** 19-Jan-12 15:11:08  
**Bunker End Time:** 19-Jan-12 15:11:28  
**Mass In Vacuum:** 24.15430 mTon  
**Mass In Air:** 24.12833 mTon  
**Mass Total:** 24.15430 mTon  
**Mass Inventory:** 79.06028 mTon  
**Bunker Begin Forward Mass Inventory:** 54.82288 mTon  
**Bunker End Forward Mass Inventory:** 78.97719 mTon  
**Bunker Begin Reverse Mass Inventory:** 0.00007 mTon  
**Bunker End Reverse Mass Inventory:** 0.00007 mTon  
**Gross Volume Total:** 0.00000 m3  
**Net Volume Total:** 86.62148 m3  
**Average Temperature:** NAN °C  
**Average API Density:** NAN kg/m3  
**Aeration Limit:** 71.42857% Pass  
**Alarms Occurred:** None  
**Minimum Quantity:** Pass  
**No Power Interrupt:** Pass  
**Overall Bunker Results:** Pass With High Aeration  
**Meter Verification Test Results:** Fail




To convert mass to mass in air, multiply by 0.998925.

Figure 6-2: Sample profile report for Profile/MID systems



**Bunker Delivery Verification**  
**Micro Motion Inc., Business Unit of Emerson**  
**FUEL OIL**  
**v8.10**

**BOL Number:** 256  
**Reset Time:** 19-Jan-12 15:06:00  
**Print Time:** 19-Jan-12 15:07:22  
**Bunker Begin Time:** 19-Jan-12 15:06:47  
**Bunker End Time:** 19-Jan-12 15:07:00  
**Mass In Vacuum:** 14.62141 mTon  
**Mass In Air:** 14.60569 mTon  
**Mass Total:** 14.62141 mTon  
**Mass Inventory:** 54.90598 mTon  
**Bunker Begin Forward Mass Inventory:** 40.20147 mTon  
**Bunker End Forward Mass Inventory:** 54.82288 mTon  
**Bunker Begin Reverse Mass Inventory:** 0.00007 mTon  
**Bunker End Reverse Mass Inventory:** 0.00007 mTon  
**Gross Volume Total:** 0.00000 m3  
**Net Volume Total:** 62.46829 m3  
**Average Temperature:** NAN °C  
**Average API Density:** NAN kg/m3  
**Aeration Limit:** 71.42857% Pass  
**Alarms Occurred:** None  
**Minimum Quantity:** Pass  
**No Power Interrupt:** Pass  
**Overall Bunker Results:** Pass With High Aeration  
**Accuracy within 1%:**  
**Meter Verification Test Results:** Fail



MID Certificate #:T1215  
 To convert mass to mass in air, multiply by 0.998925.

## 6.6 Print or export bunker transfer data using ProLink II

You can print bunker transfer data from the current bunker transfer or from any bunker transfer in the ProLink II bunkering database. You can export bunker transfer data to Unicode CSV (comma-separated values) files for use in other applications.

- To print process data for the current bunker transfer:
  1. Ensure that ProLink II is connected to the transmitter during the bunker transfer.
  2. Select the Monitor panel in the Marine Bunkering window.
  3. Click Print Graph (if the transfer is in progress) or Print Report (if the transfer is complete).

---

### Tip

If you want to change the appearance of the graph before you print it, right-click anywhere on the graph and use the graphics toolbox that is provided. You can also use the graphics toolbox to save the graph as an image.

- To print a profile report for a bunker transfer in the bunkering database:
  1. Connect ProLink II to the transmitter.
  2. Select the History panel in the Marine Bunkering window.
  3. Select the desired transfer record from Historical Transfer Log Index.

Transfer records are ordered by timestamp. Historical Transfer 1 is the most recent bunker transfer.

4. Click Preview to preview the profile report or to export the data to a CSV file.
5. Click Print Report to print the profile report.

---

### Restriction

You cannot use the History panel to print a profile report for the current bunker transfer while it is in progress. To print a profile report for the current bunker transfer, you must use the Marine Bunkering dashboard on the transmitter. When the transfer is complete, it is available from the History panel as Historical Transfer 1.

---

## 6.7 Maintain bunker transfer history

You can keep bunkering transfer data as long as required by storing it outside the ProLink II bunkering database.

The ProLink II bunkering database can store data for up to five bunker transfers. When the database is full, the oldest bunker transfer will be overwritten.

---

### Tip

Be sure to store any required data externally before the bunker transfer is overwritten.

---

### Procedure

- To keep the profile report data in both TIF format and HTML format, print the profile report.

A graphics file in TIF format will be created and saved in the location you specify. Additionally, a set of HTML files is automatically generated and saved on your PC in a folder named Reports. Reports is located in the ProLink II installation folder. You can view the report by opening the HTML file in a browser.

- To store the corresponding trend data, export the data for the transfer to a CSV file. To do this, preview the profile report and click Export to CSV.



# Appendix A

## Integrated wiring diagrams

### Topics covered in this appendix:

- [Integrated wiring diagrams for Basic systems](#)
- [Integrated wiring diagrams for Basic/MID systems](#)
- [Integrated wiring diagrams for Profile systems](#)
- [Integrated wiring diagrams for Profile/MID systems](#)

## A.1 Integrated wiring diagrams for Basic systems

Use these integrated wiring diagrams for Basic systems only. Choose the wiring diagrams that match the direction of the pipe and the orientation of your sensor.

Vertical pipe (Sensor orientation = Flag)	<a href="#">Figure A-1</a> <a href="#">Figure A-2</a>
Horizontal pipe (Sensor orientation = Tubes down)	<a href="#">Figure A-3</a> <a href="#">Figure A-4</a>

Figure A-1: Basic systems, vertical pipe (Sensor orientation = Flag): Sheet 1








Figure A-3: Basic systems, horizontal pipe (Sensor orientation = Tubes down): Sheet 1





Figure A-4: Basic systems, horizontal pipe (Sensor orientation = Tubes down): Sheet 2



## A.2 Integrated wiring diagrams for Basic/MID systems

Use these integrated wiring diagrams for Basic/MID systems only. Choose the wiring diagrams that match the direction of the pipe and the orientation of your sensor.

Vertical pipe (Sensor orientation = Flag)	<a href="#">Figure A-5</a> <a href="#">Figure A-6</a>
Horizontal pipe (Sensor orientation = Tubes down)	<a href="#">Figure A-7</a> <a href="#">Figure A-8</a>

Figure A-5: Basic/MID systems, vertical pipe (Sensor orientation = Flag): Sheet 1









Figure A-8: Basic/MID systems, horizontal pipe (Sensor orientation = Tubes down): Sheet 2





## A.3 Integrated wiring diagrams for Profile systems

Use these integrated wiring diagrams for Profile systems only. Choose the wiring diagrams that match the direction of the pipe and the orientation of your sensor.

Vertical pipe (Sensor orientation = Flag)	<a href="#">Figure A-9</a> <a href="#">Figure A-10</a>
Horizontal pipe (Sensor orientation = Tubes down)	<a href="#">Figure A-11</a> <a href="#">Figure A-12</a>

Figure A-9: Profile systems, vertical pipe (Sensor orientation = Flag): Sheet 1




Figure A-10: Profile systems, vertical pipe (Sensor orientation = Flag): Sheet 2




Figure A-11: Profile systems, horizontal pipe (Sensor orientation = Tubes down): Sheet 1





Figure A-12: Profile systems, horizontal pipe (Sensor orientation = Tubes down): Sheet 2



## A.4 Integrated wiring diagrams for Profile/MID systems

Use these integrated wiring diagrams for Profile/MID systems only. Choose the wiring diagrams that match the direction of the pipe and the orientation of your sensor.

Vertical pipe (Sensor orientation = Flag)	<a href="#">Figure A-13</a> <a href="#">Figure A-14</a>
Horizontal pipe (Sensor orientation = Tubes down)	<a href="#">Figure A-15</a> <a href="#">Figure A-16</a>

Figure A-13: Profile/MID systems, vertical pipe (Sensor orientation = Flag): Sheet 1








Figure A-15: Profile/MID systems, horizontal pipe (Sensor orientation = Tubes down): Sheet 1





Figure A-16: Profile/MID systems, horizontal pipe (Sensor orientation = Tubes down): Sheet 2



# Appendix B

## Printer setup

### B.1 Communications settings for the ticket printer

Component and settings	System type			
	Basic	Basic/MID	Profile	Profile/MID
Printer	TM-U295	TM-T88V	TM-U295	TM-T88V
Printer DIP switches	1: OFF 2: OFF 3: OFF 4: OFF 5: ON 6: ON 7: OFF 8: OFF 9: OFF 10: OFF	1-1: OFF 1-2: OFF 1-3: OFF 1-4: OFF 1-5: ON 1-6: ON 1-7: ON 1-8: ON 2-1: OFF 2-2 – 2-8: As desired	1: OFF 2: OFF 3: OFF 4: OFF 5: ON 6: ON 7: OFF 8: OFF 9: OFF 10: OFF	1-1: OFF 1-2: OFF 1-3: OFF 1-4: OFF 1-5: ON 1-6: ON 1-7: ON 1-8: ON 2-1: OFF 2-2 – 2-8: As desired
K2-ADE-TB signal converter DIP switches	1: ON 2: OFF 3: OFF 4: ON 5: OFF 6: OFF	1: ON 2: OFF 3: OFF 4: ON 5: OFF 6: OFF	1: ON 2: OFF 3: OFF 4: ON 5: OFF 6: OFF	1: ON 2: OFF 3: OFF 4: ON 5: OFF 6: OFF
Transmitter digital communications	Baud: 9600 Parity: None Data bits: 8 Stop bits: 1 Characters per second: 32 Buffer size: 512	Baud: 38400 Parity: Even Data bits: 8 Stop bits: 1 Characters per second: 400 Buffer size: 1024	Baud: 9600 Parity: None Data bits: 8 Stop bits: 1 Characters per second: 32 Buffer size: 512	Baud: 38400 Parity: Even Data bits: 8 Stop bits: 1 Characters per second: 400 Buffer size: 1024
Transmitter DO3 (discrete output)	As desired	RS485 Dual Function	As desired	RS485 Dual Function



# Index

## A

- aeration 2, 3
- Aeration Limit 3
- Alarm check
  - See also bunker-critical alarms
  - definition 2
- alarms, See Alarm check; bunker-critical alarms

## B

- Basic system
  - bunker tickets
    - contents 55
    - sample 57
  - definition 5
  - installation 11
  - operation 47
  - requirements 5
  - wiring diagrams 83
- Basic/MID system
  - bunker tickets
    - contents 61
    - sample 63
  - definition 5
  - installation 15
  - operation 47
  - requirements 6
  - wiring diagrams 88
- bunker tickets
  - configuring
    - using ProLink II 69
    - using the display 38
  - contents
    - Basic system 55
    - Basic/MID system 61
    - Profile system 55
    - Profile/MID system 61
  - duplicate tickets, See bunker tickets, reprinting
  - print failure recovery
    - using ProLink II 74
    - using the display 68
  - printing
    - from ProLink II 72
    - from the display 47, 50
  - reprinting
    - from ProLink II 74
    - from the display 68

- retrieving
  - using ProLink II 74
  - using the display 68
- samples
  - Basic system 57
  - Basic/MID system 63
  - Profile system 57
  - Profile/MID system 63
- Weights & Measures document 2
- bunker transfers
  - Basic system 47
  - Basic/MID system 47
  - history
    - in the ProLink II bunkering database 75
    - on the transmitter 68
  - monitoring
    - from ProLink II 72
    - from the display 53, 54
  - Profile system
    - from ProLink II 72
    - from the display 50
  - Profile/MID system
    - from ProLink II 72
    - from the display 50
- bunker-critical alarms
  - definition 3
  - list 4

## C

- calibration
  - density, See LD Optimization
  - mA output, See trimming the mA outputs
  - water, See LD Optimization
  - zero 32
- Certified Marine Bunker Measurement Solution
  - documentation 9
  - installation locations 5
  - overview 1
- configuration, See configuring auxiliary devices;
  - configuring basic flowmeter parameters; configuring the bunker ticket; configuring communications
- configuring auxiliary devices 33
- configuring basic flowmeter parameters 34
- configuring communications
  - Basic system 41
  - Basic/MID system 41

- printer settings summary 103
- Profile system 42
- Profile/MID system 42
- configuring the bunker ticket
  - using ProLink II 69
  - using the display 38
- custody transfer, *See* Weights & Measures
- customer service
  - contacting ii

## D

- default values for flowmeter configuration 36
- density calibration, *See* LD Optimization
- documentation 1,9
- duplicate tickets, *See* bunker tickets, reprinting

## E

- entrained air, *See* aeration
- entrained gas, *See* aeration

## F

- ferrite beads 28

## H

- history, *See* ProLink II bunkering database
- hydrocarbon compensation, *See* LD Optimization

## I

- installation
  - Basic system 11
  - Basic/MID system 15
  - ferrite beads 28
  - marine approvals 28
  - Profile system 18
  - Profile/MID system 23
  - wiring diagrams
    - Basic system 83
    - Basic/MID system 88
    - Profile system 93
    - Profile/MID system 98
- integrity detection loop
  - configuring the device 33
  - configuring the loop 34
  - installation 13, 16, 21, 26

## L

- LD Optimization 32

- level switches
  - configuring the device 33
  - configuring the loop 34
  - installation 13, 16, 21, 26
- loop tests 32

## M

- mA output calibration, *See* trimming the mA outputs
- marine approvals 28
- Marine Bunker Instruments
  - in Basic system 5
  - in Basic/MID system 6
  - in Profile system 7
  - in Profile/MID system 8
- Marine Bunker Transfer Package
  - compliance with OIML R-117-1 MID 2004-22/EC
    - Annex MI-005 2
  - documentation 1,9
  - installation locations 5
  - overview 2
  - system options 5, 11
  - system requirements 5
- Marine Bunkering dashboard
  - contents 31
  - during bunker transfer 53
  - exiting 31
  - returning to 31
- Mass in Air conversion 40
- mass in vacuum, *See* Mass in Air conversion
- Max Aeration check
  - See also* aeration
  - definition 2
- MID 2004/22/EC Annex MI-005 2
- Minimum Measured Quantity, *See* MMQ
- MMQ 2
- MMQ check
  - See also* MMQ
  - definition 2

## O

- OIML R117-1 2
- operation
  - Basic system 47
  - Basic/MID system 47
  - Profile system
    - from ProLink II 72
    - from the display 50
  - Profile/MID system
    - from ProLink II 72
    - from the display 50

**P**

- power
  - applying power 31
- Power check
  - definition 2
- pressure transmitter
  - configuring the device 33
  - configuring the loop 34
  - installation 13, 16, 21, 26
- printing
  - See also* bunker tickets
  - See also* profile reports
  - current bunker data 80
  - historical bunker data 80
- profile reports
  - contents 76
  - printing 50, 72, 75, 80
  - sample
    - Profile system 78
    - Profile/MID system 78
  - viewing 75
- Profile system
  - bunker tickets
    - contents 55
    - sample 57
  - definition 5
  - installation 18
  - operation
    - from ProLink II 72
    - from the display 50
  - profile reports
    - contents 76
    - sample 78
  - requirements 7
  - wiring diagrams 93
- Profile/MID system
  - bunker tickets
    - contents 61
    - sample 63
  - definition 5
  - installation 23
  - operation
    - from ProLink II 72
    - from the display 50
  - profile reports
    - contents 76
    - sample 78
  - requirements 8
  - wiring diagrams 98
- ProLink II
  - in Basic system 5

- in Basic/MID system 6
  - in Profile system 7
  - in Profile/MID system 8
- ProLink II bunkering database
  - data in CSV format 80
  - data in HTML format 80
  - exporting data 80
  - maintaining history 80
  - printing data 80
  - viewing data 75

**Q**

- Quick Reference Guide 9

**R**

- RF (radio frequency) emissions 28

**S**

- sealing the transmitter, *See* security
- securing the transmitter, *See* security
- security
  - sealing the transmitter 44
  - securing the transmitter 44
- system options and requirements 5
- system startup
  - applying power 31
  - optional startup tasks 32
- Systemic Holdup 49, 53

**T**

- temperature transmitter
  - configuring the device 33
  - configuring the loop 34
  - installation 13, 16, 21, 26
- tickets, *See* bunker tickets
- transfer, *See* bunker transfers
- trimming the mA outputs 32
- true mass, *See* Mass in Air conversion

**W**

- water calibration, *See* LD Optimization
- Weights & Measures
  - bunker tickets as legal documents 2
  - sealing the transmitter 44
- wiring, *See* installation
- wiring diagrams
  - Basic system 83
  - Basic/MID system 88

Profile system 93  
Profile/MID system 98

**Z**  
zero calibration 32







MMI-20017681

Rev AD

2014

**Micro Motion Inc. USA**

Worldwide Headquarters  
7070 Winchester Circle  
Boulder, Colorado 80301  
T +1 303-527-5200  
T +1 800-522-6277  
F +1 303-530-8459  
[www.micromotion.com](http://www.micromotion.com)

**Micro Motion Europe**

Emerson Process Management  
Neonstraat 1  
6718 WX Ede  
The Netherlands  
T +31 (0) 318 495 555  
F +31 (0) 318 495 556  
[www.micromotion.nl](http://www.micromotion.nl)

**Micro Motion Asia**

Emerson Process Management  
1 Pandan Crescent  
Singapore 128461  
Republic of Singapore  
T +65 6777-8211  
F +65 6770-8003

**Micro Motion United Kingdom**

Emerson Process Management Limited  
Horsfield Way  
Bredbury Industrial Estate  
Stockport SK6 2SU U.K.  
T +44 0870 240 1978  
F +44 0800 966 181

**Micro Motion Japan**

Emerson Process Management  
1-2-5, Higashi Shinagawa  
Shinagawa-ku  
Tokyo 140-0002 Japan  
T +81 3 5769-6803  
F +81 3 5769-6844

©2014 Micro Motion, Inc. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Micro Motion, ELITE, ProLink, MVD and MVD Direct Connect marks are marks of one of the Emerson Process Management family of companies. All other marks are property of their respective owners.

