

Operating Instructions M3 and M3HW Jackscrew Manual Override



Table of Contents

Section 1: Operating Instructions for CBA M3/M3HW, NCBA M3, CBB M3/M3HW, NCBB M3, G M3/M3HW and NG M3 Series (Jackscrew Override)

- 1.1 Operating Procedure for M3 Jackscrew..... 1
- 1.2 Return M3 to Regular Service 2

Section 2: Operating Instructions for HD, NHD, T and NT Series M3/M3HW (Jackscrew Override)

- 2.1 Operating Procedure for M3 Jackscrew..... 3
- 2.2 Return M3 to Regular Service 3

Section 3: Document Revision

Section 1: Operating Instructions for CBA M3/M3HW, NCBA M3, CBB M3/ M3HW, NCBB M3, G M3/M3HW and NG M3 Series (Jackscrew Override)

NOTE:

The M3/M3HW have left handed threads (that is, rotate counterclockwise to screw in).

NOTE:

For operating instructions for the “HD” Series M3/M3HW (Jackscrew Override), skip Page 1 and proceed to Page 2.

1.1 Operating Procedure for M3 Jackscrew

- 1.1.1 Bleed off and remove all pressure to the actuator. On double-acting actuators, make sure that both ends of cylinder (s) are exhausted and vented to atmosphere.
- 1.1.2 Apply a generous coating of grease to the M3 threads before operating.
- 1.1.3 Loosen the M3 locking nut and turn M3 counterclockwise sufficiently to allow for the customers' desired actuator travel (that is, to screw in and override the actuator).

1.2 Return M3 to Regular Service

- 1.2.1 Turn M3 clockwise until the actuator is returned to its original position.
- 1.2.2 If desirable, wipe away excess grease on M3 after operation.

NOTE:

If preferred, grease may be left on M3 to provide additional corrosion protection.

- 1.2.3 Turn jam nut counterclockwise until tight.
- 1.2.4 Restore supply pressure to the actuator's power cylinder.

Section 2: Operating Instructions for HD, NHD, T and NT Series M3/M3HW (Jackscrew Override)

NOTE:

The M3/M3HW have right handed threads (that is, rotate clockwise to screw in).

2.1 Operating Procedure for M3 Jackscrew

- 2.1.1 Bleed off and remove all pressure to the actuator. On double-acting actuators, make sure that both ends of cylinder (s) are exhausted and vented to atmosphere.
- 2.1.2 Apply a generous coating of grease to the M3 threads before operating.
- 2.1.3 Loosen the M3 locking nut and turn M3 clockwise sufficiently to allow for the customers' desired actuator travel (that is, to screw in and override the actuator).

2.2 Return M3 to Regular Service

- 2.2.1 Turn M3 counterclockwise until the actuator is returned to its original position.
- 2.2.2 If desirable, wipe away excess grease on M3 after operation.

NOTE:

If preferred, grease may be left on M3 to provide additional corrosion protection.

- 2.2.3 Turn jam nut clockwise until tight.
- 2.2.4 Restore supply pressure to the actuator's power cylinder.

Section 3: Document Revision

Table 1. Revision Overview

ECN	DATE	REV		BY *	DATE
VAWCO925	January 2011	D	COMPILED	B. Jumawan	14 January 2011
			CHECKED	D. Blahnik	14 January 2011
			APPROVED	Kenneth Chin	14 January 2011

* Signatures on file Emerson, Actuation Technologies, Waller, Texas

World Area Configuration Centers (WACC) offer sales support, service, inventory and commissioning to our global customers. Choose the WACC or sales office nearest you:

NORTH & SOUTH AMERICA

19200 Northwest Freeway
Houston TX 77065
USA
T +1 281 477 4100

Av. Hollingsworth
325 Iporanga Sorocaba
SP 18087-105
Brazil
T +55 15 3413 8888

ASIA PACIFIC

No. 9 Gul Road
#01-02 Singapore 629361
T +65 6777 8211

No. 1 Lai Yuan Road
Wuqing Development Area
Tianjin 301700
P. R. China
T +86 22 8212 3300

MIDDLE EAST & AFRICA

P. O. Box 17033
Jebel Ali Free Zone
Dubai
T +971 4 811 8100

P. O. Box 10305
Jubail 31961
Saudi Arabia
T +966 3 340 8650

24 Angus Crescent
Longmeadow Business Estate East
P.O. Box 6908 Greenstone
1616 Modderfontein Extension 5
South Africa
T +27 11 451 3700

EUROPE

Holland Fásor 6
Székesfehérvár 8000
Hungary
T +36 22 53 09 50

Strada Biffi 165
29017 Fiorenzuola d'Arda (PC)
Italy
T +39 0523 944 411

For complete list of sales and manufacturing sites, please visit www.emerson.com/actuationtechnologieslocations or contact us at info.actuationtechnologies@emerson.com

www.emerson.com/bettis

©2019 Emerson. All rights reserved.

The Emerson logo is a trademark and service mark of Emerson Electric Co. Bettis™ is a mark of one of the Emerson family of companies. All other marks are property of their respective owners.

The contents of this publication are presented for information purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available on request. We reserve the right to modify or improve the designs or specifications of our products at any time without notice.

BETTIS™

