



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES INSTALLATION AND MAINTENANCE INSTRUCTIONS

Before installation, these instructions must be carefully read and understood.



NOTE

For the High Gain Option, the valve will be in full lift by 105% of set.

The main valve uses the principle of pressurizing the top or large area of a differential area piston with line pressure to hold the piston closed up to set pressure. At set pressure, the pilot relieves, depressurizing the volume above the piston, the main valve dome, and the piston lifts permitting discharge from the main valve. As capacity relief of the system is satisfied, system pressure will begin to decrease. When it does, the pilot will actuate and direct system pressure to the main valve dome. This closes the main valve. The pilot is the nonflowing type. With the main valve open and relieving at steady pressure, no process gas or fluid flows through the pilot. When process pressure changes, the pilot actuates to change the lift of the main valve piston. During these actuations a small amount of gas or fluid from the main valve dome flows through the pilot and is discharged thru the pilot exhaust. The set pressure range is 15 psig to 740 psig.

Refer to Anderson Greenwood Pilot operated safety relief valves 05-9040-372 (VCIOM-03099 Winterization Guidelines) and 05-9040-352 for more information regarding Winterization requirements.

1.3 Start-up

There must be pressure at the valve inlet or at the pilot inlet/sense port for valves with remote sense to establish a differential force across the piston and "load" it in the closed position. Pressure must pass through the pilot and exert force on the top of the piston. On normal plant startup the valve loads itself as pressure increases.

Block valves are often used under safety valves to isolate them when maintenance is required. When putting the safety valve in service be sure the block valve is fully opened. If the block valve is opened after system startup, the safety valve may briefly vent before the dome gets pressurized to close the main valve seat.

TABLE OF CONTENTS

- 1. General valve description and start-up 1
- 2. Main valve maintenance 2
- 3. Pilot maintenance 7
- 4. Pilot adjustment 15
- 5. Valve assembly testing..... 21
- 6. Pilot set pressure field test procedure..... 24
- 7. Soft goods repair kits 25
- 8. Pilot accessories 26
- 9. Assembly and maintenance equipment 26

Installation and Maintenance Instructions for Series 400 Diaphragm Pilot Operated Safety Relief Valves (POSRV).

The intent of these instructions is to acquaint the user with the maintenance of this product. Please read these instructions carefully.

1 GENERAL VALVE DESCRIPTION AND START-UP

1.1 General

The Anderson Greenwood Series 400 valve is designed for modulating action. The main valve will open at nameplate set, but only an amount proportional to the relieving capacity required. As process pressure increases, the valve will open more and be in full lift at 110% of set.

1.2 Installation

Either or both inlet and outlet may be standard ANSI flanges or ANSI pipe threaded connections and are to be installed in accordance with accepted piping practices. When remote pressure pickup is used the pilot supply tube is connected to a remote location rather than to the inlet neck of the valve. A block valve in the remote pilot supply line is not recommended. If one is used it must be opened before pressurizing the main valve.

NOTE

Remote pressure pickup piping must have the equivalent flow area of 3/8" tubing for lengths up to 100 feet. For lengths greater than this, consult factory.

For valves supplied with eyebolts, follow the instructions in Anderson Greenwood Pilot operated safety relief valves 05-9040-352 (VCOSI-06034 Operating and Safety Instructions) pertaining to the safe use and storage of eyebolts.

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

1.4 Maintenance

Anderson Greenwood recommended main valve and pilot maintenance procedures including pilot set pressure adjustment and valve assembly testing are described in the following paragraphs. Following these procedures in a regular pressure relief valve maintenance program appropriate for the specific operating conditions will ensure satisfactory valve performance and provide optimum service life. Should the pressure/media requirements of a pilot operated pressure relief valve be outside the capabilities of the repair facility, contact Anderson Greenwood for specific instructions before starting any maintenance activity

2 MAIN VALVE MAINTENANCE

2.1 Disassembly

Before beginning disassembly, bleed off any pressure trapped in the main valve or pilot. Refer to Figure 1A (piston/seat Type XX3) and Figure 1B (piston/seat Type XX9) for parts description and location.

Remove cap (Item 17) from the body (Item 1). Remove the liner seal (Item 6), liner (Item 5) and piston (Item 10). Remove the soft goods from the piston. If the piston is equipped with a wedge ring (Item 23), clean and retain it for use during assembly. The dipper tube (Item 4) is swaged in place and no attempt should be made to remove it. The nozzle (Item 3) should not be removed unless it is damaged or the nozzle seal (Item 2) is leaking.

NOTE

Do not remove lock pin and lift adjusting bolt (Items 11 and 12) on valves so equipped unless nozzle is removed. This bolt controls the piston lift and hence the valve's relieving capacity. If either or both the nozzle and lift bolt were removed, then lift must be reset following the procedure of paragraph 2.3.3 (Type XX3) or paragraph 2.3.4 (Type XX9).

2.1.1 Nozzle and nozzle seal disassembly

Refer to Figure 2 for parts description and location.


1. Remove lock pin and lift adjusting bolt from piston, if applicable.
2. Place liner in body and piston, without seat or seat retainer, into liner and on top of nozzle.
3. Place appropriate spacer (see Table I) on top of piston and then the cap over the spacer.
4. Thread the appropriate number of cap bolts (see Table I) into threaded holes on top of body. If two bolts are used, they should be 180° apart. When using four bolts, they should be 90° apart. Always use the shortest cap bolts supplied with the valve unless all cap bolts are required. For example, the 1" Type 40/50 is equipped with two 1.50" long bolts and two 1.88" long bolts but only the two 1.50" long bolts should be used. However, the 2" Type 40/50 is equipped with two 1.25" long bolts and two 1.62" long bolts and all four bolts are required for nozzle installation.
5. Tighten cap bolts evenly to the torque listed in Table I to compress nozzle seal.
6. Use a punch or bar with a light hammer and tap on the nozzle retainer teeth to loosen the nozzle retainer. Unthread nozzle retainer approximately 1/2 turn.
7. Loosen cap bolts to remove load from nozzle. Remove components from main valve.

2.2 Main valve nozzle rework

Should the main valve nozzle seating face become nicked or scratched such that the main valve seat does not seal, the imperfections can be removed by polishing the seating face with 400 grit sandpaper. If necessary, the nozzle may be removed from the body and the nozzle seating face (only the seating face) may be remachined and/or polished using 400 grit sandpaper on a flat surface plate.


The resurfaced nozzle must be within the limiting dimensions shown in the table and figure below. If the resurfaced seating face standoff is less than the minimum projection height listed, the nozzle must be replaced.

Valve size and type X = Main valve piston/seat type, 3 or 9	Min. nozzle projection height (in)
1/1.5 x 2 Type 44X/45X (D, E and F orifice)	.045
1.5 x 2 1/2 Type 44X/45X (G and H orifice)	.040
2" Type 44X/45X	.035
3" Type 44X/45X	.035
4" Type 44X/45X	.035
6" Type 44X/45X	.035
8" Type 44X/45X	.035
1.5" Type 46X	.035
2" Type 46X	.035
3" Type 46X	.035
4" Type 46X	.030
6" Type 46X	.030
8 x 88 Type 46X	.030
8 x 10 Type 46X	.030
10" Type 46X	.030



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS



2.3 Assembly

2.3.1 Nozzle and nozzle seal installation

1. Place nozzle seal and nozzle in body.
2. Place nozzle retainer over nozzle and thread into body until it stops on nozzle shoulder. Do not lubricate nozzle retainer threads or mating body threads.
3. Repeat steps 3 through 5 of disassembly procedure to compress nozzle seal. Thread nozzle retainer into body as seal is compressed to keep nozzle retainer from binding against piston.
4. Use a punch or bar with a light hammer and tap on the nozzle retainer teeth to snug the nozzle retainer threads.
5. Loosen cap bolts to remove load from spacer.
6. Remove spacer from valve.

2.3.2 Soft goods installation and main valve reassembly

Refer to Figure 1A (piston/seat Type XX3) and Figure 1B (piston/seat Type XX9) for parts description and location.

2.3.3 Type XX3 piston and seat

Clean and apply a light coating of Dow Corning No. 33 or equivalent silicone lubricant on all threads. Install new seat and reassemble seat retainer and seat retainer screw or screws.

NOTE

Over tightening of seat retainer screw or screws can distort or damage the seat and cause leakage. Retainer screw or screws should be installed until assembly is snug. Then tighten an additional ¼ to ½ turn to secure assembly.

On 1" to 4" Type 43/53 and 1.5" to 3" Type 63 valves, if either or both the nozzle and lift bolt were removed, then lift needs to be set. If lift setting gages are available, use lift setting procedure 06.3349 (gas service) or 06.3350 (liquid service); otherwise use procedure 05.2284.

On 1" to 4" Type 40-RL (Special Restricted Lift. This is different than Type 50 restricted lift) valves, use lift setting procedure #1101-28214.

Install new piston seal along with original wedge ring (if so equipped). Lubricate upper portion of liner I. D., piston seal, and wedge ring (if present) with Dow Corning No. 33 or equivalent for all gas service valves and for liquid service valves with set pressure below 275 psig.

Liquid service valves with set pressure at 275 psig and above use Desco 600 or equivalent. Use lubricant sparingly. Insert liner and piston into body and install new liner seal.

Install the cap making sure it is seated squarely into body. Torque cap bolts uniformly so as not to 'cock' cap. Such a condition may result in leakage at the liner seal or cause the piston and liner to bind. See Table II for torque values.

TABLE I

Valve size and type X = Main valve seat type, 3 or 9	Spacer P/N	Cap bolt thread	# Cap bolts to use	Cap bolt torque (ft-lb)
1/1.5 x 2 Type 44X/45X (D, E and F orifice)	06.5612.001	.500-20 UNF	2	31
1.5 x 2½ Type 44X/45X (G and H orifice)	06.5612.002	.500-20 UNF	2	41
1.5 x 2½ Type 44X/45X (G and H orifice)	06.5612.002	.625-18 UNF	2	51
2" Type 44X/45X	06.5612.004	.500-20 UNF	4	27
2" Type 44X/45X	06.5612.004	.625-18 UNF	4	34
3" Type 44X/45X	06.5612.006	.500-20 UNF	4	35
3" Type 44X/45X	06.5612.006	.625-18 UNF	4	44
4" Type 44X/45X	06.5612.008	.750-16 UNF	4	130
4" Type 44X/45X	06.5612.008	.875-14 UNF	4	151
6" Type 44X/45X	06.5612.009	.750-16 UNF	2	82
6" Type 44X/45X	06.5612.009	.875-14 UNF	2	95
8" Type 44X/45X	06.5612.010	.875-14 UNF	4	123
8" Type 44X/45X	06.5612.010	1.000-14 UNS	4	140
1.5" Type 46X	06.5612.004	.500-20 UNF	2	19
2" Type 46X	06.5612.006	.500-20 UNF	2	31
2" Type 46X	06.5612.006	.625-18 UNF	2	39
3" Type 46X	06.5612.008	.750-16 UNF	2	113
4" Type 46X	06.5612.011	.625-18 UNF	2	63
6" Type 46X	06.5612.012	.750-16 UNF	2	88
8 x 88 Type 46X	06.5612.013	.875-14 UNF	4	119
8 x 10 Type 46X	06.5612.014	1.125-12 UNF	10	89
10" Type 46X	06.5612.015	1.125-12 UNF	10	90

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

2.3.4 Type XX9 piston and seat

Clean and apply a light coating of Dow Corning No. 33 or equivalent silicone lubricant on all threads. Do not apply any lubricant to any of the soft goods. Install new seat and reassemble seat retainer and seat retainer screw or screws.

NOTE

Over tightening of seat retainer screw or screws can distort or damage the seat and cause leakage. Retainer screw or screws should be installed until assembly is snug. Then tighten an additional 1/4 to 1/2 turn to secure assembly.

On 1" to 4" Type 49/59 and 1.5" to 3" Type 69 valves, if either or both the nozzle and lift bolt were removed, then lift needs to be set. If lift setting gages are available, use lift setting procedure 06.3349 (gas service) or 06.3350 (liquid service); otherwise use procedure 05.2284.

On 1" to 4" Type 40-RL (Special Restricted Lift. This is different than Type 50 restricted lift) valves, use lift setting procedure #1101-28214.

Install new piston seal along with original wedge ring (if so equipped) and snap ring. Insert liner and piston into body and install new liner seal.

Install the cap making sure it is seated squarely into body. Torque cap bolts uniformly so as not to 'cock' cap. Such a condition may result in leakage at the liner seal or cause the piston and liner to bind. See Table II for torque values.

FIGURE 1A
Main valve
443/453/463




TABLE II

Bolt size	Torque value (ft-lb)
1/4	7
5/16	12
3/8	21
7/16	33
1/2	45
9/16	59
5/8	97
3/4	130
7/8	202
1	271
1 1/8	408

Item no.	Part name
1	Body
2	Nozzle seal ^[1]
3	Nozzle ^[1]
4	Dipper tube
5	Liner
6	Liner seal ^[2]
7	Seat ^[2]
8	Seat retainer
9	Seat retainer screw
10	Piston

Item no.	Part name
11	Lift adjusting bolt ^[4]
12	Lock pin ^[4]
13	Piston seal ^[2]
15	Nozzle retainer
16	Dome spring
17	Cap
18	Cap bolt
21	Supply tube
22	Tube connector
23	Wedge ring ^[3]

NOTES


- Field replaceable only if required.
- Recommended spare parts for repair.
- Used only for liquid service.
- Not used on 6", 8" Type 443/453 and 4" and larger Type 463.

Refer to Section 7.1 for soft goods repair kit part numbers.

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

FIGURE 1B
Main valve



Item no.	Part name	Item no.	Part name
1	Body	12	Lock pin ^[4]
2	Nozzle seal ^[1]	13	Piston seal ^[2]
3	Nozzle ^[1]	14	Snap ring ^[2]
4	Dipper tube	15	Nozzle retainer
5	Liner	16	Dome spring
6	Liner seal ^[2]	17	Cap
7	Seat ^[2]	18	Cap bolt
8	Seat retainer	21	Supply tube
9	Seat retainer screw	22	Tube connector
10	Piston	23	Wedge ring ^[3]
11	Lift adjusting bolt ^[4]		


NOTES

1. Field replaceable only if required.
2. Recommended spare parts for repair.
3. Used on 1" / 1½" (D,E,F orif. liq. only), 2" (liq. only), and 4" and larger Type 449/459 and 1½" (liq. only), and 3" and larger Type 469.
4. Not used on 6" or 8" Type 449/459 and 4" and larger Type 469.

Refer to Section 7.1 for soft goods repair kit part numbers

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES
INSTALLATION AND MAINTENANCE INSTRUCTIONS

FIGURE 2



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

3 PILOT MAINTENANCE

Refer to Figures 3, 4 and 5.

Arrange all parts in an orderly sequence on a flat work surface during disassembly. This will facilitate assembly and help ensure that the correct parts are assembled in the proper sequence.

3.1 Disassembly

Before beginning disassembly, bleed off any pressure trapped in the main valve or pilot.

3.1.1 Standard pilot - gas or liquid service

NOTE

If the pilot is equipped with a lift lever, the lift lever handle assembly (Item 50) must be removed from the cap (Item 18) before continuing with disassembly. To do this, hold the lift lever handle in the position shown in Figure 3, unscrew the handle assembly bushing (Item 51) from the cap, and remove the handle assembly.

Remove the cap (Item 18), for pilot with lift lever remove jam nut (Item 52) and lift lever nut (Item 53), loosen the jam nut (Item 17), and turn the adjustment screw (Item 16) counterclockwise to relieve the spring tension. Exercise caution when removing the spring bonnet (Item 15) from pilots set above 500 psig, as spring tension is not completely relieved until the bonnet is removed. Remove the spring bonnet, spring (Item 6), and spring washers (Item 13).

With the bonnet removed, the diaphragm case (Item 14), diaphragm support plate (Item 38) or sense plate (Item 43), and sense washer (Item 10) with internal parts attached can be removed from the body (Item 1). Unscrew the piston nut (Item 9) from the feedback piston (Item 3) and remove the lockwasher (Item 44). Disassemble the sense washer, diaphragm support plate or sense plate, diaphragm (Item 4), diaphragm shield (Item 47), diaphragm retaining washer (Item 37), and piston sleeve (Item 24) from the feedback piston. Unscrew the inlet nozzle (Item 5) from the feedback piston. Remove the spool spring (Item 8) and inlet nozzle with the spool from the feedback piston.

Remove the bias spring (Item 11) and unscrew the body plug (Item 2) from the body. Using a hex key (Allen wrench) inserted through the bottom of the body into the hex socket in the outlet nozzle (Item 28), unscrew the outlet nozzle and remove through the top of the body. Note that when viewed from the bottom of the body, the hex key is turned clockwise to unscrew the outlet nozzle.

3.1.2 Iso-Dome pilot - gas service

NOTE

All Iso-Dome pilots are gas service pilots; however, fully assembled valves with these pilots may be either gas service valves or liquid services valves.

After bleeding off any pressure trapped in the main valve or pilot, remove the pilot with the regulator (Item 63) attached from the main valve. Unscrew and remove bracket bolts (Items 60) and bracket bolts (Items 61). Slide the bracket (Item 57) outward approximately 1½" along the regulator cover spacer (Item 58). Using an 1½" wrench, unscrew the adapter (Item 56) with regulator attached from the body (Item 1). If necessary, slide the bracket farther out along the cover spacer so that it does not hit the body. Support the regulator during this operation in order to avoid damaging the adapter threads or the body threads. Loosen set screw (Item 62) and remove regulator cover cap (Item 59), regulator cover spaces (Item 58), and bracket.

Continue pilot disassembly in accordance with the procedures described in paragraph 3.1.1 except that the Iso-Dome pilot uses an adapter in place of the body plug (Item 2) in a standard pilot.

3.1.3 Iso-Sense pilot - gas or liquid service

The Iso-Sense pilot sectional drawing shown in Figure 3 is presented for identification purposes only. This is a special pilot assembly which may incorporate non-standard components. Contact Anderson Greenwood for replacement parts and maintenance instructions for individual pilots (serial number is required for complete identification).

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

3.1.4 Pilot variations and accessories

For pilot equipped with a one-piece spool, Figure 3 Style A, remove the spool seal (Item 31) and the outlet seat (Item 33) from the spool (Item 34); then remove the spool from the inlet nozzle.

For pilot equipped with a three-piece spool, Figure 3 Style E, unscrew the spool nut (Item 48) from the inner spool (Item 36), remove the outer spool (Item 35) from the inlet nozzle and remove the inner spool from the outer spool.

For pilot equipped with a field test accessory, Figure 4, remove this accessory with the shuttle from the body (Item 1). Disassemble the dome connector from the field test body and remove the spring, plunger and shuttle.

For pilot equipped with a backflow preventer and pilot exhaust backflow check valve, Figure 5, remove these accessories from main valve dome port (backflow preventer) and the pilot exhaust port (backflow check valve). Unscrew the backflow preventer bushing from the body and remove the spring and shuttle. Unscrew the fitting from the backflow check valve body and remove the flow washer and ball.

Remove and discard all old seats, seals and O-rings before beginning assembly.

3.2 Assembly

3.2.1 Standard pilot - gas or liquid service

Assembly is done in the reverse order of disassembly. Lightly lubricate all O-rings, all sliding surfaces, screw threads and spring washer pivot points with Dow Corning No. 33 silicone grease or equivalent. Do not lubricate the inlet seat (Item 7) or the outlet seat (Item 33). For pilot with lift lever, do not install lift lever handle assembly (Item 50) until final pilot adjustment is completed, see paragraph 4.6. When assembling the pilot, the following should be observed:

Diaphragm/piston assembly

Assemble the diaphragm shield (Item 47) on top of the diaphragm. Assemble the diaphragm support plate (Item 38), with the rounded edge towards the diaphragm shield. The nut holding the diaphragm/piston assembly together must not be torqued in excess of 10 ft-lbs. Overtightening will damage the diaphragm.

Pilot assembly and pretest

When assembling diaphragm case sub-assembly to body sub-assembly, orient hole in case to fit over the length of damper bushing (Item 23) projecting past the body face. Engage spool in outlet nozzle and press gently until assembly drops into place.

Pretest to verify proper feedback piston function by depressing piston stack assembly downward. The bias spring (Item 11) should return the stack assembly to the upward position. If stack assembly does not return, identify and correct source of malfunction before completing assembly.

3.2.2 Iso-Dome pilot - gas service

All Iso-Dome pilots are gas service pilots (see Note paragraph 3.1.2).

Assemble pilot in accordance with procedures described in paragraph 3.2.1. Support the regulator when threading the adapter (Item 56) with regulator attached into the body (Item 1). With an $1\frac{1}{16}$ " wrench used to back-up the adapter, the regulator may be rotated $\pm \frac{1}{4}$ turn about the adapter axis to align the bracket (Item 57) mounting surfaces on the body and the regulator bracket (Item 64).

If alignment can not be achieved with $\pm \frac{1}{4}$ turn, unthread the regulator from the adapter. Clean the $\frac{1}{4}$ NPT threads on the adapter and in the regulator outlet port and wrap the adapter threads with several wraps of PTFE thread seal tape. Screw the regulator onto the adapter and tighten sufficiently to effect a thread seal and alignment of the bracket mounting surfaces.

Loosen the two #10-24 socket head cap screws in the regulator bracket so that the bracket can slide along the outside of the regulator. Install the bracket (Item 60) and hand tighten two bracket bolts into the body. Hand tighten two bracket bolts into the regulator bracket and securely tighten the two #10-24 socket head cap screws into the regulator bracket. Securely tighten the four bracket bolts. Do not install the regulator cover spacer and regulator cover cap until final adjustment is completed, see paragraph 4.3.

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES


INSTALLATION AND MAINTENANCE INSTRUCTIONS

3.2.3 Accessories

Assembly is done in the reverse order of disassembly. On backflow preventers [Reference Figures 4 and 5], lightly lubricate the bushing threads with Dow Corning No. 33 silicone grease or equivalent. A small amount of lubricant can be applied to the bushing seal(s).


Do not get any lubricant on the shuttle, shuttle seat(s) and or bushing seat. When re-installing the backflow preventer on the main valve dome port orient it so that the bushing is connected to the pilot (process) side.

FIGURE 3
Pilot
(Continued thru page 12)




ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES INSTALLATION AND MAINTENANCE INSTRUCTIONS

FIGURE 3
Pilot
(Continued from page 9)



Style E
(301-740 psig shown)




Lift lever assembly

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS


FIGURE 3
Pilot
(Continued from page 9)



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

FIGURE 3
Pilot
(Continued from page 9)



WARNING

In order to achieve the high gain functionality, the pilot's piston feedback, sleeve piston and seal piston are different from the standard parts. Components that are not supplied by Emerson should not, under any circumstances, be used in any Anderson Greenwood valve, because they might adversely affect the performance of the valve, and could cause personal injury and property damage.

NOTES


1. Recommended spare parts for repair.
2. For style E pilots.
3. After Nov. 1999 pilot exhaust connected to main valve outlet for standard assemblies and exhaust vent not supplied except standard Iso-Dome pilot assemblies exhaust to atmosphere and are supplied with exhaust vent.
4. Items 3, 24 and 26 are different than the standard for the Hi-Gain Option.

Item	Description	Item	Description	Item	Description
1	Body	23	Bushing/damper	45	Seal, diaphragm ^[1]
2	Plug, body	24	Sleeve, piston	46	Seal, body/case ^[1]
3	Piston, feedback	25	Seal, sleeve ^[1]	47	Shield, diaphragm ^[1]
4	Diaphragm ^[1]	26	Seal, piston ^[1]	48	Nut, spool ^[2]
5	Nozzle, inlet	27	Seal, inlet nozzle ^[1]	49	Insert, bonnet
6	Spring	28	Nozzle, outlet	50	Handle, assy, lift lever
7	Seat, inlet ^[1]	29	Seal, upper outlet nozzle ^[1]	51	Bushing, lift lever handle assy
8	Spring, spool	30	Seal, body plug ^[1]	52	Nut, jam
9	Nut, piston	31	Seal, spool ^[1]	53	Nut, lift lever
10	Washer, sense	32	Seal, lower outlet nozzle ^[1]	54	Rod, lift lever
11	Spring bias	33	Seat, outlet ^[1]	55	Bushing, lift lever
12	Seal, piston ^[1]	34	Spool	56	Adapter
13	Washer, spring	35	Spool, outer ^[2]	57	Bracket
14	Case, diaphragm	36	Spool, inner ^[2]	58	Spacer, regulator cover
15	Bonnet, spring	37	Washer, diaphragm retaining	59	Cap, regulator cover
16	Screw, adjustment	38	Plate, diaphragm support	60	Bolt-DH, bracket
17	Nut, jam	39	Pipe plug	61	Bolt, bracket
18	Cap	40	Screen, inlet	62	Screw-set
19	Vent, bonnet	41	Plug, body f.t. port	63	Regulator
20	Bolt, case	42	Vent, exhaust port ^[3]	64	Bracket-regulator
21	Bolt, body	43	Plate, sense	65	Coupling
22	Seal, body/diaphragm ^[1]	44	Washer, lock		

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS



FIGURE 4
Field test accessory




* Spring based shuttle design standard from July 1st, 2002

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES INSTALLATION AND MAINTENANCE INSTRUCTIONS


FIGURE 5
Pilot exhaust backflow check valve



Backflow preventer
(Standard prior to September 2002)



Backflow preventer with bias spring
(Standard beginning in September 2002)



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

4 PILOT ADJUSTMENT

4.1 Definitions

Set pressure is defined as that pressure where the dome pressure is 70% of the supply pressure. This corresponds to the initial audible discharge of gas or first steady stream of liquid from the main valve.

Crack pressure is defined as the supply pressure where gas or liquid flow begins at the pilot exhaust.

Reseat pressure is defined as the supply pressure where the dome pressure increases to 75% of supply pressure. The dome pressure will continue to increase until the supply pressure decreases to 94% of set.

4.2 Set pressure, standard pilot

4.2.1 Gas service pilot

To adjust the set pressure, a test setup similar to that shown in Figure 6 should be used. The test media should be air. The adjustment screw should be turned IN most of the way. Increase the supply pressure to nameplate setting and slowly back out the adjustment screw until flow through the pilot exhaust begins. Continue to slowly back out the adjustment screw until dome pressure is 70% of the supply pressure and the supply pressure meets the required set pressure tolerance of paragraph 4.5. After adjustment is completed, securely tighten the jam.

To determine reseal pressure, shut off the air supply and use the accumulator vent valve to slowly reduce the supply pressure until the dome pressure is 75% of supply pressure.

Close the shut-off valve and slowly open the bleed valve. When the dome pressure gauge reading is zero, the pilot may be removed from the test set-up.

4.2.2 Liquid service pilot

NOTE

An initial set pressure adjustment may be made with air as the supply pressure media using a test set-up similar to that shown in Figure 6 and following the procedure described in paragraph 4.2.1 above. This initial set pressure will be approximately 1½% lower than the set pressure observed when the pilot is tested on liquid.

To adjust the set pressure, a test set-up similar to that shown in Figure 7 should be used.

The test media should be water. Some air volume must be maintained above the water surface in the accumulator.

Increase the air supply pressure to nameplate setting and slowly back out the adjustment screw until water flow through the pilot exhaust begins. Continue to slowly back out the adjustment screw until dome pressure is 70% of the supply pressure and the supply pressure meets the required set pressure tolerance of paragraph 4.5.

To determine reseal pressure, shut off the air supply and use the accumulator vent valve to slowly reduce supply pressure until the dome pressure is 75% of supply pressure.

Close the shut-off valve in the water line to the pilot inlet port and slowly open the bleed valve. When the dome pressure gauge reading is zero, the pilot may be removed from the test set-up.

The optional indicator assembly shown in Figure 7 may be used for set pressure above 70 psig. If an indicator assembly is used, slowly increase the supply pressure until the indicator pin pulls into the indicator assembly and is approximately flush with the end of the indicator body. The pressure when the pin pulls in is the set pressure. Loosen the jam nut, adjust the adjustment screw, and retighten the jam nut as required to meet the set pressure tolerance of paragraph 4.5.

Shut off the air supply and use the accumulator vent valve to slowly bleed down supply pressure until the indicator pin 'pops' out of the indicator assembly (full extension of the pin is approximately 7/16"). The pressure when the pin 'pops' out is the reseal pressure.

Close the shut-off valve in the water line to the pilot inlet port and slowly open the bleed valve. When the dome pressure gauge reading is zero, the pilot may be removed from the test set-up.

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

4.3 Set pressure, Iso-Dome pilot

NOTE

All Iso-Dome pilots are gas service pilots
(See Note paragraph 3.1.2).

4.3.1 Gas sense pilot

To adjust set pressure, a test set-up similar to that shown in Figure 8 should be used. The air supply to the regulator inlet should be adjusted so that the dome pressure gauge reading is $92\% \pm 2\%$ of nameplate set pressure. The pressure at the regulator inlet should be a minimum of 200 psi greater than the specified dome pressure. The adjustment screw should be turned IN most of the way. Generally it is not necessary to perform any service work on the regulator; however, if maintenance or repair is indicated, contact the regulator manufacturer for instructions and parts. The regulator output pressure should be adjusted if service was performed on the regulator or the pilot set pressure is being changed. Apply pressure to the regulator inlet port of 200 psi greater than the specified dome pressure. Using a $\frac{1}{2}$ " open end wrench, turn the regulator adjusting screw, clockwise rotation increases and counterclockwise rotation decreases output pressure, as required to produce a dome pressure gauge reading equal to $92\% \pm 2\%$ of the specified pilot set pressure. Final adjustment should be made in the increasing pressure direction (with clockwise rotation). After final adjustment is completed, install the regulator cover spacer and the regulator cover cap. Adjust regulator adjusting screw so that socket head set screw in regulator cover cap will tighten against the flat of the regulator adjusting screw. This may require $\pm\frac{1}{4}$ turn of regulator adjusting screw. Securely tighten the socket head set screw to lock the cover cap to the regulator adjusting screw.

WARNING

If regulator output pressure is set outside of the $92\% \pm 2\%$ of nameplate set pressure limits, the pilot (and the assembled valve) set pressure may not comply with the tolerance requirements of Section VIII and Section XIII of the ASME Boiler and Pressure Vessel Code.

Increase the supply pressure to the nameplate setting and slowly back out the adjustment screw until flow through the pilot exhaust begins. Continue to slowly back out the adjustment screw until dome pressure is 70% of the supply pressure. After adjustment is completed, securely tighten the jam nut.

Close the block valve in the air supply line to the accumulator, close the block valve in the air supply line to the regulator, verify that the shut-off valve is open, slowly open the vent valve, and slowly open the bleed valve. When the supply pressure gauge and the dome pressure gauge each read zero, the pilot may be removed from the test set-up.

4.3.2 Liquid sense pilot

To adjust the set pressure, a test set-up similar to that shown in Figure 9 should be used. The air supply to the regulator inlet should be adjusted so that the dome pressure gauge reading is $92\% \pm 2\%$ of nameplate set pressure. The pressure at the regulator inlet should be a minimum of 200 psi greater than the specified dome pressure. Generally it is not necessary to perform any service work on the regulator; however, if maintenance or repair is indicated, contact the regulator manufacturer for instructions and parts. If service was performed on the regulator or if the pilot set pressure is being changed, the regulator output pressure should be adjusted following the procedure described in paragraph 4.3.1.

Adjust the pilot set pressure in accordance with procedure described in paragraph 4.2.2 except no initial set pressure adjustment is made.

Close the block valve in the air supply line to the accumulator, close the block valve in the air supply line to the regulator, verify that the shut-off valve in the water line to the pilot is open, slowly open the vent valve, and slowly open the bleed valve. When the supply pressure gauge and the dome gauge each read zero, the pilot may be removed from the test set-up.

4.4 Range of adjustment

All pilots can be adjusted $\pm 5\%$ beyond the nameplate setting. If a set pressure change is made that requires a new spring, consult Factory or refer to appropriate spring chart in Anderson Greenwood report number 05.9065.017 to make proper selection.

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

4.5 PERFORMANCE REQUIREMENTS

Set pressure (psig)	Set pressure tolerance	Crack pressure minimum	Reseat pressure limits
15-70 inclusive	± 2 psig	94% of set	0 to 3 psig below set
Above 70 to 740 inclusive	± 3%	94% of set	96 to 100% of set

CAUTION

To avoid damaging any of the lift lever components, do not rotate the lift lever handle past that position where the cam surface of the handle assembly first contacts the lower face of the lift lever nut.


4.6 Lift lever handle assembly installation

For pilot equipped with a lift lever, install the lift lever handle assembly (Item 50) after completing the final pilot adjustment. Screw the lift lever nut (Item 53) on the threaded portion of the lift lever rod (Item 54) until the lower face of the lift lever nut is approximately 2 1/16" above the top of the spring bonnet (Item 15). Use the jam nut to lightly lock the lift lever nut in place. Screw the cap on the threaded projection of the bonnet insert (Item 52) until it is hand tight against the spring bonnet. The lower face of the lift lever nut should be even with the center of the threaded hole in the cap. If the lift lever nut is not positioned correctly, remove the cap and adjust the nuts as required, and reinstall the cap. With the lift lever handle held in the position

shown in Figure 3, install the handle assembly by screwing the handle assembly bushing (Item 51) into the cap. The cam surface of the lift lever handle assembly must contact the lower face of the lift lever nut between 15° and 45° of clockwise or counterclockwise rotation of the handle past its null or centered position. Resistance of the handle indicates contact has occurred. If resistance occurs at less than 15°, the lift lever nut must be positioned higher. If resistance first occurs at more than 45°, the nut must be positioned lower on the lift lever rod.

If necessary, remove the handle assembly from the cap following the procedure of paragraph 3.1 and repeat this assembly procedure in order to correctly position the lift lever nut and jam nut on the threaded portion of the lift lever rod. When correctly positioned lock the lift lever nut with the jam nut, install and securely tighten the cap, install the handle assembly, and securely tighten the handle assembly bushing.


FIGURE 6



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS


FIGURE 7



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS


FIGURE 8



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

FIGURE 9



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

5 VALVE ASSEMBLY TESTING

5.1 General

The complete valve assembly should be tested for internal and external leakage and to verify set pressure using a test set-up similar to that shown in Figure 10, 11, or 12. The test media should be air.

CAUTION

Do not test liquid service valves using water or other liquid test media. Liquid service valves should be tested using air as the test media in accordance with the procedures described below. Testing fully assembled liquid service valves using air ensures that no water or other liquid will remain in the main valve dome after final valve testing.

5.2 Low pressure leakage check

NOTE

For valve with Iso-Dome pilot, apply regulator supply pressure equal to a minimum of 200 psi greater than 92% of set pressure.

5.2.1 Valve for gas service or valve with Iso-Dome pilot

Slowly increase the supply pressure to 30% of set pressure. Check for main valve nozzle, seat, and piston seal leakage at the main valve outlet. To help in seating the valve seat and piston seal, the valve may be actuated several times. No leakage shall occur in 15 seconds.

5.2.2 Valve for liquid service

Slowly increase supply pressure to 30% of set pressure. Check for main valve nozzle, seat, and piston seal leakage at the main valve outlet. To help in seating the valve seat and piston seal, the valve may be actuated several times. No leakage shall occur in 15 seconds. If leakage is detected at the valve outlet, note the leakage in bubbles observed in 15 seconds and remove the leakage test device from the outlet flange. With the same supply pressure applied to the valve inlet, use a bubble test leak detector to measure leakage through the pilot exhaust. Low pressure leakage performance is acceptable if the leakage at the main valve outlet is equal to the pilot exhaust leakage and this leakage value does not exceed 15 bubbles in 15 seconds.

Liquid service valve with Iso-Dome pilot should be tested per paragraph 5.2.1.

5.3 High pressure leakage check

NOTE

For valve with Iso-Dome pilot, apply regulator supply pressure equal to a minimum of 200 psi greater than 92% of set pressure.

5.3.1 Valve for gas service or valve with Iso-Dome pilot

Apply supply pressure to the inlet equal to 90% of the set pressure. Check for leakage at the main valve outlet. Using a suitable gas and air leak detector solution, check for leakage at the cap seal and other pressure connections. No leakage shall occur at the valve outlet and no visible leakage shall be detected at the cap seal or other pressure connections in one minute.

5.3.2 Valve for liquid service

Apply supply pressure to the inlet equal to 90% of the set pressure. Check for leakage at the main valve outlet. Using a suitable gas and air leak detector solution, check for leakage at the cap seal and other pressure connections. No leakage shall occur at the valve outlet and no visible leakage shall be detected at the cap seal or other pressure connections in one minute. If leakage is detected at the valve outlet, note the leakage in bubbles observed in one minute and remove the leakage test device from the outlet flange. With the same supply pressure applied to the valve inlet use a bubble test leak detector to measure leakage through the pilot exhaust. High pressure leakage performance is acceptable if the leakage at the main valve outlet is equal to the pilot exhaust leakage and this leakage value does not exceed 60 bubbles in one minute.

Liquid service valve with Iso-Dome pilot to be tested per paragraph 5.3.1.

Where superimposed back pressure is specified, the downstream or exhaust connections which are exposed to the back pressure shall be tested at 1.5 times the specified back pressure and all mechanical connections so pressurized will be checked for leaks. No visible leakage shall occur in one minute using a suitable gas and air leak detector solution.

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

5.4 Main valve function check

CAUTION

This test must be performed at a slow rate of pressure increase to ensure that the main valve does not go into full lift. The pressure applied to the inlet is not to exceed 105% of nameplate set pressure.

After completing the high pressure leakage check of paragraph 5.3, verify main valve opening as follows. Remove the leakage test device from the outlet flange. Slowly increase the inlet pressure above 90% of set pressure. Continue increasing inlet pressure until an audible discharge at the valve outlet verifies main valve opening.

FIGURE 10
Test set-up for valve with standard pilot





FIGURE 11
Test set-up for valve with remote sense pilot



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

5.7 Iso-Sense pilot operated pressure relief valve

In this special pilot operated pressure relief valve, the sense pressure applied to the pilot inlet/sense port is supplied from a remote source and the sense pressure media is isolated from the process media. The valve assembly is available for either a gas or liquid process media with either a gas or liquid sense media. The typical Iso-Sense pilot operated pressure relief valve shown in Figure 13 below is presented for identification purposes only. This is a special pressure relief valve assembly which may require special set pressure adjustment procedures. Contact Anderson Greenwood for replacement parts and maintenance instructions for individual valve assemblies (serial number is required for complete identification).

FIGURE 12
Test set-up for valve with Iso-Dome pilot





FIGURE 13
Iso-Sense pilot operated pressure relief valve



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

6 PILOT SET PRESSURE FIELD TEST PROCEDURE

6.1 General

CAUTION

If the pressure relief valve is not isolated from the process media while performing this test the main valve will open if system pressure rises to set point or above.

The set pressure of valves equipped with a field test accessory can be checked with the valve installed, in operation. The field test accessory consists of a check valve in the pilot supply line through which test pressure from an external source can be supplied to the pilot. A test set up similar to that shown in Figure 14 and procedure similar to the follow should be used. This procedure accurately checks the set pressure; it does not provide an accurate check of reseal pressure.

NOTE

Gas flows through the flexible hose and vents past the indicator plunger to atmosphere when the plunger begins to retract. With gas flowing through the hose, there will be a pressure drop from the gas bottle to the field test fitting port. To ensure an accurate reading of set pressure, the flexible hose should be a 3/8-inch inside diameter hose and if the length exceeds 10-feet, the test gauge should be positioned at the alternate location (see Figure 14). If the test gas is supplied through a regulator, the effective orifice diameter of the regulator should be a minimum of 0.125-inch.

The main valve will not open while performing this field test as long as the process pressure remains below the set pressure. To cause the main valve to open, slowly increase the test pressure above the set pressure until the piston lifts and process media is discharged through the main valve. To close the main valve, close block valve 'A' and open vent valve 'C'.

6.2 Procedure


- Connect flexible hose from test gas bottle to field test fitting port.
- Close vent valve 'C'.
- Open block valve 'A' slowly to increase pressure until the indicator actuates. The set pressure will be the pressure indicated on the test gauge at the time gas vents past the indicator plunger and/or the indicator plunger retracts (test gauge reading will decrease if rate of pressure increase is sufficiently slow).

WARNING

Keep all parts of body clear of indicator plunger during test to avoid contact with gas venting past the indicator plunger.

- To remove set up, close block valve 'A', open vent valve 'C', and remove flexible hose from field test fitting port.

FIGURE 14



ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

7 SOFT GOODS REPAIR KITS

The kits listed below are available from stock. Each kit contain all the seals and seats to repair a main valve or pilot and any required lubricants. Pilot kits also contain all the seals and seats for field test and backflow accessories. To order soft goods kits specify the base number and select the last three digits from the following tables.

To ensure the correct soft goods kit is ordered, specify the valve model and serial number.

For soft goods kits with elastomers other than those listed, contact Anderson Greenwood or an authorized representative.

7.1 Main valve - kit base number: 06.3365.XXX

TYPE 443/453

Material	1 x 2 1½ x 2	1½ x 3*	2 x 3	3 x 4	4 x 6	6 x 8	8 x 10
Urethane and NBR seats, NBR seals	001	002	003	004	005	006	007
Urethane and FPM seats, FPM seals	012	013	014	015	016	017	018
Urethane and EPR seats, EPR seals	141	142	143	144	145	146	147

* Also 1½ x 2 threaded valve with 'G' and 'H' orifice

TYPE 463

Material	1½ x 2	2 x 3 2 x 3 x 3	3 x 4 3 x 4 x 4	4 x 6 4 x 6 x 6	6 x 8 6 x 8 x 8	8 x 8 x 8	8 x 10 8 x 10 x 10	10 x 14
Urethane and NBR seats, NBR seals	003	004	005	008	009	010	011	357
Urethane and FPM seats, FPM seals	014	015	016	019	020	021	022	358
Urethane and EPR seats, EPR seals	143	144	145	148	149	150	151	359

TYPE 449/459

Material	1 x 2 1½ x 2	1½ x 3*	2 x 3	3 x 4	4 x 6	6 x 8	8 x 10
PTFE seat/seal (set press., psig)	200 (15-600)	201 (15-600)	202 (15-400)	203 (15-400)	204 (15-400)	205 (15-275)	206 (15-275)
PTFE seat/seal (set press., psig)	211 (601-740)	212 (601-740)	213 (401-740)	214 (401-740)	215 (401-740)	216 (276-740)	217 (276-740)

* Also, 1½ x 2 threaded valve with G and H orifice

TYPE 469

Material	1½x2	2x3 2x3x3	3x4 3x4x4	4x6 4x6x6	6x8 6x8x8	8x8x8	8x10 8x10x10	10x14
PTFE seat/seal (set press., psig)	202 (15-400)	203 (15-400)	204 (15-400)	207 (15-400)	208 (15-275)	209 (50-275)	210 (15-275)	362 (50-275)
PTFE seat/seal (set press., psig)	213 (401-740)	214 (401-740)	215 (401-740)	218 (401-740)	219 (276-740)	220 (276-740)	221 (276-740)	363 (276-740)

ANDERSON GREENWOOD SERIES 400 DIAPHRAGM PILOT OPERATED SAFETY RELIEF VALVES

INSTALLATION AND MAINTENANCE INSTRUCTIONS

7.2 PILOT - (Includes seals for BFP and FT)

Material	15-1480 psig Diaphragm version
NBR	04.4749.763
FPM	04.4749.764
EPR	04.4749.818
AFLAS	04.4749.819

7.3 ACCESSORIES - (Supply filter kit includes filter screen)

Accessory	Material	Kit
Spike snubber	NBR	04.6419.012
Spike snubber	FPM	04.6419.013
Supply filter	PTFE/SST	04.6419.014

8 PILOT ACCESSORIES

8.1 LIFT LEVER CONVERSION KITS

Pilot set pressure	Kit part no.
15-500 psig	06.3416.001
501-1480 psig	06.3416.002

9 ASSEMBLY AND MAINTENANCE EQUIPMENT

9.1 NOZZLE REMOVAL AND INSTALLATION SPACER KITS

Description	Kit part no.
All sizes and types	06.3362.001
1" - 3" All types	06.3362.002
4" - 8" All types	06.3362.003
All sizes and types except without Series 500	06.3362.004
1" - 3" All types except without Series 500	06.3362.005

9.2 LIFT STOP SETTING GAUGE KITS

Description	Kit part no.
All sizes and types all services	06.3352.001
All Sizes and types gas service only	06.3352.002

9.3 PILOT TEST STANDS

Description	Kit part no.
Multiple configurations available	Contact Anderson Greenwood
Indicator assembly for liquid service pilots	01.4434.001

ANGMC-6019-EN © 2013, 2022 Emerson Electric Co. All rights reserved 04/22. Anderson Greenwood is a mark owned by one of the companies in the Emerson Automation Solutions business unit of Emerson Electric Co. The Emerson logo is a trademark and service mark of Emerson Electric Co. All other marks are the property of their prospective owners.

The contents of this publication are presented for informational purposes only, and while every effort has been made to ensure their accuracy, they are not to be construed as warranties or guarantees, express or implied, regarding the products or services described herein or their use or applicability. All sales are governed by our terms and conditions, which are available upon request. We reserve the right to modify or improve the designs or specifications of such products at any time without notice.

Emerson Electric Co. does not assume responsibility for the selection, use or maintenance of any product. Responsibility for proper selection, use and maintenance of any Emerson Electric Co. product remains solely with the purchaser.

Emerson.com