


Modul Controller SE-Power

CANopen manual



EG-Konformitätserklärung

Dokument-Nr. V1.01d
Monat Jahr Feb. 2003
Hersteller Afag Automation AG
Anschrift Fiechtenstrasse 32
CH-4950 Huttwil
Produktbezeichnung SE-Power PTL5

Die bezeichneten Produkte stimmen mit den Vorschriften folgender Europäischer Richtlinien überein:


Nummer 73/23EWG mit Änderung 93/68/EWG
Text Richtlinien des Rates vom 19. Februar 1973 zur Angleichung der Rechtsvorschriften der Mitgliedsstaaten betreffend elektrische Betriebsmittel zur Verwendung innerhalb bestimmter Spannungsgrenzen.
Nummer 89/336/EWG
Text Richtlinien des Rates zur Angleichung der Rechtsvorschriften der Mitgliedsstaaten über die elektromagnetische Verträglichkeit

Weitere Angaben zur Einhaltung dieser Richtlinien enthält der Anhang 1 und 2. Diese Anhänge sind Bestandteil dieser Erklärung. Diese Erklärung bescheinigt die Übereinstimmung mit der genannten Richtlinie, beinhaltet jedoch keine Zusicherung von Eigenschaften. Die Sicherheits- und Installationshinweise der Produktdokumentation sind zu beachten.


Anbringung der CE-Kennzeichnung (nur nach Niederspannungsrichtlinien): 2002

Aussteller Afag Automation AG
Ort, Datum Huttwil, den 12.8.2004

Rechtsverbindliche Unterschrift



Dr. Martin Daniel
Geschäftsführer Afag AG



Marc Zingg
Produktmanager Afag AG

Inhaltsverzeichnis:

1	General Terms	10
1.1	Documentation	10
1.2	CANopen	10
2	Safety Notes for electrical drives and controls	11
2.1	Symbols and signs	11
2.2	General notes	12
2.3	Danger resulting from misuse.....	13
2.4	Safety notes	13
2.4.1	General safety notes	13
2.4.2	Safety notes for assembly and maintenance	15
2.4.3	Protection against contact with electrical parts	16
2.4.4	Protection against electrical shock by means of protective extra-low voltage (PELV)	17
2.4.5	Protection against dangerous movements.....	18
2.4.6	Protection against contact with hot parts	19
2.4.7	Protection during handling and assembly	19
3	Cabling and pin assignment	20
3.1	Pin assignment.....	20
3.2	Verkabelungs-Hinweise.....	21
4	Activation of CANopen	21
4.1	Survey.....	21
5	Access methods.....	23
5.1	Survey.....	23
5.2	Access by SDO	25
5.2.1	SDO sequences to read or write parameters.....	26
5.2.2	SDO-error messages	28
5.2.3	Simulation of SDO accesses via RS232.....	29
5.3	PDO-Message.....	30
5.3.1	Description of objects	31
5.3.2	Objects for parameterising PDOs	33
5.3.3	Activation of PDOs	38
5.4	SYNC-Message	40
5.5	EMERGENCY-Message	40
5.5.1	Structure of an EMERGENCY message.....	40
5.5.2	Description of Objects	42
5.6	Heartbeat / Bootup (Error Control Protocol).....	44
5.6.1	Structure of the heartbeat message	44
5.6.2	Structure of the Bootup message	44
5.6.3	Objects.....	45

5.7	Network management (NMT service)	45
5.8	Table of identifiers.....	47
6	Adjustment of parameters	47
6.1	Load and save set of parameters	48
6.1.1	Survey.....	48
6.1.2	Description of Objects	50
6.2	Conversion factors (Factor Group)	52
6.2.1	Survey.....	52
6.2.2	Description of Objects	53
6.3	Power stage parameters	61
6.3.1	Survey.....	61
6.3.2	Description of Objects	61
6.4	Current control and motor adaptation.....	68
6.4.1	Survey.....	68
6.4.2	Description of Objects	68
6.5	Velocity controller.....	76
6.5.1	Survey.....	76
6.5.2	Description of Objects	76
6.6	Position Control Function	78
6.6.1	Survey.....	78
6.6.2	Description of Objects	80
6.7	Analogue inputs	88
6.7.1	Survey.....	88
6.7.2	Description of Objects	88
6.8	Digital inputs and outputs	90
6.8.1	Survey.....	90
6.8.2	Description of Objects	90
6.9	Homing switches (Limit / Reference switch)	92
6.9.1	Survey.....	92
6.9.2	Description of Objects	92
6.10	Brake control.....	95
6.10.1	Survey.....	95
6.10.2	Description of Objects	95
6.11	Device informations.....	97
6.11.1	Description of Objects	97
7	Device Control.....	105
7.1	State diagram (State machine).....	105
7.1.1	Survey.....	105
7.1.2	The state diagram of the servo controller	106
7.1.3	controlword	110
7.1.4	Reading the status of the servo controller	113
7.1.5	statusword.....	114

7.1.6	Description of Objects	117
8	Operating Modes.....	119
8.1	Adjustment of the Operating Mode	119
8.1.1	Survey.....	119
8.1.2	Description of Objects	119
8.2	Operating Mode »Homing mode«	122
8.2.1	Survey.....	122
8.2.2	Description of Objects	122
8.2.3	Homing sequences	125
8.2.4	Control of the homing operation	131
8.3	Operating Mode »Profile Position Mode«	133
8.3.1	Survey.....	133
8.3.2	Description of Objects	134
8.3.3	Functional Description.....	139
8.4	Interpolated Position Mode.....	141
8.4.1	Survey.....	141
8.4.2	Description of Objects	141
8.4.3	Functional Description.....	148
8.5	Profile Velocity Mode.....	150
8.5.1	Survey.....	150
8.5.2	Description of Objects	151
8.6	Profile Torque Mode.....	158
8.6.1	Survey.....	158
8.6.2	Description of Objects	159
9	Changes to SE-POWER series	164
10	Appendix	165
10.1	Characteristics of the CAN interface.....	165
10.2	Header File	165
11	Keyword index.....	172
12	180

Abbildungsverzeichnis:

Figure 3.1:	CAN connector for SE-POWER.....	20
Figure 3.2:	Cabling (schematically).....	21
Figure 5.3:	Access methods	24
Figure 5.4:	NMT-State machine.....	46
Figure 6.5:	Survey: Factor Group	53
Figure 6.6:	Trailing error (Following Error) – Function Survey.....	78
Figure 6.7:	Trailing error (following error).....	79
Figure 6.8:	Position Reached – Function Survey	79
Figure 6.9:	Position reached.....	80
Figure 6.10:	Function of brake delay (in Operating Mode Profile Velocity Mode and Operating Mode »Profile Position Mode«)	95
Figure 7.11:	State diagram of the servo controller	106
Figure 7.12:	Most important state transitions	107
Figure 8.1:	Homing Mode	122
Figure 8.2:	Home Offset	123
Figure 8.3:	Homing operation to the negative limit switch including evaluation of the zero impulse	126
Figure 8.4:	Homing operation to the positive limit switch including evaluation of the zero impulse	126
Figure 8.5:	Homing operation to the reference switch evaluating the zero impulse for a positive start motion.....	127
Figure 8.6:	Homing operation to the reference switch evaluating the zero impulse for a negative start motion	127
Figure 8.7:	Homing operation to the negative limit switch	128
Figure 8.8:	Homing operation to the positive limit switch	128
Figure 8.9:	Homing operation to the reference switch for a positive start motion	129
Figure 8.10:	Homing operation to the reference switch for a negative start motion	129
Figure 8.11:	Homing operation to the negative stop evaluating the zero impulse.....	130
Figure 8.12:	Homing operation to the positive stop evaluating the zero impulse	130
Figure 8.13:	Homing operation to the negative stop	131
Figure 8.14:	Homing operation to the positive stop.....	131
Figure 8.15:	Homing operation only referring to the zero impulse.....	131
Figure 8.16:	Trajectory generator and position controller.....	133
Figure 8.17:	The trajectory generator	134

Figure 8.18: Positioning job transfer from a host.....	139
Figure 8.19: Simple positioning job.....	140
Figure 8.20: Gapless sequence of positioning jobs.....	140
Figure 8.21: Linear interpolation between two positions	141
Figure 8.22: First synchronisation und data processing.....	149
Figure 8.23: Structure of the Profile Velocity Mode.....	151
Figure 8.24: Structure of the Profile Torque Mode.....	158

Copyright

© 2003 Afag. All rights reserved.

The information and data contained in this document have been composed to the best of our knowledge. However, deviations between this document and the product cannot be excluded entirely. Afag Meßgeräte und Elektronik GmbH does not accept liability for any resulting errors or consequential damage. Neither will any liability be accepted for damage resulting from the use of the device or applications or from damaged circuits in the device. Afag Meßgeräte und Elektronik GmbH reserves the right to modify, amend or improve the document or the product without prior notification. This document may not, neither entirely nor in part, be reproduced, translated into any other natural or machine-readable language or transferred to data carriers, neither electronically, mechanically, optically nor any other way - without expressive authorisation by the author.

Revision log			
Authors:	U. Matthiesen, M. Willms		
Name of manual:	Servo positioning controller SE-POWER		
Filename:	CanOpen_manual_SE_Power_V1.0E.doc		
No.	Description	Revisions -index	Date of revision
001	Prerelease	0.1	26.09.2003
002	1. Version	1.0	19.12.2003

1 General Terms

1.1 Documentation

This manual describes how to parametrize and control the servo positioning controller SE-POWER using the standardised protocol CANopen. The adjustment of the physical parameters, the activation of the CANopen protocol, the embedding into a CAN network and the communication with the controller will be explained.

It is intended for persons who are already well versed with the servo positioning controller series.

It contains safety notes that have to be noticed.

For more informations, please refer to the following manuals of the SE-POWER series products:

- ❖ **Product Manual „Servo Positioning Controller SE-POWER”**: Description of the technical specifications and the device functionality as well as notes on installation and the operation of the servo positioning controller SE-POWER.
- ❖ **Software Manual “Servo Positioning Controller SE-POWER”**: Description of the device functionality and the software functions of the firmware including RS232 communication. Description of the parameterisation program Afag ServoCommander with instructions on the commissioning of an SE-POWER series servo positioning controller.

1.2 CANopen

CANopen is a standard established by the association "CAN in Automation". A great number of device manufacturers are organised in this association. This standard has replaced most of all manufacturer-specific CAN protocols. So a manufacturer independent communication interface is available for the user:

CiA Draft Standard 201...207: In these standards the general network administration and the transfer of objects are determined. This book is rather comprehensive. The relevant aspects are treated in the CANopen manual in hand so that it is not necessary in general to acquire the DS201..207.

CiA Draft Standard 301: In this standard the basic structure of the object dictionary of a CANopen device and the access to this directory are described. Besides this the statements made in the DS201..207 are described in detail. The elements needed for the servo controller family SE-POWER of the object directory and the access methods which belong to them are described in the present manual. It is advisable to acquire the DS301 but not necessary.

CiA Draft Standard 402: The concrete This standard describes implementation of CANopen in servo controllers. Though all implemented objects are also briefly documented and described in this CANopen manual the user should own this book.

Order address

CAN in Automation (CiA) International Headquarter
Am Weichselgarten 26
D-91058 Erlangen
Tel. +49-09131-601091
Fax: +49-09131-601092
www.can-cia.de

2 Safety Notes for electrical drives and controls

2.1 Symbols and signs



Information

Important informations and notes.



Caution!

The nonobservance can result in high property damage.



DANGER!

The nonobservance can result in property damages and in injuries to persons.



Caution! High voltage.

The note on safety contains a reference to a possibly occurring life dangerous voltage.



The parts of this document marked with this sign should give examples to make it easier to understand the use of single objects and parameters.

2.2 General notes

In the case of damage resulting from non-compliance of the safety notes in this manual Afag Meßgeräte und Elektronik GmbH will assume any liability.



Prior to the initial use you must read the chapters Safety Notes for electrical drives and controls *starting on page 11*

If the documentation in the language at hand is not understood accurately, please contact and inform your supplier.

Sound and safe operation of the servo drive controller requires proper and professional transportation, storage, assembly and installation as well as proper operation and maintenance. Only trained and qualified personnel may handle electrical devices:

TRAINED AND QUALIFIED PERSONNEL

in the sense of this product manual or the safety notes on the product itself are persons who are sufficiently familiar with the setup, assembly, commissioning and operation of the product as well as all warnings and precautions as per the instructions in this manual and who are sufficiently qualified in their field of expertise:

- ❖ Education and instruction or authorisation to switch devices/systems on and off and to ground them as per the standards of safety engineering and to efficiently label them as per the job demands.
- ❖ Education and instruction as per the standards of safety engineering regarding the maintenance and use of adequate safety equipment.
- ❖ First aid training.

The following notes must be read prior to the initial operation of the system to prevent personal injuries and/or property damages:



These safety notes must be complied with at all times.



Do not try to install or commission the servo drive controller before carefully reading all safety notes for electrical drives and controllers contained in this document. These safety instructions and all other user notes must be read prior to any work with the servo drive controller.



In case you do not have any user notes for the servo positioning controller, please contact your sales representative. Immediately demand these documents to be sent to the person responsible for the safe operation of the servo drive controller.



If you sell, rent and/or otherwise make this device available to others, these safety notes must also be included.



The user must not open the servo drive controller for safety and warranty reasons.



Professional control process design is a prerequisite for sound functioning of the servo drive controller!



DANGER!

Inappropriate handling of the servo drive controller and non-compliance of the warnings as well as inappropriate intervention in the safety features may result in property damage, personal injuries, electric shock or in extreme cases even death.

2.3 Danger resulting from misuse



DANGER!

High electrical voltages and high load currents!
Danger to life or serious personal injury from electrical shock!



DANGER!

High electrical voltage caused by wrong connections!
Danger to life or serious personal injury from electrical shock!



DANGER!

Surfaces of device housing may be hot!
Risk of injury! Risk of burning!



DANGER!

Dangerous movements!

Danger to life, serious personal injury or property damage due to unintentional movements of the motors!

2.4 Safety notes

2.4.1 General safety notes



The servo drive controller corresponds to IP20 class of protection as well as pollution level 1. Make sure that the environment corresponds to this class of protection and pollution level.



Only use replacements parts and accessories approved by the manufacturer.



The devices must be connected to the mains supply as per EN regulations, so that they can be cut off the mains supply by means of corresponding separation devices (e.g. main switch, contactor, power switch).



The servo drive controller may be protected using an AC/DC sensitive 300mA fault current protection switch (RCD = Residual Current protective Device).



Gold contacts or contacts with a high contact pressure should be used to switch the control contacts.



Preventive interference rejection measures should be taken for control panels, such as connecting contactors and relays using RC elements or diodes.



The safety rules and regulations of the country in which the device will be operated must be complied with.



The environment conditions defined in the product documentation must be kept. Safety-critical applications are not allowed, unless specifically approved by the manufacturer.



For notes on installation corresponding to EMC, please refer to Product Manual SE-POWER. The compliance with the limits required by national regulations is the responsibility of the manufacturer of the machine or system.



The technical data and the connection and installation conditions for the servo drive controller are to be found in this product manual and must be met.



DANGER!

The general setup and safety regulations for work on power installations (e.g. DIN, VDE, EN, IEC or other national and international regulations) must be complied with.

Non-compliance may result in death, personal injury or serious property damages.



Without claiming completeness, the following regulations and others apply:

VDE 0100 Regulations for the installation of high voltage (up to 1000 V) devices

EN 60204 Electrical equipment of machines

EN 50178 Electronic equipment for use in power installations

2.4.2 Safety notes for assembly and maintenance

The appropriate DIN, VDE, EN and IEC regulations as well as all national and local safety regulations and rules for the prevention of accidents apply for the assembly and maintenance of the system. The plant engineer or the operator is responsible for compliance with these regulations:



The servo drive controller must only be operated, maintained and/or repaired by personnel trained and qualified for working on or with electrical devices.

Prevention of accidents, injuries and/or damages:



Additionally secure vertical axes against falling down or lowering after the motor has been switched off, e.g. by means of:

- Mechanical locking of the vertical axle,
- External braking, catching or clamping devices or
- Sufficient balancing of the axle.



The motor holding brake supplied by default or an external motor holding brake driven by the drive controller alone is not suitable for personal protection!



Render the electrical equipment voltage-free using the main switch and protect it from being switched on again until the DC bus circuit is discharged, in the case of:

- Maintenance and repair work
- Cleaning
- long machine shutdowns



Prior to carrying out maintenance work make sure that the power supply has been turned off, locked and the DC bus circuit is discharged.



The external or internal brake resistor carries dangerous DC bus voltages during operation of the servo drive controller and up to 5 minutes thereafter. Contact may result in death or serious personal injury.



Be careful during the assembly. During the assembly and also later during operation of the drive, make sure to prevent drill chips, metal dust or assembly parts (screws, nuts, cable sections) from falling into the device.



Also make sure that the external power supply of the controller (24V) is switched off.



The DC bus circuit or the mains supply must always be switched off prior to switching off the 24V controller supply.



Carry out work in the machine area only, if AC and/or DC supplies are switched off. Switched off output stages or controller enablings are no suitable means of locking. In the case of a malfunction the drive may accidentally be put into action.



Initial operation must be carried out with idle motors, to prevent mechanical damages e.g. due to the wrong direction of rotation.



Electronic devices are never fail-safe. It is the user's responsibility, in the case an electrical device fails, to make sure the system is transferred into a secure state.



The servo drive controller and in particular the brake resistor, externally or internally, can assume high temperatures, which may cause serious burns.

2.4.3 Protection against contact with electrical parts

This section only concerns devices and drive components carrying voltages exceeding 50 V. Contact with parts carrying voltages of more than 50 V can be dangerous for people and may cause electrical shock. During operation of electrical devices some parts of these devices will inevitably carry dangerous voltages.



DANGER!

High electrical voltage!

Danger to life, danger due to electrical shock or serious personal injury!

The appropriate DIN, VDE, EN and IEC regulations as well as all national and local safety regulations and rules for the prevention of accidents apply for the assembly and maintenance of the system. The plant engineer or the operator is responsible for compliance with these regulations:



Before switching on the device, install the appropriate covers and protections against accidental contact. Rack-mounted devices must be protected against accidental contact by means of a housing, e.g. a switch cabinet. The regulations VBG 4 must be complied with!



Always connect the ground conductor of the electrical equipment and devices securely to the mains supply. Due to the integrated line filter the leakage current exceeds 3.5 mA!



Comply with the minimum copper cross-section for the ground conductor over its entire length as per EN60617!



Prior to the initial operation, even for short measuring or testing purposes, always connect the ground conductor of all electrical devices as per the terminal diagram or connect it to the ground wire. Otherwise the housing may carry high voltages which can cause electrical shock.



Do not touch electrical connections of the components when switched on.



Prior to accessing electrical parts carrying voltages exceeding 50 Volts, disconnect the device from the mains or power supply. Protect it from being switched on again.



For the installation the amount of DC bus voltage must be considered, particularly regarding insulation and protective measures. Ensure proper grounding, wire dimensioning and corresponding short-circuit protection.



The device comprises a rapid discharge circuit for the DC bus as per EN60204 section 6.2.4. In certain device constellations, however, mostly in the case of parallel connection of several servo drive controllers in the DC bus or in the case of an unconnected brake resistor, this rapid discharge may be rendered ineffective. The servo drive controllers can carry voltage until up to 5 minutes after being switched off (residual capacitor charge).

2.4.4 Protection against electrical shock by means of protective extra-low voltage (PELV)

All connections and terminals with voltages between 5 and 50 Volts at the servo drive controller are protective extra-low voltage, which are designed safe from contact in correspondence with the following standards:

International: IEC 60364-4-41

European countries within the EU: EN 50178/1998, section 5.2.8.1.

**DANGER!**

High electrical voltages due to wrong connections!
Danger to life, risk of injury due to electrical shock!

Only devices and electrical components and wires with a protective extra low voltage (PELV) may be connected to connectors and terminals with voltages between 0 to 50 Volts.

Only connect voltages and circuits with protection against dangerous voltages. Such protection may be achieved by means of isolation transformers, safe optocouplers or battery operation.

2.4.5 Protection against dangerous movements

Dangerous movements can be caused by faulty control of connected motors, for different reasons:

- ❖ Improper or faulty wiring or cabling
- ❖ Error in handling of components
- ❖ Error in sensor or transducer
- ❖ Defective or non-EMC-compliant components
- ❖ Error in software in superordinated control system

These errors can occur directly after switching on the device or after an indeterminate time of operation.

The monitors in the drive components for the most part rule out malfunctions in the connected drives. In view of personal protection, particularly the danger of personal injury and/or property damage, this may not be relied on exclusively. Until the built-in monitors come into effect, faulty drive movements must be taken into account; their magnitude depends on the type of control and on the operating state.

**DANGER!**

Dangerous movements!
Danger to life, risk of injury, serious personal injuries or property damage!

For the reasons mentioned above, personal protection must be ensured by means of monitoring or superordinated measures on the device. These are installed in accordance with the specific data of the system and a danger and error analysis by the manufacturer. The safety regulations applying to the system are also taken into consideration. Random movements or other malfunctions may be caused by switching the safety installations off, by bypassing them or by not activating them.

2.4.6 Protection against contact with hot parts



DANGER!

Housing surfaces may be hot!
Risk of injury! Risk of burning!



Do not touch housing surfaces in the vicinity of heat sources! Danger of burning!



Before accessing devices let them cool down for 10 minutes after switching them off.



Touching hot parts of the equipment such as the housing, which contain heat sinks and resistors, may cause burns!

2.4.7 Protection during handling and assembly

Handling and assembly of certain parts and components in an unsuitable manner may under adverse conditions cause injuries.



DANGER!

Risk of injury due to improper handling!
Personal injury due to pinching, shearing, cutting, crushing!

The following general safety notes apply:



Comply with the general setup and safety regulations on handling and assembly.



Use suitable assembly and transportation devices.



Prevent incarcerations and contusions by means of suitable protective measures.



Use suitable tools only. If specified, use special tools.



Use lifting devices and tools appropriately.



If necessary, use suitable protective equipment (e.g. goggles, protective footwear, protective gloves).



Do not stand underneath hanging loads.



Remove leaking liquids on the floor immediately to prevent slipping.

3 Cabling and pin assignment

3.1 Pin assignment

At the SE-POWER series the CAN interface is already integrated in the device and therefore always available.

According to the CANopen specification a 9-pin DSUB-plug (male) is integrated in the device.




Figure 3.1: CAN connector for SE-POWER



CAN bus cabling

Please respect carefully the following information and notes for the cabling of the controller to get a stable and undisturbed communication system. A non professional cabling can cause malfunctions of the CAN bus which hence the controller to shutdown with an error.



120Ω Termination resistor

No termination resistor is integrated in the servo positioning controller series SE-POWER

3.2 Verkabelungs-Hinweise

The CAN bus offers an easy and safe way to connect all parts of a plant. As condition all following instructions have to be respected carefully.




Figure 3.2: Cabling (schematically)

- All nodes of a network are principally connected in series, so that the CAN cable is looped through all controllers (see **Figure 3.2**).
- The two ends of the CAN cable have to be terminated by a resistor of $120\Omega \pm 5\%$. Please note that such a resistor is often already installed in CAN cards or the PLC.
- For cabling **shielded** cable with exactly two **twisted** pairs have to be used.
 - One twisted pair is used for CAN-H and CAN-L.
 - One twisted pair is used commonly for CAN-GND.
 - The shield of the cable is connected to CAN-SHIELD at all nodes.

A table with technical data of suitable cables can be found at the end of this chapter. Recommended cables can be found in the product manual.

- We dissuade from using connectors in between the CAN bus line. If it is still necessary to use connectors, assure that the connection of the shield is done by using metallic cases.
- For less noise injection principally
 - never place motorcables parallel to signalcables.
 - use only motorcables specified by Afag.
 - shield and earth motorcables correctly.
- For further informations refer to the Controller Area Network protocol specification, Ver. 2.0, Robert Bosch GmbH, 1991.
- Technical data CAN bus cable:

2 twisted pairs, $d \geq 0,22 \text{ mm}^2$
shielded


loop resistance $< 0,2 \text{ } \square/\text{m}$
char. impedance $100\text{-}120 \text{ } \square$

4 Activation of CANopen

4.1 Survey

The activation of CANopen is done one-time using the serial interface of the servo controller.

The CAN protocol can be activated in the window „CANopen“ of the Afag ServoCommander.



There have to be set three different parameters:

- **Basic Node Number**

For unmistakable identification each user within the network has to have an unique node number. The node number is used to address the device.

As an option it is possible to calculate the node number dependent of the plug-in location of the device. Therefore once after reset the combination of digital inputs (DIN0...DIN3) or analogue inputs AIN1 and AIN2 is added to the basic node number. AIN1 will be added with a valence of 32 and AIN2 with a valence of 64, if the particular input is connected to

Vref = 10V.

- **Baudrate**

This parameter determines the used baudrate in kBaud. Please note that high baudrates can only be achieved with short cable length.

- **Options**

All CANopen nodes send a bootup message containing their own node number. If the servo positioning controller receives such a message containing its own node number, the error 12-0 will be raised.

Finally the CANopen protocol can be activated. Please take into account that the parameters mentioned above can only be changed when the protocol is deactivated.



Please note that the activation of CANopen will only be available after a reset if the parameter set has been saved.

5 Acces methods

5.1 Survey

CANopen offers an easy and standardised way to access all parameters of the servo controller (e.g. the maximum current). To achieve a clear arrangement an unique index and subindex is assigned to every parameter (CAN object). The parameters altogether form the so called object dictionary.

The object dictionary can be accessed via CAN bus in primarily two ways: A confirmed access with so called SDOs and a unconfirmed access using so called PDOs with no hand-shake.





Figure 5.3: **Access methods**

As a rule the servo controller will be parametrized and controlled by SDOs. Additional types of messages (so called Communication Objects, COB) are defined for special applications. They will be sent either by the superimposed control or the servo controller:

SDO	S ervice D ata O bject	Used for normal parametrization of the servo controller
PDO	P rocess D ata O bject	Fast exchange of process data (e.g. velocity actual value) possible.
SYNC	S ynchronization Message	Synchronisation of several CAN nodes.

EMCY	Emergency Message	Used to transmit error messages of the servo controller.
NMT	Network Management	Used for network services. For example the user can act on all controllers at the same time via this object type.
HEARTBEAT	Error Control Protocol	Used for observing all nodes by cyclic messages.

Every message sent via CAN bus contains an address to identify the node the message is meant for. This address is called *Identifier*. The lower the identifier, the higher the priority. Each communication object mentioned above has a specific identifier. The following figure shows the schematic structure of a CANopen message:



5.2 Access by SDO

The object dictionary can be accessed with **S**ervice **D**ata **O**bjects (SDO). This access is particularly easy and clear. Therefore it is recommended to base the application on SDOs first and later adapt some accesses to the certainly faster but more complicated **P**rocess **D**ata **O**bjects (PDOs).

SDO accesses always start from the superimposed control (host). The host sends a write request to change a parameter or a read request to get a parameter from the servo controller. Every request will be answered by the servo controller either sending the requested parameter or confirming the write request.

Every command has to be sent with a definite identifier so that the servo controller knows what command is intended for it.

This identifier is composed of the base 600_h + node number of the corresponding servo controller. The servo controller answers with identifier 580_h + node number.

The structure of the writing and reading sequences depends on the data type as 1, 2 or 4 data bytes have to be sent or received. The following data types will be supported:

UINT8	8 bit value, unsigned	0 .. 255
		.
INT8	8 bit value, signed	-128 .. 127
		.
UINT16	16 bit value, unsigned	0 .. 65535


INT16 16 bit value, signed -32768 .. 32767

UINT32 32 bit value, unsigned 0 .. (2³²-1)

INT32 32 bit value, signed -(2³¹) .. (2³¹-1)

5.2.1 SDO sequences to read or write parameters

Following sequences have to be used to read or write can objects of mentioned type. Commands to write a value into the servo controller start with a different token depending on the parameters data type, whereas the first token of the answer is always the same. For commands to read parameters its vice versa: They always start with the same token, whereas the answer of the servo controller starts with a token depending on the parameters data type. For all numerical values the hexadecimal notation is used.



EXAMPLE	
UINT8 / INT8	Reading of Obj. 6061_00 _h Returning data: 01 _h
Command:	40 _h 61 _h 60 _h 00 _h
Answer:	4F _h 61 _h 60 _h 00 _h 01 _h
UINT16 / INT16	Reading of Obj. 6041_00 _h Returning data: 1234 _h
Command:	40 _h 41 _h 60 _h 00 _h
Answer:	4B _h 41 _h 60 _h 00 _h 34 _h 12 _h
UINT8 / INT8	Writing of Obj. 1401_02 _h Data: EF _h
Command:	2F _h 01 _h 14 _h 02 _h EF _h
Answer:	60 _h 01 _h 14 _h 02 _h
UINT16 / INT16	Writing of Obj. 6040_00 _h Data: 03E8 _h
Command:	2B _h 40 _h 60 _h 00 _h E8 _h 03 _h
Answer:	60 _h 40 _h 60 _h 00 _h




UINT32 / INT32		Reading of Obj. 6093_01 _h	Writing of Obj. 6093_01 _h
		Returning data: 12345678 _h	Data: 12345678 _h
Command:	40 _h 93 _h 60 _h 01 _h		23 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h
Answer:	43 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h		60 _h 93 _h 60 _h 01 _h



Always wait for the acknowledge of the controller !
 Only if a request has been acknowledged by the controller it is allowed to send the next request.

5.2.2 SDO-error messages

If an error occurs reading or writing an object (e.g. because the value is out of range) the servo controller answers with an error message instead of the normal answer:



Error code	Description
F3 F2 F1 F0	
06 01 00 00 _h	Unsupported access to an object
06 02 00 00 _h	Object does not exist in the object dictionary
06 04 00 41 _h	Object cannot be mapped to the PDO
06 04 00 42 _h	The number and length of the objects to be mapped would exceed PDO length
06 07 00 10 _h	Data type does not match, length of service parameter does not match
06 07 00 12 _h	Data type does not match, length of service parameter too high
06 07 00 13 _h	Data type does not match, length of service parameter too low
06 09 00 11 _h	Sub-index does not exist
06 01 00 01 _h	Attempt to read a write only object
06 01 00 02 _h	Attempt to write a read only object
06 04 00 47 _h	General internal incompatibility in the device
06 06 00 00 _h	Access failed due to an hardware error * ¹⁾
05 03 00 00 _h	Toggle bit not alternated
05 04 00 01 _h	Client / server command specifier not valid or unknown
06 09 00 30 _h	Value range of parameter exceeded
06 09 00 31 _h	Value of parameter written too high
06 09 00 32 _h	Value of parameter written too low
06 09 00 36 _h	Maximum value is less than minimum value
08 00 00 20 _h	Data cannot be transferred or stored to the application * ¹⁾
08 00 00 21 _h	Data cannot be transferred or stored to the application because of local control
08 00 00 22 _h	Data cannot be transferred or stored to the application because of the present device state * ³⁾
08 00 00 23 _h	No Object Dictionary is present * ²⁾

*¹⁾ According to DS301 used on invalid access to store_parameters /restore_parameters


*²⁾ This abort codes signals that another fieldbus controls the servo or the access to the parameter is not allowed.

*³⁾ „Device State“ is used generally: This can be a wrong mode of operation as well as a missing technology module.


5.2.3 Simulation of SDO accesses via RS232

The firmware of the servo controller offers the option to simulate SDO accesses via the serial port. Consequently it is possible to check objects written to the controller via CAN bus by using the serial port. Particularly using the transfer window of Afag ServoCommander (see **File | Transfer**) will simplify the building of applications.

The following syntax has to be used:



Please note that the commands are composed of chars without spaces.



Never use this access mechanism in real applications !

The access via RS232 is only implemented for checking your application. The protocol is inapplicable for real time access to the controller and may cause errors.

In addition the syntax of this protocol may change without notice.

5.3 PDO-Message

Process Data Objects (PDOs) are suitable to transmit data event-controlled, whereas the PDO contains one or more predefined parameters. In contrast to SDOs no handshake is used. So the receiver has to be able to handle an arriving PDO at any time. In most cases this requires a great deal of software in the host computer. This disadvantage is in contrast to the advantage that the host computer does not need cyclically inquiry of the objects embedded in a PDO, which means a strong reduction of bus load.

EXAMPLE



The host computer wants to know when the servo controller has reached the target position at a positioning from A to B.

If SDOs are used the host constantly has to poll the object **statusword**, e.g. every millisecond, thus loading the bus capacity more or less depending on the request cycle time.

If PDOs are used the servo controller is parametrized at the start of an application in such a way that a PDO including the **statusword** is sent on each modification of the **statusword**.

So the host computer does not need to poll the statusword all the time. Instead a message is sent to the host automatically if the specified event occurs.


Following types of PDOs can be differentiated:

Transmit-PDO (T-PDO)	Servo ⇒ Host	Servo controller sends PDO if a certain event occurs
Receive-PDO (R-PDO)	Host ⇒ Servo	Servo controller evaluates PDO if a certain event occurs

The servo controller disposes of four Transmit- and four Receive-PDOs.

Almost all parameters can be embedded (mapped) into a PDO, i.e. the PDO is for example composed of the velocity actual value, the position actual value or the like.

Before a PDO can be used the servo controller has to know, what data shall be transmitted, because a PDO only contains useful data and no information about the kind of parameter. In the following example the PDO contains the position actual value in the data byte D0...D3 and the velocity actual value in the data bytes D4...D7.



Almost any desired data frame can be built this way. The following chapter shows how to parametrize the servo controller for that purpose:

5.3.1 Description of objects

Identifier of PDOs **COB_ID_used_by_PDO**

In the object **COB_ID_used_by_PDO** the desired identifier has to be entered. The PDO will be sent with this identifier. If bit 31 is set the associated PDO will be deactivated. This is the default setting.

It is prohibited to change the COB-ID if the PDO is not deactivated, i.e. bit 31 is set. Therefore the following sequence has to be used to change the COB-ID:

- Read the COB-ID out of the servo
- Write back the written COB-ID + 80000000_h
- Write the new COB-ID + 80000000_h
- Write only the new COB-ID, the PDO is active again.

Number of objects to be transmitted **number_of_mapped_objects**

The object determines how many objects are mapped into the specific PDO. Following restrictions has to be respected:


- A maximum of 4 objects can be mapped into a PDO.
- The total length of a PDO must not exceed 64 bit.

Objects to be transmitted **first_mapped_object ... fourth_mapped_object**

The host has to parametrize the index, the subindex and the length of each object that should be transmitted by the PDO. The length has to match with the length stored in the Object Dictionary.

Parts of an object cannot be mapped.

The following format has to be used:



To simplify the mapping the following sequence has to be used:

- 1.) The `number_of_mapped_objects` is set to 0.
- 2.) The `first_mapped_object...fourth_mapped_object` parameter can be parameterised (The length of all objects will not be considered at this time).
- 3.) The `number_of_mapped_objects` is set to a value between 1...4: The length of all mapped objects may not exceed 64 bit now.

Transmissiontype

transmission_type und **inhibit_time**

For each PDO it can be parametrized which event results in sending (Transmit-PDO) resp. evaluating (Receive-PDO) the PDO:

Value	Description	Allowed with
00 _n –F0 _h	<p>SYNC message</p> <p>The value determines how many SYNC messages will be ignored before the PDO will be</p> <ul style="list-style-type: none"> - sent (T-PDO) resp. - evaluated (R-PDO). 	TPDOs RPDOs
FE _h	<p>Cyclic</p> <p>A Transfer-PDO will be updated and sent cyclic. The period is determined by the object inhibit_time.</p> <p>Receive-PDOs will be evaluated immediately after receipt.</p>	TPDOs (RPDOs)
FF _h	<p>On change</p> <p>The Transfer-PDO will be sent, if at least one bit of the PDO data has changed. Therefore the object inhibit_time determines the minimal period between two PDOs in multiples of 100µs.</p>	TPDOs

The use of any other value for this parameter is inhibited.

Mask

transmit_mask_high and **transmit_mask_low**

Using the **transmission_type** "On change" the TPDO will always be sent if at least one bit has changed. Sometimes it is useful to send the TPDO only if a defined bit has changed. Therefore it is possible to mask the TPDO. Thereby only TPDO bits with an "1" in the corresponding bit of the mask will take effect to determine if the PDO has changed. This function is manufacturer specific and deactivated by default, i.e. all bits of the mask are set by default.

EXAMPLE

Following objects should be transmitted in a PDO:



Name of object	Index_subindex	Meaning
statusword	6041 _h _00 _h	Device Control
modes_of_operation_display	6061 _h _00 _h	Operating mode
digital_inputs	60FD _h _00 _h	Digital inputs

The 1st Transmit-PDO (TPDO 1) should be used and should always be sent if a digital input changes but with a minimum repetition time of 10 ms. The PDO should use identifier 187_h.

1.) Set number of mapped objects to 0

To enable the mapping, the number of mapped objects have to be zero.

⇒ **number_of_mapped_objects = 0**

2.) Parametrize objects to be mapped:

The above mentioned objects have to be assembled to a 32 bit value:

Index =6041_h Subin. = 00_h Length = 10_h ⇒ **first_mapped_object = 60410010_h**

Index =6061_h Subin. = 00_h Length = 08_h ⇒ **second_mapped_object = 60610008_h**

Index =60FD_h Subin. = 00_h Length = 20_h ⇒ **third_mapped_object = 60FD0020_h**

3.) Set number of mapped objects:

The PDO contains 3 objects

⇒ **number_of_mapped_objects = 3_h**

4.) Parametrize transmission type

The PDO should be sent if a digital input changes.

⇒ **transmission_type = FF_h**

The PDO have to be masked in order to restrict the condition for a transmission of the PDO to a change of the digital inputs.

⇒ **transmit_mask_high = 00FFFF00_h**

⇒ **transmit_mask_low = 00000000_h**

The PDO should be sent at most every 10 ms (100×100µs).

⇒ **inhibit_time = 64_h**

5.) Parametrize the identifier

The PDO should use identifier 187_h.

If the PDO is activated, it has to be disabled at first.

Read the identifier: ⇒ **00000181_h = cob_id_used_by_pdo**

Set bit 31 (deactivate): ⇒ **cob_id_used_by_pdo = 80000181_h**

Write new identifier: ⇒ **cob_id_used_by_pdo = 80000187_h**

Activate by deleting bit 31: ⇒ **cob_id_used_by_pdo = 00000187_h**



Parametrising PDOs

Please note that it is only allowed to change the settings of the PDO if the Network state (NMT) is not **operational**. See also chapter 5.3.2

Objects for parameterising PDOs

The servo positioning controller of the SE-POWER series contain 4 Transmit- and 4 Receive-PDOs. The objects for parameterising these PDOs are equal for each 4 TPDOs and each 4 RPDOs. Therefore only the description for the first TPDO is

stated below. It can be taken analogous for all the other PDOs, listed in a table thereafter.

Index	1800_h
Name	transmit_pdo_parameter_tpdo1
Object Code	RECORD
No. of Elements	3

Sub-Index	01_h
Description	cob_id_used_by_pdo_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	-
Value Range	181 _h ...1FF _h , Bit 31 may be set
Default Value	80000181 _h

Sub-Index	02_h
Description	transmission_type_tpdo1
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	-
Value Range	0...8C _h , FE _h , FF _h
Default Value	FF _h

Sub-Index	03_h
Description	inhibit_time_tpdo1
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	100μs (i.e. 10 = 1ms)
Value Range	
Default Value	0

Index	1A00_h
Name	transmit_pdo_mapping_tpdo1
Object Code	RECORD
No. of Elements	2

Sub-Index	00_h
Description	number_of_mapped_objects_tpdo1
Data Type	UINT8
Access	rw
PDO Mapping	no
Units	--
Value Range	0...4
Default Value	0

Sub-Index	02_h
Description	second_mapped_object_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	--
Value Range	--
Default Value	see Table

Sub-Index	03_h
Description	third_mapped_object_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	--
Value Range	--
Default Value	see Table

Sub-Index	04_h
Description	fourth_mapped_object_tpdo1
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	--
Value Range	--
Default Value	see Table

1. Transmit-PDO

Index	Comment	Type	Acc	Default
1800 _h _00 _h	number of entries	UINT8	ro	03 _h
1800 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000181 _h
1800 _h _02 _h	transmission type	UINT8	rw	FF _h
1800 _h _03 _h	inhibit time (100 μs)	UINT1	rw	0000 _h
1A00 _h _00 _h	number of mapped objects	UINT8	rw	01 _h
1A00 _h _01 _h	first mapped object	UINT3	rw	60410010 _h
1A00 _h _02 _h	second mapped object	UINT3	rw	00000000 _h
1A00 _h _03 _h	third mapped object	UINT3	rw	00000000 _h
1A00 _h _04 _h	fourth mapped object	UINT3	rw	00000000 _h

2. Transmit-PDO

Index	Comment	Type	Acc	Default
1801 _h _00 _h	number of entries	UINT8	ro	03 _h
1801 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000281 _h
1801 _h _02 _h	transmission type	UINT8	rw	FF _h
1801 _h _03 _h	inhibit time (100 μs)	UINT1	rw	0000 _h
1A01 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1A01 _h _01 _h	first mapped object	UINT3	rw	60410010 _h
1A01 _h _02 _h	second mapped object	UINT3	rw	60610008 _h
1A01 _h _03 _h	third mapped object	UINT3	rw	00000000 _h
1A01 _h _04 _h	fourth mapped object	UINT3	rw	00000000 _h

3. Transmit-PDO

Index	Comment	Type	Acc	Default
1802 _h _00 _h	number of entries	UINT8	ro	03 _h
1802 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000381 _h
1802 _h _02 _h	transmission type	UINT8	rw	FF _h
1802 _h _03 _h	inhibit time (100 μs)	UINT1	rw	0000 _h
1A02 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1A02 _h _01 _h	first mapped object	UINT3	rw	60410010 _h
1A02 _h _02 _h	second mapped object	UINT3	rw	60640020 _h
1A02 _h _03 _h	third mapped object	UINT3	rw	00000000 _h
1A02 _h _04 _h	fourth mapped object	UINT3	rw	00000000 _h

4. Transmit-PDO

Index	Comment	Type	Acc	Default
1803 _h _00 _h	number of entries	UINT8	ro	03 _h
1803 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000481 _h
1803 _h _02 _h	transmission type	UINT8	rw	FF _h
1803 _h _03 _h	inhibit time (100 μs)	UINT1	rw	0000 _h
1A03 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1A03 _h _01 _h	first mapped object	UINT3	rw	60410010 _h
1A03 _h _02 _h	second mapped object	UINT3	rw	606C0020 _h

1A03h_03h	third mapped object	UINT3	rw	00000000h
1A03h_04h	fourth mapped object	UINT3	rw	00000000h

tpdo_1_transmit_mask

Index	Comment	Type	Acc.	Default Value
2014h_00h	number of entries	UINT8	ro	02h
2014h_01h	tpdo_1_transmit_mask_low	UINT3 2	rw	FFFFFFFFh
2014h_02h	tpdo_1_transmit_mask_high	UINT3 2	rw	FFFFFFFFh

tpdo_2_transmit_mask

Index	Comment	Type	Acc.	Default Value
2015h_00h	number of entries	UINT8	ro	02h
2015h_01h	tpdo_2_transmit_mask_low	UINT3 2	rw	FFFFFFFFh
2015h_02h	tpdo_2_transmit_mask_high	UINT3 2	rw	FFFFFFFFh

tpdo_3_transmit_mask

Index	Comment	Type	Acc.	Default Value
2016h_00h	number of entries	UINT8	ro	02h
2016h_01h	tpdo_3_transmit_mask_low	UINT3 2	rw	FFFFFFFFh
2016h_02h	tpdo_3_transmit_mask_high	UINT3 2	rw	FFFFFFFFh

tpdo_4_transmit_mask

Index	Comment	Type	Acc.	Default Value
2017h_00h	number of entries	UINT8	ro	02h
2017h_01h	tpdo_4_transmit_mask_low	UINT3 2	rw	FFFFFFFFh
2017h_02h	tpdo_4_transmit_mask_high	UINT3 2	rw	FFFFFFFFh

1. Receive PDO

Index	Comment	Type	Acc	Default
1400 _h _00 _h	number of entries	UINT8	ro	02 _h
1400 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000201 _h
1400 _h _02 _h	transmission type	UINT8	rw	FF _h
1600 _h _00 _h	number of mapped objects	UINT8	rw	01 _h
1600 _h _01 _h	first mapped object	UINT3	rw	60400010 _h
1600 _h _02 _h	second mapped object	UINT3	rw	00000000 _h
1600 _h _03 _h	third mapped object	UINT3	rw	00000000 _h
1600 _h _04 _h	fourth mapped object	UINT3	rw	00000000 _h

2. Receive PDO

Index	Comment	Type	Acc	Default
1401 _h _00 _h	number of entries	UINT8	ro	02 _h
1401 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000301 _h
1401 _h _02 _h	transmission type	UINT8	rw	FF _h
1601 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1601 _h _01 _h	first mapped object	UINT3	rw	60400010 _h
1601 _h _02 _h	second mapped object	UINT3	rw	60600008 _h
1601 _h _03 _h	third mapped object	UINT3	rw	00000000 _h
1601 _h _04 _h	fourth mapped object	UINT3	rw	00000000 _h

3. Receive PDO

Index	Comment	Type	Acc	Default
1402 _h _00 _h	number of entries	UINT8	ro	02 _h
1402 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000401 _h
1402 _h _02 _h	transmission type	UINT8	rw	FF _h
1602 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1602 _h _01 _h	first mapped object	UINT3	rw	60400010 _h
1602 _h _02 _h	second mapped object	UINT3	rw	607A0020 _h
1602 _h _03 _h	third mapped object	UINT3	rw	00000000 _h
1602 _h _04 _h	fourth mapped object	UINT3	rw	00000000 _h

4. Receive PDO

Index	Comment	Type	Acc	Default
1403 _h _00 _h	number of entries	UINT8	ro	02 _h
1403 _h _01 _h	COB-ID used by PDO	UINT3	rw	80000501 _h
1403 _h _02 _h	transmission type	UINT8	rw	FF _h
1603 _h _00 _h	number of mapped objects	UINT8	rw	02 _h
1603 _h _01 _h	first mapped object	UINT3	rw	60400010 _h
1603 _h _02 _h	second mapped object	UINT3	rw	60FF0020 _h
1603 _h _03 _h	third mapped object	UINT3	rw	00000000 _h
1603 _h _04 _h	fourth mapped object	UINT3	rw	00000000 _h

5.3.2 Activation of PDOs

The following points have to be fulfilled for the activation of a PDO:


- The object **number_of_mapped_objects** has to be different from zero
- The bit 32 has to be deleted in the object **cob_id_used_for_pdos**
- The communication status of the servo has to be **operational** (see chapter 5.6, Network management)

The following points have to be fulfilled to parametrize a PDO

- The communication status of the servo must not be **operational**

5.4 SYNC-Message

Several devices of a plant can be synchronised with each other. To that purpose one of the devices (in most cases the superimposed control) periodically sends synchronisation messages. All connected servo controllers receive these messages and use them for the treatment of the PDOs (see chapter 5.3).



The identifier the servo controller receives SYNC messages is fixed to 080_h. The identifier can be read via the object **cob_id_sync**.

Index	1005_h
Name	cob_id_sync
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	no
Units	
Value Range	80000080 _h , 00000080 _h
Default Value	00000080 _h

5.5 EMERGENCY-Message


The servo controller monitors the functions of its essential units. The power supply, the power stage, the angle encoder input, and the technology module belong to these units. Besides this the motor (temperature, angle encoder) and the limit switches are constantly controlled. Bad parameters could also result in error messages (division by zero etc.).

If an error occurs the error number is displayed by the servo controller. If several error messages occur at the same time the message which has the highest priority (the least number) is displayed.

5.5.1 Structure of an EMERGENCY message

If an error occurs the servo controller always sends an EMERGENCY message. The identifier of this message is **080_h** plus node number.

The EMERGENCY message consists of eight data bytes with the **error code** in the first two bytes. These **error_codes** are described in the following table. There is a further error code (object **1001_h**) in the third byte. The other five bytes contain zeros.



The following **error_codes** can occur

error_code (hex)	Display	Description
6180	E 01 0	Stack overflow
3220	E 02 0	Undervoltage of DC-bus
4310	E 03 0	Overtemperature motor analogue
4210	E 04 0	Overtemperature of the power stage
4280	E 04 1	Overtemperature in the DC-bus
5114	E 05 0	Internal undervoltage supply 1
5115	E 05 1	Internal undervoltage supply 2
5116	E 05 2	Driver voltage fault
5410	E 05 3	Undervoltage dig. I/O
5410	E 05 4	Overcurrent dig. I/O
2110	E 06 0	Short circuit in the power stage
3210	E 07 0	Overvoltage
7380	E 08 0	Angle encoder error resolver
7382	E 08 2	Error in encoder communication
7383	E 08 3	Error of track signals Z1 incremental encoder
7384	E 08 4	Error of track signals of digital incremental encoder
7385	E 08 5	Error of Hall signals of incremental encoder
8A80	E 11 0	Error at start of homing run
8A81	E 11 1	Error during homing run
8A82	E 11 2	Homing: Erroneous index pulse
8180	E 12 0	CAN bus: Duplicate node number
8120	E 12 1	CAN bus: Communication error: BUS OFF
8181	E 12 2	CAN bus: Communication error: Transmit error
8182	E 12 3	CAN bus: Communication error: Receive error
6185	E 15 0	Division by 0
6186	E 15 1	Range overflow
6181	E 16 0	Erroneous program execution
6182	E 16 1	Illegal interrupt
6187	E 16 2	Initialisation error
6183	E 16 3	Unexpected state
8611	E 17 0	Max. following error exceeded

error_code (hex)	Display	Description
5280	E 21 0	Error 1 in current meas. U
5281	E 21 1	Error 1 in current meas. V
5282	E 21 2	Error 2 in current meas. U
5283	E 21 3	Error 2 in current meas. V
6080	E 25 0	Invalid device type
6081	E 25 1	Device type not supported
5580	E 26 0	No user parameter set
5581	E 26 1	Checksum error
5582	E 26 2	Flash: error during write-operation
5583	E 26 3	Flash: error during erase-operation
5584	E 26 4	Flash: error in internal Flash
5585	E 26 5	No calibration data
8611	E 27 0	Following error warning level
6380	E 30 0	Internal calculation error
2312	E 31 0	I ² T-motor
2311	E 31 1	I ² T-servo controller
2313	E 31 2	I ² T – PFC
2314	E 31 3	I ² T brake chopper
3280	E 32 0	Loading period DC-bus exceeded
3281	E 32 1	Undervoltage for active PFC
3282	E 32 5	Braking chopper overload
3283	E 32 6	Discharging period DC-bus exceeded
8A83	E 33 0	Following error encoder emulation
8780	E 34 0	No synchronisation via fieldbus
8781	E 34 1	Synchronisation error fieldbus
8480	E 35 0	Overspeed protection linear motor
6320	E 36 0	Parameter has been limited
8612	E 40 0	SW-limit switch
8680	E 42 0	Positioning: Drive stopped. Following positioning missing.
8681	E 42 1	Positioning: Drive stopped. Inversion of direction is not allowed.
8682	E 42 2	Positioning: Inversion of direction is not allowed after "Halt"

5.5.2 Description of Objects

5.5.2.1 Object 1003_h: pre_defined_error_field

The **error_codes** of the error messages are recorded in a four-stage error memory. This memory is structured like a shift register so that always the last error is stored in the object 1003_h01_h (**standard_error_field_0**). By a read access to the object 1003_h00_h (**pre_defined_error_field**) you can find out how many error messages are recorded in the error memory at the moment. The error memory is deleted by writing the value 00_h into the object 1003_h00_h (**pre_defined_error_field**). In addition an **error reset** (see chapter 7.1: state transition 15) has to be executed to reactivate the power stage of the servo controller after an error.

Index	1003_h
Name	pre_defined_error_field
Object Code	ARRAY
No. of Elements	4
Data Type	UINT32

Sub-Index	01_h
Description	standard_error_field_0
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

Sub-Index	02_h
Description	standard_error_field_1
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--


Sub-Index	03_h
Description	standard_error_field_2
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

Sub-Index	04_h
Description	standard_error_field_3
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

Heartbeat / Bootup (Error Control Protocol)


5.5.3 Structure of the heartbeat message

To monitor the communication between slave (servo) and master the heartbeat protocol is implemented. The servo cyclically sends a message to the master. The master can check if it cyclically receives the heartbeat and initiate appropriate reactions if not. The heartbeat message will be sent with the identifier **700_h + node number**. It is only composed of 1 Byte, containing the NMT state of the servo (see Chapter 5.6, Network management).



5.5.4 Structure of the Bootup message

After power-on or after reset, the servo positioning controller reports through a Bootup message that the initialising has been finished. The servo is afterwards in the NMT state **preoperational** (see Chapter 5.6, Network management)



The Bootup message is nearly identical with the Heartbeat message. Only instead of the NMT state zero will be sent.

5.5.5 Objects

5.5.5.1 Object 1017_h: producer_heartbeat_time

The time between two heartbeat messages can be determined by the object **producer_heartbeat_time**.

Index	1017 _h
Name	producer_heartbeat_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	no
Units	ms
Value Range	0...65536
Default Value	0


The **producer_heartbeat_time** can be saved in the parameter set. If the servo starts with a **producer_heartbeat_time** unequal zero, the Bootup messages is seen as the first heartbeat.

5.6 Network management (NMT service)

All CANopen devices can be triggered via the network management. A special identifier (000h) is reserved for that.

Commands can be sent to one or all servo controller via this identifier. Each command consists of two bytes. The first byte contains the command code and the second byte the node address of the addressed servo controller. All nodes which are in the network can be addressed via the node address zero simultaneously. So it is possible, for example, to make a reset in all devices at the same time. The servo controller does not quit the NMT-commands. It is only indirectly possible to decide if a reset was successful (e. g. through the Bootup message after a reset).

Structure of the message:



The NMT states of a CANopen device are determined in a state diagram . With the byte **CS** of the NMT message state transitions can be initiated. They are mostly determined by the target state.




Figure 5.4: NMT-State machine

With the following commands the NMT state can be changed:

CS	Meaning	Transition	Target state
01 _h	Start Remote Node	3, 6	Operational
02 _h	Stop Remote Node	5, 8	Stopped
80 _h	Enter Pre-Operational	4, 7	Pre-Operational
81 _h	Reset Application	12, 13, 14	Reset Application
82 _h	Reset Communication	9, 10, 11	Reset Communication

All remaining transitions will be executed automatically by the servo controller, e.g. if initialising has been finished.

The parameter **NI** contains the node number of the servo controller or zero, if all nodes within the network will be addressed. Depending on the NMT state several communication objects can not be used. For example it is necessary to set the NMT state to **operational** to enable sending and receiving PDOs.

Name	Meaning	SDO	PDO	NMT
Reset Application	No communication. All CAN objects are set to their reset values (application parameter set).	-	-	-
Reset Communication	No communication. The CAN controller will be re-initialised.	-	-	-
Initialising	State after Hardware Reset. Reset of the CAN node, sending of the Bootup message	-	-	-
Pre-Operational	Communication via SDOs possible. PDOs inactive (No sending / receiving)	X	-	X
Operational	Communication via SDOs possible. PDOs active (sending / receiving)	X	X	X
Stopped	No communication except heartbeat + NMT	-	-	X



The communication status has to be set to **operational** to allow the servo to send and receive PDOs

5.7 Table of identifiers

The following table gives a survey of the used identifiers.

Object-Type	Identifier (hexadecimal)	Remark
SDO (Host to Servo)	600_h + node id	
SDO (Servo to Host)	580_h + node id	
TPDO1	181_h	Standard values. Can be changed on demand.
TPDO2	281_h	
TPDO3	381_h	
TPDO4	481_h	
RPDO1	201_h	
RPDO2	301_h	
RPDO3	401_h	
RPDO4	501_h	
SYNC	080_h	
EMCY	080_h + node id	
HEARTBEAT	700_h + node id	
BOOTUP	700_h + node id	
NMT	000_h	

6 Adjustment of parameters

Before a certain task (e.g. torque or velocity control) can be managed by the servo controller several parameters have to be adjusted according to the used motor and the specific application. Therefore the chronological order suggested by the following chapters should be abided.

After explaining the parameter adjustment the device control and the several modes of operation will be presented.



An "A" will be displayed by the servo controller if it is not properly commissioned yet. If the complete adjustment of parameter should be done via the CAN bus, object **6510_h_C0_h** have to be parametrized to suppress the "A". (see chapter 6.10.1.11 Object 6510_h_C0_h: commissioning_state).

6.1 Load and save set of parameters

6.1.1 Survey

The servo controller has three parameter sets:

Current parameter set

- This parameter set is in the transient memory (RAM) of the servo controller. It can be read and written optionally via the parameter set-up program Afag ServoCommander or via the CAN bus. When the servo controller is switched on the **application parameter set** is copied into the **current parameter set**.


Default parameter set

- This is the unmodifiable **default parameter set** of the servo controller given by the manufacturer. The **default parameter set** can be copied to the current parameter set through a write process into the CANopen object **1011_h_01_h** (**restore_all_default_parameters**). This copy process is only possible while the output power stage is switched off.

Application parameter set

- The **current parameter set** can be saved into the non-transient flash memory. This saving process is enabled by a write access to the CANopen object **1010_h_01_h** (**save_all_parameters**). When the servo controller is switched on the **application parameter set** is copied to the **current parameter set**.

The following graphic illustrates the coherence between the respective parameter sets.



Two different methods are possible concerning the parameter set administration:

1. The parameter set is made up with the parameter set-up program Afag ServoCommander and also transferred to the single servo controller by the parameter set-up program Afag ServoCommander. With this method only those objects which can be accessed via CANopen exclusively have to be adjusted via the CAN bus.

This method has the disadvantage that the parameter set-up software is needed for every start of a new machine or in case of repair (exchange of servo controller). Therefore this method only makes sense for individual units.

2. This method is based on the fact that most application specific parameter sets only vary in few parameters from the **default parameter set**. Thus it is possible to set up the **current parameter set** after every reset via the CAN bus. To that purpose the **default parameter set** is first loaded by the superimposed control (call of the CANopen object **1011_h01_h (restore_all_default_parameters)**). Afterwards only those objects are transferred which vary. The complete process only lasts about 0,3 seconds per drive. It is advantageous that this method also works for non-parametrized servo controllers and the parameter set-up software Afag ServoCommander is not necessary for this.



It is urgently recommended to use method 2.



Before switching on the power stage for the first time, assure that the servo controller contains the desired parameters.

An incorrect parameter set-up may cause uncontrolled behaviour of the motor and thereby personal or material damage may occur.

6.1.2 Description of Objects

6.1.2.1 Object 1011_h: restore_default_parameters

Index	1011 _h
Name	restore_parameters
Object Code	ARRAY
No. of Elements	1
Data Type	UINT32

Sub-Index	01 _h
Description	restore_all_default_parameters
Access	rw
PDO Mapping	no
Units	-
Value Range	64616F6C _h („load“)
Default Value	1 (read access)

Through the object 1011_h_01_h (restore_all_default_parameters) it is possible to put the **current parameter set** into a defined state. For that purpose the **default parameter set** is copied to the **current parameter set**. The copy process is enabled by a write access to this object and the string "load" is to be passed as data set in hexadecimal form. This command is only executed while the output power stage is deactivated. Otherwise the SDO error "The controller is in wrong operation mode for this kind of operation" is generated. The parameter for the CAN communication (node number, baudrate and mode) remain unchanged.

6.1.2.2 Object 1010_h: store_parameters

Index	1010_h
Name	store_parameters
Object Code	ARRAY
No. of Elements	1
Data Type	UINT32

Sub-Index	01_h
Description	save_all_parameters
Access	rw
PDO Mapping	no
Units	-
Value Range	65766173 _h („save“)
Default Value	1


To store the **default parameter set** as **application parameter set**, the object **1010_h_01_h** (**save_all_parameters**) must be used additionally.

6.2 Conversion factors (Factor Group)

6.2.1 Survey

Servo controllers will be used in a huge number of applications: As direct drive, with gear or for linear drives. To allow an easy parametrization for all kinds of applications, the servo controller can be parametrized in such a way that all values like the demand velocity refer to the driven side of the plant. The necessary calculation is done by the servo controller.

Consequently it is possible to enter values directly in e.g. millimetre per second if a linear drive is used. The conversion is done by the servo controller using the Factor Group. For each physical value (position, velocity and acceleration) exists a specific conversion factor to adapt the unit to the own application. In general the user specific units defined by the Factor Group are called **position_units**, **speed_units** and **acceleration_units**. The following Figure shows the function of the Factor Group:



Principally all parameters will be stored in its internal units and converted while reading or writing a parameter.

Therefore the Factor Group should be adjusted once before commissioning the servo controller and not to be changed during parametrization.

The default setting of the Factor Group is as follows:

Value	Name	Unit	Remark
Length	position_units	Increments	65536 Increments per revolution

Velocity	speed_units	min^{-1}	Revolution per minute
Acceleration	acceleration_units	min^{-1}/s	Increase of velocity per second

6.2.2 Description of Objects

6.2.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6093 _h	ARRAY	position_factor	UINT32	rw
6094 _h	ARRAY	velocity_encoder_factor	UINT32	rw
6097 _h	ARRAY	acceleration_factor	UINT32	rw
607E _h	VAR	polarity	UINT8	rw

6.2.2.2 Object 6093_h: position_factor

The object **position_factor** converts all values of length of the application from **position_units** into the internal unit **increments** (65536 Increments equals 1 Revolution). It consists of numerator and divisor:




Figure 6.5: Survey: Factor Group

Index	6093_h
Name	position_factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01_h
Description	numerator
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	1

Sub-Index	02_h
Description	divisor
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	1

To calculate the **position_factor** the following values are necessary:

gear_ratio	Ratio between revolutions on the driving side (R_{IN}) and revolutions on the driven side (R_{OUT}).
feed_constant	Ratio between revolutions on the driven side (R_{OUT}) and equivalent motion in position_units (e.g. 1 rev = 360°)

The calculation of the **position_factor** is done with the following equation:

$$\text{position_factor} = \frac{\text{numerator}}{\text{divisor}} = \frac{65536 \cdot \text{gear_ratio}}{\text{feed_constant}}$$

Numerator and divisor of the **position_factor** has to be entered separately. Therefore it may be necessary to extend the fraction to generate integers:



EXAMPLE

1. Desired unit on the driven side (*position_units*)
2. *feed_constant*: How many *position_units* are 1 revolution(R_{OUT})
3. *gear_ratio*: R_{IN} per R_{OUT}
4. Calculate equation

1.	2.	3.	4.	Result shortened
Increments	$1 R_{OUT}$ = 65536 Inc	1/1	$\frac{65536 \frac{Inc}{R} \cdot \frac{1R}{1R} \cdot \frac{1}{1}}{\frac{65536 Inc}{1R}} = \frac{1 Inc}{1 Inc}$	num: 1 div: 1
1/10 degree ($^{degree}/_{10}$)	$1 R_{OUT}$ = 3600 $^{degree}/_{10}$	1/1	$\frac{65536 \frac{Inc}{R} \cdot \frac{1R}{1R}}{\frac{3600 \text{ } ^{degree}/_{10}}{1R}} = \frac{65536 Inc}{3600 \text{ } ^{degree}/_{10}}$	num: 4096 div: 225
1/100 Rev. ($^R/_{100}$)	$1 R_{OUT}$ = 100 $^U/_{100}$	1/1	$\frac{65536 \frac{Inc}{R} \cdot \frac{1R}{1R}}{\frac{100 \text{ } ^R/_{100}}{1R}} = \frac{65536 Inc}{100 \text{ } ^R/_{100}}$	num: 16384 div: 25
1/100 Rev. ($^R/_{100}$)	$1 R_{OUT}$ = 100 $^R/_{100}$	2/3	$\frac{65536 \frac{Inc}{R} \cdot \frac{2R}{3R}}{\frac{100 \text{ } ^R/_{100}}{1R}} = \frac{131072 Inc}{300 \text{ } ^R/_{100}}$	num: 32768 div: 75
1/10 mm ($^{mm}/_{10}$)	$1 R_{OUT}$ = 631.5 $^{mm}/_{10}$	1/1	$\frac{65536 \frac{Inc}{R} \cdot \frac{1R}{1R}}{\frac{631.5 \text{ } ^{mm}/_{10}}{1R}} = \frac{655360 Inc}{6315 \text{ } ^{mm}/_{10}}$	num: 131072 div: 1263
1/10 mm ($^{mm}/_{10}$)	$1 R_{OUT}$ = 631.5 $^{mm}/_{10}$	4/5	$\frac{65536 \frac{Inc}{R} \cdot \frac{4R}{5R}}{\frac{631.5 \text{ } ^{mm}/_{10}}{1R}} = \frac{2621440 Inc}{31575 \text{ } ^{mm}/_{10}}$	num: 524288 div: 6315

6.2.2.3 Object 6094_h: velocity_encoder_factor

The object **velocity_encoder_factor** converts all speed values of the application from **speed_units** into the internal unit **revolutions per 4096 seconds**. It consists of numerator and divisor:

Index	6094_h
Name	velocity_encoder_factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01_h
Description	numerator
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	1000 _h

Sub-Index	02_h
Description	divisor
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	1

In principle the calculation of the **velocity_encoder_factor** is composed of two parts: A conversion factor from internal units of length into **position_units** and a conversion factor from internal time units into user defined time units (e.g. from seconds to minutes). The first part equals the calculation of the **position_factor**. For the second part another factor is necessary for the calculation:

time_factor_v	Ratio between internal and user defined time units.
gear_ratio	Ratio between revolutions on the driving side (RIN) and revolutions on the driven side (ROUT).
feed_constant	Ratio between revolutions on the driven side (ROUT) and equivalent motion in position_units (e.g. 1 rev = 360°)

The calculation of the **velocity_encoder_factor** is done with the following equation:

$$\text{velocity_encoder_factor} = \frac{\text{numerator}}{\text{divisor}} = \frac{65536 \cdot \text{gear_ratio} \cdot \text{time_factor_v}}{\text{feed_constant}}$$

Numerator and divisor of the **velocity_encoder_factor** has to be entered separately. Therefore it may be necessary to extend the fraction to generate integers:

EXAMPLE



1. Desired unit on the driven side (**position_units**)
2. **feed_constant**: How many **position_units** are 1 revolution(ROUT)
3. **time_factor_v**: Desired time unit contains how many seconds ?
4. **gear_ratio**: RIN per ROUT
5. Calculate equation

1.	2.	3.	4.	5.	ERGEBNIS Gekürzt
R/min	1 ROUT = 65536 Inc	$1 \frac{1}{\text{min}} =$ 4096 $\frac{1}{4096 \text{ min}}$	1/1	$\frac{\frac{1 R}{1 R} \cdot \frac{1 R}{1 R} \cdot \frac{4096 \frac{1}{4096 \text{min}}}{1 \frac{1}{\text{min}}}}{\frac{1 R}{1 R}} = \frac{4096 R/4096 \text{min}}{1 R/\text{min}}$	num: 4096 div: 1
$1/10 \text{ degree/s}$ ($\text{degree}/10\text{s}$)	1 ROUT = 3600 $\text{degree}/10$	$1 \frac{1}{\text{s}} =$ $1/60 \frac{1}{\text{min}} =$ 4096/60 $\frac{1}{4096 \text{ min}}$	1/1	$\frac{\frac{1 R}{1 R} \cdot \frac{1 R}{1 R} \cdot \frac{4096 \frac{1}{4096 \text{min}}}{60 \frac{1}{\text{min}}}}{\frac{3600 \text{ degree}/10}{1 R}} = \frac{4096 R/4096 \text{min}}{216000 \text{ degree}/10\text{s}}$	num: 16 div: 3375
$1/100 R/\text{min}$ ($R/100 \text{ min}$)	1 ROUT = 100 $U/100$	$1 \frac{1}{\text{min}} =$ 4096 $\frac{1}{4096 \text{ min}}$	1/1	$\frac{\frac{1 R}{1 R} \cdot \frac{1 R}{1 R} \cdot \frac{4096 \frac{1}{4096 \text{min}}}{1 \frac{1}{\text{min}}}}{\frac{100 R/100}{1 R}} = \frac{4096 R/4096 \text{min}}{100 R/100 \text{min}}$	num: 1024 div: 25
$1/100 R/\text{min}$ ($R/100 \text{ min}$)	1 ROUT = 100 $U/100$	$1 \frac{1}{\text{min}} =$ 4096 $\frac{1}{4096 \text{ min}}$	2/3	$\frac{\frac{1 R}{1 R} \cdot \frac{2 R}{3 R} \cdot \frac{4096 \frac{1}{4096 \text{min}}}{1 \frac{1}{\text{min}}}}{\frac{100 R/100}{1 R}} = \frac{8192 R/4096 \text{min}}{300 R/100 \text{min}}$	num: 2048 div: 75
$1/10 \text{ mm/s}$ ($\text{mm}/10\text{s}$)	1 ROUT = 631.5 $\text{mm}/10$	$1 \frac{1}{\text{s}} =$ $1/60 \frac{1}{\text{min}} =$ 4096/60 $\frac{1}{4096 \text{ min}}$	1/1	$\frac{\frac{1 R}{1 R} \cdot \frac{1 R}{1 R} \cdot \frac{4096 \frac{1}{4096 \text{min}}}{60 \frac{1}{\text{min}}}}{\frac{631.5 \text{ mm}/10}{1 R}} = \frac{4096 R/4096 \text{min}}{37890 \text{ mm}/10\text{s}}$	num: 2048 div: 18945
$1/10 \text{ mm/s}$ ($\text{mm}/10\text{s}$)	1 ROUT = 631.5 $\text{mm}/10$	$1 \frac{1}{\text{s}} =$ $1/60 \frac{1}{\text{min}} =$ 4096/60 $\frac{1}{4096 \text{ min}}$	4/5	$\frac{\frac{1 R}{1 R} \cdot \frac{2 R}{3 R} \cdot \frac{4096 \frac{1}{4096 \text{min}}}{1 \frac{1}{\text{min}}}}{\frac{631.5 R/100}{1 R}} = \frac{16384 R/4096 \text{min}}{3789 R/100 \text{min}}$	num: 16384 div: 3789

6.2.2.4 Object 6097_h: acceleration_factor

The object **acceleration_factor** converts all acceleration values of the application from **acceleration_units** into the internal unit **increments per second²** (65536 Increments equals 1 Revolution). It consists of numerator and divisor:

Index	6097_h
Name	acceleration_factor
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01_h
Description	numerator
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	100 _h

Sub-Index	02_h
Description	divisor
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	1

The calculation of the **velocity_encoder_factor** is also composed of two parts: A conversion factor from internal units of length into **position_units** and a conversion factor from internal time units squared into user defined time units squared (e.g. from seconds² to minutes²). The first part equals the calculation of the **position_factor**. For the second part another factor is necessary for the calculation:

- time_factor_a** Ratio between internal time units squared and user defined time units squared
(e.g. $1 \text{ min}^2 = 1 \text{ min} \cdot 1 \text{ min} = 60\text{s} \cdot 1 \text{ min}$)
- gear_ratio** Ratio between revolutions on the driving side (RIN) and revolutions on the driven side (ROUT).
- feed_constant** Ratio between revolutions on the driven side (ROUT) and equivalent motion in position_units (e.g. 1 rev = 360°)

The calculation of the acceleration_factor is done with the following equation:
 Numerator and divisor of the **acceleration_factor** has to be entered separately.
 Therefore it may be necessary to extend the fraction to generate integers:



EXAMPLE

1. Desired unit on the driven side (position_units)
2. feed_constant: How many position_units are 1 revolution(ROUT)
3. time_factor_v: Desired (time unit)² contains how many seconds² ?
4. gear_ratio: RIN per ROUT
5. Calculate equation

1.	2.	3.	4.	5.	Result shortened
$\frac{R}{\text{min}}$ s $(\frac{R}{\text{min}} \cdot s)$	$1 R_{\text{OUT}} =$ $1 R_{\text{IN}}$	$1 \frac{1}{\text{min} \cdot s} =$ $256 \frac{1}{256 \cdot s}$	$1/1$	$\frac{\frac{1R}{1R} \cdot \frac{1R}{1R} \cdot \frac{256 \frac{1}{256} \text{min} \cdot s}{1 \frac{1}{\text{min}} \cdot s}}{\frac{1R}{1R}} = \frac{\frac{R}{256} \frac{\text{min}}{\text{min}} / \frac{R}{1} \frac{s}{s}}{1 \frac{R}{\text{min}} / s}$	num: 256 div: 1
$\frac{1}{10}$ $\frac{\text{degree}}{s^2}$ $(\frac{\text{degree}}{10s^2})$	$1 R_{\text{OUT}} =$ $3600 \frac{\text{degree}}{10}$	$1 \frac{1}{s^2} =$ $1/60 \frac{1}{\text{min} \cdot s} =$ $256/60 \frac{1}{\text{min} \cdot s}$	$1/1$	$\frac{\frac{1R}{1R} \cdot \frac{1R}{1R} \cdot \frac{256 \frac{1}{256} \text{min} \cdot s}{1R \cdot 1R \cdot 60 \frac{1}{\text{min}} \cdot s}}{\frac{3600 \frac{\text{degree}}{10}}{1R}} = \frac{\frac{R}{256} \frac{\text{min}}{\text{min}} / \frac{R}{256} \frac{s}{s}}{216000 \frac{\text{degree}}{10s^2}}$	num: 4 div: 3375
$\frac{1}{100} \frac{R}{\text{min}^2}$ $(\frac{R}{100 \text{min}^2})$	$1 R_{\text{OUT}} =$ $100 \frac{R}{100}$	$1 \frac{1}{\text{min}^2} =$ $60 \frac{1}{\text{min} \cdot s} =$	$1/1$	$\frac{\frac{1R}{1R} \cdot \frac{1R}{1R} \cdot \frac{15360 \frac{1}{256} \text{min} \cdot s}{1R \cdot 1R \cdot 1 \frac{1}{\text{min}} \cdot \text{min}}}{\frac{100 \frac{R}{100}}{1R}} = \frac{\frac{R}{15360} \frac{\text{min}}{\text{min}} / \frac{R}{100} \frac{s}{s}}{100 \frac{R}{100 \text{min}^2}}$	num: 3840 div: 25
$\frac{1}{100} \frac{R}{\text{min}^2}$ $(\frac{R}{100 \text{min}^2})$		$256 \cdot 60 \frac{1}{256 \cdot s}$	$2/3$	$\frac{\frac{1R}{1R} \cdot \frac{2R}{3R} \cdot \frac{15360 \frac{1}{256} \text{min} \cdot s}{1R \cdot 3R \cdot 1 \frac{1}{\text{min}} \cdot \text{min}}}{\frac{100 \frac{R}{100}}{1R}} = \frac{\frac{R}{30720} \frac{\text{min}}{\text{min}} / \frac{R}{256} \frac{s}{s}}{300 \frac{R}{100 \text{min}^2}}$	num: 2560 div: 25
$\frac{1}{10}$ $\frac{\text{mm}}{s^2}$ $(\frac{\text{mm}}{10s^2})$	$1 R_{\text{OUT}} =$ $631.5 \frac{\text{mm}}{10}$	$1 \frac{1}{s^2} =$ $1/60 \frac{1}{\text{min} \cdot s} =$	$1/1$	$\frac{\frac{1R}{1R} \cdot \frac{1R}{1R} \cdot \frac{256 \frac{1}{256} \text{min} \cdot s}{1R \cdot 1R \cdot 60 \frac{1}{\text{min}} \cdot \text{min}}}{\frac{631.5 \frac{\text{mm}}{10 \text{degree}}}{1R}} = \frac{\frac{R}{256} \frac{\text{min}}{\text{min}} / \frac{R}{256} \frac{s}{s}}{37890 \frac{R}{100 \text{min}^2}}$	num: 128 div: 18945
$\frac{1}{10}$ $\frac{\text{mm}}{s^2}$ $(\frac{\text{mm}}{10s^2})$		$256/60 \frac{1}{256 \cdot s}$	$4/5$	$\frac{\frac{1R}{1R} \cdot \frac{4R}{5R} \cdot \frac{256 \frac{1}{256} \text{min} \cdot s}{1R \cdot 5R \cdot 60 \frac{1}{\text{min}} \cdot \text{min}}}{\frac{631.5 \frac{\text{mm}}{10 \text{degree}}}{1R}} = \frac{\frac{R}{1024} \frac{\text{min}}{\text{min}} / \frac{R}{256} \frac{s}{s}}{189450 \frac{R}{100 \text{min}^2}}$	num: 512 div: 94725

6.2.2.5 Object 607E_h: polarity

The signs of the position and velocity values of the servo controller can be adjusted via the corresponding polarity flag. This flag can be used to invert the direction of rotation of the motor keeping the same desired values. In most applications it makes sense to set the **position_polarity_flag** and the **velocity_polarity_flag** to the same value. The conversion factors will be used when reading or writing a position or velocity value. Stored parameters will not be affected.

Index	607E _h
Name	polarity
Object Code	VAR
Data Type	UINT8

Access	rw
PDO Mapping	yes
Units	--
Value Range	40 _h , 80 _h , C0 _h
Default Value	0

Bit	Value	Name	Description
6	40 _h	velocity_polarity_flag	0: multiply by 1 (default) 1: multiply by -1 (invers)
7	80 _h	position_polarity_flag	0: multiply by 1 (default) 1: multiply by -1 (invers)

6.3 Power stage parameters

6.3.1 Survey

The intermediate circuit is charged by the main supply voltage using a precharge control. Thereby the current is limited and the loading process is controlled. The precharge control will be bridged if the intermediate circuit is loaded completely. Before this it is not possible to enable the controller.

The rectified supply voltage is smoothed by the capacitors of the intermediate circuit. The motor is fed from the intermediate circuit via the IGBTs. The power stage contains a number of security functions which can be parametrized in part:

- Controller enable logic (software and hardware enabling)
- Overcurrent control
- Over- and undervoltage control of the intermediate circuit
- Power stage control

6.3.2 Description of Objects

Index	Object	Name	Typ	Attr.
6510 _n	VAR	drive_data		

6.3.2.1 Object 6510_{n_10n}: enable_logic

The digital inputs **enable power stage** and **enable controller** have to be set so that the power stage of the servo controller can be activated:

The input **enable power stage** directly acts on the trigger signals of the power transistors and would also be able to interrupt them in case of a defective microprocessor. Therefore the clearing of the signal **enable power stage** during the motor is rotating causes the effect that the motor coasts down without being braked or is only stopped by a possibly existing holding brake.



The signal of the input **enable controller** is processed by the microcontroller of the servo controller. Depending on the mode of operation the servo controller reacts differently after clearing this signal:

Profile Position Mode and Profile Velocity Mode

- The motor is decelerated using the defined brake ramp after clearing the signal. The power stage is switched off if the motor speed is below 10 rpm and a possibly existing holding brake is locked.

Torque Mode

- The power stage is switched off immediately after the signal has been cleared. At the same time a possibly existing holding brake is locked. Therefore the motor coasts down without being braked or is only stopped by a stop brake which might exists.

 	<p>CAUTION !</p> <p>Both signals do not ensure that the motor is de-energised, although the power stage has been switched off.</p>
---	---

If the servo controller is operated via the CAN bus, it is possible to connect the digital inputs **enable power stage** and **enable controller** together at 24 V and to control the enabling via the CAN bus. To that object **6510_h_10_h** (**enable_logic**) has to be set to 2. For safety reasons this is done automatically after activation of CANopen (also after a reset).

Index	6510_h
Name	drive_data
Object Code	RECORD
No. of Elements	44

Sub-Index	10_h
Description	enable_logic
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	
Value Range	0...2
Default Value	2

Value	Description
0	Digital inputs enable power stage + enable controller.
1	Digital inputs enable power stage + enable controller + RS232
2	Digital inputs enable power stage + enable controller + CAN

6.3.2.2 Object 6510_h_30_h: pwm_frequency

The switching losses of the power stage is proportional to the switching frequency of the power transistors. A little more power can be taken from some devices of the SE-POWER series by dividing the PWM frequency by two. The disadvantage is an increasing current ripple. Switch over is only possible while the power stage is switched off.

Sub-Index	30_h
Description	pwm_frequency
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0, 1
Default Value	0

Value	Description
0	Nominal PWM frequency
1	Half of nominal PWM frequency

6.3.2.3 Object 6510_h_3A_h: enable_enhanced_modulation

With the object **enable_enhanced_modulation** the enhanced modulation can be activated. The DC bus voltage will be used more effectively thereby increasing the possible velocity by up to 14%. In contrast the control behaviour and the smooth running properties at low speed diminish a little. This object can only be written if the power stage is switched off.

Sub-Index	3A _h
Description	enable_enhanced_modulation
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0, 1
Default Value	0

Value	Description
0	Enhanced sinus modulation switched OFF
1	Enhanced sinus modulation switched ON

6.3.2.4 Object 6510_h_31_h: power_stage_temperature

The temperature of the power stage can be read via the object **power_stage_temperature**. If the temperature specified in the object 6510_h_32_h (**max_power_stage_temperature**) is exceeded the power stage is switched off and an error message is sent.

Sub-Index	31 _h
Description	power_stage_temperature
Data Type	INT16
Access	ro
PDO Mapping	no
Units	°C
Value Range	--
Default Value	--

6.3.2.5 Object 6510_h_32_h: max_power_stage_temperature

The temperature of the power stage can be read via the object 6510_h_31_h (**power_stage_temperature**). If the temperature specified in the object **max_power_stage_temperature** is exceeded the power stage is switched off and an error message is sent.

Sub-Index	32_h
Description	max_power_stage_temperature
Data Type	INT16
Access	ro
PDO Mapping	no
Units	°C
Value Range	100
Default Value	100

6.3.2.6 Object 6510_h_33_h: nominal_dc_link_circuit_voltage

The nominal device voltage in mV can be read via the object **nominal_dc_link_circuit_voltage**.

Sub-Index	33_h
Description	nominal_dc_link_circuit_voltage
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	Device specific

Device Type	Value
SE-POWER	360000
SE-POWER	360000

6.3.2.7 Object 6510_h_34_h: actual_dc_link_circuit_voltage

The current voltage in mV of the intermediate circuit can be read via the object **actual_dc_link_circuit_voltage**.

Sub-Index	34_h
Description	actual_dc_link_circuit_voltage
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	--

6.3.2.8 Object 6510_h_35_h: max_dc_link_circuit_voltage

The **max_dc_link_circuit_voltage** indicates above which voltage in the intermediate circuit the power stage is immediately switched off for reasons of safety. An error message is sent, too.

Sub-Index	35_h
Description	max_dc_link_circuit_voltage
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	Device specific

Device Type	Value
SE-POWER	460000
SE-POWER	460000

6.3.2.9 Object 6510_h_36_h: min_dc_link_circuit_voltage

The servo controller has an undervoltage control. This control can be activated via the object 6510_h_37_h (**enable_dc_link_undervoltage_error**). The object 6510_h_36_h (**min_dc_link_circuit_voltage**) determines the lower voltage range. Below this voltage the servo controller decelerates and switches off the power stage afterwards. Furthermore the error E 02 0, “Undervoltage in DC bus“ will be activated.

Sub-Index	36 _h
Description	min_dc_link_circuit_voltage
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	mV
Value Range	0...1000000
Default Value	0

6.3.2.10 Object 6510_h_37_h: enable_dc_link_undervoltage_error

The undervoltage control can be activated via the object **enable_dc_link_undervoltage_error**. The voltage of the intermediate circuit above which the servo should work correctly has to be placed in the object 6510_h_36_h (**min_dc_link_circuit_voltage**).

Sub-Index	37 _h
Description	enable_dc_link_undervoltage_error
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0, 1
Default Value	0

Value	Description
0	Undervoltage error switched OFF (Reaction: Warning)
1	Undervoltage error switched ON (Reaction: Disable servo controller)

The enabling of the error is done by changing the error reaction. Reactions leading to a stop of the motor, will be returned as ON, all the rest as OFF. On writing a 0 the reaction „Warning“ will be set, on writing a 1 the reaction „Disable servo controller“.

6.3.2.11 Object 6510_h_40_h: nominal_current

The nominal current of the device can be read via this object. It is also the upper limit for the object 6075_h (motor_rated_current).

Sub-Index	40 _h
Description	nominal_current
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mA
Value Range	--
Default Value	Device specific

DeviceType	Value
SE-POWER	2500
SE-POWER	5000

6.3.2.12 Object 6510_h_41_h: peak_current

The devices peak current can be read via this object. It is also the upper limit for the object 6073_h (max_current).

Sub-Index	41 _h
Description	peak_current
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	mA
Value Range	--
Default Value	Device specific

Device Type	Value
SE-POWER	5000
SE-POWER	10000

6.4 Current control and motor adaptation



Caution !

Incorrect setting of current control parameters and the current limits may possibly destroy the **motor** and even the **servo controller** immediately!

6.4.1 Survey

The parameter set of the servo controller has to be adapted to the connected motor and the used cable set. The following parameters are concerned:

- Nominal current Depending on motor
- Overload Depending on motor
- Pairs of poles Depending on motor
- Current controller Depending on motor
- Direction of rotation Depending on motor and the phase sequence in the motor cable and the resolver cable
- Offset angle Depending on motor and the phase sequence in the motor cable and the resolver cable

These data have to be determined by the program Afag ServoCommander when a motor type is used for the first time. You may obtain elaborate parameter sets for a number of motors from your dealer. Please remember that direction of rotation and offset angle also depend on the used cable set. Therefore the parameter sets only work correctly if wiring is identical.



Permuted phase order in the motor or the resolver cable may result in a positive feedback so the velocity in the motor cannot be controlled. The motor will rotate uncontrolled!

6.4.2 Description of Objects

Index	Object	Name	Type	Attr.
6075 _h	VAR	motor Rated current	UINT32	rw
6073 _h	VAR	max current	UINT16	rw
604D _h	VAR	pole number	UINT8	rw
6410 _h	RECORD	motor data	UINT32	rw
60F6 _h	RECORD	torque control parameters	UINT16	rw

6.4.2.1 Object 6075_h: motor Rated current

This value can be read on the motor plate and is specified in mA (effective value, RMS). The upper limit is determined by the object **6510_h_40_h: nominal current**.

Index	6075_h
Name	motorRatedCurrent
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	mA
Value Range	0...nominalCurrent
Default Value	500



If a new value is written into the object **6075_h** (**motorRatedCurrent**) also object **6073_h** (**maxCurrent**) has to be rewritten.

6.4.2.2 Object 6073_h: max_current

Servo motors may be overloaded for a certain period of time. The maximum permissible motor current is set via this object. It refers to the nominal motor current (object 6075_h: motorRatedCurrent) and is set in thousandths. The upper limit for this object is determined by the object 6510_h_41_h (peakCurrent). Many motors may be overloaded by the factor 2 for a short while. In this case the value 2000 has to be written into this object.



Before writing object 6073_h (max_current) the object 6075_h (motorRatedCurrent) must have a valid value.

Index	6073 _h
Name	max_current
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	per thousands of rated current
Value Range	-
Default Value	2023

6.4.2.3 Object 604D_h: pole_number

The number of poles of the motor can be read in the datasheet of the motor or the parameter set-up program Afag ServoCommander. The number of poles is always an integer value. Often the number of pole pairs is specified instead of the number of poles. In this case the number of poles equals the number of pole pairs multiplied with two.

Index	604D _h
Name	pole_number
Object Code	VAR
Data Type	UINT8

Access	rw
PDO Mapping	yes
Units	--
Value Range	2... 254
Default Value	2

6.4.2.4 Object 6410_h_03_h: iit_time_motor

Servo motors may be overloaded for a certain period of time. This object indicates how long the motor may receive a current specified in the object 6073_h (**max_current**). After the expiry of the I²t-time the current is automatically limited to the value specified in the object 6075_h (**motor_rated_current**) in order to protect the motor. The default adjustment is 3 seconds and can be used for most motors.

Index	6410_h
Name	motor_data
Object Code	RECORD
No. of Elements	5

Sub-Index	03_h
Description	iit_time_motor
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	ms
Value Range	0...10000
Default Value	2000

6.4.2.5 Object 6410_h_04_h: iit_ratio_motor

The actual value of iit can be read via the object **iit_ratio_motor**.

Sub-Index	04_h
Description	iit_ratio_motor
Data Type	UINT16
Access	ro
PDO Mapping	no
Units	per mille
Value Range	--
Default Value	--

6.4.2.6 Object 6510_h_38_h: iit_error_enable

The object **iit_error_enable** determines the behaviour when reaching the iit limit: Either this will only be displayed in the **statusword** or Error 31 0 will be generated

Index	6510_h
Name	drive_data
Object Code	RECORD
No. of Elements	44

Sub-Index	38_h
Description	iit_error_enable
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0, 1
Default Value	0

Value	Description
0	lit-error switched OFF (Reaction: Warning)
1	lit-error switched On (Reaction: Disable servo controller)

The enabling of the error is done by changing the error reaction. Reactions leading to a stop of the motor, will be returned as ON, all the rest as OFF. On writing a 0 the reaction „Warning“ will be set, on writing a 1 the reaction „Disable servo controller“.

6.4.2.7 Object 6410_h_10_h: phase_order

With the object **phase_order** it is possible to consider permutations of motor- or resolver cable. This value can be taken from Afag ServoCommander. A zero means “right”, a one means “left”.

Sub-Index	10_h
Description	phase_order
Data Type	INT16
Access	rw
PDO Mapping	yes
Units	--
Value Range	0, 1
Default Value	0

Value	Description
-------	-------------

0	Right
1	Left

6.4.2.8 Object 6410_h_11_h: encoder_offset_angle

In case of the used servo motors permanent magnets are on the rotor. These magnets generate a magnetic field whose orientation to the stator depends on the rotor position. For the electronic commutation the controller always has to position the electromagnetic field of the stator in the correct angle towards this permanent magnetic field. For that purpose it permanently determines the rotor position with an angle encoder (resolver etc.).

The orientation of the angle encoder to the magnetic field has to be written to the object **resolver_offset_angle**. This angle can be determined by the parameter set-up program Afag ServoCommander. The angle determined by the parameter set-up program Afag ServoCommander is in the range of +/-180°. It has to be converted as follows to be written into the object **resolver_offset_angle**:

$$\text{encoder_offset_angle} = \text{„Offset of encoder“} \times \frac{32767}{180^\circ}$$

Index	6410_h
Name	motor_data
Object Code	RECORD
No. of Elements	5

Sub-Index	11_h
Description	encoder_offset_angle
Data Type	INT16
Access	rw
PDO Mapping	yes
Units	
Value Range	-32767...32767
Default Value	E000 _h (-45°)

6.4.2.9 Object 2415_h: current_limitation

The record **current_limitation** allows the limitation of the maximum current independent of the mode of operation (velocity control, positioning) whereby torque limited speed control is possible. The source of the torque limit can be chosen by the object **limit_current_input_channel**. Possibly sources for the torque limit are Fieldbus, RS232 or an analogue input. Depending on the chosen source the object **limit_current** determines the torque limit (Source = Fieldbus / RS232) or the scaling factor for the analogue input (Source = Analogue input). In the first case the current limit in mA can be entered directly, in the later case the current in mA corresponding to an input value of 10V has to be entered

Index	2415_h
Name	current_limitation
Object Code	RECORD
No. of Elements	2

Sub-Index	01_h
Description	limit_current_input_channel
Data Type	INT8
Access	rw
PDO Mapping	no
Units	--
Value Range	0...4
Default Value	0

Sub-Index	02_h
Description	limit_current
Data Type	INT32
Access	rw
PDO Mapping	no
Units	mA
Value Range	--
Default Value	0

Value	Description
0	No limitation
1	AIN0
2	AIN1
3	AIN2
4	Fieldbus (Fieldbus selector 2)

6.4.2.10 Object 60F6_h: torque_control_parameters

The data of the current controller has to be taken from the parameter set-up program Afag ServoCommander. The following conversions have to be noticed:

The gain of the current controller has to be multiplied by 256. In case of a gain of 1.5 in the parameter set-up program WMEMOC the value $384 = 180_{\text{h}}$ has to be written into the object **torque_control_gain**.

The time constant of the current controller is specified in milliseconds in the parameter set-up program Afag ServoCommander. This time constant has to be converted to microseconds before it can be transferred into the object **torque_control_time**. In case of a specified time of 0.6 milliseconds a value of 600 has to be entered into the object **torque_control_time**.

Index	60F6_h
Name	torque_control_parameters
Object Code	RECORD
No. of Elements	2

Sub-Index	01_h
Description	torque_control_gain
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	256 = „1“
Value Range	0...32*256
Default Value	3*256 (768)

Sub-Index	02_h
Description	torque_control_time
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	μs
Value Range	104... 64401
Default Value	1020

6.5 Velocity controller

6.5.1 Survey

The parameter set of the servo controller has to be adapted to the specific application. In particular the gain strongly depends on the masses coupled to the motor. So the data have to be determined by means of the program Afag ServoCommander when the plant is set into operation.



Incorrect setting of the velocity control parameters may lead to strong vibrations and destroy parts of the plant!

6.5.2 Description of Objects

Index	Object	Name	Type	Attr.
60F9 _n	RECORD	velocity_control_parameters		rw

6.5.2.1 Object 60F9_n: velocity_control_parameters

The data of the velocity controller can be taken from the parameter set-up program Afag ServoCommander. Note the following conversions:

The gain of the velocity controller has to be multiplied by 256. In case of a gain of 1.5 in Afag ServoCommander the value 384 has to be written into the object **velocity_control_gain**.

The time constant of the velocity controller is specified in milliseconds in Afag ServoCommander. This time constant has to be converted to microseconds before it can be transferred into the object **velocity_control_time**. In case of a specified time of 2.0 milliseconds a value of 2000 has to be written into the object **velocity_control_time**.

Index	60F9_h
Name	velocity_control_parameter_set
Object Code	RECORD
No. of Elements	3

Sub-Index	01_h
Description	velocity_control_gain
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	256 = Gain 1
Value Range	20...64*256 (16384)
Default Value	256

Sub-Index	02_h
Description	velocity_control_time
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	μs
Value Range	1...32000
Default Value	2000

Sub-Index	04_h
Description	velocity_control_filter_time
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	μs
Value Range	1...32000
Default Value	2000

6.6 Position Control Function

6.6.1 Survey

This chapter describes all parameters which are required for the position controller. The desired position value (**position_demand_value**) of the trajectory generator is the input of the position controller. Besides this the actual position value (**position_actual_value**) is supplied by the angle encoder (resolver, incremental encoder, etc.). The behaviour of the position controller can be influenced by parameters. It is possible to limit the output quantity (**control_effort**) in order to keep the position control system stable. The output quantity is supplied to the speed controller as desired speed value. In the **Factor Group** all input and output quantities are converted from the application-specific units to the respective internal units of the controller.

The following subfunctions are defined in this chapter:

1. Trailing error (Following Error)

The deviation of the actual position value (**position_actual_value**) from the desired position value (**position_demand_value**) is named trailing error. If for a certain period of time this trailing error is bigger than specified in the trailing error window (**following_error_window**) bit 13 (**following_error**) of the object **statusword** will be set. The permissible time can be defined via the object **following_error_time_out**.




Figure 6.6: Trailing error (Following Error) – Function Surve

Figure 6.7 shows how the window function is defined for the message "following error". The range between $x_i - x_0$ and $x_i + x_0$ is defined symmetrically around the desired position (**position_demand_value**) x_i . For example the positions x_{t2} and x_{t3} are outside this window (**following_error_window**). If the drive leaves this window and does not return to the window within the time defined in the object **following_error_time_out** then bit 13 (**following_error**) in the **statusword** will be set.




Figure 6.7: Trailing error (following error)

2. Position Reached

This function offers the chance to define a position window around the target position (**target_position**). If the actual position of the drive is within this range for a certain period of time – the **position_window_time** – bit 10 (**target_reached**) will be set in the **statusword**.




Figure 6.8: Position Reached – Function Survey

Figure 6.9 shows how the window function is defined for the message "position reached". The position range between $x_i - x_0$ and $x_i + x_0$ is defined symmetrically around the target position (**target_position**) x_i . For example the positions x_{t0} and x_{t1} are inside this position window (**position_window**). If the drive is within this window a timer is started. If this timer reaches the time defined in the object **position_window_time** and the drive uninterruptedly was within the valid range between $x_i - x_0$ and $x_i + x_0$, bit 10 (**target_reached**) will be set in the **statusword**. As far as the drive leaves the permissible range, bit 10 is cleared and the timer is set to zero.




Figure 6.9: Position reached

6.6.2 Description of Objects

6.6.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6062 _h	VAR	position_demand_value	INT32	ro
6063 _h	VAR	position_actual_value*	INT32	ro
6064 _h	VAR	position_actual_value	INT32	ro
6065 _h	VAR	following_error_window	UINT32	rw
6066 _h	VAR	following_error_time_out	UINT16	rw
6067 _h	VAR	position_window	UINT32	rw
6068 _h	VAR	position_window_time	UINT16	rw
60FA _h	VAR	control_effort	INT32	ro
60FB _h	RECORD	position_control_parameter_set		rw
60FC _h	VAR	position_demand_value*	INT32	ro

6.6.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
607A _h	VAR	target_position	INT32	8.3 Operating Mode »Profile Position Mode«
607B _h	VAR	position_range_limit	INT32	8.3 Operating Mode »Profile Position Mode«
607C _h	VAR	home_offset	INT32	8.2 Operating Mode »Homing mode«
607D _h	VAR	software_position_limit	INT32	8.3 Operating Mode »Profile Position Mode«
607E _h	VAR	polarity	UINT8	6.2 Conversion factors (Factor Group)
6093 _h	VAR	position_factor	UINT32	6.2 Conversion factors (Factor Group)
6094 _h	ARRAY	velocity_encoder_factor	UINT32	6.2 Conversion factors (Factor Group)
6096 _h	ARRAY	acceleration_factor	UINT32	6.2 Conversion factors (Factor Group)
6040 _h	VAR	controlword	INT16	6.9. Device Control
6041 _h	VAR	statusword	UINT16	6.9. Device Control

6.6.2.3 Object 60FB_h: position_control_parameter_set

All parameters of the servo controller have to be adapted to the specific application. Therefore the position control parameters have to be determined optimal by means of the parameter set-up program Afag ServoCommander.



Incorrect setting of the position control parameters may lead to strong vibrations and so destroy parts of the plant !

The position controller compares the desired position with the actual position and forms a correction speed (Object **60FA_h: control_effort**). This correction speed is supplied to the speed controller. The position controller is relatively slow compared to the current controller and speed controller. Therefore the controller internally works with feed forward so that the correction work for the position controller is minimised reaching a fast settling time.

Usually a proportional control unit is sufficient as position controller. The gain of the position controller has to be multiplied by 256. In case of a gain of 1.5 in the menu **Position controller** of the parameter set-up program Afag ServoCommander the value $384 = 180_{16}$ has to be written into the object **position_control_gain**.

Normally the position controller can work without an integrator. In this case 0 has to be written into the object **position_control_time**. Otherwise the time constant of the position controller has to be converted to microseconds. So the value 4000 has to be written into the object **position_control_time** in case of a time of 4.0 milliseconds.

As the position controller even transforms smallest deviations into a considerable correction speed, very high correction speeds may occur in case of a short disturbance (e. g. short blocking). This can be avoided if the output of the position controller is adequately limited (e.g. 500 rpm) via the object **position_control_v_max**. The object **position_error_tolerance_window** determines the maximum control deviation without reaction of the position controller. Therewith it is possible to even out backlash within the plant.

Index	60FB_h
Name	position_control_parameter_set
Object Code	RECORD
No. of Elements	4

Sub-Index	01_h
Description	position_control_gain
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	256 = „1“
Value Range	0...64*256 (16384)
Default Value	102

Sub-Index	02_h
Description	position_control_time
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	µs
Value Range	0
Default Value	0

Sub-Index	04_h
Description	position_control_v_max
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	speed units
Value Range	0...131072 min ⁻¹
Default Value	500 min ⁻¹

Sub-Index	05_h
Description	position_error_tolerance_window
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	position units

Value Range	0...65536 (1 R)
Default Value	2 (1 / 32768 R)

6.6.2.4 Object 6062_h: position_demand_value

The current position demand value can be read by this object. This position is fed into the position controller by the trajectory generator.

Index	6062_h
Name	position_demand_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	position units
Value Range	--
Default Value	--

The actual position can be read by this objects. This value is given to the position controller by the angle encoder.

Index	6064_h
Name	position_actual_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	position units
Value Range	--
Default Value	--

6.6.2.5 Object 6065_h: following_error_window

The object **following_error_window** (trailing error window) defines a symmetrical range around the desired position value (**position_demand_value**). If the actual position (**position_actual_value**) is outside the trailing error window (**following_error_window**) a trailing error occurs and bit 13 in the object **statusword** will be set.

The following reasons may cause a trailing error:

- A drive is locked
- The positioning speed is too high
- The accelerations are too high
- The object **following_error_window** parametrized too small
- The position controller is not parametrized correctly.

Index	6065_h
Name	following_error_window
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	0...7FFFFFFF _h
Default Value	9101 (9101 / 65536 R = 50°)

6.6.2.6 Object 6066_h: following_error_time_out

If a trailing error occurs longer than defined in this object bit 13 (**following_error**) will be set in the **statusword**.

Index	6066_h
Name	following_error_time_out
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...27314
Default Value	0

6.6.2.7 Object 60FA_h: control_effort

The output quantity of the position controller can be read via this object. This value is supplied internally to the speed controller as desired value.

Index	60FA_h
Name	control_effort
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	--

6.6.2.8 Object 6067_h: position_window

A symmetrical range around the target position (**target_position**) is defined by the object **position_window**. If the actual position value (**position_actual_value**) is within this range the target position (**target_position**) is regarded as reached.

Index	6067_h
Name	position_window
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	--
Default Value	1820 (1820 / 65536 R = 10°)

6.6.2.9 Object 6068_h: position_window_time

If the actual position of the drive is within the positioning window (**position_window**) as long as defined in this object bit 10 (**target_reached**) will be set in the **statusword**.

Index	6068 _h
Name	position_window_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...65536
Default Value	0

6.7 Analogue inputs

6.7.1 Survey

The servo controller of the SE-POWER series contains three analogue inputs, which can be used to enter a demand value for instance. For all of these inputs the following objects allow to read out the current input voltage (**analog_input_voltage**) and to determine an offset (**analog_input_offset**).

6.7.2 Description of Objects

Index	Object	Name	Type	Attr.
2400 _h	ARRAY	analog_input_voltage	INT16	ro
2401 _h	ARRAY	analog_input_offset	INT32	rw

6.7.2.1 2400_h: analog_input_voltage

The object record **analog_input_voltage** returns the current input voltage in millivolt considering the offset voltage.

Index	2400_h
Name	analog_input_voltage
Object Code	ARRAY
No. of Elements	3
Data Type	INT16

Sub-Index	01_h
Description	analog_input_voltage_ch_0
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	--

Sub-Index	02_h
Description	analog_input_voltage_ch_1
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	--

Sub-Index	03_h
Description	analog_input_voltage_ch_2
Access	ro
PDO Mapping	no
Units	mV
Value Range	--
Default Value	--

6.7.2.2 Object 2401_h: analog_input_offset (Offset Analogeingänge)

The object record **analog_input_offset** can be used to determine an offset voltage in millivolt for the respective analogue input. A positive offset compensates a positive dc offset voltage.

Index	2401_h
Name	analog_input_offset
Object Code	ARRAY
No. of Elements	3
Data Type	INT32

Sub-Index	01_h
Description	analog_input_offset_ch_0
Access	rw
PDO Mapping	no
Units	mV
Value Range	-10000...10000
Default Value	0

Sub-Index	02_h
Description	analog_input_offset_ch_1
Access	rw
PDO Mapping	no
Units	mV
Value Range	-10000...10000
Default Value	0

Sub-Index	03_h
Description	analog_input_offset_ch_2
Access	rw
PDO Mapping	no
Units	mV
Value Range	-10000...10000
Default Value	0

Digital inputs and outputs

6.7.3 Survey

All digital inputs of the servo controller can be read and almost all digital outputs can be set or reset using the can bus.

6.7.4 Description of Objects

Index	Object	Name	Type	Attr.
60FD _h	VAR	digital_inputs	UINT32	ro
60FE _h	ARRAY	digital_outputs	UINT32	rw

6.7.4.1 Object 60FD_h: digital_inputs

Using object **60FD_h** the digital inputs can be read out:

Index	60FD_h
Name	digital_inputs
Object Code	VAR
Data Type	UINT32

Access	ro
PDO Mapping	yes
Units	--
Value Range	according table
Default Value	0

Bit	Value	Digital input
0	00000001 _h	Negative limit switch
1	00000002 _h	Positive limit switch
2	00000004 _h	Reference switch
3	00000008 _h	Interlock (either "controller enable" or "power stage enable" is missing)
16...23	00FF0000 _h	Additional inputs of an optional EA88-module (EA88-0)
24...27	0F000000 _h	DIN0...DIN3

28	10000000 _h	DIN8
29	20000000 _h	DIN9

6.7.4.2 Object 60FE_h: digital_outputs

The digital outputs can be set via the object **60FE_h**. For that purpose it has to be indicated which of the digital outputs are allowed to be set in the object **digital_outputs_mask**. Then the selected outputs can be set optionally via the object **digital_outputs_data**. It has to be kept in mind that a delay of up to 10 ms may occur between sending the command and a real reaction of the. The time the outputs are really set can be seen by rereading the object **60FE_h**.

Index	60FE_h
Name	digital_outputs
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01_h
Description	digital_outputs_data
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	0

Sub-Index	02_h
Description	digital_outputs_mask
Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	00FF0000 _h

Bit	Value	Digital Outputs
0	00000001 _h	Brake
16...23	00FF0000 _h	Additional digital Outputs of an optional EA88 module (EA88-0)
25...27	0E000000 _h	DOUT1...DOUT3

6.8 Homing switches (Limit / Reference switch)

6.8.1 Survey

For the definition of the reference (zero) position of the servo controller optional limit switches or reference switches can be used. Further information concerning reference methods can be found in chapter 8.2, Operating Mode »Homing mode«.

6.8.2 Description of Objects

Index	Object	Name	Type	Attr.
6510h	RECORD	drive_data		rw

6.8.2.1 Object 6510_h_11_h: limit_switch_polarity

The polarity of the limit switches can be parametrized by the object **6510_h_11_h** (**limit_switch_polarity**). For B-contacts (normally closed) zero has to be entered, for A-contacts (normally opened) one.

Index	6510_h
Name	drive_data
Object Code	RECORD
No. of Elements	44

Sub-Index	11_h
Description	limit_switch_polarity
Data Type	INT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0, 1
Default Value	1

Value	Description
0	B-contact (normally closed)
1	A-contact (normally opened)

6.8.2.2 Object 6510_h_14_h: homing_switch_polarity

The polarity of the homing switch can be parametrized by the object 6510_h_14_h (**homing_switch_polarity**). For B-contacts (normally closed) zero has to be entered, for A-contacts (normally opened) one.

Sub-Index	14 _h
Description	homing_switch_polarity
Data Type	INT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0, 1
Default Value	1

Value	Description
0	B-contact (normally closed)
1	A-contact (normally opened)

6.8.2.3 Object 6510_h_13_h: homing_switch_selector

The object 6510_h_13_h (**homing_switch_selector**) determines, whether DIN8 or DIN9 should be used as reference switch.

Sub-Index	13 _h
Description	homing_switch_selector
Data Type	INT16
Access	rw
PDO Mapping	no
Units	--
Value Range	0,1
Default Value	1

Value	Description
0	DIN8
1	DIN9

6.8.2.4 Object 6510_h_15_h: **limit_switch_deceleration**

The object **limit_switch_deceleration** determines the deceleration used to stop the motor if a limit switch will be reached during normal operation (limit switch emergency stop).

Sub-Index	15_h
Description	limit_switch_deceleration
Data Type	INT32
Access	rw
PDO Mapping	no
Units	acceleration units
Value Range	0...3000000 min ⁻¹ /s
Default Value	2000000 min ⁻¹ /s

6.9 Brake control

6.9.1 Survey

Using the following objects it can be determined how a possibly existing motor brake will be controlled by the servo controller. The brake will always be released if the controller is enabled, i.e. if the external and internal enable is present. For the use of brakes with a high inertia a delay time can be determined to ensure the brake is locked before the power stage switches off (Dropping of vertical axis). This delay time can be set via the object **brake_delay_time**. As can be seen in the following figure the velocity demand value will be delayed for the **brake_delay_time** after enabling the servo controller. Equally the deactivation of the power stage will be delayed when disabling the servo controller.




Figure 6.10: Function of brake delay (in Operating Mode Profile Velocity Mode and Operating Mode »Profile Position Mode«)

6.9.2 Description of Objects

Index	Object	Name	Type	Attr.
6510h	RECORD	drive_data		rw

6.9.2.1 Object 6510_h_18_h: brake_delay_time

With the object **brake_delay_time** the delay of the brake can be parametrized.

Index	6510_h
Name	drive_data
Object Code	RECORD
No. of Elements	44

Sub-Index	18_h
Description	brake_delay_time
Data Type	UINT16
Access	rw
PDO Mapping	no
Units	ms
Value Range	0...32000
Default Value	0

6.10 Device informations

Index	Object	Name	Type	Attr.
1018h	RECORD	identity_object		rw
6510h	RECORD	drive_data		rw

A huge number of CAN objects have been implemented to read out several device informations like type of servo controller, firmware revision and so on.

6.10.1 Description of Objects

6.10.1.1 Object 1018_h: identity_object

To identify the servo controller uniquely in a CANopen-network the **identity_object** according to the DS301 can be used.

A unique manufacturer code (**vendor_id**), a unique product code (**product_code**), the revision number of the CANopen implementation (**revision_number**) and the device serial number (**serial_number**) can be read.

Index	1018_h
Name	identity_object
Object Code	RECORD
No. of Elements	4

Sub-Index	01_h
Description	vendor_id
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	--
Value Range	000000E4
Default Value	000000E4

Sub-Index	02_h
Description	product_code
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	--
Value Range	s.u.
Default Value	s.u.

Value	Description
2005 _h	SE-POWER
2006 _h	SE-POWER
2009 _h	
200A _h	
200B _h	

Sub-Index	03_h
Description	revision_number
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	MMMMSSSS _h (M: main version, S: sub version)
Value Range	--
Default Value	--

Sub-Index	04_h
Description	serial_number
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

6.10.1.2 Object 6510_h_A0_h: drive_serial_number

With the object **drive_serial_number** the serial number of the servo controller can be read. This object is implemented because of terms of compatibility to older versions.

Index	6510_h
Name	drive_data
Object Code	RECORD
No. of Elements	44

Sub-Index	A0_h
Description	drive_serial_number
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	--
Value Range	--
Default Value	--

6.10.1.3 Object 6510_h_A1_h: drive_type

The object **drive_type** returns the type of servo controller. This object is implemented because of terms of compatibility to older versions.

Sub-Index	A1_h
Description	drive_type
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	
Value Range	see 1018 _h _02 _h , product_code
Default Value	see 1018 _h _02 _h , product_code

6.10.1.4 Object 6510_h_A9_h: firmware_main_version

The object **firmware_main_version** returns the main revision index of the firmware (product step).

Sub-Index	A9_h
Description	firmware_main_version
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	MMMMSSSS _h (M: main version, S: sub version)
Value Range	--
Default Value	--

6.10.1.5 Object 6510_h_AA_h: firmware_custom_version

The object **firmware_custom_version** returns the version number of the customer-specific variant of the firmware.

Sub-Index	AA_h
Description	firmware_custom_version
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	MMMMSSSS _h (M: main version, S: sub version)
Value Range	--
Default Value	--

6.10.1.6 Object 6510_h_AC_h: firmware_type

With the object **firmware_type** it can be determined for what type of device and encoder module the firmware is suitable. For the SE-POWER series the encoder interface can not be plugged anymore. Consequently the parameter G will always return F_h.

Sub-Index	AC_h
Description	firmware_type
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	000000GX _h
Value Range	00000F2 _h
Default Value	00000F2 _h

Value (X)	Description
0 _h	IMD-F
1 _h	SE-POWER
2 _h	SE-POWER

6.10.1.7 Object 6510_h_B0_h: **cycletime_current_controller**

The object **cycletime_current_controller** returns the period of the current control loop in microseconds.

Sub-Index	B0_h
Description	cycletime_current_controller
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	μs
Value Range	--
Default Value	--

6.10.1.8 Object 6510_h_B1_h: **cycletime_velocity_controller**

The object **cycletime_velocity_controller** returns the period of the velocity control loop in microseconds.

Sub-Index	B1_n
Description	cycletime_velocity_controller
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	µs
Value Range	--
Default Value	--

6.10.1.9 Object 6510_h_B2_h: **cycletime_position_controller**

The object **cycletime_position_controller** returns the period of the position control loop in microseconds.

Sub-Index	B2_h
Description	cycletime_position_controller
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	μs
Value Range	--
Default Value	000001A0 _h

6.10.1.10 Object 6510_h_B3_h: **cycletime_trajectory_generator**

The object **cycletime_trajectory_generator** returns the period of the positioning unit in microseconds.

Sub-Index	B3_h
Description	cycletime_tracectory_generator
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	μs
Value Range	--
Default Value	00000341 _h

6.10.1.11 Object 6510_h_C0_h: commissioning_state

The parametrization program Afag ServoCommander uses the object **commissioning_state** to mark what kind of parameters have already been adjusted. The default state of this object when delivered and after **restore_default_parameter** is zero. In this case the display of the servo controller shows an "A", to indicate that no suitable parametrization has been done. For a complete set-up via CANopen it is necessary to set at least one bit of this object to suppress the "A". Of course it is possible to use this object for own applications. In this case it has to be kept in mind that Afag ServoCommander uses this object, too.

Sub-Index	C0_h
Description	commissioning_state
Data Type	UINT32
Access	rw
PDO Mapping	no
Units	--
Value Range	--
Default Value	0

Bit	Description	Bit	Description
0	motor rated current valid	8	Current controller gain valid
1	max_current valid	9	Reserved
2	Number of poles valid	10	Conversion factors valid
3	encoder offset / direction valid	11	velocity controller valid
4	Reserved	12	position controller valid
5	hall encoder offset / direction valid	13	Safety parameter valid
6	Reserved	14	Reserved
7	Absolute position encoder valid	15	Polarity of home switch valid
		16...31	Reserved



Caution!

The object **commissioning_state** does not contain any information if the servo controller has been parametrised correctly according to the specific application. It will only be used to mark if the corresponding item has been parametrised at all.



"A" on 7 segment display

Note that at least one bit in the object **commissioning_state** has to be set, to suppress the "A" on the display of the servo controller.

7 Device Control

7.1 State diagram (State machine)

7.1.1 Survey

The following chapter describes how to control the servo controller using CANopen, i.e. how to switch on the power stage or to reset an error.

Using CANopen the complete control of the servo is done by two objects. Via the **controlword** the host is able to control the servo, as the status of the servo can be read out of the **statusword**. The following items will be used in this chapter:

- State:** The servo controller is in different states dependent on for instance if the power stage is alive or if an error has occurred. States defined under CANopen will be explained in this chapter.
Example: **SWITCH_ON_DISABLED**
- State Transition:** Just as the states it is defined as well how to move from one state to another (e.g. to reset an error). These state transitions will be either executed by the host by setting bits in the **controlword** or by the servo controller itself, if an error occurs for instance.
- Command:** To initiate a state transition defined bit combinations have to be set in the **controlword**. Such bit combination are called command.
Example: **Enable Operation**
- State diagram:** All the states and all state transitions together form the so called state diagram: A survey of all states and the possible transitions between two states.

7.1.2 The state diagram of the servo controller




Figure 7.11: State diagram of the servo controller

The state diagram can be divided into three main parts: "Power Disabled" means the power stage is switched off and "Power Enabled" the power stage is live. The area "Fault" contains all states necessary to handle errors of the controller.

The most important states have been highlighted in the Figure: After switching on the servo controller initialises itself and reaches the state **SWITCH_ON_DISABLED** after all. In this state CAN communication is possible and the servo controller can be parametrized (e.g. the mode of operation can be set to "velocity control"). The power stage remains switched off and the motor shaft is freely rotatable. Through the state transitions 2, 3 and 4 – principally like the controller enable under CANopen - the state **OPERATION_ENABLE** will be reached. In this state the power stage is live and the servo controller controls the motor according to the parametrized mode of operation. Therefore previously ensure that the servo controller has been parametrized correctly and the according demand value is zero.

The state transition 9 complies with disabling the power stage, i.e. the motor is freely rotatable.

In case of a fault the servo controller branches independent of the current state lately to the state **FAULT**. Dependent on the seriousness of the fault several actions can be executed before, for instance an emergency stop (**FAULT_REACTION_ACTIVE**).

To execute the mentioned state transitions defined bit combinations have to be set in the **controlword**. To that the lower 4 bits of the **controlword** will be evaluated commonly. At first only the important transitions 2, 3, 4, 9 and 15 will be explained. A table of all possible transitions can be found at the end of this chapter.

The following chart contains the desired state transition in the 1st column. The 2nd column contains the condition for the transition (mostly a command by the host, here marked with a frame). How the command has to be built, i.e. what bits have to be set in the controlword, will be shown in the 3rd column (x = not relevant).


No.	Executed if	Bit combination (controlword)				Action		
		Bit 3	2	1	0			
2	"Enable controller" + "Enable power stage" applying + Command Shutdown	Shutdown	=	x	1	1	0	None
3	Command Switch On	Switch On	=	x	1	1	1	Power stage will be switched on
4	Command Enable Operation	Enable Operation	=	1	1	1	1	Motor is controlled according to modes_of_operation
9	Command Disable Voltage	Disable Voltage	=	x	x	0	x	Power stage is disabled. The motor is freely rotatable
15	Cause of fault remedied + Command Fault Reset	Fault Reset	=	Bit 7 = 				Reset fault

Figure 7.12: Most important state transitions

EXAMPLE



After the servo controller has been parametrized it should be enabled, i.e. the power stage should be switched on:

- 1.) The servo is in the state **SWITCH_ON_DISABLED**.
- 2.) The state **OPERATION_ENABLE** should be reached.
- 3.) In accordance to the state diagram (Figure 7.11) the state transitions 2, 3 and 4 have to be executed.
- 4.) From Figure 7.12 follows:

Transition 2: controlword = 0006_h ^{*1)} New state: **READY_TO_SWITCH_ON**

Transition 3: controlword = 0007_h New state: **SWITCHED_ON** ^{*1)}

Transition 4: controlword = 000F_h New state: **OPERATION_ENABLE** ^{*1)}

Hints:

- 1.) The example implies, that no more bits in the **controlword** are set. (For the state transitions only the bits 0..3 are necessary).
- 2.) The state transitions 3 and 4 can be combined by setting the **controlword** to 000F_h directly. For the state transition 3 the set bit 3 is irrelevant.

^{*1)} The host has to wait until the requested state can be read in the **statusword**. This will be explained more exact in the following chapter.

7.1.2.1 State diagram: States

In the following table all states and their meaning are listed:


Name	Meaning
NOT_READY_TO_SWITCH_ON	The servo controller executes its selftest. The CAN communication is not working
SWITCH_ON_DISABLE	The selftest has been completed. The CAN communication is activated..
READY_TO_SWITCH_ON	The servo controller waits until the digital inputs "Enable controller" + "Enable power stage" are connected to 24V. (controller enable logic is set to "digital inputs and CAN")
SWITCHED_ON *1)	The power stage is alive.
OPERATION_ENABLE *1)	The motor is under voltage and is controlled according to operational mode
QUICKSTOP_ACTIVE *1)	The Quick Stop Function will be executed (see: quick_stop_option_code). The motor is under voltage and is controlled according to the Quick Stop Function .
FAULT_REACTION_ACTIVE *1)	An error has occurred. On critical errors switching to state Fault . Otherwise the action according to the fault_reaction_option_code will be executed. The motor is under voltage and is controlled according to the Fault Reaction Function .
FAULT	An error has occurred. The power stage has been switched off.

*1) The power stage is alive

7.1.2.2 State diagram: State transitions

The following table lists all state transitions and their meaning:

No.	Executed if	Bit combination (controlword)					Action	
		Bit	3	2	1	0		
0	"Power on" or Reset	internal transition					Execute selftest	
1	Self test successful	internal transition					Activation of the CAN communication	
2	"Enable controller" + "Enable power stage" applying + Command Shutdown	Shutdown	=	x	1	1	0	None
3	Command Switch On	Switch On	=	x	1	1	1	Power stage will be switched on
4	Command Enable Operation	Enable Operation	=	1	1	1	1	Motor is controlled according to operation mode
5	Command Disable Operation	Disable Operation	=	0	1	1	1	Power stage is disabled. Motor is freely rotatable
6	Command Shutdown	Shutdown	=	x	1	1	0	Power stage is disabled.

No.	Executed if	Bit combination (controlword)				Action	
		Bit 3	2	1	0		
						Motor is freely rotatable	
7	Command Quick Stop	Quick Stop	= x	0	1	x	
8	Command Shutdown	Shutdown	= x	1	1	0	Power stage is disabled. Motor is freely rotatable
9	Command Disable Voltage	Disable Voltage	= x	x	0	x	Power stage is disabled. Motor is freely rotatable
10	Command Disable Voltage	Disable Voltage	= x	x	0	x	Power stage is disabled. Motor is freely rotatable
11	Command Quick Stop	Quick Stop	= x	0	1	x	A braking according to quick_stop_option_code is started.
12	Braking has ended or Command Disable Voltage	Disable Voltage	= x	x	0	x	Power stage is disabled. Motor is freely rotatable
13	Error occurred	internal transition					On non-critical errors reaction according to fault_reaction_option_code . On critical error executing transition 14.
14	Error treating has ended	internal transition					Power stage is disabled. Motor is freely rotatable
15	Cause of fault remedied + Command Fault Reset	Fault Reset	=	Bit 7 = 			Reset fault (Rising edge)



Power stage disabled

This means the transistors are not driven anymore. **If this state is reached on a rotating motor, the motor coasts down without being braked.** If a mechanical motor brake is available it will be locked.



Caution: This does not ensure that the motor is not under voltage.



Power stage enabled

This means the motor will be controlled according to the chosen mode of operation. If a mechanical motor brake is available it will be released. A defect or an incorrect parameter set-up (Motor current, number of poles, resolver offset angle, etc.) may cause an uncontrolled behaviour of the motor.

7.1.3 controlword

7.1.3.1 Object 6040_h: controlword

Via the **controlword** the state of the servo controller can be changed or a designated action (e.g. starting homing operation) can be executed directly. The meaning of the bits 4, 5, 6 and 8 depends on the actual operation mode (**modes_of_operation**), which will be explained in the chapter hereafter.

Index	6040 _h
Name	controlword
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	--
Value Range	--
Default Value	0

Bit	Value	Function
0	0001 _h	Initiating state transitions. (Bits will be evaluated commonly)
1	0002 _h	
2	0004 _h	
3	0008 _h	
4	0010 _h	new_set_point / start_homing_operation / enable_ip_mode
5	0020 _h	change_set_immediatly
6	0040 _h	absolute / relative
7	0080 _h	reset_fault
8	0100 _h	halt
9	0200 _h	reserved set to 0
10	0400 _h	reserved set to 0
11	0800 _h	reserved set to 0
12	1000 _h	reserved set to 0
13	2000 _h	reserved set to 0
14	4000 _h	reserved set to 0
15	8000 _h	reserved set to 0

Table 7.1: Bit assignment of the controlword

As described detailed in the previous chapter the bits 0..3 are used to execute state transitions. The necessary commands are summarised in the following chart. The command **Fault Reset** will be executed on a rising edge of bit 7 (from 0 to 1).


command:	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0
	0080 _h	0008 _h	0004 _h	0002 _h	0001 _h
Shutdown	×	×	1	1	0
Switch On	×	×	1	1	1
Disable Voltage	×	×	×	0	×
Quick Stop	×	×	0	1	×
Disable Operation	×	0	1	1	1
Enable Operation	×	1	1	1	1
Fault Reset		×	×	×	×

Table 7.2: Survey of all commands (× = not relevant)



As some state transitions take time for processing, all changes written into the **controlword** have to read back from the **statusword**. Only when the requested status can be read in the **statusword**, one may write in further commands using the **controlword**.

Following the remaining bits of the **controlword** will be explained. The meaning of some bits depends on the actual operation mode (object **modes_of_operation**), i.e. if the controller will be torque or velocity controlled.

Bit 4	Depending on: modes_of_operation :
new_set_point	<p>On Profile Position Mode:</p> <p>A rising edge signals that a new position parameter set should be taken over. In any case see chapter 8.3 as well.</p>
start_homing_operation	<p>On Homing Mode:</p> <p>A rising edge starts the parametrized search for reference. A falling edge stops the search immediately.</p>
enable_ip_mode	<p>On Interpolated Position Mode:</p> <p>This bit has to be set to evaluate the interpolation data. It will be acknowledged by the bit ip_mode_active in the statusword. In any case see chapter 8.4 as well.</p>

Bit 5	change_set_immediatly	Only on Profile Position Mode : If this bit is cleared a current positioning order will be processed before starting a new one. If this bit is set a current positioning order will be interrupted by the new one. See also chapter 8.3.
Bit 6	relative	Only on Profile Position Mode : If this bit is set, the target_position of the current positioning job, will be added to the position_demand_value of the position controller.
Bit 7	reset_fault	On a rising edge the servo controller tries to reset the present errors. This will only succeed if the cause of error has been remedied.
Bit 8		Depending on modes_of_operation :
	halt	On Profile Position Mode : If this bit is set the current positioning will be cancelled according to the object profile_deceleration . After stopping the bit target_reached (statusword) will be set. Resetting this bit has no effect.
	halt	On Profile Velocity Mode : If this bit is set the velocity will be reduced to zero according to the profile_deceleration . Resetting this bit will accelerate the motor again.
	halt	On Profile Torque Mode : If this bit is set the torque will be reduced to zero according to the torque_slope . Resetting this bit will accelerate the motor again
	halt	On Homing mode : If this bit is set the current homing operation will be cancelled and a homing error will be generated. Resetting this bit has no effect.

7.1.4 Reading the status of the servo controller

Similar to initiating several commands by setting bits of the **controlword**, the state of the servo controller can be read by specific bit combinations in the **statusword**.

The following chart lists all states of the state diagram and their respective bit combination occurring in the **statusword**.

State	Bit 6	Bit 5	Bit 3	Bit 2	Bit 1	Bit 0	Mask	Value
	0040 _h	0020 _h	0008 _h	0004 _h	0002 _h	0001 _h		
NOT_READY_TO_SWITCH_ON	0	×	0	0	0	0	004F _h	0000 _h
SWITCH_ON_DISABLED	1	×	0	0	0	0	004F _h	0040 _h
READY_TO_SWITCH_ON	0	1	0	0	0	1	006F _h	0021 _h
SWITCHED_ON	0	1	0	0	1	1	006F _h	0023 _h
OPERATION_ENABLE	0	1	0	1	1	1	006F _h	0027 _h
FAULT	0	×	1	1	1	1	004F _h	000F _h
FAULT_REACTION_ACTIVE	0	×	1	1	1	1	004F _h	000F _h
QUICK_STOP_ACTIVE	0	0	0	1	1	1	006F _h	0007 _h

Table 7.3: States of device (× = not relevant)

EXAMPLE

The above mentioned example shows, what bits in the **controlword** have to be set to enable the servo controller. Now the requested state should be read out of the **statusword**:

Transition from **SWITCH_ON_DISABLED** to **OPERATION_ENABLE**:

- 1.) Write state transition 2 into the **controlword**.
- 2.) Wait until state **READY_TO_SWITCH_ON** occurs in the **statusword**.

Transition 2: **controlword** = Wait until (**statusword** & 006F_h) = 0021_h ^{*1)}
 0006_h

- 3.) The state transitions 3 and 4 can be written combined into the **controlword**.
- 4.) Wait, until the state **OPERATION_ENABLE** occurs in the **statusword**.

Transition 3+4: **controlword** = Wait until (**statusword** & 006F_h) = 0027_h ^{*1)}
 000F_h

Hint:

- 3.) The example implies, that no more bits in the **controlword** are set. (For the state transitions only the bits 0..3 are necessary).

^{*1)}To identify a state also cleared bits have to be evaluated (see table). Therefore the **statusword** has to be masked properly.



7.1.5 statusword

7.1.5.1 Object 6041_h: statusword

Index	6041 _h
Name	statusword
Object Code	VAR
Data Type	UINT16

Access	ro
PDO Mapping	yes
Units	--
Value Range	--
Default Value	--

Bit	Value	Name
0	0001 _h	State of the servo controller (see Table 7.3) (These bits have to be evaluated commonly)
1	0002 _h	
2	0004 _h	
3	0008 _h	
4	0010 _h	voltage_disabled
5	0020 _h	State of the servo controller (see Table 7.3)
6	0040 _h	
7	0080 _h	warning
8	0100 _h	unused
9	0200 _h	remote
10	0400 _h	target_reached
11	0800 _h	internal_limit_active
12	1000 _h	set_point_acknowledge / speed_0 / homing_attained / ip_mode_active
13	2000 _h	following_error / homing_error
14	4000 _h	unused
15	8000 _h	trigger_result

Table 7.4: Bit assignment of the statusword




All bits of the **statusword** are not buffered and therefore representing the actual state of the device.

In addition to the state of the device several informations can be read out directly of the **statusword**, i.e. every bit is assigned a specific event like a following error. The meaning of the bits is as follows:

Bit 4 voltage_disable

This bit is set if the transistors of the power stage switched off.



Bit 5 quick_stop

If this bit is cleared a **Quick Stop** will be executed according to the **quick_stop_option_code**.

Bit 7 warning

bit is undefined. It must not be evaluated.

Bit 8 manufacturer specific

bit is undefined. It must not be evaluated.

Bit 9 remote

This bit indicates that the power stage can be enabled via the can bus. It is set if the object **enable_logic** is set accordingly.

Bit 10

Depends on **modes_of_operation**:

target_reached

On **Profile Position Mode**:

This bit will be set if the actual position (**position_actual_value**) is within the parametrized position window (**position_window**).

It will also be set if the motor stops after setting the bit **halt** in the **controlword**.

It will be cleared if a new positioning is started.

target_reached

On **Profile Velocity Mode**:

The bit will be set if the actual velocity (**velocity_actual_value**) is within the parametrized velocity window (**velocity_window**, **velocity_window_time**).

Bit 11 internal_limit_active

bit indicates that the iit limitation is active.

Bit 12

Depends on **modes_of_operation**:

set_point_acknowledge	<p>On Profile Position Mode:</p> <p>This bit will be set to acknowledge the bit new_set_point in the controlword. It will be cleared if the bit new_set_point will be cleared. See chapter 8.3 as well.</p>
speed_0	<p>On Profile Velocity Mode:</p> <p>This bit will be set if the velocity_actual_value is within the window determined by the object velocity_threshold.</p>
homing_attained	<p>On Homing mode:</p> <p>This bit will be set if the homing operation has been finished without an error.</p>
ip_mode_active	<p>On Interpolated Position Mode:</p> <p>This bit signals an active interpolation, i.e. interpolation data is evaluated. It will be set if requested by the bit enable_ip_mode in the controlword. In any case see chapter 8.4 as well.</p>
Bit 13	Depends on modes_of_operation :
following_error	<p>On Profile Position Mode:</p> <p>This bit will be set if the position_actual_value differs from the position_demand_value so much that the difference is out of the tolerance window determined by the objects following_error_window and following_error_time_out.</p>
homing_error	<p>On Homing Mode:</p> <p>This bit will be set if a homing operation was cancelled by setting the bit halt in the controlword, if both limit switches are closed or the search for the switch exceeds the predefined positioning limits (min_position_limit, max_position_limit).</p>
Bit 14 unused	bit is unused at present. It must not be evaluated.
Bit 15 reserved	manufacturer specific
	bit is reserved for compatibility reasons. It must not be evaluated.

7.1.6 Description of Objects

7.1.6.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
605B _h	VAR	shutdown_option_code	INT16	rw
605C _h	VAR	disable_operation_option_code	INT16	rw
605A _h	VAR	quick_stop_option_code	INT16	rw
605E _h	VAR	fault_reaction_option_code	INT16	rw

7.1.6.2 Object 605B_h: shutdown_option_code

The object **shutdown_option_code** determines the behaviour if the state transition 8 (from **OPERATION ENABLE** to **READY TO SWITCH ON**) will be executed.

Index	605B_h
Name	shutdown_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	--
Value Range	0
Default Value	0

Value	Name
0	Power stage will be switched off. Motor is freely rotatable.

7.1.6.3 Object 605C_h: disable_operation_option_code

The object **disable_operation_option_code** determines the behaviour if the state transition 5 (from **OPERATION ENABLE** to **SWITCHED ON**) will be executed.

Index	605C_h
Name	disable_operation_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	--
Value Range	-1
Default Value	-1

Value	Name
-1	Slow down motor with quickstop_acceleration.

7.1.6.4 Object 605A_h: quick_stop_option_code

The object **quick_stop_option_code** determines the behaviour if a **Quick Stop** will be executed.

Index	605A_h
Name	quick_stop_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	--
Value Range	2
Default Value	2

Value	Description
2	Slow down motor with quickstop_acceleration.

7.1.6.5 Object 605E_n: fault_reaction_option_code

The object **fault_reaction_option_code** determines the behaviour on a fault. Because the reaction on errors depends on the type of error in the SE-POWER series, this object can not be parametrized. It always returns the value zero.

Index	605E _n
Name	fault_reaction_option_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	no
Units	--
Value Range	0
Default Value	0

8 Operating Modes

8.1 Adjustment of the Operating Mode

8.1.1 Survey

The servo controllers of the SE-POWER series are able to work in a lot of different operation modes. Only some of them are specified in detail in the CANopen specification:

- torque controlled operation
- speed controlled operation
- homing operation (search for reference)
- positioning operation
- interpolated position mode

8.1.2 Description of Objects

8.1.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6060 _h	VAR	modes_of_operation	INT8	wo
6061 _h	VAR	modes_of_operation_display	INT8	ro

8.1.2.2 Object 6060_h: modes_of_operation

The operating mode of the servo controller is determined by the object **modes_of_operation**.

Index	6060 _h
Name	modes_of_operation
Object Code	VAR
Data Type	INT8

Access	wo
PDO Mapping	yes
Units	--
Value Range	1, 3, 4, 6, 7
Default Value	--

Value	Operation mode
1	Profile Positioning Mode (position controller with positioning operation)
3	Profile Velocity Mode (speed controller with setpoint ramp)
4	Torque Profile Mode (torque controller with setpoint ramp)
6	Homing mode (homing operation)
7	Interpolated Position Mode



The current operating mode can only be read in the object **modes_of_operation_display**. As a change of the operating mode might require some time to process, one will have to wait until the new selected mode appears in the object **modes_of_operation_display**.

8.1.2.3 Object 6061_h: modes_of_operation_display

The current operating mode of the servo controller can be read in the object **modes_of_operation_display**.

Index	6061 _h
Name	modes_of_operation_display
Object Code	VAR
Data Type	INT8

Access	ro
PDO Mapping	yes
Units	--
Value Range	-1, 1, 3, 4, 6, 7
Default Value	3

Value	Operation mode
-1	Unknown operating mode under CANopen
1	Profile Positioning Mode (position controller with positioning operation)
3	Profile Velocity Mode (speed controller with setpoint ramp)
4	Torque Profile Mode (torque controller with setpoint ramp)
6	Homing mode (homing operation)
7	Interpolated Position Mode



The operating mode can only be set via the object **modes_of_operation**. As a change of the operating mode might require some time, one will have to wait until the new selected mode appears in the object **modes_of_operation_display**. During this period of time it could happen that invalid operating modes (-1) are displayed for a short time.

8.2 Operating Mode »Homing mode«

8.2.1 Survey

This chapter describes how the servo controller searches the start position (also called reference point or zero point). There are various methods to determine this position. Either the limit switches at the end of the positioning range can be used or a reference switch (zero point switch) within the possible range of motion. Among some methods the zero impulse of the used encoder (resolver, incremental encoder, etc.) can be included to achieve a state that can be reproduced as good as possible.




Figure 8.1: Homing Mode

The user can determine the velocity, acceleration, and the kind of homing operation. After the servo controller has found its reference the zero position can be moved to the desired point via the object `home_offset`.

There are two kinds of speed for the homing operation. The higher search speed (`speed_during_search_for_switch`) is used to find the limit switch respectively the reference switch. To determine the reference slope exactly a lower speed is used (`speed_during_search_for_zero`).



The movement to the zero position is in most cases not part of the homing operation. If all required values are known (i.e. if the zero position is already known by the servo controller), no physical motion will be executed.

8.2.2 Description of Objects

8.2.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attribute
607C _h	VAR	<code>home_offset</code>	INT32	rw
6098 _h	VAR	<code>homing_method</code>	INT8	rw
6099 _h	ARRAY	<code>homing_speeds</code>	UINT32	rw
609A _h	VAR	<code>homing_acceleration</code>	UINT32	rw

8.2.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	UINT16	7 Device control
6041 _h	VAR	statusword	UINT16	7 Device control

8.2.2.3 Object 607C_h: home_offset

The object **home_offset** determines the displacement of the zero position to the limit resp. reference switch position.




Figure 8.2: Home Offset

Index	607C_h
Name	home_offset
Object Code	VAR
Data Type	INT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	--
Default Value	0

8.2.2.4 Object 6098_h: homing_method

A number of different methods are available for a homing operation. The method that is necessary for the application can be selected via the object **homing_method**. There are four possible signals for the homing operation: The negative and positive limit switch, the reference switch and the (periodic) zero impulse of the angle encoder. Besides this the controller can refer to the negative or positive endstop without additional signal.

If a method has been determined via the object **homing_method** the following parameters are fixed by that:

- The signal for reference (neg./pos. limit switch, reference switch, neg. / pos. endstop)
- The direction and process of the homing operation
- The kind of evaluation of the zero impulse of the used angle encoder.

Index	6098_h
Name	homing_method
Object Code	VAR
Data Type	INT8

Access	rw
PDO Mapping	yes
Units	
Value Range	-18, -17, -2, -1, 1, 2, 7, 11, 17, 18, 23, 27, 32, 33, 34
Default Value	17

Value	Direction	Target	Reference point for Home position
-18	Positive	Endstop	Endstop
-17	Negative	Endstop	Endstop
-2	Positive	Endstop	Zero impulse
-1	Negative	Endstop	Zero impulse
1	Negative	Limit switch	Zero impulse
2	Positive	Limit switch	Zero impulse
7	Positive	Reference switch	Zero impulse
11	Negative	Reference switch	Zero impulse
17	Negative	Limit switch	Limit switch
18	Positive	Limit switch	Limit switch
23	Positive	Reference switch	Reference switch
27	Negative	Reference switch	Reference switch
32	Negative	Zero impulse	Zero impulse
33	Positive	Zero impulse	Zero impulse
34		No run	Actual position

The homing sequence of the respective methods is explained more detailed in the following.

8.2.2.5 Object 6099_h: homing_speeds

This object determines the speeds which are used during the homing operation.

Index	6099_h
Name	homing_speeds
Object Code	ARRAY
No. of Elements	2
Data Type	UINT32

Sub-Index	01_h
Description	speed_during_search_for_switch
Access	rw
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	100 min ⁻¹

Sub-Index	02_h
Description	speed_during_search_for_zero
Access	rw
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	10 min ⁻¹

8.2.2.6 Object 609A_h: homing_acceleration

The objects **homing_acceleration** determine the acceleration which is used for all acceleration and deceleration operations during the search for reference.

Index	609A_h
Name	homing_acceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	acceleration units
Value Range	--
Default Value	1000 min ⁻¹ / s

8.2.3 Homing sequences

The various homing sequences are pictured in the following figures. Die encircled number correspond to the number of the object **homing_method**.

8.2.3.1 Method 1: Negative limit switch using zero impulse evaluation

If this method is used the drive first moves relatively quick into the negative direction until it reaches the negative limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the first zero impulse of the angle encoder in positive direction from the limit switch.




Figure 8.3: Homing operation to the negative limit switch including evaluation of the zero impulse

8.2.3.2 Method 2: Positive limit switch using zero impulse evaluation

If this method is used the drive first moves relatively quick into the positive direction until it reaches the positive limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the first zero impulse of the angle encoder in negative direction from the limit switch.




Figure 8.4: Homing operation to the positive limit switch including evaluation of the zero impulse

8.2.3.3 Methods 7 and 11: Reference switch and zero impulse evaluation

These two methods use the reference switch which is only active over parts of the distance. These reference methods are particularly useful for round-axis applications where the reference switch is activated once per revolution. In case of method 7 the drive first moves into positive and in case of method 11 into negative direction. Depending on the direction of the motion the zero position refers to the first zero impulse in negative or positive direction from the reference switch. This can be seen in the two following diagrams.




Figure 8.5: Homing operation to the reference switch evaluating the zero impulse for a positive start motion



On homing to the reference switch the first reached limit switch is used to reverse the search direction. If thereupon the opposite limit switch is reached an error occurs.




Figure 8.6: Homing operation to the reference switch evaluating the zero impulse for a negative start motion

8.2.3.4 Method 17: Homing operation to the negative limit switch

If this method is used the drive first moves relatively quick into the negative direction until it reaches the negative limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the descending edge from the negative limit switch.




Figure 8.7: Homing operation to the negative limit switch

8.2.3.5 Method 18: Homing operation to the positive limit switch

If this method is used the drive first moves relatively quick into the positive direction until it reaches the positive limit switch. This is displayed in the diagram by the rising edge. Afterwards the drive slowly returns and searches for the exact position of the limit switch. The zero position refers to the descending edge from the positive limit switch.




Figure 8.8: Homing operation to the positive limit switch

8.2.3.6 Methods 23 and 27: Homing operation to the reference switch

These two methods use the reference switch which only is active over part of the distance. These reference methods are particularly useful for round-axis applications where the reference switch is activated once per revolution.

In case of method 23 the drive first moves into positive and in case of method 27 into negative direction. The zero position refers to the edge from the reference switch. This can be seen in the two following diagrams.




Figure 8.9: Homing operation to the reference switch for a positive start motion



On homing to the reference switch the first reached limit switch is used to reverse the search direction. If thereupon the opposite limit switch is reached an error occurs.




Figure 8.10: Homing operation to the reference switch for a negative start motion

8.2.3.7 Method -1: Negative stop evaluating the zero impulse

If this method is used the drive moves into negative direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the parametrized maximum current. The zero position refers to the first zero impulse of the angle encoder in positive direction from the stop.




Figure 8.11: Homing operation to the negative stop evaluating the zero impulse

8.2.3.8 Method -2: Positive stop evaluating the zero impulse

If this method is used the drive moves into positive direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the parametrized maximum current. The zero position refers to the first zero impulse of the angle encoder in negative direction from the stop.




Figure 8.12: Homing operation to the positive stop evaluating the zero impulse

8.2.3.9 Method -17: Homing operation to the negative stop

If this method is used the drive moves into negative direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the parametrized maximum current. The zero position refers directly to the endstop.




Figure 8.13: Homing operation to the negative stop

8.2.3.10 Method -18: Homing operation to the positive stop

If this method is used the drive moves into positive direction until it reaches the stop. The I^2t integral of the motor reaches a maximum value of 90%. The stop has to be mechanically dimensioned so that it is not damaged in case of the parametrized maximum current. The zero position refers directly to the endstop.




Figure 8.14: Homing operation to the positive stop

8.2.3.11 Methods 32 and 33: Homing operation to the zero impulse

For the methods 32 and 33 the direction of the homing operation is negative and positive, respectively. The zero position refers to the first zero impulse from the angle encoder in search direction.




Figure 8.15: Homing operation only referring to the zero impulse

8.2.3.12 Method 34: Homing operation to the current position

On method 34 the zero position is referred to the current position.

8.2.4 Control of the homing operation

The homing operation is started by setting bit 4 in the **controlword**. The successful end of a homing operation is indicated by a set bit 12 in the object

statusword. A set bit 13 in the object **statusword** indicates that an error has occurred during the homing operation. The error reason can be identified by the objects **error_register** and **predefined_error_field**.

Bit 4	Description
0	Homing operation is not active
0 → 1	Start homing operation
1	Homing operation is active
1 → 0	Interrupt homing operation

Table 8.1: Description of the bits in the controlword

Bit 13	Bit 12	Description
0	0	Homing operation has not yet finished
0	1	Homing operation executed successfully
1	0	Homing operation not executed successfully
1	1	Illegal state

Table 8.2: Description of the bits in the statusword

8.3 Operating Mode »Profile Position Mode«

8.3.1 Survey

The structure of this operating mode is shown in Figure 8.16:

The target position (**target_position**) is passed to the trajectory generator. This generator generates a desired position value (**position_demand_value**) for the position controller that is described in the chapter **Position Controller** (position control function, chapter 6.6). These two function blocks can be adjusted independently from each other.




Figure 8.16: Trajectory generator and position controller

All input quantities of the trajectory generator are converted into internal quantities of the controller by means of the quantities of the **Factor group** (see chapter 6.2: Conversion factors (Factor Group)). The internal quantities are marked by an asterisk and are not imperatively needed by the user.




Figure 8.17: The trajectory generator

8.3.2 Description of Objects

8.3.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
607A _h	VAR	target_position	INT32	rw
6081 _h	VAR	profile_velocity	UINT32	rw
6082 _h	VAR	end_velocity	UINT32	rw
6083 _h	VAR	profile_acceleration	UINT32	rw
6084 _h	VAR	profile_deceleration	UINT32	rw
6085 _h	VAR	quick_stop_deceleration	UINT32	rw
6086 _h	VAR	motion_profile_type	INT16	rw

8.3.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040h	VAR	controlword	INT16	6.9 Device control
6041h	VAR	statusword	UINT16	6.9 Device control
605Ah	VAR	quick_stop_option_code	INT16	6.9 Device control
607Eh	VAR	polarity	UINT8	6.2 Conversion factors (Factor Group)
6093h	ARRAY	position_factor	UINT32	6.2 Conversion factors (Factor Group)
6094h	ARRAY	velocity_encoder_factor	UINT32	6.2 Conversion factors (Factor Group)
6097h	ARRAY	acceleration_factor	UINT32	6.2 Conversion factors (Factor Group)

8.3.2.3 Object 607A_h: target_position

Das Object **target_position** (Zielposition) bestimmt, an welche Position der AntriebsThe object **target_position** determines the destination the servo controller moves to. For this purpose the current adjustments of the velocity, of the acceleration, of the deceleration and the kind of motion profile (**motion_profile_type**) have to be considered. The target position (**target_position**) is interpreted either as an absolute or relative position. This depends on bit 6 (**relative**) of the object **controlword**.

Index	607A_h
Name	target_position
Object Code	VAR
Data Type	INT32

Access	rw
PDO Mapping	yes
Units	position units
Value Range	--
Default Value	0

8.3.2.4 Object 6081_h: profile_velocity

The object **profile_velocity** specifies the speed that usually is reached during a positioning motion at the end of the acceleration ramp. The object **profile_velocity** is specified in **speed_units**.

Index	6081 _h
Name	profile_velocity
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	position_units
Value Range	--
Default Value	0

8.3.2.5 Object 6082_h: end_velocity

The object **end_velocity** defines the speed at the target position (**target_position**). Usually this object has to be set to zero so that the controller stops when it reaches the target position. For gapless sequences of positionings a value unequal zero can be set. The object **end_velocity** is specified in **speed_units** like the object **profile_velocity**.

Index	6082 _h
Name	end_velocity
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	0

8.3.2.6 Object 6083_h: profile_acceleration

The object **profile_acceleration** determines the maximum acceleration used during a positioning motion. It is specified in user specific acceleration units (**acceleration_units**). (see 6.2 Conversion factors (Factor Group)).

Index	6083 _h
Name	profile_acceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	acceleration units
Value Range	--
Default Value	10000 min ⁻¹ /s

8.3.2.7 Object 6084_h: profile_deceleration

The object **profile_deceleration** specifies the maximum deceleration used during a positioning motion. This object is specified in the same units as the object **profile_acceleration**. (see chapter 6.2 Conversion factors (Factor Group)).

Index	6084 _h
Name	profile_deceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	10000 min ⁻¹ /s

8.3.2.8 Object 6085_h: quick_stop_deceleration

The object **quick_stop_deceleration** determines the deceleration if a Quick Stop will be executed (see chapter 7.1.2.2) The object **quick_stop_deceleration** is specified in the units as the object **profile_deceleration**.

Index	6085 _h
Name	quick_stop_deceleration
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	acceleration units
Value Range	--
Default Value	14100 min ⁻¹ /s

8.3.2.9 Object 6086_h: motion_profile_type

The object **motion_profile_type** is used to select the kind of positioning profile. At present only a linear profile is available.

Index	6086 _h
Name	motion_profile_type
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	--
Value Range	0
Default Value	0

Value	Profile
0	Linear ramp

8.3.3 Functional Description

Two different ways to apply target positions to the servo controller are supported.

Single setpoints

After reaching the **target_position** the servo controller signals this status to the host by the bit **target_reached** (Bit 10 of **controlword**) and then receives a new setpoint. The servo controller stops at the **target_position** before starting a move to the next setpoint.

Set of setpoints

After reaching the **target_position** the servo controller immediately processes the next **target_position** which results in a move where the velocity of the drive normally is not reduced to zero after reaching a setpoint.

These two methods are controlled by the bits **new_set_point** and **change_set_immediately** in the object **controlword** and **set_point_acknowledge** in the object **statusword**. These bits are in a request-response relationship. So it is possible to prepare one positioning job while another job is still running.




Figure 8.18: Positioning job transfer from a host

Figure 8.18 shows the communication between the host and the servo controller via the CAN bus:

At first the positioning data (**target_position**, **profile_velocity**, **end_velocity** and **profile_acceleration**) are transferred to the servo controller. After the positioning data set has been transferred completely (1) the host can start the positioning motion by setting the bit **new_set_point** in the **controlword** (2). This will be acknowledged by the servo controller by setting the bit **set_point_acknowledge** in the **statusword** (3), when the positioning data has been copied into the internal buffer.

Afterwards the host can start to transfer a new positioning data set into the servo controller (4) and clear the bit **new_set_point** (5). The servo controller signals by a cleared **set_point_acknowledge** bit that it can accept a new drive job (6). The host has to wait for the falling edge of the bit **set_point_acknowledge** before a new positioning motion can be started (7).

In Figure 8.19 a new positioning motion is started after the previous one has been finished completely. For that purpose the host evaluates the bit **target_reached** in the object **statusword**.




Figure 8.19: Simple positioning job

In Figure 8.20 a new positioning motion has already been started while the previous motion was still running. The host already transfers the subsequent target to the servo controller if it signals by a cleared **setpoint_acknowledge** bit that it has read the buffer and started the corresponding positioning motion. In this way the positioning motions are joined together gaplessly. For this operating mode the object **end_velocity** of the first job should be parametrized to the same value as the object **profile_velocity** of the following job so that the servo controller does not decelerate to zero amongst the single positioning motions.




Figure 8.20: Gapless sequence of positioning jobs

If beside the bit **new_setpoint** the bit **change_set_immediately** is set in the **controlword**, too, the new positioning job will interrupt the actual job immediately and will be started instead. The actual positioning job is canceled in this case.

8.4 Interpolated Position Mode

8.4.1 Survey

The interpolated position mode (IP) allows cyclic sending of position demand values to the servo in a multi-axe system. Therefore the host sends synchronisation telegrams (SNYC) and position demand values in a fixed interval (synchronisation interval). The servo controller itself interpolates between two setpoints, if the synchronisation interval is larger than the position control interval as shown in the following figure:




Figure 8.21: Linear interpolation between two positions

In the following the objects of the **interpolated position mode** will be described first. After it a functional description will explain the activation and the order of parameterisation detailed.

8.4.2 Description of Objects

8.4.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
60C0 _h	VAR	interpolation_submode_select	INT16	rw
60C1 _h	REC	interpolation_data_record		rw
60C2 _h	REC	interpolation_time_period		rw
60C3 _h	VAR	interpolation_sync_definition	UINT8	rw
60C4 _h	REC	interpolation_data_configuration		rw

8.4.2.2 Affected objects of other chapters

Index	Object	Name	Type	Chapter
6040h	VAR	controlword	INT16	7 Device control
6041h	VAR	statusword	UINT16	7 Device control
6093h	ARRAY	position_factor	UINT32	6.2 Conversion factors (Factor Group)
6094h	ARRAY	velocity_encoder_factor	UINT32	6.2 Conversion factors (Factor Group)
6097h	ARRAY	acceleration_factor	UINT32	6.2 Conversion factors (Factor Group)

8.4.2.3 Object 60C0_h: interpolation_submode_select

The object **interpolation_submode_select** determines the type of interpolation. At present only the manufacturer specific type „Linear interpolation without buffer“ is available.

Index	60C0_h
Name	interpolation_submode_select
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	--
Value Range	-2
Default Value	-2

Value	Type of interpolation
-2	Linear interpolation without buffer

8.4.2.4 Object 60C1_h: interpolation_data_record

The object record **interpolation_data_record** represents the interpolation data itself. It contains the position demand value (**ip_data_position**) and a controlword (**ip_data_controlword**), that determines whether the position value is relative or absolute. The use of the controlword is optional. If it should be used it is necessary to write subindex 2 first (**ip_data_controlword**) followed by subindex 1 (**ip_data_position**) to achieve data consistence, because the position will be copied by a write access to **ip_data_position**.

Index	60C1_h
Name	interpolation_data_record
Object Code	RECORD
No. of Elements	2

Sub-Index	01_h
Description	ip_data_position
Data Type	INT32
Access	rw
PDO Mapping	yes
Units	position units
Value Range	--
Default Value	--

Sub-Index	02_h
Description	ip_data_controlword
Data Type	UINT8
Access	rw
PDO Mapping	yes
Units	--
Value Range	0, 1
Default Value	0

Value	ip_data_position is
0	Absolute position
1	Relative distance



The data will be copied on a write access to subindex 1. If also subindex 2 should be used it is necessary to write subindex 2 first followed by subindex 1 .

8.4.2.5 Object 60C2_h: interpolation_time_period

Using the object record **interpolation_time_period** the synchronisation interval can be determined. First the unit (ms oder 1/10 ms) can be set by the object **ip_time_index**. After that the interval can be written to **ip_time_units**.

For the synchronisation the complete controller loops (Current-, velocity- and position controller) will be synchronised to the external clock. Therefore the change of the interval will only take effect after a reset. If the synchronisation interval should be changed via CAN bus, it is necessary to save the parameter set first (see chapter 6.1), and reset the device after that (see chapter 5.6). The external clock has to have a high precision.

Index	60C2_h
Name	interpolation_time_period
Object Code	RECORD
No. of Elements	2

Sub-Index	01_h
Description	ip_time_units
Data Type	UINT8
Access	rw
PDO Mapping	yes
Units	according to ip_time_index
Value Range	ip_time_index = -3: 1, 2,..., 9, 10 ip_time_index = -4: 10, 20,..., 90, 100
Default Value	--

Sub-Index	02_h
Description	ip_time_index
Data Type	INT8
Access	rw
PDO Mapping	yes
Units	--
Value Range	-3, -4
Default Value	-3

Value	ip_time_units will be written in
-3	10 ⁻³ seconds (ms)
-4	10 ⁻⁴ seconds (0.1 ms)



The change of the synchronisation interval will only take effect after a reset. If the interval should be changed via CAN bus, it is necessary to save the parameter set first and reset the device after that.

8.4.2.6 Object 60C3_h: interpolation_sync_definition

The object **interpolation_sync_definition** determines the kind of synchronisation (**synchronize_on_group**) and the number (**ip_sync_every_n_event**) of synchronisations messages (SYNC) per synchronisation interval. For the SE-POWER series only the standard SYNC telegram and 1 SYNC per interval can be set.

Index	60C3_h
Name	interpolation_sync_definition
Object Code	ARRAY
No. of Elements	2
Data Type	UINT8

Sub-Index	01_h
Description	synchronize_on_group
Access	rw
PDO Mapping	yes
Units	--
Value Range	0
Default Value	0

Value	Description
0	Use standard SYNC telegramm

Sub-Index	02_h
Description	ip_sync_every_n_event
Access	rw
PDO Mapping	yes
Units	--
Value Range	1
Default Value	1

8.4.2.7 Object 60C4_h: interpolation_data_configuration

By the object record **interpolation_data_configuration** the kind (**buffer_organisation**) and size (**max_buffer_size**, **actual_buffer_size**) of a possibly available buffer can be set. Additionally the access can be controlled by the objects **buffer_position** and **buffer_clear**. The object **size_of_data_record** returns the size of one buffer item. Even though no buffer is available for the interpolation type „linear interpolation without buffer“, the access has to be enabled using the object **buffer_clear**.

Index	60C4_h
Name	interpolation_data_configuration
Object Code	RECORD
No. of Elements	6

Sub-Index	01_h
Description	max_buffer_size
Data Type	UINT32
Access	ro
PDO Mapping	no
Units	--
Value Range	0
Default Value	0

Sub-Index	02_h
Description	actual_size
Data Type	UINT32
Access	rw
PDO Mapping	yes
Units	--
Value Range	0...max_buffer_size
Default Value	0

Sub-Index	03_h
Description	buffer_organisation
Data Type	UINT8
Access	rw
PDO Mapping	yes
Units	--
Value Range	0
Default Value	0

Value	Description
0	FIFO

Sub-Index	04_h
Description	buffer_position
Data Type	UINT16
Access	rw
PDO Mapping	yes
Units	--
Value Range	0
Default Value	0

Sub-Index	05_h
Description	size_of_data_record
Data Type	UINT8
Access	wo
PDO Mapping	yes
Units	--
Value Range	2
Default Value	2

Sub-Index	06_h
Description	buffer_clear
Data Type	UINT8
Access	wo
PDO Mapping	yes
Units	--
Value Range	0, 1
Default Value	0

Value	Description
0	Clear buffer / Access to 60C1 _h disabled
1	Access to 60C1 _h enabled

8.4.3 Functional Description

8.4.3.1 Preliminary parameterisation

Before the **interpolated position mode** can be entered, several settings have to be done: The interpolation interval (**interpolation_time_period**), i.e the time between two SYNC messages, the kind of interpolation (**interpolation_submode_select**) and the kind of synchronisation (**interpolation_sync_definition**) have to be set. Additionally the access to the position buffer has to be enabled by the object **buffer_clear** .

EXAMPLE



Task		CAN object / COB	
Interpolation type	-2	60C0h, interpolation_submode_select	= -2
Time unit	0.1 ms	60C2h_02h, interpolation_time_index	= -04
Time interval	4 ms	60C2h_01h, interpolation_time_units	= 40
Save parameter set		1010h_01h, save_all_parameters	
Execute reset		NMT reset node	
Wait for bootup		Bootup message	
Enable buffer	1	60C4h_06h, buffer_clear	= 1
Create SYNCs		SYNC (every 4 ms)	

8.4.3.2 Activation of the Interpolated Position Mode and first synchronisation

The **IP** will be activated by the object **modes_of_operation (6060_h)**. From this point in time the controller tries to synchronise to the external clock given by the SYNC telegrams. On success the **interpolated position mode** will be displayed in the object **modes_of_operation_display (6061_h)**. During the first synchronisation period „**unknown mode**“ (-1) will be returned as well as if the synchronisation is lost because of an invalid interval for example.

If the **interpolated position mode** is reached the transmission of position data can be started. For logical reasons the host first reads the position actual value of the servo controller and transmits it cyclically as demand value (**interpolation_data_record**). After that the acceptance of the data can be enabled by handshake bits of the **controlword** and the **statusword**. By setting the bit **enable_ip_mode** in the **controlword** the host signals that the position data should be evaluated. The position data will not be processed until the servo controller acknowledges that with setting bit **ip_mode_selected** in the **statusword**.

This results in the following sequence:




Figure 8.22: First synchronisation und data processing

No.	Event	CAN object
1	Create SYNC messages	
2	Request the operation mode „IP“	6060 _h , modes_of_operation = 07
3	Wait for the operation mode	6061 _h , modes_of_operation_display = 07
4	Read actual position	6064 _h , position_actual_value
5	Rewrite it as demand value	60C1 _h _01 _h , ip_data_position
6	Start interpolation	6040 _h , controlword, enable_ip_mode
7	Wait for acknowledge	6041 _h , statusword, ip_mode_active
8	Change position setpoints according to the desired trajectory	60C1 _h _01 _h , ip_data_position

To prevent the further evaluation of position data the bit **enable_ip_mode** can be cleared and the operation mode can be changed after that.

8.4.3.3 Interruption of interpolation in case of an error.

If a currently running interpolation (**ip_mode_active** set) will be interrupted by the occurrence of an error, the servo controller reacts as specified for the certain error (i.e. disabling the controller and changing to the state **SWICHTH_ON_DISABLED**).

The interpolation can only be restarted by a re-synchronization, because the state **OPERATION_ENABLE** has to be entered again, whereby the bit **ip_mode_active** will be cleared.


8.5 Profile Velocity Mode

8.5.1 Survey

The profile velocity mode includes the following subfunctions:

- Setpoint generation by the ramp generator
- Speed recording via the angle encoder by differentiation
- Speed control with suitable input and output signals
- Limitation of the desired torque value (**torque_demand_value**)
- Control of the actual speed (**velocity_actual_value**) with the window-function/threshold

The meaning of the following parameters is described in the chapter Profile Position Mode: **profile_acceleration**, **profile_deceleration**, **quick_stop**






Figure 8.23: Structure of the Profile Velocity Mode

8.5.2 Description of Objects

8.5.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6069 _h	VAR	velocity_sensor_actual_value	INT32	ro
606A _h	VAR	sensor_selection_code	INT16	rw
606B _h	VAR	velocity_demand_value	INT32	ro
606C _h	VAR	velocity_actual_value	INT32	ro
606D _h	VAR	velocity_window	UINT16	rw
606E _h	VAR	velocity_window_time	UINT16	rw
606F _h	VAR	velocity_treshold	UINT16	rw
6080 _h	VAR	max_motor_speed	UINT32	rw
60FF _h	VAR	target_velocity	INT32	rw

8.5.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	INT16	7. Device control
6041 _h	VAR	statusword	UINT16	7. Device control
6063 _h	VAR	position_actual_value*	INT32	6.6 Position Control Function
6069 _h	VAR	velocity_sensor_actual_value	INT32	6.6 Position Control Function
6071 _h	VAR	target_torque	INT16	8.6 Profile Torque Mode
6072 _h	VAR	max_torque_value	UINT16	8.6 Profile Torque Mode
607E _h	VAR	polarity	UINT8	6.2 Conversion factors (Factor Group)
6083 _h	VAR	profile_acceleration	UINT32	8.3 Operating Mode »Profile Position Mode«
6084 _h	VAR	profile_deceleration	UINT32	8.3 Operating Mode »Profile Position Mode«
6085 _h	VAR	quick_stop_deceleration	UINT32	8.3 Operating Mode »Profile Position Mode«
6086 _h	VAR	motion_profile_type	INT16	8.3 Operating Mode »Profile Position Mode«
6094 _h	ARRAY	velocity_encoder_factor	UINT32	6.2 Conversion factors (Factor Group)

8.5.2.3 Object 6069_h: velocity_sensor_actual_value

The speed encoder is read via the object **velocity_sensor_actual_value**. The value is normalised in internal units. As no external speed encoder can be connected to servo controllers of the SE-POWER device family, the actual velocity value always has to be read via the object **606C_h**.

Index	6069_h
Name	velocity_sensor_actual_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	R / 4096 min
Value Range	--
Default Value	--

8.5.2.4 Object 606A_h: sensor_selection_code

The speed sensor can be selected by this object. Currently no separate speed sensor will be provided by the servo controller. Therefore only the default angle encoder can be selected.

Index	606A_h
Name	sensor_selection_code
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	--
Value Range	0
Default Value	0

8.5.2.5 Object 606B_h: velocity_demand_value

The velocity demand value can be read via this object. It will be influenced by the ramp generator and the trajectory generator respectively. Besides this the correction speed of the position controller is added if it is activated.

Index	606B_h
Name	velocity_demand_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	--

8.5.2.6 velocity_actual_value

The actual velocity value can be read via the object **velocity_actual_value**.

Index	606C_h
Name	velocity_actual_value
Object Code	VAR
Data Type	INT32

Access	ro
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	--

8.5.2.7 Object 606D_h: velocity_window

With the object **velocity_window** a tolerance window for the velocity actual value will be defined for comparing the **velocity_actual_value** with the target velocity (**target_velocity** object 60FF_h). If the difference is smaller than the velocity window for a longer time than specified by the object **velocity_window_time** bit 10 (**target_reached**) will be set in the object **statusword**.

See also: Object 606E_h (**velocity_window_time**).

Index	606D _h
Name	velocity_window
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	0...65536 min ⁻¹
Default Value	4 min ⁻¹

8.5.2.8 Object 606E_h: velocity_window_time

The object **velocity_window_time** serves besides the object 606D_h: **velocity_window** to adjust the window comparator. It compares the **velocity_actual_value** with the **target_velocity** (object 60FF_h). If the difference is smaller than specified by **velocity_window** for a longer time than specified by the object **velocity_window_time** bit 10 (**target_reached**) will be set in the object **statusword**.

Index	606E _h
Name	velocity_window_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...4999
Default Value	0

8.5.2.9 Object 606F_h: velocity_threshold

The object **velocity_threshold** determines the velocity underneath the axis is regarded as stationary. As soon as the **velocity_actual_value** exceeds the **velocity_threshold** longer than the **velocity_threshold_time** bit 12 is cleared in the **statusword**.

Index	606F_h
Name	velocity_threshold
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	0...65536 min ⁻¹
Default Value	10

8.5.2.10 Object 6070_h: velocity_threshold_time

The object **velocity_threshold** determines the velocity below the axis is regarded as stationary. As soon as the **velocity_actual_value** exceeds the **velocity_threshold** longer than the **velocity_threshold_time** bit 12 is cleared in the **statusword**.

Index	6070_h
Name	velocity_threshold_time
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	ms
Value Range	0...4999
Default Value	0

8.5.2.11 Object 6080_h: max_motor_speed

The object **max_motor_speed** specifies the maximum permissible speed for the motor in rpm. The object is used to protect the motor and can be taken from the motor specifications. The velocity set point value is limited to the value of the object **max_motor_speed**.

Index	6080 _h
Name	max_motor_speed
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	min ⁻¹
Value Range	0... 32768 min ⁻¹
Default Value	32768 min ⁻¹

8.5.2.12 Object 60FF_h: target_velocity

The object **target_velocity** is the setpoint for the ramp generator.

Index	60FF _h
Name	target_velocity
Object Code	VAR
Data Type	INT32

Access	rw
PDO Mapping	yes
Units	speed units
Value Range	--
Default Value	--

8.6 Profile Torque Mode

8.6.1 Survey

This chapter describes the torque controlled operation. This operating mode offers the chance to demand an external torque value (**target_torque**) which can be smoothed by the integrated ramp generator. So it is also possible to use this servo controller for trajectory control functions where both position controller and speed controller are dislocated to an external computer.




Figure 8.24: Structure of the Profile Torque Mode

The parameters **torque_slope** and **torque_profile_type** (ramp form) have to be specified for the ramp generator. If bit 8 **halt** is set in the **controlword** the ramp generator reduces the torque down to zero. Correspondingly it raises it again to the **target_torque** if bit 8 is cleared. In both cases this will be done under consideration of the ramp generator. All definitions within this document refer to rotatable motors. If linear motors are used all "torque"-objects correspond to "force" instead. For reasons of simplicity the objects do not exist twice and their names should not be modified.

The operating modes Profile Position Mode and Profile Velocity Mode need the torque controller to work properly. Therefore it is always necessary to parametrize the torque controller.

8.6.2 Description of Objects

8.6.2.1 Objects treated in this chapter

Index	Object	Name	Type	Attr.
6071 _h	VAR	target_torque	INT16	rw
6072 _h	VAR	max_torque	UINT16	rw
6074 _h	VAR	torque_demand_value	INT16	ro
6076 _h	VAR	motorRatedTorque	UINT32	rw
6077 _h	VAR	torque_actual_value	INT16	ro
6078 _h	VAR	current_actual_value	INT16	ro
6079 _h	VAR	DC_link_circuit_voltage	UINT32	ro
6087 _h	VAR	torque_slope	UINT32	rw
6088 _h	VAR	torque_profile_type	INT16	rw
60F7 _h	RECORD	power_stage_parameters		rw
60F6 _h	RECORD	torque_control_parameters		rw

8.6.2.2 Affected objects from other chapters

Index	Object	Name	Type	Chapter
6040 _h	VAR	controlword	INT16	6.9 Device control
60F9 _h	RECORD	motor_parameters		6.4 Current control and motor adaptation
6075 _h	VAR	motorRatedCurrent	UINT32	6.4 Current control and motor adaptation
6073 _h	VAR	max_current	UINT16	6.4 Current control and motor adaptation

8.6.2.3 Object 6071_h: target_torque

This parameter is the input value for the torque controller in Profile Torque Mode. It is specified as thousandths of the nominal torque (object 6076_h).

Index	6071_h
Name	target_torque
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	motorRatedTorque / 1000
Value Range	-32768...32768
Default Value	0

8.6.2.4 Object 6072_h: max_torque

This value is the maximum permissible value of the motor. It is specified as thousandths of **motorRatedTorque** (object 6076_h). If for example a double

overload of the motor is permissible for a short while the value 2000 has to be entered.



The Object **6072_h: max_torque** corresponds with object **6073_h: max_current**. You are only allowed to write to one of these objects, once the object **6075_h: motorRatedCurrent** has been parametrized with a valid value.

Index	6072_h
Name	max_torque
Object Code	VAR
Data Type	UINT16

Access	rw
PDO Mapping	yes
Units	motorRatedTorque / 1000
Value Range	1000...65536
Default Value	2023

8.6.2.5 Object 6074_h: torqueDemandValue

The current demand torque can be read in thousandths of **motorRatedTorque** (**6076_h**) via this object. The internal limitations of the servo controller will be considered (current limit values and I²t control).

Index	6074_h
Name	torqueDemandValue
Object Code	VAR
Data Type	INT16

Access	ro
PDO Mapping	yes
Units	motorRatedTorque / 1000
Value Range	--
Default Value	--

8.6.2.6 Object 6076_h: motorRatedTorque

This object specifies the nominal torque of the motor. This value can be taken from the motor plate. It has to be entered by the unit 0.001 Nm.

Index	6076_h
Name	motorRatedTorque
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	0.001 Nm
Value Range	--
Default Value	296

8.6.2.7 Object 6077_h: torque_actual_value

The actual torque value of the motor can be read via this object in thousandths of the nominal torque (object 6076_h).

Index	6077_h
Name	torque_actual_value
Object Code	VAR
Data Type	INT16

Access	ro
PDO Mapping	yes
Units	motorRatedTorque / 1000
Value Range	--
Default Value	--

8.6.2.8 Object 6078_h: current_actual_value

The actual current value of the motor can be read via this object in thousandths of the nominal current (object 6075_h).

Index	6078_h
Name	current_actual_value
Object Code	VAR
Data Type	INT16

Access	ro
PDO Mapping	yes
Units	motorRatedCurrent / 1000
Value Range	--
Default Value	--

8.6.2.9 Object 6079_h: dc_link_circuit_voltage

The voltage in the intermediate circuit of the regulator can be read via this object. The voltage is specified in millivolt.

Index	6079 _h
Name	dc_link_circuit_voltage
Object Code	VAR
Data Type	UINT32

Access	ro
PDO Mapping	yes
Units	mV
Value Range	--
Default Value	--

8.6.2.10 Object 6087_h: torque_slope

This parameter describes the modification speed of the setpoint ramp. This speed is to be specified as thousandths of the nominal torque per second. For example the desired torque value **target_torque** is raised from 0 Nm to the value **motor_rated_torque**. If the output value of the interconnected torque ramp is to reach this value within a second the value 1000 is to be entered into this object.

Index	6087 _h
Name	torque_slope
Object Code	VAR
Data Type	UINT32

Access	rw
PDO Mapping	yes
Units	motor_rated_torque / 1000 s
Value Range	--
Default Value	E310F94 _h

8.6.2.11 Object 6088_h: torque_profile_type

The object **torque_profile_type** defines by which shape of curve a setpoint step is executed. Instantaneous only the linear ramp is implemented in the servo controller so only 0 can be written to this object.

Index	6088 _h
Name	torque_profile_type
Object Code	VAR
Data Type	INT16

Access	rw
PDO Mapping	yes
Units	--
Value Range	0
Default Value	0

Value	Description
0	Linear Ramp

9 Changes to SE-POWER series

The present CANopen implementation of the SE-POWER series is based on the Draft Standard (DS) 301 Version 4.02 and the Draft Standard Proposal (DSP) 402 Version 2.0. Therefore some changes have been made with regard to the SE-POWER- / series. To make it easier for CANopen user easier to change to the SE-POWER series the main changes have been listed in the following table:

Changes in the value range of CAN objects are not listed explicitly. As a rule the most value ranges are increased in relation to the SE-POWER- / series.

Topic	Description	Kap.
Activation of CANopen	The activation of the CANopen functionality will only be available after a reset if the parameter set has been saved.	4
Bootup	The Bootup message is now send with the identifier the Error Control Protocol (701 _h + node number)	5.5.4
Heartbeat instead of Node Guarding	Up to now a manufacturer specific (non-conforming) variation of the Node Guarding was implemented. Instead of that the Heartbeat Protocol has been implemented.	0
Order of PDO parameterisation	For parameterising PDOs a designated order has to be used. This applies to the mapped objects as well as to the identifier.	5.3
Mapping byte by byte	The mapping of parts of an object will not be supported anymore.	5.3
PDO request by a remoteframe	Due to the used hardware is it not possible to support the request of a PDO by a remoteframe conforming to DS301. Therefore this will not be supported.	5.3
Different sdo abort	The sdo abort codes of the SE-POWER serie comply with the	5.2.2

codes	above mentioned version of DS301. Therefore some codes changed in relation to the SE-POWER- / series.	
Factor Group	The Factor Group converts values in internal units in values in external units. Because the internal units have been changed, new values have to be used for position_factor , velocity_encoder_factor and acceleration_factor , if they will be changed. The default values of the Factor Group leads to the same external values as before.	6.2

10 Appendix

10.1 Characteristics of the CAN interface

The CAN interface has the following features:

- CAN specification V2.0 part A (part B passive, e. g. messages of this kind will be tolerated but not processed)
- physical layer: ISO 11898

10.2 Header File

```

/*****
*
*                                OBJECTS.H                                *
*
* Definition der CANopen-Objects
*
* Autor:           Ulf Matthiesen
* Date:           07.11.2003
* Update:
* Tests:         ----
* Freigabe:       ----
* Version:        3.00
*
*
*
* Codierung:      (0xHHHHSULL mit HHHH = Hauptindex
*                  SU   = Subindex
*                  LL   = Länge in Bits + 0, wenn unsigned
*                  + 1, wenn signed
*
*
* (c) Copyright 2003 Afag GmbH, Braunschweig
*
*****/

#define cUINT8      0x08
#define cUINT16     0x10
#define cUINT32     0x20
#define cINT8       0x09
#define cINT16      0x11
#define cINT32      0x21
#define cPDO        0x00 /* Hier geeignete Bitkonstanten einfügbar */
#define cWR         0x00 /* Hier geeignete Bitkonstanten einfügbar */
#define cRD         0x00 /* Hier geeignete Bitkonstanten einfügbar */

#define device_type (0x100000 + cUINT32 + cRD }

```

```

#define error_register (0x100100 + cUINT8 + cRD + cPDO )
#define manufacturer_status_register (0x100200 + cUINT32 + cRD )
#define pre_defined_error_field (0x100300 + cUINT8 + cRD + cWR )
#define standard_error_field_0 (0x100301 + cUINT32 + cRD )
#define standard_error_field_1 (0x100302 + cUINT32 + cRD )
#define standard_error_field_2 (0x100303 + cUINT32 + cRD )
#define standard_error_field_3 (0x100304 + cUINT32 + cRD )
#define cob_id_sync (0x100500 + cUINT32 + cRD + cWR )
#define communication_cycle_period (0x100600 + cUINT32 + cRD + cWR )
#define synchronous_window_length (0x100700 + cUINT32 + cRD + cWR )
#define guard_time (0x100C00 + cUINT16 + cRD )
#define life_time_factor (0x100D00 + cUINT8 + cRD )
#define store_parameters (0x101000 + cUINT8 + cRD )
#define save_all_parameters (0x101001 + cUINT32 + cRD + cWR )
#define restore_parameters (0x101100 + cUINT8 + cRD )
#define restore_all_default_parameters (0x101101 + cUINT32 + cRD + cWR )
#define cob_id_time_stamp_message (0x101200 + cUINT32 + cRD + cWR )
#define cob_id_emergency_message (0x101400 + cUINT32 + cRD + cWR )
#define consumer_heartbeat_time (0x101600 + cUINT16 + cRD )
#define consumer_heartbeat_time_1 (0x101601 + cUINT32 + cRD + cWR )
#define producer_heartbeat_time (0x101700 + cUINT16 + cRD + cWR )
#define identity_object (0x101800 + cUINT8 + cRD )
#define vendor_id (0x101801 + cUINT32 + cRD )
#define product_code (0x101802 + cUINT32 + cRD )
#define revision_number (0x101803 + cUINT32 + cRD )
#define serial_number (0x101804 + cUINT32 + cRD )
#define server_sdo_parameter (0x120000 + cUINT8 + cRD )
#define cob_id_client_server (0x120001 + cUINT32 + cRD )
#define cob_id_server_client (0x120002 + cUINT32 + cRD )
#define receive_pdo_parameter_rpdo1 (0x140000 + cUINT8 + cRD )
#define cob_id_used_by_pdo_rpdo1 (0x140001 + cUINT32 + cRD + cWR )
#define transmission_type_rpdo1 (0x140002 + cUINT8 + cRD + cWR )
#define receive_pdo_parameter_rpdo2 (0x140100 + cUINT8 + cRD )
#define cob_id used_by_pdo_rpdo2 (0x140101 + cUINT32 + cRD + cWR )
#define transmission_type_rpdo2 (0x140102 + cUINT8 + cRD + cWR )
#define receive_pdo_parameter_rpdo3 (0x140200 + cUINT8 + cRD )
#define cob_id used_by_pdo_rpdo3 (0x140201 + cUINT32 + cRD + cWR )
#define transmission_type_rpdo3 (0x140202 + cUINT8 + cRD + cWR )
#define receive_pdo_parameter_rpdo4 (0x140300 + cUINT8 + cRD )
#define cob_id used_by_pdo_rpdo4 (0x140301 + cUINT32 + cRD + cWR )
#define transmission_type_rpdo4 (0x140302 + cUINT8 + cRD + cWR )
#define receive_pdo_mapping_rpdo1 (0x160000 + cUINT8 + cRD + cWR )
#define first_mapped_object_rpdo1 (0x160001 + cUINT32 + cRD + cWR )
#define second_mapped_object_rpdo1 (0x160002 + cUINT32 + cRD + cWR )
#define third_mapped_object_rpdo1 (0x160003 + cUINT32 + cRD + cWR )
#define fourth_mapped_object_rpdo1 (0x160004 + cUINT32 + cRD + cWR )
#define receive_pdo_mapping_rpdo2 (0x160100 + cUINT8 + cRD + cWR )
#define first_mapped_object_rpdo2 (0x160101 + cUINT32 + cRD + cWR )
#define second_mapped_object_rpdo2 (0x160102 + cUINT32 + cRD + cWR )
#define third_mapped_object_rpdo2 (0x160103 + cUINT32 + cRD + cWR )
#define fourth_mapped_object_rpdo2 (0x160104 + cUINT32 + cRD + cWR )
#define receive_pdo_mapping_rpdo3 (0x160200 + cUINT8 + cRD + cWR )
#define first_mapped_object_rpdo3 (0x160201 + cUINT32 + cRD + cWR )
#define second_mapped_object_rpdo3 (0x160202 + cUINT32 + cRD + cWR )
#define third_mapped_object_rpdo3 (0x160203 + cUINT32 + cRD + cWR )
#define fourth_mapped_object_rpdo3 (0x160204 + cUINT32 + cRD + cWR )
#define receive_pdo_mapping_rpdo4 (0x160300 + cUINT8 + cRD + cWR )
#define first_mapped_object_rpdo4 (0x160301 + cUINT32 + cRD + cWR )
#define second_mapped_object_rpdo4 (0x160302 + cUINT32 + cRD + cWR )
#define third_mapped_object_rpdo4 (0x160303 + cUINT32 + cRD + cWR )
#define fourth_mapped_object_rpdo4 (0x160304 + cUINT32 + cRD + cWR )
#define transmit_pdo_parameter_tpdo1 (0x180000 + cUINT8 + cRD )
#define cob_id_used_by_pdo_tpdo1 (0x180001 + cUINT32 + cRD + cWR )
#define transmission_type_tpdo1 (0x180002 + cUINT8 + cRD + cWR )
#define inhibit_time_tpdo1 (0x180003 + cUINT16 + cRD + cWR )
#define transmit_pdo_parameter_tpdo2 (0x180100 + cUINT8 + cRD )
#define cob_id_used_by_pdo_tpdo2 (0x180101 + cUINT32 + cRD + cWR )
#define transmission_type_tpdo2 (0x180102 + cUINT8 + cRD + cWR )

```

```

#define inhibit_time_tpdo2 (0x180103 + cUINT16 + cRD + cWR }
#define transmit_pdo_parameter_tpdo3 (0x180200 + cUINT8 + cRD }
#define cob_id_used_by_pdo_tpdo3 (0x180201 + cUINT32 + cRD + cWR }
#define transmission_type_tpdo3 (0x180202 + cUINT8 + cRD + cWR }
#define inhibit_time_tpdo3 (0x180203 + cUINT16 + cRD + cWR }
#define transmit_pdo_parameter_tpdo4 (0x180300 + cUINT8 + cRD }
#define cob_id_used_by_pdo_tpdo4 (0x180301 + cUINT32 + cRD + cWR }
#define transmission_type_tpdo4 (0x180302 + cUINT8 + cRD + cWR }
#define inhibit_time_tpdo4 (0x180303 + cUINT16 + cRD + cWR }
#define transmit_pdo_mapping_tpdo1 (0x1A0000 + cUINT8 + cRD + cWR }
#define first_mapped_object_tpdo1 (0x1A0001 + cUINT32 + cRD + cWR }
#define second_mapped_object_tpdo1 (0x1A0002 + cUINT32 + cRD + cWR }
#define third_mapped_object_tpdo1 (0x1A0003 + cUINT32 + cRD + cWR }
#define fourth_mapped_object_tpdo1 (0x1A0004 + cUINT32 + cRD + cWR }
#define transmit_pdo_mapping_tpdo2 (0x1A0100 + cUINT8 + cRD + cWR }
#define first_mapped_object_tpdo2 (0x1A0101 + cUINT32 + cRD + cWR }
#define second_mapped_object_tpdo2 (0x1A0102 + cUINT32 + cRD + cWR }
#define third_mapped_object_tpdo2 (0x1A0103 + cUINT32 + cRD + cWR }
#define fourth_mapped_object_tpdo2 (0x1A0104 + cUINT32 + cRD + cWR }
#define transmit_pdo_mapping_tpdo3 (0x1A0200 + cUINT8 + cRD + cWR }
#define first_mapped_object_tpdo3 (0x1A0201 + cUINT32 + cRD + cWR }
#define second_mapped_object_tpdo3 (0x1A0202 + cUINT32 + cRD + cWR }
#define third_mapped_object_tpdo3 (0x1A0203 + cUINT32 + cRD + cWR }
#define fourth_mapped_object_tpdo3 (0x1A0204 + cUINT32 + cRD + cWR }
#define transmit_pdo_mapping_tpdo4 (0x1A0300 + cUINT8 + cRD + cWR }
#define first_mapped_object_tpdo4 (0x1A0301 + cUINT32 + cRD + cWR }
#define second_mapped_object_tpdo4 (0x1A0302 + cUINT32 + cRD + cWR }
#define third_mapped_object_tpdo4 (0x1A0303 + cUINT32 + cRD + cWR }
#define fourth_mapped_object_tpdo4 (0x1A0304 + cUINT32 + cRD + cWR }
#define tpdo1_transmit_mask (0x201400 + cUINT8 + cRD }
#define tpdo1_transmit_mask_low (0x201401 + cINT32 + cRD + cWR }
#define tpdo1_transmit_mask_high (0x201402 + cINT32 + cRD + cWR }
#define tpdo2_transmit_mask (0x201500 + cUINT8 + cRD }
#define tpdo2_transmit_mask_low (0x201501 + cINT32 + cRD + cWR }
#define tpdo2_transmit_mask_high (0x201502 + cINT32 + cRD + cWR }
#define tpdo3_transmit_mask (0x201600 + cUINT8 + cRD }
#define tpdo3_transmit_mask_low (0x201601 + cINT32 + cRD + cWR }
#define tpdo3_transmit_mask_high (0x201602 + cINT32 + cRD + cWR }
#define tpdo4_transmit_mask (0x201700 + cUINT8 + cRD }
#define tpdo4_transmit_mask_low (0x201701 + cINT32 + cRD + cWR }
#define tpdo4_transmit_mask_high (0x201702 + cINT32 + cRD + cWR }
#define position_controller_resolution (0x202000 + cINT32 + cRD + cWR }
#define analog_input_voltage (0x240000 + cINT8 + cRD }
#define analog_input_voltage_ch_0 (0x240001 + cINT16 + cRD }
#define analog_input_voltage_ch_1 (0x240002 + cINT16 + cRD }
#define analog_input_voltage_ch_2 (0x240003 + cINT16 + cRD }
#define analog_input_offset (0x240100 + cUINT8 + cRD }
#define analog_input_offset_ch_0 (0x240101 + cINT32 + cRD + cWR }
#define analog_input_offset_ch_1 (0x240102 + cINT32 + cRD + cWR }
#define analog_input_offset_ch_2 (0x240103 + cINT32 + cRD + cWR }
#define current_limitation (0x241500 + cUINT8 + cRD }
#define limit_current_input_channel (0x241501 + cINT8 + cRD + cWR }
#define limit_current (0x241502 + cINT32 + cRD + cWR }
#define error_code (0x603F00 + cUINT16 + cRD + cPDO }
#define controlword (0x604000 + cUINT16 + cRD + cWR + cPDO }
#define statusword (0x604100 + cUINT16 + cRD + cPDO }
#define pole_number (0x604D00 + cUINT8 + cRD + cWR + cPDO }
#define quick_stop_option_code (0x605A00 + cINT16 + cRD + cWR }
#define shutdown_option_code (0x605B00 + cINT16 + cRD + cWR }
#define disable_operation_option_code (0x605C00 + cINT16 + cRD + cWR }
#define stop_option_code (0x605D00 + cINT16 + cRD + cWR }
#define fault_reaction_option_code (0x605E00 + cINT16 + cRD + cWR }
#define modes_of_operation (0x606000 + cINT8 + cWR + cPDO }
#define modes_of_operation_display (0x606100 + cINT8 + cRD + cPDO }
#define position_demand_value (0x606200 + cINT32 + cRD + cPDO }
#define position_actual_value (0x606400 + cINT32 + cRD + cPDO }
#define following_error_window (0x606500 + cUINT32 + cRD + cWR + cPDO }
#define following_error_time_out (0x606600 + cUINT16 + cRD + cWR + cPDO }

```

```

#define position_window (0x606700 + cUINT32 + cRD + cWR + cPDO )
#define position_window_time (0x606800 + cUINT16 + cRD + cWR + cPDO )
#define velocity_sensor_actual_value (0x606900 + cINT32 + cRD + cWR + cPDO )
#define sensor_selection_code (0x606A00 + cINT16 + cRD + cWR + cPDO )
#define velocity_demand_value (0x606B00 + cINT32 + cRD + cWR + cPDO )
#define velocity_actual_value (0x606C00 + cINT32 + cRD + cWR + cPDO )
#define velocity_window (0x606D00 + cUINT16 + cRD + cWR + cPDO )
#define velocity_window_time (0x606E00 + cUINT16 + cRD + cWR + cPDO )
#define velocity_threshold (0x606F00 + cUINT16 + cRD + cWR + cPDO )
#define velocity_threshold_time (0x607000 + cUINT16 + cRD + cWR + cPDO )
#define target_torque (0x607100 + cINT16 + cRD + cWR + cPDO )
#define max_torque (0x607200 + cUINT16 + cRD + cWR + cPDO )
#define max_current (0x607300 + cUINT16 + cRD + cWR + cPDO )
#define torque_demand_value (0x607400 + cINT16 + cRD + cWR + cPDO )
#define motor_rated_current (0x607500 + cUINT32 + cRD + cWR + cPDO )
#define motor_rated_torque (0x607600 + cUINT32 + cRD + cWR + cPDO )
#define torque_actual_value (0x607700 + cINT16 + cRD + cWR + cPDO )
#define current_actual_value (0x607800 + cINT16 + cRD + cWR + cPDO )
#define dc_link_circuit_voltage (0x607900 + cUINT32 + cRD + cWR + cPDO )
#define target_position (0x607A00 + cINT32 + cRD + cWR + cPDO )
#define home_offset (0x607C00 + cINT32 + cRD + cWR + cPDO )
#define polarity (0x607E00 + cUINT8 + cRD + cWR + cPDO )
#define max_motor_speed (0x608000 + cUINT16 + cRD + cWR + cPDO )
#define profile_velocity (0x608100 + cUINT32 + cRD + cWR + cPDO )
#define end_velocity (0x608200 + cUINT32 + cRD + cWR + cPDO )
#define profile_acceleration (0x608300 + cUINT32 + cRD + cWR + cPDO )
#define profile_deceleration (0x608400 + cUINT32 + cRD + cWR + cPDO )
#define quick_stop_deceleration (0x608500 + cUINT32 + cRD + cWR + cPDO )
#define motion_profile_type (0x608600 + cINT16 + cRD + cWR + cPDO )
#define torque_slope (0x608700 + cUINT32 + cRD + cWR + cPDO )
#define torque_profile_type (0x608800 + cINT16 + cRD + cWR + cPDO )
#define position_notation_index (0x608900 + cINT8 + cRD + cWR + cPDO )
#define position_dimension_index (0x608A00 + cUINT8 + cRD + cWR + cPDO )
#define velocity_notation_index (0x608B00 + cINT8 + cRD + cWR + cPDO )
#define velocity_dimension_index (0x608C00 + cUINT8 + cRD + cWR + cPDO )
#define acceleration_notation_index (0x608D00 + cINT8 + cRD + cWR + cPDO )
#define acceleration_dimension_index (0x608E00 + cUINT8 + cRD + cWR + cPDO )
#define position_encoder_resolution (0x608F00 + cUINT8 + cRD + cWR + cPDO )
#define encoder_increments (0x608F01 + cUINT32 + cRD + cWR + cPDO )
#define motor_revolutions (0x608F02 + cUINT32 + cRD + cWR + cPDO )
#define velocity_encoder_resolution (0x609000 + cUINT8 + cRD + cWR + cPDO )
#define encoder_increments_per_second (0x609001 + cUINT32 + cRD + cWR + cPDO )
#define motor_revolutions_per_second (0x609002 + cUINT32 + cRD + cWR + cPDO )
#define gear_ratio (0x609100 + cUINT8 + cRD + cWR + cPDO )
#define motor_revolutions (0x609101 + cUINT32 + cRD + cWR + cPDO )
#define shaft_revolutions (0x609102 + cUINT32 + cRD + cWR + cPDO )
#define feed_constant (0x609200 + cUINT8 + cRD + cWR + cPDO )
#define feed (0x609201 + cUINT32 + cRD + cWR + cPDO )
#define shaft_revolutions (0x609202 + cUINT32 + cRD + cWR + cPDO )
#define position_factor (0x609300 + cUINT8 + cRD + cWR + cPDO )
#define numerator (0x609301 + cUINT32 + cRD + cWR + cPDO )
#define divisor (0x609302 + cUINT32 + cRD + cWR + cPDO )
#define velocity_encoder_factor (0x609400 + cUINT8 + cRD + cWR + cPDO )
#define numerator (0x609401 + cUINT32 + cRD + cWR + cPDO )
#define divisor (0x609402 + cUINT32 + cRD + cWR + cPDO )
#define velocity_factor_1 (0x609500 + cUINT8 + cRD + cWR + cPDO )
#define numerator (0x609501 + cUINT32 + cRD + cWR + cPDO )
#define divisor (0x609502 + cUINT32 + cRD + cWR + cPDO )
#define velocity_factor_2 (0x609600 + cUINT8 + cRD + cWR + cPDO )
#define numerator (0x609601 + cUINT32 + cRD + cWR + cPDO )
#define divisor (0x609602 + cUINT32 + cRD + cWR + cPDO )
#define acceleration_factor (0x609700 + cUINT8 + cRD + cWR + cPDO )
#define numerator (0x609701 + cUINT32 + cRD + cWR + cPDO )
#define divisor (0x609702 + cUINT32 + cRD + cWR + cPDO )
#define homing_method (0x609800 + cINT8 + cRD + cWR + cPDO )
#define homing_speeds (0x609900 + cUINT8 + cRD + cWR + cPDO )
#define speed_during_search_for_switch (0x609901 + cUINT32 + cRD + cWR + cPDO )
#define speed_during_search_for_zero (0x609902 + cUINT32 + cRD + cWR + cPDO )

```



```

#define homing_acceleration (0x609A00 + cUINT32 + cRD + cWR + cPDO )
#define interpolation_submode_select (0x60C000 + cINT16 + cRD + cWR + cPDO )
#define interpolation_data_record (0x60C100 + cUINT8 + cRD )
#define ip_data_position (0x60C101 + cINT32 + cRD + cWR + cPDO )
#define ip_data_controlword (0x60C102 + cUINT8 + cRD + cWR + cPDO )
#define interpolation_time_period (0x60C200 + cUINT8 + cRD )
#define ip_time_units (0x60C201 + cUINT8 + cRD + cWR + cPDO )
#define ip_time_index (0x60C202 + cINT8 + cRD + cWR + cPDO )
#define interpolation_sync_definition (0x60C300 + cUINT8 + cRD )
#define synchronize_on_group (0x60C301 + cUINT8 + cRD + cWR + cPDO )
#define ip_sync_every_n_event (0x60C302 + cUINT8 + cRD + cWR + cPDO )
#define interpolation_data_configuration (0x60C400 + cUINT8 + cRD + cPDO )
#define max_buffer_size (0x60C401 + cUINT32 + cRD + cPDO )
#define actual_size (0x60C402 + cUINT32 + cRD + cWR + cPDO )
#define buffer_organisation (0x60C403 + cUINT8 + cRD + cWR + cPDO )
#define buffer_position (0x60C404 + cUINT16 + cRD + cWR + cPDO )
#define size_of_data_record (0x60C405 + cUINT8 + cWR + cPDO )
#define buffer_clear (0x60C406 + cUINT8 + cWR + cPDO )
#define torque_control_parameters (0x60F600 + cUINT8 + cRD )
#define torque_control_gain (0x60F601 + cUINT16 + cRD + cWR )
#define torque_control_time (0x60F602 + cUINT16 + cRD + cWR )
#define velocity_control_parameter_set (0x60F900 + cUINT8 + cRD )
#define velocity_control_gain (0x60F901 + cUINT16 + cRD + cWR )
#define velocity_control_time (0x60F902 + cUINT16 + cRD + cWR )
#define velocity_control_filter_time (0x60F904 + cUINT16 + cRD + cWR )
#define control_effort (0x60FA00 + cINT32 + cRD + cPDO )
#define position_control_parameter_set (0x60FB00 + cUINT8 + cRD )
#define position_control_gain (0x60FB01 + cUINT16 + cRD + cWR )
#define position_control_time (0x60FB02 + cUINT16 + cRD + cWR )
#define position_control_v_max (0x60FB04 + cUINT32 + cRD + cWR )
#define position_error_tolerance_window (0x60FB05 + cUINT32 + cRD + cWR )
#define digital_inputs (0x60FD00 + cUINT32 + cRD + cPDO )
#define digital_outputs (0x60FE00 + cUINT8 + cRD )
#define digital_outputs_data (0x60FE01 + cUINT32 + cRD + cWR + cPDO )
#define digital_outputs_mask (0x60FE02 + cUINT32 + cRD + cWR + cPDO )
#define target_velocity (0x60FF00 + cINT32 + cRD + cWR + cPDO )
#define motor_type (0x640200 + cUINT16 + cRD + cPDO )
#define motor_data (0x641000 + cUINT8 + cRD )
#define iit_time_motor (0x641003 + cUINT16 + cRD + cWR )
#define iit_ratio_motor (0x641004 + cUINT16 + cRD )
#define phase_order (0x641010 + cUINT16 + cRD + cWR )
#define encoder_offset_angle (0x641011 + cINT16 + cRD + cWR + cPDO )
#define motor_temperatur_sensor_polarity (0x641014 + cINT16 + cRD + cWR + cPDO )
#define supported_drive_modes (0x650200 + cUINT32 + cRD + cPDO )
#define drive_data (0x651000 + cUINT8 + cRD )
#define serial_number (0x651001 + cUINT32 + cRD )
#define drive_code (0x651002 + cUINT32 + cRD )
#define user_variable_not_saved (0x651003 + cINT16 + cRD + cWR )
#define user_variable_saved (0x651004 + cINT16 + cRD + cWR )
#define enable_logic (0x651010 + cUINT16 + cRD + cWR )
#define limit_switch_polarity (0x651011 + cINT16 + cRD + cWR )
#define homing_switch_selector (0x651013 + cINT16 + cRD + cWR )
#define homing_switch_polarity (0x651014 + cINT16 + cRD + cWR )
#define limit_switch_deceleration (0x651015 + cINT32 + cRD + cWR )
#define brake_delay_time (0x651018 + cUINT16 + cRD + cWR )
#define automatic_brake_delay (0x651019 + cUINT16 + cRD + cWR )
#define position_error_switch_off_limit (0x651022 + cUINT32 + cRD + cWR )
#define pwm_frequency (0x651030 + cUINT16 + cRD + cWR )
#define power_stage_temperature (0x651031 + cINT16 + cRD )
#define max_power_stage_temperature (0x651032 + cINT16 + cRD )
#define nominal_dc_link_circuit_voltage (0x651033 + cUINT32 + cRD )
#define actual_dc_link_circuit_voltage (0x651034 + cUINT32 + cRD )
#define max_dc_link_circuit_voltage (0x651035 + cUINT32 + cRD )
#define min_dc_link_circuit_voltage (0x651036 + cUINT32 + cRD + cWR )
#define enable_dc_link_undervoltage_error (0x651037 + cUINT16 + cRD + cWR )
#define iit_error_enable (0x651038 + cUINT16 + cRD + cWR )
#define enable_enhanced_modulation (0x65103A + cUINT16 + cRD + cWR )
#define iit_ratio_servo (0x65103D + cINT16 + cRD )

```

```

#define nominal_current          (0x651040 + cUINT32 + cRD          )
#define peak_current             (0x651041 + cUINT32 + cRD          )
#define drive_serial_number     (0x6510A0 + cUINT32 + cRD          )
#define drive_type              (0x6510A1 + cUINT32 + cRD          )
#define drive_revision          (0x6510A2 + cUINT32 + cRD          )
#define encoder_serial_number   (0x6510A3 + cUINT32 + cRD          )
#define encoder_type            (0x6510A4 + cUINT32 + cRD          )
#define encoder_revision        (0x6510A5 + cUINT32 + cRD          )
#define module_serial_number    (0x6510A6 + cUINT32 + cRD          )
#define module_type             (0x6510A7 + cUINT32 + cRD          )
#define module_revision         (0x6510A8 + cUINT32 + cRD          )
#define firmware_main_version   (0x6510A9 + cUINT32 + cRD          )
#define firmware_custom_version (0x6510AA + cUINT32 + cRD          )
#define mdc_version             (0x6510AB + cUINT32 + cRD          )
#define firmware_type           (0x6510AC + cUINT32 + cRD          )
#define cycletime_current_controller (0x6510B0 + cUINT32 + cRD      )
#define cycletime_velocity_controller (0x6510B1 + cUINT32 + cRD      )
#define cycletime_position_controller (0x6510B2 + cUINT32 + cRD      )
#define cycletime_tracectory_generator (0x6510B3 + cUINT32 + cRD      )
#define device_current          (0x6510B8 + cUINT32 + cRD          )
#define commisioning_state      (0x6510C0 + cUINT32 + cRD + cWR      )

/*****
/*      'magic' word for loading parameter
*****/
#define cLOAD      0x64616F6C
#define cSAVE      0x65766173

/*****
/*      modes of operation
*****/
#define cPositionMode      0x01
#define cVelocityMode      0x03
#define cTorqueMode        0x04
#define cHomingMode        0x06
#define cInterpolatedMode  0x07
#define cUnknownMode       0xFF

/*****
/*      digital inputs
*****/
#define cEND0      0x00000001 /* negativer Endschalter
#define cEND1      0x00000002 /* positiver Endschalter
#define cHOME_SAMPLE 0x00000004 /* Home / Sample
#define cLOCK      0x00000008 /* Regler- oder Endstufenfreigabe fehlt
#define cPOS0      0x01000000 /* Digital Input Target selector
#define cPOS1      0x02000000 /* Digital Input Target selector
#define cPOS2      0x04000000 /* Digital Input Target selector
#define cPOS3      0x08000000 /* Digital Input Target selector
#define cSTART     0x10000000
#define cSAMPLE    0x20000000

/* ----- Definition nach Steckerbenamung ----- */
#define cDIN0      cPOS0
#define cDIN1      cPOS1
#define cDIN2      cPOS2
#define cDIN3      cPOS3
#define cDIN5      cLOCK
#define cDIN6      cEND0
#define cDIN7      cEND1
#define cDIN8      cSTART
#define cDIN9      cSAMPLE

/*****
/*      controlword
*****/
#define cwSHUT_DOWN      0x0006
#define cwSWITCH_ON      0x0007

```

```

#define cwDISABLE_VOLTAGE      0x0000
#define cwQUICK_STOP           0x0002
#define cwDISABLE_OPERATION    0x0007
#define cwENABLE_OPERATION     0x000F
#define cwFAULT_RESET         0x0080 /* Fault Reset mit steigender Flanke */

#define cwNEW_SET_POINT        0x0010
#define cwSTART_HOMING_OPERATION 0x0010
#define cwENABLE_IP_MODE      0x0010
#define cwCHANGE_SET_IMMEDIATLY 0x0020
#define cwABSOLUTE_RELATIV    0x0040
#define cwHOLD                 0x0100

/*****
/*      statusword
*****/
/* state definition */
#define cdNOT_READY_TO_SWITCH_ON      0x0000
#define cdSWITCHED_ON_DISABLED        0x0040
#define cdREADY_TO_SWITCH_ON          0x0021
#define cdSWITCHED_ON                  0x0023
#define cdOPERATION_ENABLED            0x0027
#define cdFAULT                        0x000F
#define cdFAULT_REACTION_ACTIVE        0x000F
#define cdQUICK_STOP_ACTIVE            0x0007

/* Bits of staus word */
#define swVOLTAGE_DISABLED             0x0010
#define swSWITCH_ON_DISABLED           0x0040
#define swWARNING                       0x0080
#define swREMOTE                       0x0200
#define swTARGET_REACHED               0x0400
#define swINTERNAL_LIMIT_ACTIVE        0x0800
#define swSET_POINT_ACKNOWLEDGE        0x1000
#define swSPEED0                       0x1000
#define swHOMING_ATTAINED              0x1000
#define swIP_MODE_ACTIVE               0x1000
#define swFOLLOWING_ERROR              0x2000
#define swHOMING_ERROR                 0x2000

/* position modes */
#define pCONTINUOUS                     0x0000
#define pIMMEDIATE                      0x0020
#define pABSOLUTE                       0x0000
#define pRELATIVE                       0x0040

/* motion profile types */
#define mpLINEAR                        0

```

11 Keyword index

7

7 segment display

'A' on 104

A

A on 7 segment display 104

acceleration_factor 59

Action on command 'disable operation' 118

Action on command 'quick stop' 118

Actual value

Position (position_units) 84

actual_dc_link_circuit_voltage 66

actual_size 147

analog_input_offset 89

analog_input_offset_ch_0 89

analog_input_offset_ch_1 90

analog_input_offset_ch_2 90

analog_input_voltage 88

analog_input_voltage_ch_0 88

analog_input_voltage_ch_1 89

analog_input_voltage_ch_2 89

Analogue inputs 88

B

Bootstrap 45

brake_delay_time 97

buffer_clear 148

buffer_organisation 147

buffer_position 148

C

Cabling 22

cabling hints 23

CAN interface

Characteristics of the 168

cob_id_sync 41

cob_id_used_by_pdo 35

commissioning_state 104

Control of the device 105

control_effort 86

controlword 110

Bits of the 110

Commands 111

Description 110

Conversion factors 53

Sign 61

Current controller 69

Parameters 76

Current DC link voltage 66

current_actual_value 164

current_limitation 75

cycletime_current_controller 102

cycletime_position_controller 103

cycletime_tracectory_generator 103

cycletime_velocity_controller 102

D

DC link voltage

current 66

maximum 66

dc_link_circuit_voltage 165

Demand value

Position (position_units) 84

Device Control 105

digital_inputs 91

digital_outputs 92

digital_outputs_data 92

digital_outputs_mask 92

disable_operation_option_code 118

Display, 7 segment

'A' on 104

divisor

acceleration_factor 59

position_factor 55

velocity_encoder_factor 57

drive_data 63, 93, 97, 100

drive_serial_number 100

drive_type 100

E

EMERGENCY 41

EMERGENCY message 41

Structure of an 41

enable_dc_link_undervoltage_error 67

enable_enhanced_modulation 64

enable_logic 63

Enabling the device	105
encoder_offset_angle	74
end_velocity	137
Endstop	131, 132
Error	
pre_defined_error_field	44
Error	
'A' on 7 segment display	104
Error of servo controller	41
SDO-Error messages	29
Error Control Protocol	
Bootup	45
Heartbeat	45
Error message	41
F	
Factor Group	53
acceleration_factor	59
polarity	61
position_factor	55
velocity_encoder_factor	57
Fault	108
Fault Reaction Active	108
fault_reaction_option_code	119
Faults	41
firmware_custom_version	101
firmware_main_version	101
firmware_type	102
first_mapped_object	36
Following error	79
following_error_time_out	85
following_error_window	85
fourth_mapped_object	36
H	
Heartbeat	45
home_offset	124
Homing mode	123
home_offset	124
homing_acceleration	126
homing_method	125
homing_speeds	126
Speed during search for switch	126
Speed during search for zero	126
Homing operation	123
Control of the	133

Homing switches	93
homing_acceleration	126
homing_method	125
homing_speeds	126
homing_switch_polarity	94
homing_switch_selector	94

I

Identifier	
NMT service	46
identity_object	98
iit error	73
iit_error_enable	73
iit_ratio_motor	72
iit_time_motor	72
inhibit_time	35
Inputs	
Analogue	88
interpolation_data_configuration	147
interpolation_data_record	144
interpolation_submode_select	143
interpolation_sync_definition	146
interpolation_time_period	145
Interpolation-Type	143
ip_data_controlword	144
ip_data_position	144
ip_sync every n event	146
ip_time_index	145
ip_time_units	145

L

Limit switch	127, 129
Limit switches	93
limit_current	75
limit_current_input_channel	75
limit_switch_deceleration	95
limit_switch_polarity	93
Load and save parameter sets	49

M

Max. current	71
Max. DC link voltage	66
max_buffer_size	147
max_current	71
max_dc_link_circuit_voltage	66
max_motor_speed	159

max_power_stage_temperature.....	65	Object 1003 _{h_02h}	44
max_torque.....	162	Object 1003 _{h_03h}	44
Maximum current.....	68	Object 1003 _{h_04h}	44
Maximum power stage temperature.....	65	Object 1005 _h	41
min_dc_link_circuit_voltage.....	67	Object 1010 _h	52
Mode of operation		Object 1010 _{h_01h}	52
Profile Position Mode.....	134	Object 1011 _h	51
Profile Torque Mode.....	160	Object 1011 _h	51
Profile Velocity Mode.....	152	Object 1011 _{h_01h}	51
modes_of_operation.....	121	Object 1017 _h	46
modes_of_operation_display.....	122	Object 1018 _h	98
motion_profile_type.....	139	Object 1018 _{h_01h}	98
Motor adaptation.....	69	Object 1018 _{h_02h}	99
Motor parameter		Object 1018 _{h_03h}	99
iit time.....	72	Object 1018 _{h_04h}	99
Max. current.....	71	Object 1400 _h	39
Number of poles.....	71	Object 1401 _h	39
Phase order.....	73	Object 1402 _h	39
Rated current.....	70	Object 1403 _h	39
Resolver offset angle.....	74	Object 1600 _h	39
motor_data.....	74	Object 1601 _h	39
motorRatedCurrent.....	70	Object 1602 _h	39
motorRatedTorque.....	163	Object 1603 _h	39
N		Object 1800 _h	35, 37
NMT service.....	46	Object 1800 _{h_01h}	35
nominal voltage.....	65	Object 1800 _{h_02h}	35
nominalCurrent.....	68	Object 1800 _{h_03h}	35
nominal_dc_link_circuit_voltage.....	65	Object 1801 _h	37
Not Ready to Switch On.....	108	Object 1802 _h	37
Number of poles.....	71	Object 1803 _h	38
number_of_mapped_objects.....	36	Object 1A00 _h	36, 37
numerator		Object 1A00 _{h_00h}	36
acceleration_factor.....	59	Object 1A00 _{h_01h}	36
position_factor.....	55	Object 1A00 _{h_02h}	36
velocity_encoder_factor.....	57	Object 1A00 _{h_03h}	36
O		Object 1A00 _{h_04h}	36
Object		Object 1A01 _h	37
Object 6093 _h	55	Object 1A02 _h	37
Object 6093 _{h_01h}	55	Object 1A03 _h	38
Object 6093 _{h_02h}	55	Object 2014 _h	38
Objects		Object 2015 _h	38
Object 1003 _h	44	Object 2016 _h	38
Object 1003 _h	44	Object 2017 _h	38
Object 1003 _{h_01h}	44	Object 2400 _h	88
		Object 2400 _{h_01h}	88

Object 2400h_02h.....	89	Object 607Eh.....	61
Object 2400h_03h.....	89	Object 6080h.....	159
Object 2401h.....	89	Object 6081h.....	137
Object 2401h_01h.....	89	Object 6082h.....	137
Object 2401h_02h.....	90	Object 6083h.....	138
Object 2401h_03h.....	90	Object 6084h.....	138
Object 2415h.....	75	Object 6085h.....	139
Object 2415h_01h.....	75	Object 6086h.....	139
Object 2415h_02h.....	75	Object 6087h.....	165
Object 6040h.....	110	Object 6088h.....	166
Object 6040h.....	110	Object 6094h.....	57
Object 6041h.....	114	Object 6094h_01h.....	57
Object 604Dh.....	71	Object 6094h_02h.....	57
Object 605Ah.....	118	Object 6097h.....	59
Object 605Bh.....	117	Object 6097h_01h.....	59
Object 605Ch.....	118	Object 6097h_02h.....	59
Object 605Eh.....	119	Object 6098h.....	125
Object 6060h.....	121	Object 6099h.....	126
Object 6061h.....	122	Object 6099h_01h.....	126
Object 6062h.....	84	Object 6099h_02h.....	126
Object 6062h.....	84	Object 609Ah.....	126
Object 6064h.....	84	Object 60C0h.....	143
Object 6065h.....	85	Object 60C1h.....	144
Object 6066h.....	85	Object 60C1h_01h.....	144
Object 6067h.....	86	Object 60C1h_02h.....	144
Object 6068h.....	87	Object 60C2h.....	145
Object 6069h.....	154	Object 60C2h_01h.....	145
Object 606Ah.....	155	Object 60C2h_02h.....	145
Object 606Bh.....	155	Object 60C3h.....	146
Object 606Ch.....	156	Object 60C3h_01h.....	146
Object 606Dh.....	157	Object 60C3h_02h.....	146
Object 606Eh.....	157	Object 60C4h.....	147
Object 606Fh.....	158	Object 60C4h_01h.....	147
Object 6070h.....	158	Object 60C4h_02h.....	147
Object 6071h.....	162	Object 60C4h_03h.....	147
Object 6072h.....	162	Object 60C4h_04h.....	148
Object 6073h.....	71	Object 60C4h_05h.....	148
Object 6074h.....	163	Object 60C4h_06h.....	148
Object 6075h.....	70	Object 60F6h.....	76
Object 6076h.....	163	Object 60F6h_02h.....	76
Object 6077h.....	164	Object 60F9h.....	78
Object 6078h.....	164	Object 60F9h_01h.....	78
Object 6079h.....	165	Object 60F9h_02h.....	78
Object 607Ah.....	136	Object 60F9h_04h.....	78
Object 607Ch.....	124	Object 60FAh.....	86

Object 60FB _h	83
Object 60FB _{h_01h}	83
Object 60FB _{h_02h}	83
Object 60FB _{h_04h}	83
Object 60FB _{h_05h}	83
Object 60FD _h	91
Object 60FE _h	92
Object 60FE _{h_01h}	92
Object 60FE _{h_02h}	92
Object 60FF _h	159
Object 6410 _h	74
Object 6410 _{h_03h}	72
Object 6410 _{h_03h}	72
Object 6410 _{h_04h}	72
Object 6410 _{h_10h}	73
Object 6410 _{h_10h}	73
Object 6410 _{h_11h}	74
Object 6410 _{h_11h}	74
Object 6510 _h	63, 93, 97, 100
Object 6510 _{h_10h}	63
Object 6510 _{h_10h}	63
Object 6510 _{h_11h}	93
Object 6510 _{h_11h}	93
Object 6510 _{h_13h}	94
Object 6510 _{h_14h}	94
Object 6510 _{h_15h}	95
Object 6510 _{h_18h}	97
Object 6510 _{h_30h}	63
Object 6510 _{h_31h}	64
Object 6510 _{h_32h}	65
Object 6510 _{h_33h}	65
Object 6510 _{h_34h}	66
Object 6510 _{h_35h}	66
Object 6510 _{h_36h}	67
Object 6510 _{h_37h}	67
Object 6510 _{h_38h}	73
Object 6510 _{h_38h}	73
Object 6510 _{h_3Ah}	64
Object 6510 _{h_40h}	68
Object 6510 _{h_41h}	68
Object 6510 _{h_A0h}	100
Object 6510 _{h_A1h}	100
Object 6510 _{h_A9h}	101
Object 6510 _{h_AA_h}	101
Object 6510 _{h_AC_h}	102

Object 6510 _{h_B0h}	102
Object 6510 _{h_B1h}	102
Object 6510 _{h_B2h}	103
Object 6510 _{h_B3h}	103
Object 6510 _{h_C0h}	104
Operating Mode	
Homing mode	123
Parameterisation of the	120
Position control	134
Torque control	160
Velocity control	152
Operation enable	108
Overspeed protection.....	77

P

Parameter	
Load default parameter	51
Parameter adjustment.....	49
PDO	26, 31
RPDO1	
COB-ID used by PDO.....	39
first mapped object	39
fourth mapped object.....	39
Identifier	39
number of mapped objects	39
second mapped object	39
third mapped object	39
transmission type.....	39
RPDO2	
COB-ID used by PDO.....	39
first mapped object	39
fourth mapped object.....	39
Identifier	39
number of mapped objects	39
second mapped object	39
third mapped object	39
transmission type.....	39
RPDO3	
COB-ID used by PDO.....	39
first mapped object	39
fourth mapped object.....	39
Identifier	39
number of mapped objects	39
second mapped object	39
third mapped object	39

transmission type	39	inhibit time.....	38
RPDO4		number of mapped objects	38
COB-ID used by PDO	39	second mapped object	38
first mapped object	39	third mapped object	38
fourth mapped object.....	39	transmission type.....	38
Identifier.....	39	PDO message.....	26
number of mapped objects.....	39	PDO-Message	31
second mapped object	39	peak_current.....	68
third mapped object.....	39	phase_order.....	73
transmission type	39	polarity.....	61
TPDO1		pole_number.....	71
COB-ID used by PDO	37	Position control	134
first mapped object.....	37	position control function	79
fourth mapped object.....	37	Position controller	79
Identifier.....	37	Gain.....	83
inhibit time	37	Max. correction speed	83
number of mapped objects.....	37	Output of.....	86
second mapped object	37	Time constant.....	83
third mapped object.....	37	Tolerance window	83
transmission type	37	Position reached	80
TPDO2		position_actual_value	84
COB-ID used by PDO	37	position_control_gain.....	83
first mapped object.....	37	position_control_parameter_set	83
fourth mapped object.....	37	position_control_time.....	83
Identifier.....	37	position_control_v_max.....	83
inhibit time	37	position_demand_value	84
number of mapped objects.....	37	position_error_tolerance_window	83
second mapped object	37	position_factor.....	55
third mapped object.....	37	position_window.....	86
transmission type	37	position_window_time.....	87
TPDO3		Positioning	134
COB-ID used by PDO	37	Power stage parameter	
first mapped object.....	37	DC link voltage	66
fourth mapped object.....	37	Max. current	68
Identifier.....	37	Max. DC link voltage	66
inhibit time	37	Max. Temperature	65
number of mapped objects.....	37	Min. DC link voltage	67
second mapped object	37	Nominal current.....	68
third mapped object.....	37	Nominal voltage.....	65
transmission type	37	Temperature.....	64
TPDO4		Power stage parameters.....	62
COB-ID used by PDO	38	power stage protection.....	67
first mapped object.....	38	Power stage protection	66
fourth mapped object.....	38	power_stage_temperature	64
Identifier.....	38	pre_defined_error_field.....	44

pre_defined_error_field	44	Receive_PDO_2	39
producer_heartbeat_time	46	Receive_PDO_3	39
product_code	99	Receive_PDO_4	39
Profile Position Mode	134	Reference switch	93
end_velocity	137	Referenzfahrt Methoden	127
motion_profile_type	139	resolver_offset_angle	74
profile_acceleration	138	restore_all_default_parameters	51
profile_deceleration	138	restore_default_parameters	51
profile_velocity	137	restore_parameters	51
quick_stop_deceleration	139	revision_number	99
target_position	136	R-PDO 1	39
Profile Torque Mode	160	R-PDO 2	39
current_actual_value	164	R-PDO 3	39
dc_link_circuit_voltage	165	R-PDO 4	39
max_torque	162	S	
motorRated_torque	163	save_all_parameters	52
target_torque	162	Scaling factors	53
torque_actual_value	164	Sign	61
torque_demand_value	163	SDO	26, 27
torque_profile_type	166	Error messages	29
torque_slope	165	SDO message	26
Profile Velocity Mode	152	SDO-Message	27
max_motor_speed	159	second_mapped_object	36
sensor_selection_code	155	sensor_selection_code	155
target_velocity	159	serial_number	99
velocity_actual_value	156	Setpoint	
velocity_demand_value	155	Position (position_units)	84
velocity_sensor	154	Velocity (speed_units)	155
velocity_threshold	158	shutdown_option_code	117
velocity_threshold_time	158	Sinus modulation	64
velocity_window	157	size_of_data_record	148
velocity_window_time	157	Speed controller	77
profile_acceleration	138	standard_error_field_0	44
profile_deceleration	138	standard_error_field_1	44
profile_velocity	137	standard_error_field_2	44
pwm_frequency	63	standard_error_field_3	44
Q		State	
Quick Stop Active	108	Fault	108
quick_stop_deceleration	139	Fault Reaction Active	108
quick_stop_option_code	118	Not Ready to Switch On	108
R		Operation Enable	108
Rated current	70	Quick Stop Active	108
Ready to Switch On	108	Ready to Switch On	108
Receive_PDO_1	39	Switch On Disabled	108

Switched On.....	108
state diagram.....	106
statemachine.....	106
statusword	
Bits of the	114
Description.....	114
store_parameters.....	52
Switch On Disabled.....	108
Switched On.....	108
SYNC.....	41
SYNC-Message.....	41
synchronize_on_group.....	146
T	
Target position	
Time.....	87
Target position window.....	86
target_position.....	136
target_reached.....	80
target_torque.....	162
target_velocity.....	159
third_mapped_object.....	36
Torque control.....	160
Max. torque.....	162
Torque limitation	
Demand value.....	75
Scaling.....	75
Torque limitation	
Source.....	75
Torque limited speed control.....	75
torque_actual_value.....	164
torque_control_parameters.....	76
torque_control_time.....	76
torque_demand_value.....	163
torque_profile_type.....	166
torque_slope.....	165
T-PDO 1.....	37
T-PDO 2.....	37
T-PDO 3.....	37
T-PDO 4.....	38
tpdo_1_transmit_mask.....	38
tpdo_2_transmit_mask.....	38
tpdo_3_transmit_mask.....	38
tpdo_4_transmit_mask.....	38
Trailing error.....	79

Trajectory generator.....	134
transfer_PDO_1.....	37
transfer_PDO_2.....	37
transfer_PDO_3.....	37
transfer_PDO_4.....	38
transmission_type.....	35
transmit_pdo_mapping.....	36
transmit_pdo_parameter.....	35

V

Velocity control.....	152
Velocity controller.....	77
Filter time.....	78
Gain.....	78
Parameter.....	78
Time constant.....	78
velocity_actual_value.....	156
velocity_control_filter_time.....	78
velocity_control_gain.....	78
velocity_control_parameters.....	78
velocity_control_time.....	78
velocity_demand_value.....	155
velocity_encoder_factor.....	57
velocity_sensor_actual_value.....	154
velocity_threshold.....	158
velocity_threshold_time.....	158
velocity_window.....	157
velocity_window_time.....	157
vendor_id.....	98

Z

Zero impulse.....	132
-------------------	-----



Afag Automation AG
Fiechtenstrasse 32
CH - 4950 Huttwil
Switzerland

Tel.: +41 (0)62 959 86 86

Fax.: +41 (0)62 959 87 87

e-mail: sales@afag.com

Internet: www.afag.com