



**EMERSON**<sup>™</sup>

Original Instructions  
4000859 - REV. 00



# DCX S

## Power Supply

Rack Mount Version

# Operating Manual

**Branson Ultrasonics Corp.**  
120 Park Ridge Road  
Brookfield, CT 06804  
(203) 796-0400  
<http://www.bransonultrasonics.com>

**BRANSON**

## Manual Change Information

At Branson, we strive to maintain our position as the leader in ultrasonics plastics joining, metal welding, cleaning and related technologies by continually improving our circuits and components in our equipment. These improvements are incorporated as soon as they are developed and thoroughly tested.

Information concerning any improvements will be added to the appropriate technical documentation at its next revision and printing. Therefore, when requesting service assistance for specific units, note the Revision information found on this document, and refer to the printing date which appears on this page.

## Copyright and Trademark Notice

Copyright © 2022 Branson Ultrasonics Corporation. All rights reserved. Contents of this publication may not be reproduced in any form without the written permission of Branson Ultrasonics Corporation.

Mylar is a registered trademark of DuPont Teijin Films.

Loctite is a registered trademark of Loctite Corporation.

WD-40 is a registered trademark of WD-40 Company.

Windows 7, Windows Vista, and Windows XP are registered trademarks of Microsoft Corporation

Other trademarks and service marks mentioned herein are held by their respective owners.

## Foreword

Congratulations on your choice of a Branson Ultrasonics Corporation system!

The Branson DCX S Power Supply system is process equipment for the joining of plastic parts using ultrasonic energy. It is the newest generation of product using this sophisticated technology for a variety of customer applications. This Operating Manual is part of the documentation set for this system, and should be kept with the equipment.

Thank you for choosing Branson!

## Introduction

This manual is arranged into several structured chapters which will help you find the information you may need to know to safely handle, install, set up, program, operate, and/or maintain this product. Please refer to the [Table of Contents](#) and/or the [Index](#) of this manual to find the information you may be looking for. In the event you require additional assistance or information, please contact our Product Support department (see [1.3 How to Contact Branson](#) for information on how to contact them) or your local Branson representative.



---

# Table of Contents

---

## Chapter 1: Safety and Support

|     |  |   |
|-----|--|---|
| 1.1 | Safety Requirements and Warnings . . . . . | 2 |
| 1.2 | General Precautions . . . . .              | 6 |
| 1.3 | How to Contact Branson . . . . .           | 8 |

## Chapter 2: Introduction

|     |   |    |
|-----|---|----|
| 2.1 | Models Covered . . . . .                            | 14 |
| 2.2 | Compatibility with other Branson Products . . . . . | 16 |
| 2.3 | Features . . . . .                                  | 17 |
| 2.4 | Controls and Indicators . . . . .                   | 20 |
| 2.5 | Welding Systems . . . . .                           | 25 |
| 2.6 | Glossary . . . . .                                  | 26 |

## Chapter 3: Delivery and Handling

|     |   |    |
|-----|---|----|
| 3.1 | Shipping and Handling . . . . .         | 30 |
| 3.2 | Receiving . . . . .                     | 31 |
| 3.3 | Unpacking the Power Supply . . . . .    | 32 |
| 3.4 | Take Inventory of Small Parts . . . . . | 33 |
| 3.5 | Returning Equipment . . . . .           | 34 |

## Chapter 4: Technical Specifications

|     |                                     |    |
|-----|-------------------------------------|----|
| 4.1 | Technical Specifications . . . . .  | 36 |
| 4.2 | Physical Description . . . . .      | 38 |
| 4.3 | Declaration of Conformity . . . . . | 39 |

## Chapter 5: Installation and Setup

|     |   |    |
|-----|---|----|
| 5.1 | About Installation . . . . .            | 42 |
| 5.2 | Installation Requirements . . . . .     | 43 |
| 5.3 | Installation Steps . . . . .            | 48 |
| 5.4 | Power Supply Configuration . . . . .    | 61 |
| 5.5 | Assembling the Acoustic Stack . . . . . | 62 |
| 5.6 | Converter Cooling . . . . .             | 66 |
| 5.7 | Testing the Installation . . . . .      | 68 |
| 5.8 | Still Need Help? . . . . .              | 69 |

## Chapter 6: Converters and Boosters

|     |                                   |    |
|-----|-----------------------------------|----|
| 6.1 | Converters and Boosters . . . . . | 72 |
|-----|-----------------------------------|----|

## Chapter 7: Operation

|     |  |     |
|-----|--|-----|
| 7.1 | Activating Ultrasonic Power . . . . .            | 86  |
| 7.2 | Setting the Amplitude . . . . .                  | 87  |
| 7.3 | Resetting the Power Supply Alarms . . . . .      | 89  |
| 7.4 | Configuring the Power Supply Registers . . . . . | 90  |
| 7.5 | LCD Bar-Graph . . . . .                          | 94  |
| 7.6 | Web Page Interface . . . . .                     | 97  |
| 7.7 | Ultrasonics Test Procedure . . . . .             | 102 |

## **Chapter 8: Maintenance**

|     |  |     |
|-----|--|-----|
| 8.1 | General Maintenance Considerations . . . . . | 106 |
| 8.2 | Preventive Maintenance . . . . .             | 108 |
| 8.3 | Calibration . . . . .                        | 114 |
| 8.4 | Recommended Spare Stock . . . . .            | 115 |
| 8.5 | Troubleshooting . . . . .                    | 121 |
| 8.6 | Cold Start Procedure . . . . .               | 125 |

## **Appendix A: Signal Diagrams**

|     |                           |     |
|-----|---------------------------|-----|
| A.1 | Signal Diagrams . . . . . | 128 |
|-----|---------------------------|-----|

# List of Figures

## Chapter 1: Safety and Support

|            |   |   |
|------------|---|---|
| Figure 1.1 | Safety-related Labels found on the DCX S Power Supply | 4 |
| Figure 1.2 | Safety-related Labels found on the DCX S Power Supply | 5 |

## Chapter 2: Introduction

|            |  |    |
|------------|--|----|
| Figure 2.1 | The DCX S Power Supply                                 | 15 |
| Figure 2.2 | DCX S Power Supply Front Panel Controls and Indicators | 20 |
| Figure 2.3 | LCD Description  | 22 |
| Figure 2.4 | DCX S Power Supply Back Panel                          | 24 |

## Chapter 3: Delivery and Handling

## Chapter 4: Technical Specifications

|            |                           |    |
|------------|---------------------------|----|
| Figure 4.1 | Declaration of Conformity | 39 |
|------------|---------------------------|----|

## Chapter 5: Installation and Setup

|             |  |    |
|-------------|--|----|
| Figure 5.1  | DCX S Power Supply Dimensional Drawing (Small)       | 44 |
| Figure 5.2  | DCX S Power Supply Dimensional Drawing (Medium)      | 45 |
| Figure 5.3  | DCX S Power Supply Dimensional Drawing (Large)       | 46 |
| Figure 5.4  | LCD Viewing Angle                                    | 49 |
| Figure 5.5  | DCX S Power Supply Connections                       | 50 |
| Figure 5.6  | Input Power Connector                                | 51 |
| Figure 5.7  | User I/O Cable Identification and Wire Color Diagram | 53 |
| Figure 5.8  | Typical Digital I/O Wiring Examples                  | 58 |
| Figure 5.9  | Typical Analog I/O Wiring Examples                   | 58 |
| Figure 5.10 | RF Cable Connection                                  | 59 |
| Figure 5.11 | Assembling the Acoustic Stack                        | 63 |
| Figure 5.12 | Connecting Tip to Horn                               | 65 |

## Chapter 6: Converters and Boosters

|            |   |    |
|------------|---|----|
| Figure 6.1 | 20 kHz typical Converter Dimensions               | 73 |
| Figure 6.2 | 20 kHz Booster Dimensions                         | 74 |
| Figure 6.3 | 20 kHz Converter/Booster/Horn, Typical Dimensions | 75 |
| Figure 6.4 | 30 kHz Converter Dimensions                       | 76 |
| Figure 6.5 | 30 kHz Booster Dimensions                         | 77 |
| Figure 6.6 | 30 kHz Converter/Booster/Horn, Typical Dimensions | 78 |
| Figure 6.7 | 40 kHz, 4TR Converter Dimensions                  | 79 |
| Figure 6.8 | 40 kHz Booster Dimensions                         | 80 |
| Figure 6.9 | 40 kHz Converter/Booster/Horn, Typical Dimensions | 81 |

## Chapter 7: Operation

|            |   |     |
|------------|---|-----|
| Figure 7.1 | LCD at Power Up                             | 87  |
| Figure 7.2 | LCD when in External Amplitude Control Mode | 88  |
| Figure 7.3 | Test Connections                            | 104 |

## Chapter 8: Maintenance

|            |                                      |     |
|------------|--------------------------------------|-----|
| Figure 8.1 | Reconditioning Stack Mating Surfaces | 110 |
|------------|--------------------------------------|-----|

## Appendix A: Signal Diagrams

|            |                           |     |
|------------|---------------------------|-----|
| Figure A.1 | Continuous Mode . . . . . | 128 |
|------------|---------------------------|-----|



# List of Tables

## Chapter 1: Safety and Support

|           |  |    |
|-----------|--|----|
| Table 1.1 | Authorized Service Center (North America)  | 8  |
| Table 1.2 | Authorized Service Centers (South America) | 8  |
| Table 1.3 | Authorized Service Centers (Asia)          | 9  |
| Table 1.4 | Authorized Service Centers (Europe)        | 10 |

## Chapter 2: Introduction

|           |  |    |
|-----------|--|----|
| Table 2.1 | Models Covered in this manual                          | 14 |
| Table 2.2 | Power Supply Compatibility with Branson Converters     | 16 |
| Table 2.3 | Control Features                                       | 17 |
| Table 2.4 | DCX S Power Supply Front Panel Controls and Indicators | 20 |
| Table 2.5 | LCD Description  | 22 |
| Table 2.6 | Connections to the DCX S Power Supply                  | 24 |
| Table 2.7 | Glossary   | 26 |

## Chapter 3: Delivery and Handling

|           |  |    |
|-----------|--|----|
| Table 3.1 | Shipping Specifications                            | 30 |
| Table 3.2 | Inspect the power supply                           | 31 |
| Table 3.3 | Unpacking the power supply                         | 32 |
| Table 3.4 | Small Parts included (=x): Power Supply Assemblies | 33 |
| Table 3.5 | DCX S Power Supply System Cables                   | 33 |

## Chapter 4: Technical Specifications

|           |  |    |
|-----------|--|----|
| Table 4.1 | Environmental Specifications                 | 36 |
| Table 4.2 | Electrical Input Operating Voltages          | 36 |
| Table 4.3 | Input Current and Fuse Specifications        | 36 |
| Table 4.4 | Continuous Duty Max. Power                   | 37 |
| Table 4.5 | Dimensions and Weights of DCX S Power Supply | 38 |

## Chapter 5: Installation and Setup

|            |  |    |
|------------|--|----|
| Table 5.1  | Environmental Requirements                       | 47 |
| Table 5.2  | Input Current and Circuit Breaker Specifications | 47 |
| Table 5.3  | DCX S Power Supply Connections                   | 50 |
| Table 5.4  | Input Power Connector                            | 51 |
| Table 5.5  | User I/O Cable                                   | 53 |
| Table 5.6  | User I/O Cable Pin Assignments                   | 54 |
| Table 5.7  | Default User I/O Connector Pin Assignments       | 55 |
| Table 5.8  | Available Digital Input Functions                | 56 |
| Table 5.9  | Available Digital Output Functions               | 56 |
| Table 5.10 | Available Analog Input Functions                 | 57 |
| Table 5.11 | Available Analog Output Functions                | 57 |
| Table 5.12 | RF Cable Connection                              | 59 |
| Table 5.13 | Input Power Connection                           | 60 |
| Table 5.14 | Acoustic Stack Description                       | 63 |
| Table 5.15 | Stack Torque Values                              | 63 |
| Table 5.16 | Tools  | 64 |
| Table 5.17 | 20 kHz System                                    | 64 |
| Table 5.18 | 30 kHz System                                    | 64 |
| Table 5.19 | 40 kHz System                                    | 65 |

|            |   |    |
|------------|---|----|
| Table 5.20 | Tip to horn torque values. . . . .                          | 65 |
| Table 5.21 | Continuous Duty Max. Power & Full Power Duty Cycle. . . . . | 66 |
| Table 5.22 | Converter Cooling Procedure . . . . .                       | 67 |

## Chapter 6: Converters and Boosters

|           |   |    |
|-----------|---|----|
| Table 6.1 | 20 kHz Converter . . . . .              | 73 |
| Table 6.2 | 20 kHz Booster. . . . .                 | 74 |
| Table 6.3 | 20 kHz Converter/Booster/Horn . . . . . | 75 |
| Table 6.4 | 30 kHz Converter . . . . .              | 76 |
| Table 6.5 | 30 kHz Booster. . . . .                 | 77 |
| Table 6.6 | 30 kHz Converter/Booster/Horn . . . . . | 78 |
| Table 6.7 | 40 kHz, 4TR Converter . . . . .         | 79 |
| Table 6.8 | 40 kHz Booster. . . . .                 | 80 |
| Table 6.9 | 40 kHz Converter/Booster/Horn . . . . . | 81 |

## Chapter 7: Operation

|            |  |     |
|------------|--|-----|
| Table 7.1  | Setting the Amplitude Using the Front Panel Controls . . . . .         | 87  |
| Table 7.2  | Resetting the DCX S Power Supply . . . . .                             | 89  |
| Table 7.3  | Steps to Configure the Power Supply Registers . . . . .                | 90  |
| Table 7.4  | Power Supply Registers . . . . .                                       | 92  |
| Table 7.5  | Power Bar-Graph Interpretation Examples. . . . .                       | 94  |
| Table 7.6  | Frequency Bar-Graph Interpretation - 20 kHz (50 Hz Segment) . . . . .  | 95  |
| Table 7.7  | Frequency Bar-Graph Interpretation - 30 kHz (76 Hz Segment) . . . . .  | 95  |
| Table 7.8  | Frequency Bar-Graph Interpretation - 40 kHz (100 Hz/Segment) . . . . . | 96  |
| Table 7.9  | Frequency Bar-Graph Interpretation Examples. . . . .                   | 96  |
| Table 7.10 | Power Supply Ultrasonic Test Procedure (Front Panel). . . . .          | 103 |
| Table 7.11 | Power Supply Ultrasonic Test Procedure (User I/O). . . . .             | 104 |

## Chapter 8: Maintenance

|            |   |     |
|------------|---|-----|
| Table 8.1  | Stack Reconditioning Procedure . . . . .                    | 109 |
| Table 8.2  | Reconditioning Stack Mating Surfaces . . . . .              | 110 |
| Table 8.3  | Stack Torque Values . . . . .                               | 111 |
| Table 8.4  | Stack Reassembly for a 20 kHz System. . . . .               | 111 |
| Table 8.5  | Stack Reassembly for a 30 kHz System. . . . .               | 112 |
| Table 8.6  | Stack Reassembly for a 40 kHz System. . . . .               | 112 |
| Table 8.7  | Stud Torque Values. . . . .                                 | 113 |
| Table 8.8  | DCX S Power Supply System Cables . . . . .                  | 115 |
| Table 8.9  | Suggested Spares. . . . .                                   | 116 |
| Table 8.10 | Converters Compatible with the DCX S Power Supply . . . . . | 117 |
| Table 8.11 | DCX S Power Supply Compatible Boosters . . . . .            | 118 |
| Table 8.12 | Other Items used with the DCX S Power Supply. . . . .       | 120 |
| Table 8.13 | Troubleshooting . . . . .                                   | 121 |
| Table 8.14 | Troubleshooting Common Electrical Problems. . . . .         | 122 |
| Table 8.15 | Troubleshooting Ultrasonic Power Problems . . . . .         | 123 |
| Table 8.16 | Troubleshooting Weld Cycle Problems . . . . .               | 124 |
| Table 8.17 | Steps to Perform a Cold Start. . . . .                      | 125 |

## Appendix A: Signal Diagrams

---

# Chapter 1: Safety and Support

---





|     |  |   |
|-----|--|---|
| 1.1 | Safety Requirements and Warnings . . . . . | 2 |
| 1.2 | General Precautions . . . . .              | 6 |
| 1.3 | How to Contact Branson . . . . .           | 8 |




## 1.1 Safety Requirements and Warnings

This chapter contains an explanation of the different Safety Notice symbols and icons found both in this manual and on the product itself and provides additional safety information for ultrasonic welding. This chapter also describes how to contact Branson for assistance.

### 1.1.1 Symbols Found in this Manual

These symbols used throughout this manual warrant special attention:



|   |   |
|---|---|
| <b>WARNING</b>  | <b>Indicates a possible danger</b>  |
|    | If these risks are not avoided, death or severe injury might result.          |
| <b>WARNING</b>  | <b>High Voltage Hazard</b>  |
|   | High voltage. Turn power off before servicing.                                |
| <b>WARNING</b>  | <b>Corrosive Material Hazard</b>  |
|  | Corrosive material. Avoid contact with eyes and skin. Wear proper protection. |
| <b>CAUTION</b>  | <b>Indicates a possible danger</b>  |
|  | If these risks are not avoided, slight or minor injury might result.          |

|  |  |
|--|--|
| <b>CAUTION</b>   | <b>Loud Noise Hazard</b>   |
|   | <p>Loud noise hazard. Ear protection must be worn.</p>   |
| <b>CAUTION</b>   | <b>Heavy Object</b>  |
|   | <p>Heavy object. To avoid muscle strain or back injury, use lifting aids and proper lifting techniques.</p>  |
| <b>NOTICE</b>  | <b>Indicates a possible damaging situation</b>   |
|  | <p>If this situation is not avoided, the system or something in its vicinity might get damaged.</p> <p>Application types and other important or useful information are emphasized.</p> |

## 1.1.2 Symbols Found on the Product

The DCX S Power Supply has several safety-related labels on it to indicate the presence of hazardous voltages inside the unit.

**Figure 1.1** Safety-related Labels found on the DCX S Power Supply




**Figure 1.2** Safety-related Labels found on the DCX S Power Supply



## 1.2 General Precautions

Take the following precautions before servicing the power supply:

- To prevent the possibility of an electrical shock, always plug the power supply into a grounded power source
- To prevent the possibility of an electrical shock, ground the power supply by securing an AWG #8 grounded conductor to the ground screw located next to the air outlet
- Power supplies produce high voltage. Before working on the power supply assembly, do the following:
  - Turn off the power supply
  - Unplug main power
  - Allow at least 2 minutes for capacitors to discharge
- High voltage is present in the power supply. Do not operate with the cover removed
- High line voltages exist in the ultrasonic power supply assembly. Common points are tied to circuit reference, not chassis ground. Therefore, use only non-grounded, battery-powered multimeters when testing the power supply assembly. Using other types of test equipment can present a shock hazard
- Keep hands from under the horn. Down force (pressure) and ultrasonic vibrations can cause injury
- Do not cycle the welding system if either the RF cable or converter is disconnected
- When using larger horns, avoid situations where fingers could be pinched between the horn and the fixture
- Ensure power supply installation is performed by qualified personnel and in accordance with local standards and regulations

| CAUTION   | Loud Noise Hazard  |
|---|--|
|  | <p>Sound level and frequency of the noise emitted during the ultrasonic assembly process may depend upon a. type of application, b. size, shape and composition of the material being assembled, c. shape and material of the holding fixture, d. welder setup parameters and e. tool design.</p> <p>Some parts vibrate at an audible frequency during the process. Some or all of these factors may result in an uncomfortable noise being emitted during the process.</p> <p>In such cases operators may need to be provided with personal protective equipment. See 29 CFR (Code of Federal Regulations) 1910.95 Occupational Noise Exposure.</p> |



### 1.2.1 Intended Use of the System


The DCX S Power Supply and components are designed to be used as part of an ultrasonic welding system. These are designed for a wide variety of welding or processing applications.

If the equipment is used in a manner not specified by Branson, the protection provided by the equipment may be impaired.

Branson Ultrasonics Corporation designs and manufactures machines giving the first priority to safety precautions, to allow customers to use the machines safely and effectively. Only trained operators should run and service the equipment. Untrained operators can misuse the equipment or ignore safety instructions that can result in personal injury or equipment damage. It is most essential that all operators and service personnel pay attention to safety instructions when operating and servicing the equipment.

### 1.2.2 Emissions

Because of the various types of toxic or injurious gases that may be liberated during the welding based on the material being processed, sufficient ventilation should be provided to prevent a concentration of these gases in excess of 0.1 ppm. Check with your materials suppliers for recommended protection when processing their materials.

| CAUTION  | Corrosive Material Hazard  |
|--|--|
|  | <p>Processing of many materials, such as PVC, can be hazardous to an operator's health and could cause corrosion/damage to the equipment. Use proper ventilation and take protective measures.</p> |

### 1.2.3 Setting up the Workplace

Measures for setting up a workplace for safe operation of the ultrasonic welder are outlined in [Chapter 5: Installation and Setup](#)

### 1.2.4 Regulatory Compliance

This product meets electrical safety requirements and EMC (Electromagnetic Compliance) requirements for North America and the European Union.

## 1.3 How to Contact Branson

Branson is here to help you. We appreciate your business and are interested in helping you successfully use our products. To contact Branson for help, use the following telephone numbers, or contact the office nearest you.

### 1.3.1 Authorized Service Center (North America)

**Table 1.1** Authorized Service Center (North America)

| Name  | Address                                     | Tel/Fax Number   |
|---|---|--|
| Branson Ultrasonics Corp.<br>Global Headquarters<br>United States | 120 Park Ridge Road<br>Brookfield, CT 06804 | Tel: 1-203-796-0400<br>Fax: 1-203-796-0593<br><a href="mailto:info@bransonultrasonics.com">info@bransonultrasonics.com</a> |

### 1.3.2 Authorized Service Centers (South America)

**Table 1.2** Authorized Service Centers (South America)

| Name                        | Address                                      | Tel/Fax Number                                       |
|-----------------------------|--|--|
| Intersonic<br>Argentina     | Av. Cramer 2361 1C<br>Buenos Aires 1428      | Tel: 011-54-11-4781-2327<br>Fax: 011-54-11-4782-2412 |
| Branson do Brasil<br>Brasil | Rua Goiatuba, 81<br>06465-300 – Barueri / SP | Tel: 55-11-4208-1652                                 |

### 1.3.3 Authorized Service Centers (Asia)

**Table 1.3** Authorized Service Centers (Asia)

| Name  | Address   | Tel/Fax Number   |
|---|---|--|
| Branson Ultrasonics (Shanghai) Co. Ltd. – China Headquarters<br>China               | 528 Rong Le Dong Road,<br>Song Jiang<br>Song Jiang Industry Zone<br>CN-Shanghai, 201613 PRC                                   | Tel: 86-21-3781-0588<br>Fax: 86-21-5774-5100<br><a href="mailto:c.service@emerson.com">c.service@emerson.com</a> |
| Branson Ultrasonics Co. Ltd. Beijing Office   | Room 216, Flat B, 12 Hong Da North Road,<br>Chuangxin Technological Mansion Beijing<br>Department Area.<br>Beijing 100176 PRC | Tel: 86-10-6787-7806<br>Fax: 86-10-6787-3378   |
| Branson Ultrasonics Co. Ltd. Tianjin Office   |   | Tel: 86-22-2732-5233<br>Fax: 86-22-2732-3581   |
| Branson Ultrasonics Co. Ltd. Dongguan Office  |   | Tel: 86-769-8541-0736<br>Fax: 86-769-8541-0735   |
| Branson Ultrasonics Co. Ltd. Suzhou Office  |   | Tel: 86-512-6295-3652<br>Fax: 86-512-6295-3651   |
| Branson Ultrasonics Asia Pacific Co. Ltd.<br>Hong Kong Office                       | Flat A, 5/F Pioneer Building<br>213 Wai Yip Street, Kwung Tong<br>Kowloon, Hong Kong  | Tel: 852-2790-3393<br>Fax: 852-2341-2716<br><a href="mailto:info@emerson.com">info@emerson.com</a>               |
| Branson Ultrasonics<br>Div. of Emerson Electric Co. P. Ltd. "Ajanta House"<br>India | 8/35, Marol Co-Op Industrial Estate<br>M.V. Road, Andheri (East)<br>Mumbai 400 059, India                                     | Tel: 91-22-2850-5570<br>Fax: 91-22-2850-8681   |
| Branson Ultrasonics<br>Japan Headquarters<br>Division of Emerson Japan Ltd.         | 4-3-14 Okada, Atsugi-Shi<br>Kanagawa 243-0021<br>Japan  | Tel: 81-46-228-2881<br>Fax: 81-46-288-8892   |
| Branson Korea Co., Ltd.<br>Korea  | #803, 8F Dongil Techno Town<br>823, Kwan Yang-2dong,<br>Dong An-gu<br>An Yang-si, Kyung Ki-do,<br>431-062 Korea               | Tel: 82-1577-0631<br>Fax: 82-31-422-9572   |

**Table 1.3** Authorized Service Centers (Asia)

| Name  | Address   | Tel/Fax Number   |
|---|---|--|
| Branson Ultrasonics<br>Div. of Emerson Elec (M)<br>Sdn Bhd.<br>Malaysia | No. 20, Jalan Rajawali 3,<br>Puchong Jaya Industrial<br>Park<br>Batu 8, Jalang Puchong<br>47170 Puchong, Selangor<br>Malaysia                               | Tel: 603-8076-8608<br>Fax: 603-8076-8302                             |
| Branson Ultrasonics<br>Philippines                                      | Emerson Building<br>104 Laguna Blvd.<br>Laguna Technopark Inc.<br>Sta. Rosa, Laguna, 4026<br>Philippines  | Tel: 63-49-502-8860<br>Fax: 63-49-502-8860<br>Mobile: 63-917-5372072 |
| Branson Ultrasonics<br>Singapore  | 10 Pandan Crescent<br>#03-06 UE Tech Park LL3<br>Singapore 128466   | Tel: 65-6891-7600<br>Fax: 65-6873-7882                               |
| Branson Ultraschall<br>Taiwan   | Div. of Emerson Electric<br>(Taiwan) Co. Ltd.<br>5F-3, No. 1, Wu-Chiuan<br>First Road<br>Wu-Ku Ind Zone, Hsin-<br>Chuang City<br>Taipei Hsien 24892, Taiwan | Tel: 886-2-2298-0828<br>Fax: 886-2-2298-9985                         |
| Emerson Limited<br>Thailand   | 662/39-40 Rama 3 Road<br>Bangpongpan, Yannawa<br>Bangkok 10120, Thailand  | Tel: 66-2-293-01217<br>Fax: 66-2-293-0129                            |

## 1.3.4 Authorized Service Centers (Europe)

**Table 1.4** Authorized Service Centers (Europe)

| Name                                  | Address   | Tel/Fax Number                               |
|---------------------------------------|---|--|
| Branson Ultraschall<br>Czech Republic |   | Tel: 420-374-625-620<br>Fax: 420-374-625-617 |
| Branson Ultrasonics<br>France         | 1 Rue des Pyrenees Silic<br>404<br>94573 Rungis Cedex<br>France | Tel: 33-1-4180-2550<br>Fax: 33-1-4687-8729   |

**Table 1.4** Authorized Service Centers (Europe)

| Name  | Address   | Tel/Fax Number  |
|---|---|---|
| Branson Ultraschall<br>European Headquarters<br>Germany | Niederlassung der<br>EMERSON Technologies<br>GmbH & Co. OHG<br>Waldstraße 53-55<br>63128 Dietzenbach,<br>Germany  | Tel: 49 (0)6074/497-0<br>Tel: 49 (0)6074/497-784<br>Fax: 49 (0)6074/497-199<br><a href="mailto:info@branson.de">info@branson.de</a> |
| Branson Ultrasuoni, S.r.l.<br>Italy                     | Via Dei Lavoratori, 25<br>20092 Cinisello Balsamo<br>Milano, Italy  | Tel: 39-02-660-8171<br>Fax: 39-02-660-10480   |
| Branson Ultrasonics B.V.<br>Netherlands                 | P.O. Box 9, 3760 Soest<br>The Netherlands   | Tel: 31-35-60-98101   |
| Branson Ultrasonidos<br>S.A.E.<br>Portugal              | Rua General Orlando<br>Barbosa 74, RC-NP<br>4490-640 Póvoa de Varzim<br>Portugal  | Tel: 351-936-059-080<br>Mobil: 351-252-101-754  |
| Emerson a.s., division<br>Branson<br>Slovakia           | Piestandska 1202/44<br>91528 Nove Mesto Nad<br>Vahom<br>Slovak Republic   | Tel: 421-32-7700-501<br>Fax: 421-32-7700-470  |
| Branson Ultrasonidos<br>S.A.E.<br>Spain                 | Edificio Emerson<br>C/Can Pi, 15 1ª Planta<br>(Antigua Carretera del<br>Prat)<br>Polígono Industrial Gran<br>Vía Sur<br>08908 HOSPITALET DE<br>LLOBREGAT (BARCELONA)<br>Spain | Tel: 34-93-586-0500<br>Fax: 34-93-588-2258  |
| Branson Ultrasonics S.A.<br>Switzerland                 | Sonifers: Case Postale<br>1031<br>Bransonics: Chemin du<br>Faubourg-de-Cruseilles 9<br>CH 1227, Carouge,<br>Switzerland   | Tel: 41-22-304-8340<br>Tel: 41-58-611-1222<br>Fax: 41-22-304-8359   |
| Branson Ultrasonics<br>United Kingdom                   | 158 Edinburgh Avenue<br>Slough, Berkshire<br>England SL1 4UE  | Tel: 44-1753-756675<br>Fax: 44-1753-551270  |

**Table 1.4** Authorized Service Centers (Europe)

| <b>Name</b>                  | <b>Address</b>  | <b>Tel/Fax Number</b>                           |
|------------------------------|---|---|
| Branson Ultraschall<br>Rusia | Torfyanaya road, 7F<br>197374, Saint-Petersburg<br>Russia | Tel: 7-812-449-35-24<br>Mobile: 7-962-693-77-12 |

---

## Chapter 2: Introduction

---

|     |   |    |
|-----|---|----|
| 2.1 | Models Covered . . . . .                            | 14 |
| 2.2 | Compatibility with other Branson Products . . . . . | 16 |
| 2.3 | Features . . . . .                                  | 17 |
| 2.4 | Controls and Indicators . . . . .                   | 20 |
| 2.5 | Welding Systems . . . . .                           | 25 |
| 2.6 | Glossary . . . . .                                  | 26 |

## 2.1 Models Covered

This manual covers all models of the DCX S Power Supply.

**Table 2.1** Models Covered in this manual

| Frequency | Power  | EDP          |
|-----------|--------|--------------|
| 20 kHz    | 1250 W | 101-132-2072 |
|           | 2500 W | 101-132-2073 |
|           | 4000 W | 101-132-2074 |
| 30 kHz    | 1500 W | 101-132-2071 |
| 40 kHz    | 800 W  | 101-132-2070 |



## 2.1.1 Overview of these Models

**Figure 2.1** The DCX S Power Supply



The DCX S Power Supply generates ultrasonic energy through an ultrasonic converter for welding plastics. Several models are available, depending on the desired frequency (for example, 20 kHz) and the desired power range (for example, 4.0 kW). The power supply also contains a microprocessor-based controller module that provides for control and monitoring of welding operations.

The power supply provides the following features:

**End of Weld Store:** Allows the power supply to track and store the frequency of the last weld.

**Timed Seek:** Tracks and starts the stack on the correct frequency. It does this by running the horn at a low-level amplitude (10%) to find and lock on to the stack operating frequency. Seeks are timed from the moment sonics was last activated.

**Line Regulation:** Maintains converter amplitude by regulating for variances in the line voltages.

**Load Regulation:** Maintains converter amplitude over the full range of rated power.

**System Protection:** Protects the power supply by providing five levels of protection.

- Voltage
- Current
- Phase
- Temperature
- Power
- Frequency

**Web Page Interface:** Provides access, via Ethernet connection, to power supply information, diagnostics, and configuration web pages.


**Frequency Offset:** Provides for applying an external frequency offset to the operating frequency.

**Amplitude Control:** Provides complete control of amplitude throughout the weld cycle: programmable starting ramp, and digital setting of weld amplitude.

## 2.2 Compatibility with other Branson Products

**Table 2.2** Power Supply Compatibility with Branson Converters

| DCX S Models | Converter           |
|--------------|---------------------|
| 20 kHz       | CR-20               |
|              | CR-20S              |
|              | CR-20C              |
|              | CH-20S (932 AH SPL) |
|              | CH-20C              |
|              | CS-20S              |
|              | CS-20C              |
| 30 kHz       | CR-30S              |
|              | CR-30C              |
|              | CH-30S              |
|              | CH-30C              |
|              | CS-30S              |
|              | CS-30C              |
| 40 kHz       | CR-40S (4TH)        |
|              | CR-40C              |
|              | 4TP                 |
|              | 4TR                 |

| NOTICE  |   |
|---|---|
|  | <p>Special adaptor cables are available to connect to MS-style converters (CR20 and 4TR). See <a href="#">Table 8.8 DCX S Power Supply System Cables</a>.</p> |

## 2.3 Features

### 2.3.1 The Welding System

The welding system consists of a DCX S Power Supply and a converter-booster-horn stack. The system can perform ultrasonic welding, inserting, staking, spot welding, swaging, degating, and continuous ultrasonic operations. It is designed for automated, semi-automated and/or manual production operations.

### 2.3.2 The Power Supply

The DCX S Power Supply consists of an ultrasonic power supply assembly with a system controller and user interfaces. The ultrasonic power supply assembly converts conventional 50/60 Hz line current to 20 kHz, 30 kHz or 40 kHz electrical energy. The system controller controls the welding system.

Listed below are the control features of the DCX S Power Supply ultrasonic welding system:

**Table 2.3** Control Features

| Name                         | Description   |
|------------------------------|---|
| Autotuning                   | Branson power supply tuning ensures that the system is running at peak efficiency.  |
| Digital Amplitude Setting    | This feature allows you to set the exact amplitude necessary for your application, allowing increased range and setting repeatability over analog systems.  |
| Frequency Offset             | This process feature allows a user to set an offset relative to the starting frequency, for certain specific applications, where the force imparted on the fixture or anvil causes a frequency shift in the stack's operation. You should only use this feature when advised to do so by Branson. |
| Horn Signature               | Using the DCX S Power Supply Web Page Interface, you may scan your ultrasonic stack to view its operating frequency on your computer, using digital readouts to give you the best picture of the stack's operation.   |
| LCD (Liquid Crystal Display) | Provides a clear visual interface to monitor and configure the system.  |
| Line Regulation              | Maintains converter amplitude by regulating for variances in the line voltages.   |
| Load Regulation              | Maintains converter amplitude over the full range of rated power.   |
| Membrane Keys                | Front panel controls are designed for high reliability and immunity from factory dust and oils.   |
| User ID and Passcodes        | Allows for keeping track of user access to the DCX S Power Supply Web Page Interface.   |
| Ramp Starting                | The starting of the DCX S Power Supply and horn is done at a rate that helps reduce electrical and mechanical stress on the system. The horn start rate may be adjusted for some tough-to-start applications.   |

**Table 2.3** Control Features

| Name                 | Description  |
|----------------------|--|
| Seek                 | Ensures operation at resonance; minimizes tuning errors; and operates the stack at low amplitude (10%), then provides a means of sensing and storing the resonant operating frequency value.                                   |
| Start-up Diagnostics | At start-up, the controls test the major internal components.  |
| System Protection    | Protects the power supply by providing six levels of protection: voltage, current, phase, temperature, power, and frequency.   |
| Timed Seek           | When enabled, will do a Seek once every minute to update horn resonant frequency to memory. This is especially useful when the welding process affects the actual temperature of the horn, causing a resonant frequency shift. |
| True Watt-meter      | The controls on the power supply include a true watt-meter for accurate measurement of power and energy.   |
| Web Page Interface   | Provides access, via Ethernet connection, to power supply information, diagnostics, and configuration web pages.   |

### 2.3.3 The Actuator

The DCX S Power Supply does not provide actuator control functions, and does not interface with actuator signals.

### 2.3.4 Converter/Booster/Horn Assembly

#### The Converter

The ultrasonic electrical energy from the power supply is applied to the converter (sometimes called the transducer). This transforms the high frequency electrical oscillations into mechanical vibrations at the same frequency as the electrical oscillations. The heart of the converter is piezoelectric ceramic elements. When subjected to an alternating voltage, these elements alternately expand and contract, resulting in better than 90% conversion of electrical to mechanical energy.

#### The Booster

Success in ultrasonic assembly depends on the right amplitude of movement at the horn face. Amplitude is a function of horn shape, which is largely determined by the size and form of the parts to be assembled. The booster can be used as a mechanical transformer to increase or decrease the amplitude of vibrations applied to the parts through the horn.

The booster is a resonant half-wave section of aluminum or titanium. It is mounted between the converter and the horn, as part of the ultrasonic stack. It also provides a clamping point for rigid stack mounting.

Boosters are designed to resonate at the same frequency as the converter with which they are used. Boosters are usually mounted at a nodal (minimum vibration) point of axial motion. This minimizes the loss of energy and prevents vibration from being transmitted to the stack supporting structure.

#### The Horn

The horn is selected or designed for a specific application. Each horn is tuned typically as a half-wave section that applies the necessary force and vibration uniformly to the parts to be assembled. It transfers ultrasonic vibrations from the converter to the workpiece. The horn is mounted to the booster as part of the ultrasonic stack.

Depending on their profile, horns are referred to as stepped, conical, exponential, bar, or catenoidal. The shape of the horn determines the amplitude at the face of the horn. Depending on the application, horns can be made from titanium alloys, aluminum, or steel. Titanium alloys are the best materials for horn fabrication due to their high level of strength and low loss. Aluminum horns are usually chrome- or nickel-plated or hard-coated to reduce wear. Steel horns are for low amplitude requiring hardness, such as ultrasonic insertion applications.




## 2.4 Controls and Indicators

### 2.4.1 DCX S Power Supply Front Panel

Figure 2.2 DCX S Power Supply Front Panel Controls and Indicators



Table 2.4 DCX S Power Supply Front Panel Controls and Indicators

| Reference   | Description  |
|---|--|
|  | <p><b>LCD</b></p> <p>For detailed information refer to <a href="#">Figure 2.3 LCD Description</a> and <a href="#">Table 2.5 LCD Description</a>.</p>   |
|  | <p><b>Up/Down Keys</b></p> <p>Use to adjust the amplitude of ultrasonic vibrations (10% to 100%). Also used to adjust weld mode parameters, select registers and edit register values.</p>   |
|  | <p><b>Alarm Reset Key</b></p> <p>Use the Reset key to reset alarms.</p> <p>When changing system registers, use the Reset key to set a register back to its default value after entering the register and before editing the value.</p> |

**Table 2.4** DCX S Power Supply Front Panel Controls and Indicators






| Reference   | Description   |
|---|---|
|    | <p><b>Configuration Key</b></p> <p>Use the Configuration key to change system registers. Registers are used to change system parameters. For information on using the Configuration key to set system registers see <a href="#">7.4 Configuring the Power Supply Registers</a>.</p> |
|    | <p><b>Ultrasonics Test Key</b></p> <p>Use the Test key to perform an ultrasonic test. Test performs a seek and then ramps the amplitude to the current setting.</p>   |
|    | <p><b>Ethernet Port</b></p> <p>Use the Ethernet Port to connect to the DCX S Power Supply Web Page Interface.</p>   |
|  | <p><b>Power-On Indicator</b></p> <p>Lights when the power supply is connected to main power.</p>  |
|  | <p><b>24 V Indicator</b></p> <p>Lights when 24 V DC are supplied to the DCX S Power Supply.</p>   |

Figure 2.3 LCD Description




Table 2.5 LCD Description









| Reference   | Description  |
|---|--|
|   | <p><b>Numeric Display</b></p> <p>Displays the Power Supply amplitude settings, register numbers, register values or alarm numbers.</p>   |
|  | <p><b>Continuous Mode Icon</b></p> <p>Indicates the power supply is running in Continuous mode. When in Continuous mode, the amplitude setting is shown on the numeric display in conjunction with the % icon. The amplitude setting may range from 10% to 100%. For more information see <a href="#">Chapter 7: Operation</a>.</p>      |
|  | <p><b>Circle Icon</b></p> <p>Indicates that the value shown on the numeric display is a register value. Use up and down keys to modify the register value. For more information see <a href="#">7.4 Configuring the Power Supply Registers</a>.</p>  |
|  | <p><b>Number Sign Icon</b></p> <p>Indicates that the value shown on the numeric display is a register number. Use up and down keys to select a register. For more information see <a href="#">7.4 Configuring the Power Supply Registers</a>.</p>  |
|  | <p><b>Percentage Icon</b></p> <p>Indicates that the value shown on the numeric display represents a percentage. When in Peak Power mode, the value shown on the numeric display represents a percentage of the power supply rated power. If not in Peak Power mode, the value shown on the numeric represents the amplitude setting.</p> |



Table 2.5 LCD Description

| Reference  | Description  |
|--|--|
|   | <p><b>Sonics Active Indicator</b><br/>Indicates ultrasonics is running.</p>  |
|   | <p><b>Power/Frequency Bar-Graph</b><br/>Shows the true percentage of ultrasonic power during a weld cycle. The bar-graph can be configured to show the peak power or the memory frequency at the end of each weld or test cycle. For instructions on how to modify this setting see <a href="#">7.4 Configuring the Power Supply Registers</a>.<br/>For detailed bar-graph description and bar-graph reading examples, see <a href="#">7.5.2 Frequency Bar-Graph Interpretation</a>.</p> |
|  | <p><b>Alarm Icon</b><br/>A flashing icon which indicates an alarm condition.</p>   |

## 2.4.2 DCX S Power Supply Connections

Figure 2.4 DCX S Power Supply Back Panel




Table 2.6 Connections to the DCX S Power Supply

| Item | Name                 | Function  |
|------|----------------------|---|
| 1    | Line Input Connector | Detachable connector block for connecting the input power. For wiring details refer to <a href="#">Chapter 5: Installation and Setup</a> .  |
| 2    | User I/O Connector   | Provides the necessary input/output signals to interface with user automation or control interfaces. For detailed information on interfacing with the DCX S Power Supply refer to <a href="#">Chapter 5: Installation and Setup</a> . |
| 3    | RF Connector         | SHV connector for RF cable, which provides ultrasonic energy to the converter.  |

## **2.5 Welding Systems**

### **2.5.1 Principle of Operation**

Thermoplastic parts are welded ultrasonically by applying high frequency vibrations to the parts being assembled. The vibrations, through surface and intermolecular friction, produce a sharp rise in temperature at the welding interface.

When the temperature is high enough to melt the plastic, there is a flow of material between the parts. When the vibrations stop, the material solidifies under pressure and a weld results.

### **2.5.2 Weld System Applications**

DCX S Power Supply weld systems can be used for the following applications:

- Ultrasonic welding
- Cutting and sealing thermoplastic fabric and film
- Staking, spot welding, swaging, and degating thermoplastic parts
- Other ultrasonic processing applications

DCX S Power Supply weld systems typically consist of a power supply operated with a fixed converter-booster-horn stack.

## 2.6 Glossary

The following terminology may be encountered when using or operating a DCX S Power Supply ultrasonic welding system.

**Table 2.7** Glossary

| Name                       | Description  |
|----------------------------|--|
| Actuator                   | The unit which houses the converter/booster/horn stack assembly in a rigid mounting, allowing the stack to move up and down, either mechanically or pneumatically, applying force to the part at a user-adjustable force and velocity.   |
| Alarm                      | Visual indication of error.  |
| Amplitude Control          | The ability to set amplitude digitally or by an external control.  |
| Amplitude                  | The peak-to-peak movement at the horn face. Always expressed as a percentage of the maximum.   |
| Booster                    | A one-half-wavelength-long resonant metal section mounted between the converter and horn, sometimes having a change in cross-sectional area between the input and output surfaces. The booster mechanically alters the amplitude of vibrations received from the converter, and imparts the new amplitude to the horn. |
| Clamping Force             | The pounds or kilograms exerted by the horn onto the workpiece.  |
| Cold Start                 | Restores the settings of the power supply back to its original condition.  |
| Converter                  | The device that converts electrical energy into mechanical vibrations at a high frequency (an ultrasonic rate).  |
| Counters                   | A record of the number of preset cycles recorded in the power supply.  |
| Degating                   | Removing a molded part from its runner system  |
| Energy Director            | A triangular-shaped projection of plastic material which concentrates the ultrasonic energy at the joint interface of a plastic part.  |
| External Amplitude Control | Enables you to access real-time amplitude control directly via the user I/O connector.   |
| External Frequency Control | Enables you to access real-time frequency offset control directly via the user I/O connector.  |
| Fixture                    | A device for holding a part in position for assembly.  |
| Flash                      | Material displaced from the joint area.  |
| Forming                    | Reshaping a section of thermoplastic.  |
| Fretting Corrosion         | A black surface condition, that results from friction between metal parts, that appears on the converter-booster-horn stack mating surfaces.   |
| Frequency                  | The operating frequency of the ultrasonic stack. The frequency stored is measured at the end of the ultrasonic portion of the cycle (when ultrasonics are terminated).   |

Table 2.7 Glossary

| Name               | Description   |
|--------------------|---|
| Frequency Offset   | An offset factor applied to the ultrasonic frequency stored in the power supply.  |
| Gain               | The ratio of output to input amplitude of a horn or booster.  |
| Horn               | A bar or metal section, usually one half-wavelength-long which transfers vibratory energy to the workpiece.   |
| Horn Amplitude     | The peak-to-peak displacement of a horn at its work face.   |
| Horn Signature     | A scan to enhance selection of operating frequency and control parameters.  |
| Insertion          | The process of embedding a metal component in plastic.  |
| Interface          | <ol style="list-style-type: none"> <li>1. The contact surface of two mating parts.</li> <li>2. The connection between two pieces of equipment.</li> </ol>   |
| Joint              | The weld surfaces.  |
| Parameter          | A unique factor or element which affects the welding operation in a particular mode.  |
| Parameter Range    | Valid range of parameters accepted for a particular setup.  |
| Power Supply       | The electronic instrument in an ultrasonic assembly system which changes conventional 50/60 Hz electrical power into high frequency electrical power at 20 kHz, 30 kHz or 40 kHz.   |
| Seek               | The activation of ultrasonics at a low-level (10%) amplitude, for the purpose of finding the resonant frequency of the stack.   |
| Staking            | The process of melting and reforming a plastic stud to mechanically lock a dissimilar material in place.  |
| Swaging            | The process of capturing another component of an assembly by melting and reforming a ridge of plastic.  |
| Thermoplastic      | A polymer which undergoes a reversible change of state when subjected to heat.  |
| Thermoset          | A polymer which undergoes an irreversible change when subjected to heat.  |
| Ultrasonic Power   | Presence of ultrasonic power at the horn face.  |
| Ultrasonic Welding | The use of ultrasonic vibrations to generate heat and subsequently melt the mating surfaces of two thermoplastic parts. When ultrasonic vibrations stop, the molten material resolidifies, and a weld occurs.             |
| User ID            | A unique 12 character long alphanumeric ID used to keep track of user access to the web page interface.   |
| Weld System        | A combination of components required to perform an ultrasonic operation. Usually consists of a power supply, converter, booster, and horn, with either an actuator or a handheld device, or in a fixed, mounted location. |




---

## **Chapter 3: Delivery and Handling**

---

|            |  |           |
|------------|--|-----------|
| <b>3.1</b> | <b>Shipping and Handling</b> . . . . .         | <b>30</b> |
| <b>3.2</b> | <b>Receiving</b> . . . . .                     | <b>31</b> |
| <b>3.3</b> | <b>Unpacking the Power Supply</b> . . . . .    | <b>32</b> |
| <b>3.4</b> | <b>Take Inventory of Small Parts</b> . . . . . | <b>33</b> |
| <b>3.5</b> | <b>Returning Equipment</b> . . . . .           | <b>34</b> |

## 3.1 Shipping and Handling

| CAUTION   | Heavy Object   |
|---|--|
|  | <p>The power supply may be heavy. Handling, unpacking, and installation may require the assistance of a colleague or the use of lifting platforms or hoists.</p> |

### 3.1.1 Environmental Specifications

The DCX S Power Supply is an electronic unit that converts line voltage to ultrasonic energy and responds to user input for regulating the weld process. Its internal components are sensitive to static discharge, and many of its components can be harmed if the unit is dropped, shipped under improper conditions, or otherwise mishandled.

The following environmental guidelines should be respected in the shipping of the power supply.

**Table 3.1** Shipping Specifications

| Environmental Condition        | Acceptable Range  |
|--------------------------------|---|
| Storage / Shipping Temperature | -25° C / -13° F to +55° C / +131° F (+70° C / +158° F for 24 hours)         |
| Shock / Vibration (transit)    | 45 g shock / 0.5 g and (3 to 100 Hz) vibration per ASTM 3332-88 and 3580-90 |
| Drop Test                      | ISTA Procedure 1 & 2A (while packaged)                                      |
| Humidity                       | Maximum 95%, non-condensing   |



## 3.2 Receiving

The DCX S Power Supply is a sensitive electronic device. Many of its components can be harmed if the unit is dropped or otherwise mishandled.


### Scope of Delivery

Branson equipment is carefully checked and packed before dispatch. It is recommended, however, that you follow the procedure below upon receiving your DCX S Power Supply.


### Inspect the Power Supply when it is delivered, take the following steps:

**Table 3.2** Inspect the power supply

| Step | Action   |
|------|--|
| 1    | Verify that all parts are complete according to the packing slip.                              |
| 2    | Check the packing and the unit for damage (visual inspection).                                 |
| 3    | Report any damage claims to your carrier immediately.  |
| 4    | Determine if any component has become loose during shipping and, if necessary, tighten screws. |

| NOTICE  |   |
|---|---|
|  | <p>If the goods delivered have been damaged during shipping, please contact the forwarding agent immediately. Retain packing material (for possible inspection or for sending back the unit).</p> |

## 3.3 Unpacking the Power Supply

| NOTICE  |   |
|---|---|
|  | <p>If there are any visible signs of damage to the shipping containers or the product, or you later discover hidden damage, NOTIFY YOUR CARRIER IMMEDIATELY. Save the packing material.</p> |

The power supply is fully assembled. It is shipped in a sturdy cardboard box. Some additional items are shipped in the box with the power supply. Note orientation of packaging material in case return/repack is necessary. When unpacking the power supply, take the following steps:

**Table 3.3** Unpacking the power supply

| Step | Action  |
|------|---|
| 1    | Unpack the power supply as soon as it arrives. Save the packing material                      |
| 2    | Verify you have all of the equipment ordered. Some components are packed inside other boxes.  |
| 3    | Inspect the controls, indicators, and surface for signs of damage.                            |
| 4    | Remove the cover of the power supply to check if any components became loose during shipping. |

## 3.4 Take Inventory of Small Parts

**Table 3.4** Small Parts included (=x): Power Supply Assemblies

| Part or Kit                    | 20 kHz | 30 kHz | 40 kHz |
|--------------------------------|--------|--------|--------|
| Mylar® plastic film Washer Kit | X      | X      |        |
| Silicone Grease                |        |        | X      |
| Spanners (2)                   | X      | X      | X      |

\* Mylar is a registered trademark of DuPont Teijin Films.

### 3.4.1 Cables

The RF cable connects the power supply to the converter. For automated systems you will also need a user I/O cable to monitor and control the power supply. Check your invoice for cable types and cable lengths.

**Table 3.5** DCX S Power Supply System Cables

| P/N         | Description                                       |
|-------------|---|
| 100-240-383 | Cable, RF 8 ft (2.5 m)                            |
| 100-240-384 | Cable, RF 15 ft (4.5 m)                           |
| 100-240-385 | Cable, RF 25 ft (7.5 m)                           |
| 100-240-387 | Cable, RF right angle 8 ft (2.5 m)                |
| 100-240-388 | Cable, RF right angle 15 ft (4.5 m)               |
| 100-240-389 | Cable, RF right angle 25 ft (7.5 m)               |
| 100-240-391 | Cable, RF adaptor for CR20 converter 3 ft (0.9 m) |
| 100-240-392 | Cable, User I/O 25 ft (7.5 m)                     |
| 200-240-396 | Cable Ethernet Cat 5e 7 ft (2.1 m)                |

## 3.5 Returning Equipment

If you are returning equipment to Branson Ultrasonic Corporation, please call your Customer Service Representative to receive approval to return the goods. Refer to [1.3 How to Contact Branson](#).


---

## Chapter 4: Technical Specifications

---

|            |  |           |
|------------|--|-----------|
| <b>4.1</b> | <b>Technical Specifications . . . . .</b>  | <b>36</b> |
| <b>4.2</b> | <b>Physical Description . . . . .</b>      | <b>38</b> |
| <b>4.3</b> | <b>Declaration of Conformity . . . . .</b> | <b>39</b> |

## 4.1 Technical Specifications

| NOTICE  |  |
|---|--|
|  | All specifications are subject to change without notice. |

### 4.1.1 Environmental Specifications

The DCX S Power Supply has the following environmental specifications:

**Table 4.1** Environmental Specifications

| Environmental Condition        | Acceptable Range                     |
|--------------------------------|--------------------------------------|
| Ambient Operating Temperature  | +41° F to +104° F (+5° C to +40° C)  |
| Storage / Shipping Temperature | -13° F to +131° F (-25° C to +55° C) |
| Operating Altitude             | Up to 6560 ft (2000 m)               |
| Humidity                       | Maximum 95%, non-condensing          |
| IP Rating                      | 2X                                   |

### 4.1.2 Electrical Specifications

The following tables list input voltage and current requirements for the DCX S Power Supply.

**Table 4.2** Electrical Input Operating Voltages

| Power Supply Rating | Input Operating Voltage  |
|---------------------|--|
| All Models          | 200 V to 230 V Nominal (180 V Min.* to 253 V Max.), 50 Hz or 60 Hz, Single Phase |
|                     | 24 VDC, 2.5 A  |

\* 200 V Min. for 4 kW units.

**Table 4.3** Input Current and Fuse Specifications

| Model  | Power  | Current Rating                |
|--------|--------|-------------------------------|
| 20 kHz | 1250 W | 7 A Max. @ 200 V / 15 A Fuse  |
|        | 2500 W | 14 A Max. @ 200 V / 15 A Fuse |
|        | 4000 W | 25 A Max. @ 200 V / 25 A Fuse |

**Table 4.3** Input Current and Fuse Specifications

| Model  | Power  | Current Rating                |
|--------|--------|-------------------------------|
| 30 kHz | 1500 W | 10 A Max. @ 200 V / 15 A Fuse |
| 40 kHz | 800 W  | 5 A Max. @ 200 V / 15 A Fuse  |

**Table 4.4** Continuous Duty Max. Power

| Model  | Power  | Continuous Duty. Max. Power |
|--------|--------|-----------------------------|
| 20 kHz | 1100 W | 330 W                       |
|        | 2200 W | 660 W                       |
|        | 4000 W | 1200 W                      |
| 30 kHz | 1500 W | 460 W                       |
| 40 kHz | 800 W  | 240 W                       |

**NOTICE**


High duty cycles require additional cooling for the converter. For information on converter cooling refer to [5.6 Converter Cooling](#) in [Chapter 5: Installation and Setup](#).

**NOTICE**

System average power must be limited to the specified continuous maximum. Higher peak power, up to the maximum acceptable power limit, with an on time of up to 10 seconds may be obtained if appropriate off time ensures that, on average, the Continuous Duty Maximum Power is not exceeded.

## 4.2 Physical Description

This section describes the physical dimensions of the DCX S Power Supply.

| NOTICE  |                         |
|---|-------------------------|
|  | Dimensions are nominal. |

**Table 4.5** Dimensions and Weights of DCX S Power Supply

| Size   | Width         | Height          | Depth         | Weight          |
|--------|---------------|-----------------|---------------|-----------------|
| Small  | 4.2"<br>106mm | 5.07"<br>128 mm | 22"<br>560 mm | 8 lb<br>3.6 kg  |
| Medium | 5.6"<br>142mm |                 |               | 12 lb<br>5.4 kg |
| Large  | 8.4"<br>213mm |                 |               | 15 lb<br>6.8 kg |

For detailed dimensional information refer to [Chapter 5: Installation and Setup](#).



## 4.3 Declaration of Conformity

Figure 4.1 Declaration of Conformity

DocuSign Envelope ID: B0909E8A-D9E3-4295-81B6-06331CD21321

**EU DECLARATION OF CONFORMITY**  
According to Low Voltage Directive 2014/35/EU,  
EMC Directive 2014/30/EU,  
and RoHS Directive 2011/65/EU.



We, the manufacturer

**BRANSON ULTRASONICS CORPORATION**  
120 Park Ridge Rd.  
Brookfield, CT 06804  
USA

represented in the community by

BRANSON ULTRASONICS, a.s.  
Piestanska 1202  
91501 Nove Mesto nad Vahom  
Slovak Republic

expressly declare under our sole responsibility that the following electrical equipment product:

Ultrasonic Assembly System consisting of an Ultrasonic Power Supply, model:

0.80 DCX(S, A, f-EIP, or f-DP) 40 RACKMT  
1.50 DCX(S, A, f-EIP, or f-DP) 30 RACKMT  
1.25 DCX(S, A, f-EIP, or f-DP) 20 RACKMT  
1.50 DCX(S, A, f-EIP, or f-DP) 20 RACKMT  
4.00 DCX(S, A, f-EIP, or f-DP) 20 RACKMT  
DCX RM 222 STD  
DCX RM 240 STD  
DCX RM 222 B  
DCX RM 240 B  
DCX RM 480 STD  
DCX RM 315 STD  
DCX RM 211 STD  
DCX RM 480 B  
DCX RM 315 B  
DCX RM 211 B  
P/S 2.20 DCX STD 20 SIG

used with converter model: CR-20, CR-20S, CR-20C, CH-20C, CS-20S, CS-20C, CR-30, CR-30C, CH-30, CH-30C, CS-30S, CS-30C, CR-40C, 4TR, 4TH, 4TP or 932, and associated cables.

in the state in which it was placed on the market, fulfills all the relevant provisions of:

Low Voltage Directive **2014/35/EU**  
EMC Directive **2014/30/EU**  
RoHS Directive **2011/65/EU**

The object of this declaration is in conformity with relevant Union harmonization legislation. The electrical equipment product, to which this declaration relates, is in conformity with the following standards:

EN 61010-1:2010+A1:2019  
EN 55011:2016/A11:2020  
EN 61000-6-2:2005/AC:2005

Brookfield, CT, USA  
March 29, 2022

DocuSigned by:  
*Luis Benavides*  
0182358F CDE 147C  
Luis Benavides  
Product safety Officer



---


## Chapter 5: Installation and Setup

---

|     |  |    |
|-----|--|----|
| 5.1 | About Installation. . . . .            | 42 |
| 5.2 | Installation Requirements . . . . .    | 43 |
| 5.3 | Installation Steps . . . . .           | 48 |
| 5.4 | Power Supply Configuration. . . . .    | 61 |
| 5.5 | Assembling the Acoustic Stack. . . . . | 62 |
| 5.6 | Converter Cooling. . . . .             | 66 |
| 5.7 | Testing the Installation . . . . .     | 68 |
| 5.8 | Still Need Help? . . . . .             | 69 |

## 5.1 About Installation

This chapter is intended to help the installer with the basic installation and setup of your new DCX S Power Supply.

| CAUTION   | Heavy Object   |
|---|--|
|  | The power supply, and related components are heavy. Handling, unpacking, and installation may require the assistance of a colleague or the use of lifting platforms or hoists. |

International safety-related labels are found on the power supply. Those that are of importance during installation of the system are identified in [Figure 1.1 Safety-related Labels found on the DCX S Power Supply](#) and [Figure 1.2 Safety-related Labels found on the DCX S Power Supply](#).

## 5.2 Installation Requirements

This section covers the location requirements, mounting options, power supply dimensions, environmental requirements, and electrical requirements, to help you plan and execute your installation successfully.

### 5.2.1 Installing the DCX S Power Supply Drawers in a Customer Rack

The power supply units can be installed in any rack complying with the 19" industrial standard.

For successful installation in a rack, the respective demands on the electric and cooling system have to be met.

- If multiple drawers are to be installed in a rack we recommend to provide three phase power to the rack in order to provide each drawer with a dedicated supply and one phase to each drawer
- Particular care has to be taken that the heat generated during operation is dissipated. The heat generated depends on the power output by the module and the ambient conditions
- The heat sink of the module is mounted on the right. Make sure that the cooling device is mounted in a way allowing the cooling air to pass freely on this side
- For each group of four power supply modules installed one cooling drawer is required. The cooling drawers must be installed directly under the power supplies in order to ensure sufficient cooling
- In case a filter element is used to clean the intake air, regular inspection and cleaning of the filter depending on the ambient conditions is required to maintain the airflow volume
- To prevent thermal overload, the system is protected by thermostats which are reset automatically after cooling down

### 5.2.2 Location

The power supply should be accessible for parameter changes and settings. The power supply should be located in an area away from radiators or heating vents.

The DCX S Power Supply must not be positioned so that is difficult to plug in or unplug the main power plug.

### 5.2.3 Dimensions


Refer to the illustrations on the pages that follow for dimensional drawings. All dimensions are approximate and may vary slightly:

[Figure 5.1 DCX S Power Supply Dimensional Drawing \(Small\)](#)


[Figure 5.2 DCX S Power Supply Dimensional Drawing \(Medium\)](#)

[Figure 5.3 DCX S Power Supply Dimensional Drawing \(Large\)](#)


**Figure 5.1** DCX S Power Supply Dimensional Drawing (Small)



**Figure 5.2** DCX S Power Supply Dimensional Drawing (Medium)



**Figure 5.3** DCX S Power Supply Dimensional Drawing (Large)





## 5.2.4 Environmental Requirements

Verify the DCX S Power Supply is operated in an environment that meets the temperature and humidity requirements indicated in [Table 5.1 Environmental Requirements](#).

**Table 5.1** Environmental Requirements

| Environmental Condition       | Acceptable Range                    |
|-------------------------------|-------------------------------------|
| Ambient Operating Temperature | +41° F to +104° F (+5° C to +40° C) |
| Operating Altitude            | Up to 6560 ft (2000 m)              |
| Humidity                      | Maximum 95%, non-condensing         |
| IP Rating                     | 2X                                  |

## 5.2.5 Electrical Input Power Ratings

Connect the power supply to a single-phase, grounded, 3-wire, 50 Hz or 60 Hz 200 V to 230 V power source. [Table 5.2 Input Current and Circuit Breaker Specifications](#) lists the current and breaker ratings for the various models.

**Table 5.2** Input Current and Circuit Breaker Specifications

| Model  | Power  | Current Rating                   |
|--------|--------|----------------------------------|
| 20 kHz | 1250 W | 7 A Max. @ 200 V / 15 A Breaker  |
|        | 2500 W | 14 A Max. @ 200 V / 15 A Breaker |
|        | 4000 W | 25 A Max. @ 200 V / 25 A Breaker |
| 30 kHz | 1500 W | 10 A Max. @ 200 V / 15 A Breaker |
| 40 kHz | 800 W  | 5 A Max. @ 200 V / 10 A Breaker  |


## 5.2.6 Pneumatic Requirements

Your welding system may require a cooling air stream for the converters. In continuous operations, or applications with longer duty cycles, it may be necessary to cool the horn as well as the converter.

Typically 80 cubic feet (2.26 m<sup>3</sup>) per hour of clean, dry, compressed air are required to cool most welding operations.

To verify the 80 cubic feet (2.26 m<sup>3</sup>) per hour cooling air stream required for your welding system, refer to [5.6 Converter Cooling](#).

## 5.3 Installation Steps

| WARNING   | High Voltage Hazard   |
|---|---|
|  | <p>To prevent the possibility of an electrical shock:</p> <ul style="list-style-type: none"><li>• Ensure the power source is disconnected before beginning work on line connections</li><li>• Ensure the power switch on the back of the unit is in the OFF position before making any electrical connections</li><li>• Always plug the power supply into a grounded power source</li><li>• To prevent the possibility of an electrical shock, ground the power supply by securing an AWG #14 grounded conductor to the ground screw located next to the air outlet</li><li>• Ensure power supply installation is performed by qualified personnel and in accordance with local standards and regulations</li></ul> |


### Basic installation notes:

- To avoid problems associated with EMI, you should route high power lines (AC and Ultrasonic RF) away from low power lines (controls signals)
- You should consider future troubleshooting and repair when installing all wiring. All wiring should be either color coded or tagged with industrial wire tags
- The minimum cable bend radius is 5 times the cable outer diameter for RF cables
- The minimum cable bend radius is 10 times the cable outer diameter for user I/O & Ethernet cables
- Ground wires should not be shared with other equipment
- All inductive coils must be suppressed with appropriate devices, such as diodes or RC networks

## 5.3.1 Mount the Power Supply

The cable lengths are limited based on the operating frequency of the welding system. Performance and results can suffer if the RF cable is crushed, pinched, damaged or modified. Contact your Branson Representative if you have special cable requirements.

Do not place the power supply on the floor or in other locations that will allow dust, dirt or contaminants to be drawn into the power supply.


| NOTICE  |   |
|---|---|
|  | <p>Do not block exhaust and intake air circulation, which is needed to maintain a safe operating temperature.</p> |


For dimensional drawings of the DCX S Power Supply, see figures [Figure 5.1](#), [Figure 5.2](#), and [Figure 5.3](#).

## 5.3.2 Mounting Considerations

In addition to the considerations mentioned above, the LCD's viewing angle should be taken into account when selecting a location for your DCX S Power Supply. The LCD is designed to be viewed from the top. Please refer to [Figure 5.4 LCD Viewing Angle](#) below when selecting a location for your DCX S Power Supply.

**Figure 5.4** LCD Viewing Angle



| NOTICE  |  |
|---|--|
|  | <p>Optimal viewing angle is 25° above the normal to the display (indicated by 0°).</p> |

## 5.3.3 Electrical Connections

Figure 5.5 DCX S Power Supply Connections




Table 5.3 DCX S Power Supply Connections

| Item | Description  |
|------|--|
| 1    | Input power connector. See <a href="#">5.3.14 Input Power Connection</a> for more information    |
| 2    | Line cord  |
| 3    | RF connector. See <a href="#">5.3.13 Output Power (RF Cable) Connection</a> for more information |
| 4    | RF cable (ferrite end)   |
| 5    | User I/O Connectors  |

### 5.3.3.1 Input Power Connector

Figure 5.6 Input Power Connector





Table 5.4 Input Power Connector

| Item  | Description                     |
|-------|---------------------------------|
| L1    | 200-230 V 50-60 Hz power source |
| L2    | N                               |
| G     | Ground                          |
| 24 V  | 24 VDC                          |
| 24 VR | 24 V Return                     |

## 5.3.4 User I/O Connections

The user I/O is a standard interface for automation, provided on the power supply. It provides the ability to make your own interface for your automation, actuator interface, special control, or reporting needs. The interface cable has a 26-pin HD male D-Sub connector on one end, and wires on the other end. Pins are wired to ICEA standard color code (see [Figure 5.7 User I/O Cable Identification and Wire Color Diagram](#) and table [Table 5.6 User I/O Cable Pin Assignments](#)).


| NOTICE  |   |
|---|---|
|  | Ensure all unused wires are properly isolated. Failure to do so may result in a power supply malfunction. |

Digital I/O functions can be configured to either active-high or active-low using the DCX S Power Supply web page interface. [Table 5.8 Available Digital Input Functions](#) to [Table 5.11 Available Analog Output Functions](#) list the input and output functions available on the DCX S Power Supply. See [Table 5.7 Default User I/O Connector Pin Assignments](#) for the default user I/O pin assignments.


[Figure 5.8 Typical Digital I/O Wiring Examples](#) and [Figure 5.9 Typical Analog I/O Wiring Examples](#) show typical wiring examples.

**Figure 5.7** User I/O Cable Identification and Wire Color Diagram

User I/O Cable  
 Stripped Jacket one end,  
 HD-26 male connector other end  
 (cable length as ordered)



Wire Color Diagram  
 Two Colors = Insulator/Stripe  
 Three Colors = Insulator/Stripe/Dot



**Table 5.5** User I/O Cable

| Item | Description |
|------|-------------|
| 1    | Part number |
| 2    | Insulation  |
| 3    | Stripe      |
| 4    | Dot         |

## 5.3.5 User I/O Cable Pin Assignments

**Table 5.6** User I/O Cable Pin Assignments

| Pin | Input/Output  | Signal Type    | Signal Range   | Color<br>100-240-392   | Color<br>011-004-030 |
|-----|---------------|----------------|--|------------------------|----------------------|
| 1   | Digital In 1  | Digital Input  | 0 V to 24 V<br>±10%, 12 mA   | Black                  | White                |
| 2   | Digital In 2  |                |  | White                  | Brown                |
| 3   | Digital In 3  |                |  | Red                    | Green                |
| 4   | Digital In 4  |                |  | Green                  | Yellow               |
| 5   | +24 V Out     | 24 V Source    | 24 V ±10%,<br>250 mA Max<br><br><b>CAUTION</b><br>Do not connect<br>an external 24 V<br>power supply.<br>Internally con-<br>nected to input<br>power connector<br>on the rear. | Orange                 | Gray                 |
| 6   |               |                |  | Blue                   |                      |
| 7   | Digital Out 1 | Digital Output | 0 V to 24 V,<br>±10%, 25mA<br>Max  | White/Black            | Pink                 |
| 8   | Digital Out 2 |                |  | Red/Black              | Blue                 |
| 9   | Digital Out 3 |                |  | Green/Black            | Red                  |
| 10  | Digital Out 4 |                |  | Orange/Black           | Black                |
| 14  | GND           | 24 V Ground    | 0 V  | Green/White            | Violet               |
| 15  |               |                |  | Blue/White             |                      |
| 17  | Analog In 1   | Analog Input   | 0 V to +10 V,<br>2 mA  | White/Red              | Gray/Pink            |
| 18  | Analog In 2   |                |  | Orange/Red             | Red/Blue             |
| 24  | Analog Out 1  | Analog Output  | 0 V to 10 V ±5%,<br>1 mA Max   | Red/Black/<br>White    | White/Green          |
| 25  | Analog Out 2  |                |  | Green/Black/<br>White  | Brown/Green          |
| 26  | Analog GND    | Analog Ground  | 0 V  | Orange/<br>Black/White | White/Yellow         |



### 5.3.6 Default User I/O Connector Pin Assignments

**Table 5.7** Default User I/O Connector Pin Assignments

| PIN* | Function                      | I/O Type             | Values   |
|------|-------------------------------|----------------------|--|
| 1    | External Start                | Digital Input        | Apply +24 VDC to run cycle<br><b>NOTICE</b><br>DCX S Power Supply must be in ready mode before External Start.                                   |
| 2    | External Seek                 |                      | Apply +24 VDC to perform a seek  |
| 3    | External Reset                |                      | Apply +24 VDC to reset alarm   |
| 4    | Memory Clear                  |                      | Apply +24 VDC to clear memory  |
| 5    | +24 V Out                     | I/O Signal Source    | +24 V, 250 mA max.<br><b>CAUTION</b><br>Do not connect an external 24 V power supply. Internally connected to input power connector on the rear. |
| 6    |                               |                      |  |
| 7    | Ready                         | Digital Output       | +24 V indicates the system is ready  |
| 8    | Sonics Active                 |                      | +24 V indicates ultrasonics are active   |
| 9    | General Alarm                 |                      | +24 V indicates an alarm occurred  |
| 10   | Seek/Scan Out                 |                      | +24 V indicates either Seek or a Scan is in progress   |
| 14   | +24 VDC Return and I/O Return | I/O Signal Return    | Return for all pins except pins 17, 18, 24, and 25   |
| 15   |                               |                      |  |
| 17   | Amplitude In                  | Analog Input         | 1 V to + 10 V (10% to 100%)**  |
| 18   | Frequency Offset              |                      | 1 V to + 9 V (5 V is zero offset)**  |
| 24   | Power Out                     | Analog Output        | 0 V to + 10 V (0% to 100%)   |
| 25   | Amplitude Out                 |                      | 0 V to + 10 V (0% to 100%)   |
| 26   | Analog Signal Return          | Analog Signal Return | Return for pins 17, 18, 24, and 25   |

\* Pins 11, 12, 13, 16, 19, 20, 21, 22, and 23 are not used

\*\* If the input signals are not within their valid range, or if left unconnected, the power supply will use 50% amplitude and zero frequency offset, respectively

## 5.3.7 Available Digital Input Functions

**Table 5.8** Available Digital Input Functions

| Function           | Description  |
|--------------------|--|
| Cable Detect       | Disables ultrasonics if 24 V signal is removed when using 0 V negative logic (active low) for the external Start input. Used to prevent ultrasonics from coming on if a cable is removed.  |
| Display Lock       | Locks the front panel display controls   |
| External Horn Scan | Starts horn scan sequence.   |
| External Reset     | Resets alarm conditions.   |
| External Seek      | Activates ultrasonic energy at 10% amplitude for the purpose of finding the ultrasonic stack resonant frequency.   |
| External Start     | Activates ultrasonic energy at the currently set amplitude.<br><div style="background-color: #003366; color: white; padding: 2px; display: inline-block; font-weight: bold;">NOTICE</div><br>DCX S Power Supply must be in ready mode before External Start. |
| External Test      | Performs a test cycle.   |
| Memory Clear       | Centers the power supply start frequency.  |

## 5.3.8 Available Digital Output Functions

**Table 5.9** Available Digital Output Functions

| Function       | Description  |
|----------------|--|
| General Alarm  | Indicates an alarm occurred.                           |
| Overload Alarm | Indicates an overload alarm has occurred.              |
| Ready          | Indicates the system is ready.                         |
| Seek/Scan Out  | Indicates either a seek or a horn scan is in progress. |
| Sonics Active  | Indicates sonics are active.                           |

### 5.3.9 Available Analog Input Functions

**Table 5.10** Available Analog Input Functions

| Function         | Description   |              | Valid Range                         |
|------------------|---|--------------|-------------------------------------|
| Amplitude In     | Controls the amplitude of ultrasonic energy that will be delivered by the power supply.   |              | 1 V to 10 V*<br>(10% to 100%)       |
| Frequency Offset | Controls the frequency offset to the power supply operating frequency. Actual offset depends on the power supply operating frequency: |              | 1 V to 9 V*<br>(5 V is zero offset) |
|                  | Frequency   | Offset Range |                                     |
|                  | 20 kHz  | ±400 Hz      |                                     |
|                  | 30 kHz  | ±600 Hz      |                                     |
|                  | 40 kHz  | ±800 Hz      |                                     |

\* If the input signals are not within their valid range, or if left unconnected, the power supply will use 50% amplitude and zero frequency offset, respectively.


### 5.3.10 Available Analog Output Functions

**Table 5.11** Available Analog Output Functions

| Function      | Description   |                   |                    | Valid Range                         |
|---------------|---|-------------------|--------------------|-------------------------------------|
| Amplitude Out | Provides a 0 V to 10 V output signal proportional to amplitude (0% to 100%).  |                   |                    | 0 V to 10 V<br>(0% to 100%)         |
| Power Out     | Provides a 0 V to 10 V output signal proportional to ultrasonic power output (0% to 100%).  |                   |                    | 0 V to 10 V<br>(0% to 100%)         |
| Frequency Out | Provides a 0 V to 10 V output signal that indicates relative frequency in memory. Actual frequency depends on the power supply operating frequency: |                   |                    | 0 V to 10 V<br>(5 V is zero offset) |
|               | Frequency   | Lower Limit (0 V) | Upper Limit (10 V) |                                     |
|               | 20 kHz  | 19,450 Hz         | 20,450 Hz          |                                     |
|               | 30 kHz  | 29,250 Hz         | 30,750 Hz          |                                     |
|               | 40 kHz  | 38,900 Hz         | 40,900 Hz          |                                     |


## 5.3.11 Typical Digital I/O Wiring Examples

Figure 5.8 Typical Digital I/O Wiring Examples



## 5.3.12 Typical Analog I/O Wiring Examples


Figure 5.9 Typical Analog I/O Wiring Examples





## 5.3.13 Output Power (RF Cable) Connection

Ultrasonic energy is delivered to the SHV connector on the power supply, which is then transmitted to the converter via the RF cable. The RF connector is located on the rear panel of the power supply.


To reduce electromagnetic interference (EMI), RF cables are equipped with a ferrite core (plastic case) on one end. This end is meant to be connected to the power supply.

| WARNING   | High Voltage Hazard   |
|---|---|
|  | <p>Operating the System with the RF Cable disconnected or damaged can present an electrical shock hazard.</p> |

| WARNING   | High Voltage Hazard   |
|---|---|
|  | <p>To avoid the possibility of electrical shock. Converters need to be properly grounded.</p> |

| NOTICE  |  |
|---|--|
|  | <p>To avoid the possibility of EMI interference, ensure the RF connection to the power supply is made with the cable end that has the ferrite core box attached (see <a href="#">Figure 5.10 RF Cable Connection</a>).</p> |


**Figure 5.10** RF Cable Connection




**Table 5.12** RF Cable Connection

| Item | Description      |
|------|------------------|
| 1    | To Power Supply  |
| 2    | Ferrite Core Box |

## 5.3.14 Input Power Connection

| WARNING   | High Voltage Hazard  |
|---|--|
|  | <p>If miss-wired, the power supply can present an electrical shock hazard.</p> <p>Ensure all electrical power is off when wiring input power to your DCX S Power Supply connector block.</p> |

| NOTICE  |   |
|---|---|
|  | <p>The power supply can be permanently damaged if it is connected to the incorrect line voltage, or if the connection is mis-wired.</p> |

Use the following procedure to connect the power supply to a 24 VDC 2.5 A external power supply and to a single-phase, grounded 3-wire, 50 Hz or 60 Hz 200 V to 230 V power source. The 24 VDC power supply must be safety certified and agency approved.

**Table 5.13** Input Power Connection

| Step | Action   |
|------|--|
| 1    | Detach the connector block on the back of the power supply.  |
| 2    | Use three properly sized wires (AWG #12, 2.5 mm or according to local standards) to connect the line 1, line 2, and ground to the connector block as shown on <a href="#">Figure 5.5 DCX S Power Supply Connections</a> . Choose wires according to the current rating as specified in <a href="#">Table 5.2 Input Current and Circuit Breaker Specifications</a> and on the label located on the back of the unit. Be sure to use agency approved wiring and use sleeving or tubing on each wire for double insulation. |
| 3    | Use cable ties to secure the wires to the connector block metal piece. This will help to prevent the line and ground wires from becoming loose and will also act as a strain relief.   |
| 4    | Secure an AWG #14 grounded conductor to the ground screw located next to the air outlet.   |
| 5    | Connect the converter-booster-horn stack to the power supply using the RF cable. See <a href="#">5.3.13 Output Power (RF Cable) Connection</a>   |
| 6    | Plug the connector block back into the power supply. Tighten the two securing screws.  |
| 7    | Connect the power supply to a single-phase, grounded, 3-wire, 50 Hz or 60 Hz 200 V to 230 V power source.  |

## 5.4 Power Supply Configuration

### 5.4.1 Selecting the Alarm Mode

The DCX S Power Supply activates ultrasonic power after receiving an External Start signal. Ultrasonic power remains on until you turn off the power supply or the External Start signal. The DCX S Power Supply response to alarm conditions can be configured to operate in one of two modes:

- **Latching:** In this mode the DCX S Power Supply requires alarm conditions to be reset before a new weld cycle can begin. To reset alarm conditions while in this mode, either press the front panel Reset key or send an External Reset signal using the user I/O connector
- **Non-Latching:** In this mode the DCX S Power Supply does not require alarm conditions to be reset, and new weld cycle can begin upon receiving an External Start signal


The alarm mode is factory-set to non-latching. For instruction on how to change the alarm mode refer to [7.4 Configuring the Power Supply Registers](#) in [Chapter 7: Operation](#) and to your DCX Series Web Page Interface Instruction Manual (4000843).

### 5.4.2 Configuring the Power Supply


Certain power supply configurations can be modified from the factory setting if needed. Although not usually requiring modifications from the factory setting, the following features are selectable:


- **Amplitude control:** Allows for varying the amplitude (10% to 100%) using the front panel LCD, the web page interface, or by way of external controls (analog signal applied through the user I/O analog input)
- **Latching Alarms:** Provides an option for selecting the power supply alarms to be latching (reset required) or non-latching (reset by reapplying the start signal)
- **Start Ramp Time:** Provides a selection for different start ramp times. This controls how fast the amplitude of the horn rises from zero to the currently set amplitude. Long ramp times may be useful when using large horns or high gain stacks
- **End of Weld Frequency Store:** Provides an option for selecting if the stack frequency is stored at the end of each weld cycle
- **Seek Ramp Time:** Provides a selection for different power supply seek ramp times
- **Timed Seek:** Provides an option for monitoring, and storing the operating frequency at timed intervals (60 seconds). Periodic frequency seeks may be helpful when welder is not used for long periods of time. Seeks are timed from the moment sonics was last activated
- **Seek Time:** Provides an option for selecting seek duration
- **Frequency Offset:** Allows for varying the start frequency by way of external controls (analog signal applied through the user I/O analog input) or setting a fixed value using the web page interface. This is useful for certain applications, where the force imparted on the fixture or anvil causes a frequency shift in the stack's operation


For instruction on how to change the power supply settings refer to [7.4 Configuring the Power Supply Registers](#) in [Chapter 7: Operation](#) and to your DCX S Power Supply Web Page Interface Instruction Manual (4000843).

| NOTICE  |   |
|---|---|
|  | Consult with Branson before changing any default factory setting. |

## 5.5 Assembling the Acoustic Stack


| CAUTION   | General Warning  |
|---|--|
|  | The following procedure must be performed by a setup person. If necessary, secure the largest portion of a square or rectangular horn in a soft jawed vise. NEVER attempt to assemble or remove a horn by holding the converter housing or the booster clamp ring in a vise. |

| CAUTION   | General Warning   |
|---|---|
|  | Do not use silicone grease with Mylar plastic film washers. Use only 1 (one) Mylar plastic film washer of the correct inside and outside diameters at each interface. |

| NOTICE  |   |
|---|---|
|  | The use of a Branson torque wrench or the equivalent is recommended. P/N 101-063-787 for 20 kHz, and 30 kHz systems and 101-063-618 for 40 kHz systems. |



**Figure 5.11** Assembling the Acoustic Stack



**Table 5.14** Acoustic Stack Description

| Item | Description                                  |
|------|--|
| 1    | Converter                                    |
| 2    | Booster                                      |
| 3    | Spanner (provided)                           |
| 4    | Horn   |
| 5    | See stack assembly procedure                 |
| 6    | Vise Jaw protectors (aluminum or soft metal) |
| 7    | Vise   |

**Table 5.15** Stack Torque Values

| Frequency | Torque                |
|-----------|-----------------------|
| 20 kHz    | 220 in·lb (24.85 N·m) |
| 30 kHz    | 185 in·lb (21 N·m)    |
| 40 kHz    | 95 in·lb (10.73 N·m)  |

**Table 5.16** Tools

| Tool                                 | EDP Number  |
|--------------------------------------|-------------|
| 20 kHz, and 30 kHz Torque Wrench Kit | 101-063-787 |
| 40 kHz Torque Wrench                 | 101-063-618 |
| 20 kHz Spanner Wrench                | 101-118-039 |
| 30 kHz Spanner Wrench                | 201-118-033 |
| 40 kHz Spanner Wrench                | 201-118-024 |
| Silicone Grease                      | 101-053-002 |
| Mylar Plastic Film Washers (20 kHz)  | 100-063-357 |
| Mylar Plastic Film Washers (30 kHz)  | 100-063-632 |

## 5.5.1 For a 20 kHz System

**Table 5.17** 20 kHz System

| Step | Action   |
|------|--|
| 1    | Ensure that the mating surfaces of the converter, booster, and horn are clean, and that the threaded holes are free of foreign material. |
| 2    | Install a single Mylar plastic film washer (matching the size of the washer to the stud) to each interface.                              |
| 3    | Assemble the converter to the booster and the booster to the horn.   |
| 4    | Torque to 220 in·lb (24.85 N·m) at each interface.   |

## 5.5.2 For a 30 kHz System

**Table 5.18** 30 kHz System

| Step | Action   |
|------|--|
| 1    | Ensure that the mating surfaces of the converter, booster, and horn are clean, and that the threaded holes are free of foreign material. |
| 2    | Install a single Mylar plastic film washer (matching the size of the washer to the stud) to each interface.                              |
| 3    | Assemble the converter to the booster and the booster to the horn.   |
| 4    | Torque to 185 in·lb (21 N·m) at each interface.  |

### 5.5.3 For a 40 kHz System


**Table 5.19** 40 kHz System

| Step | Action   |
|------|--|
| 1    | Ensure that the mating surfaces of the converter, booster, and horn are clean, and that the threaded holes are free of foreign material. |
| 2    | Coat each interface surface with a thin film of silicon grease - but do not apply silicon grease to a threaded stud or tip.              |
| 3    | Assemble the converter to the booster and the booster to the horn.   |
| 4    | Torque to 95 in·lb (10.73 N·m) at each interface.  |

### 5.5.4 Connecting Tip to Horn

1. Ensure that the mating surfaces of the tip and horn are clean. Remove any foreign matter from the threaded stud and hole
2. Hand assemble the tip to the horn. Assemble dry. Do not use any silicone grease
3. Use the spanner wrench and an open-end wrench (refer to [Figure 5.12 Connecting Tip to Horn](#)) and tighten to the following torque tip specifications:

**Figure 5.12** Connecting Tip to Horn



**Table 5.20** Tip to horn torque values

| Tip Thread | Torque                 |
|------------|------------------------|
| 1/4 - 28   | 110 in·lbs (12.42 N·m) |
| 3/8 - 24   | 180 in·lbs (20.33 N·m) |

## 5.6 Converter Cooling

Converter performance and reliability can be adversely affected if the converter ceramics are subjected to temperatures above 140° F (60° C). The converter front driver temperature should not exceed 122° F (50° C).

To prolong converter life and maintain a high degree of system reliability, the converter should be cooled with clean, dry, compressed air, particularly if your application calls for continuous ultrasonic operation. Converter cooling is especially critical in 40 kHz applications.

Use one of the following procedures to determine if a converter is operating close to the maximum allowable temperature. Check converter temperature immediately after substantial machine operation and without power applied to the horn.

- Press a pyrometer probe (or similar temperature measuring device) against the front driver of the converter assembly. Wait for the probe to reach the temperature of the shell. If the temperature is 120° F (49° C) or higher, the converter requires a cooling air stream
- If a temperature measuring device is unavailable, use your hand to feel the shell of the converter. If the converter is hot to touch, the converter requires a cooling air stream

High duty cycles require additional cooling for the converter. System average power must be limited to the specified continuous maximum. Higher peak power, up to the maximum acceptable power limit, with an on time of up to 10 seconds may be obtained, if appropriate off time ensures that, on average, the continuous duty maximum power is not exceeded.

**Table 5.21** Continuous Duty Max. Power & Full Power Duty Cycle

| Model  | Power  | Continuous Duty. Max. Power | Full Power Duty Cycles                          |
|--------|--------|-----------------------------|---|
| 20 kHz | 1100 W | 330 W                       | 1 second on, 3 seconds off.<br>(25% Duty Cycle) |
|        | 2200 W | 660 W                       |   |
|        | 4000 W | 1200 W                      |   |
| 30 kHz | 1500 W | 460 W                       |   |
| 40 kHz | 800 W  | 240 W                       |   |

If converter cooling is required, use the following steps:

**Table 5.22** Converter Cooling Procedure

| Step | Action  |
|------|---|
| 1    | Start with a 50 psi (345 kPa) air source or higher from a 0.06 in (1.5 mm) I.D. orifice   |
| 2    | Perform a run of welding operations.  |
| 3    | Immediately after completing the welding run, check the converter temperature.  |
| 4    | If the converter is still too hot, increase the diameter of the orifice in small increments until the temperature falls within the ranges in the chart. |

A 0.06 in (1.5 mm) orifice at 50 psi (345 kPa) will result in a reading of 80 ft<sup>3</sup> (2.26 m<sup>3</sup>) per hour. This should be sufficient to cool most operations requiring a cooling air stream. In continuous welding operations, or applications with longer duty cycles, it may be necessary to cool the horn as well as the converter. Horns may require cooling because of the heat transfer from contacting the work piece.

## 5.7 Testing the Installation

To test the power supply follow the procedure described in [7.7 Ultrasonics Test Procedure](#) in [Chapter 7: Operation](#).

## 5.8 Still Need Help?

Branson is pleased that you chose our product and we are here for you! If you need parts or technical assistance with your DCX S Power Supply system, call your local Branson representative. Please refer to [1.3 How to Contact Branson](#) for a list of Branson key contacts.





---


# Chapter 6: Converters and Boosters


---

6.1 Converters and Boosters ..... 72


## 6.1 Converters and Boosters

A variety of converters and boosters available for use with the DCX S Power Supply are illustrated in the following pages.

| WARNING   | High Voltage Hazard  |
|---|--|
|  | To avoid the possibility of electrical shock. Converters need to be properly grounded. |

| NOTICE  |   |
|---|---|
|  | Special adaptor cables are available to connect to MS-style converters (CR20 and 4TR). See <a href="#">Table 8.8 DCX S Power Supply System Cables</a> . |


**Figure 6.1** 20 kHz typical Converter Dimensions



**Table 6.1** 20 kHz Converter

| Item | Description   |
|------|---------------|
| 1    | Air inlet     |
| 2    | Ground stud   |
| 3    | SHV connector |
| 4    | Grip area     |

**Figure 6.2** 20 kHz Booster Dimensions




**Table 6.2** 20 kHz Booster

| Item | Description  |
|------|--|
| 1    | 1/2 - 20 x 1 - 1/4 stud (Ti boosters)<br>1/2 - 20 x 1 - 1/2 stud (Al boosters) |
| 2    | Grip Ring Diameter   |
| 3    | Variable   |
| 4    | Varies with tuning and gain  |

\* These dimensions do not vary.

**Figure 6.3** 20 kHz Converter/Booster/Horn, Typical Dimensions




**Table 6.3** 20 kHz Converter/Booster/Horn

| Item | Description   |
|------|---|
| 1    | Converter   |
| 2    | Booster   |
| 3    | One-half wavelength horn                            |
| 4    | Recommended clamping area                           |
| 5    | Booster front end diameter will vary with amplitude |

\* Overall horn length can vary beyond these typical dimensions depending on the application.

**Figure 6.4** 30 kHz Converter Dimensions




**Table 6.4** 30 kHz Converter

| Item | Description   |
|------|---------------|
| 1    | Air inlet     |
| 2    | SHV connector |
| 3    | Ground stud   |
| 4    | Grip area     |

CR-30S and CH-30S are dimensionally identical, and differ only in their respective cooling feature.

CR-30S has flow through cooling, and CH-30S has closed loop cooling (air circulates in the converter and returns to its source).

**Figure 6.5** 30 kHz Booster Dimensions




**Table 6.5** 30 kHz Booster

| Item | Description                 |
|------|-----------------------------|
| 1    | 3/8 - 24 x 1 - 1/4 stud     |
| 2    | Grip Ring Diameter          |
| 3    | Variable                    |
| 4    | Varies with tuning and gain |

\* These dimensions do not vary.

**Figure 6.6** 30 kHz Converter/Booster/Horn, Typical Dimensions




**Table 6.6** 30 kHz Converter/Booster/Horn

| Item | Description   |
|------|---|
| 1    | Converter   |
| 2    | Booster   |
| 3    | One-half wavelength horn                            |
| 4    | Recommended clamping area                           |
| 5    | Booster front end diameter will vary with amplitude |

\* Overall horn length can vary beyond these typical dimensions depending on the application.




**Figure 6.7** 40 kHz, 4TR Converter Dimensions



**Table 6.7** 40 kHz, 4TR Converter

| Item | Description   |
|------|---------------|
| 1    | Ground stud   |
| 2    | SHV connector |
| 3    | Grip area     |


**Figure 6.8** 40 kHz Booster Dimensions



**Table 6.8** 40 kHz Booster

| Item | Description  |
|------|--|
| 1    | M8 x 1 - 1/4 stud (Ti boosters)<br>M8 x 1 - 1/2 stud (Al boosters) |
| 2    | Grip ring diameter   |
| 3    | Variable   |
| 4    | Varies with tuning and gain  |

**Figure 6.9** 40 kHz Converter/Booster/Horn, Typical Dimensions



**Table 6.9** 40 kHz Converter/Booster/Horn

| Item | Description   |
|------|---|
| 1    | Converter   |
| 2    | Booster   |
| 3    | One-half wavelength horn                            |
| 4    | Recommended clamping area                           |
| 5    | Booster front end diameter will vary with amplitude |

\* Overall horn length can vary beyond these typical dimensions depending on the application.

\*\* Dimension varies with tuning and gain.

## 6.1.1 Component Functional Description

### Ultrasonic Stack

#### Converter

The converter is mounted in the customer's automation as part of the ultrasonic stack. The ultrasonic electrical energy from the power supply is applied to the converter (sometimes called the transducer). This transforms the high frequency electrical oscillations into mechanical vibrations at the same frequency as the electrical oscillations. The heart of the converter are piezoelectric ceramic elements. When subjected to an alternating voltage, these elements alternately expand and contract, resulting in better than 90 % conversion of electrical to mechanical energy.

#### Booster

It is important to be able to modify the horn face amplitude for successful ultrasonic assembly. The booster provides a means to modify the amplitude. It is designed to couple different ratios of ultrasonic energy to the horn, which will in turn increase or decrease the amplitude at the face of the horn. This is accomplished by varying the ratios of the masses of the input and output half sections of the booster.

The booster is a resonant half-wave section of aluminum or titanium. It is mounted between the converter and the horn, as part of the ultrasonic stack. It also provides a clamping point for rigid stack mounting.

#### Horn

The horn is selected or designed for a specific application. Each horn is tuned typically as a half-wave section that applies the necessary force and vibration uniformly to the parts to be assembled. It transfers ultrasonic vibrations from the converter to the workpiece. The horn is mounted to the booster as part of the ultrasonic stack.

Depending on their profile, horns are referred to as stepped, conical, exponential, bar, or catenoidal. The shape of the horn determines the amplitude at the face of the horn. Depending on the application, horns can be made from titanium alloys, aluminum, or steel. Titanium alloys are the best materials for horn fabrication due to their high level of strength and low loss. Aluminum horns are usually chrome- or nickel-plated or hard-coated to reduce wear. Steel horns are for low amplitude requiring hardness, such as ultrasonic insertion applications.

## **Solid Mount Boosters**

The solid mount booster is a one-half wave-length resonant section made exclusively of titanium. It is mounted between the converter and the horn, modifying the amplitude of vibration applied to the horn and providing a clamping point.

The solid mount booster is superior to prior versions in that deflection is minimized. This is the result of a redesigned clamp-ring which employs a metal-to-metal press fit rather than an O-ring assembly.

The advantage this booster offers is its improved rigidity. For continuous applications, this means more energy delivered to the product, while in plunge applications, improved alignment is possible. The solid mount provides improved positional alignment and will benefit continuous applications where high force, high side load, or high cycle rates are necessary. In plunge welding applications, overall deflection is reduced by an average of 0.0025 in. (0.064 mm) over a wide variety of materials, joint designs, and operating conditions. The results of this testing in combination with information drawn from field testing indicate that the solid mount will benefit plunge applications where precision alignment is necessary (such as staking, swaging, or insertion) or where concentricity/parallelism is critical.




---

## Chapter 7: Operation

---

|     |  |     |
|-----|--|-----|
| 7.1 | Activating Ultrasonic Power . . . . .            | 86  |
| 7.2 | Setting the Amplitude. . . . .                   | 87  |
| 7.3 | Resetting the Power Supply Alarms. . . . .       | 89  |
| 7.4 | Configuring the Power Supply Registers . . . . . | 90  |
| 7.5 | LCD Bar-Graph . . . . .                          | 94  |
| 7.6 | Web Page Interface . . . . .                     | 97  |
| 7.7 | Ultrasonics Test Procedure. . . . .              | 102 |

## 7.1 Activating Ultrasonic Power

| NOTICE  |   |
|---|---|
|  | There is a 2 seconds power-up delay before system is in ready mode. |

On DCX S Power Supply, ultrasonic power activates after receiving an External Start signal at the corresponding user I/O. Ultrasonic power remains On until you turn off the power supply or the External Start signal. For default user I/O assignment see [5.3.4 User I/O Connections](#). For information on configuring the power supply user I/O refer to your DCX Series Web Page Interface Instruction Manual (4000843).




## 7.2 Setting the Amplitude



### 7.2.1 Using the Front Panel Controls

At power up the DCX S Power Supply will display the last amplitude setting on the LCD. It can also be set to show weld mode.

**Figure 7.1** LCD at Power Up




**Table 7.1** Setting the Amplitude Using the Front Panel Controls

| Step | Action  | Reference   |
|------|---|---|
| 1    | Press the Configuration key until the percentage icon (%) and no mode icons are displaying on the LCD.  |  |
| 2    | <p>Press and release the Up or Down arrow keys to select the desired amplitude at 1% increments.</p> <p>Press and hold down the Up or Down arrow keys and the Amplitude will auto increment at 1% increments every quarter of a second.</p> <p>After holding down an arrow key for four straight seconds, the amplitude will auto increment at 5% increments every quarter of a second.</p> |  |

## 7.2.2 Using External Amplitude Control

When External Amplitude Control is enabled, the front panel amplitude control is disabled and the LCD displays four dashes (see [Figure 7.2 LCD when in External Amplitude Control Mode](#) below).

**Figure 7.2** LCD when in External Amplitude Control Mode



The ultrasonic amplitude can be controlled using one of the two analog input pins on the user I/O connector (pins 17 and 18).

## 7.2.3 Using the Web Page Interface


The ultrasonic amplitude can be set to a user specified value using the web page interface. For more information, refer to the DCX Series Web Page Interface Instruction Manual (4000843).

## 7.3 Resetting the Power Supply Alarms

You need to reset the weld system when you get an overload. When there is an overload, the alarm icon appears on the front panel LCD and the General Alarm output on the user I/O connector becomes active. The procedure for resetting the power supply depends on the power supply alarm settings. Refer to [Table 7.2 Resetting the DCX S Power Supply](#) for reset procedures.

**Table 7.2** Resetting the DCX S Power Supply

| Alarm Settings      | Reset Procedure  |
|---------------------|--|
| Latching Alarms     | Press the front panel Reset key. You can also send an External Reset signal. |
| Non-Latching Alarms | Remove and re-apply the start signal.  |




| NOTICE  |   |
|---|---|
|  | Alarm circuitry requires at least 20 ms before restarting ultrasonic power. |

For more information on interfacing the DCX S Power Supply using the user I/O connections refer to [5.3.4 User I/O Connections](#) in [Chapter 5: Installation and Setup](#).



## 7.4 Configuring the Power Supply Registers

At power up the DCX S Power Supply will display the last amplitude setting, this is indicated by the percentage icon (%) on the LCD. Refer to [Figure 7.1 LCD at Power Up](#).

**Table 7.3** Steps to Configure the Power Supply Registers

| Step | Action  | Reference  |
|------|---|--|
| 1    | <p>Press the Configuration key until the number icon (#) appears on the LCD.</p> <p>The power supply will display register 101 at every power up.</p>   |    |
| 2    | <p>Press and release the Up or Down arrow keys to select the desired register. For a detailed description of available registers refer to <a href="#">Table 7.4 Power Supply Registers</a>.</p> |   |
| 3    | <p>Once you have reached the desired register, press the Configuration key. The register value will be displayed, this is indicated by the circle icon.</p>                                     |  |

**Table 7.3** Steps to Configure the Power Supply Registers

| Step | Action   | Reference  |
|------|--|--|
| 4    | <p>Press and release the Up or Down arrow keys to enter the desired value at 1 increments.</p> <p>Press and hold down the Up and Down arrow keys and the value will auto increment at 1 increments every quarter of a second.</p> <p>After holding down an arrow key for four straight seconds, the value will auto increment at 5 increments every quarter of a second.</p> <p>Or press the Reset key to enter the default value. For detailed default values of available registers refer to <a href="#">Table 7.4 Power Supply Registers</a>.</p> |  <p>The image shows a digital display with the number 150. Above the display are several icons: infinity, a square with a diagonal line, a left arrow, a right arrow, a circle with a diagonal line, a hash symbol, a percent sign, and the letters JS. Below the display is a battery level indicator and a star icon. At the bottom of the device are four buttons: a left-pointing triangle, a button with a crossed-out square, a button with a gear, and a button with a lightbulb. A finger is shown pressing the gear button.</p>  |
| 5    | <p>Press the Configuration key to save the value. The current amplitude setting will be displayed only for continuous mode. For all the other modes, it will display the primary parameter of that mode.</p>   |  <p>The image shows a digital display with the number 100. Above the display are several icons: infinity, a square with a diagonal line, a left arrow, a right arrow, a circle with a diagonal line, a hash symbol, a percent sign, and the letters JS. Below the display is a battery level indicator and a star icon. At the bottom of the device are four buttons: a left-pointing triangle, a button with a crossed-out square, a button with a gear, and a button with a lightbulb. A finger is shown pressing the gear button.</p> |

## 7.4.1 Power Supply Registers

**Table 7.4** Power Supply Registers

| Register | Description  | Default Value | Max. Value | Min. Value |
|----------|--|---------------|------------|------------|
| 101      | System software version  | N/A           | N/A        | N/A        |
| 102      | Bar graph identification after weld complete<br>0: Power<br>1: Frequency | 0             | 1          | 0          |
| 104      | External amplitude control - user analog input<br>0: Off<br>1: On        | 0             | 1          | 0          |
| 105      | Amplitude ramp time (ms)   | 80            | 1000       | 10         |
| 106      | Store frequency at end of weld<br>0: Off<br>1: On                        | 1             | 1          | 0          |
| 107      | Power up seek/scan<br>0: Off<br>1: Seek<br>2: Scan                       | 1             | 2          | 0          |
| 108      | Seek ramp time (ms)  | 80            | 1000       | 10         |
| 109      | Timed seek (every 60 seconds)<br>0: Off<br>1: On                         | 0             | 1          | 0          |
| 110      | Seek time (ms)   | 500           | 1000       | 10         |
| 111      | Frequency offset<br>0: Off<br>1: On                                      | 0             | 1          | 0          |
| 112      | Frequency offset value   |               |            |            |
|          | 20 kHz   | 0             | 500        | -500       |
|          | 30 kHz   |               | 750        | -750       |
| 40 kHz   | 1000   |               | -1000      |            |
| 115      | Restore defaults<br>0: Off<br>1: Just weld preset<br>2: System defaults  | 0             | 2          | 0          |

**Table 7.4** Power Supply Registers

| Register | Description   | Default Value | Max. Value | Min. Value |
|----------|---|---------------|------------|------------|
| 116      | IP address - 1  | 192           | 255        | 0          |
| 117      | IP address - 2  | 168           | 255        | 0          |
| 118      | IP address - 3  | 10            | 255        | 0          |
| 119      | IP address - 4  | 100           | 255        | 0          |
| 120      | Gateway for IP address 1  | 192           | 255        | 0          |
| 121      | Gateway for IP address 2  | 168           | 255        | 0          |
| 122      | Gateway for IP address 3  | 10            | 255        | 0          |
| 123      | Gateway for IP address 4  | 1             | 255        | 0          |
| 124      | Subnet mask for IP address 1  | 255           | 255        | 0          |
| 125      | Subnet mask for IP address 2  | 255           | 255        | 0          |
| 126      | Subnet mask for IP address 3  | 255           | 255        | 0          |
| 127      | Subnet mask for IP address 4  | 0             | 255        | 0          |
| 128      | DHCP settings<br>0: Server<br>1: Client<br>2: Static<br>3: Restore registers 116-128 to default | 2             | 3          | 0          |
| 134      | Backlight time-out (s)<br>0: Always on  | 600           | 9999       | 0          |
| 135      | Auto scroll step size   | 5             | 50         | 1          |
| 139      | MAC address 1   | N/A           | FFFF       | 0          |
| 140      | MAC address 2   | N/A           | FFFF       | 0          |
| 141      | MAC address 3   | N/A           | FFFF       | 0          |
| 157      | Memory clear when external reset through I/O<br>0: No memory clear<br>1: Memory clear           | 0             | 1          | 0          |

## 7.5 LCD Bar-Graph

While ultrasonic power is active the LCD will always display the power value on the 20-segment LCD bar-graph as a percentage of the maximum output power.

At the end of a weld or test cycle, the bar-graph is factory set to represent the cycle's peak power as a percentage of the maximum output power.



The power supply can also be configured to show a single bar on the LCD bar-graph to represent the stack operating frequency stored at the end of each weld or test cycle. This option can be used to troubleshoot operating frequency changes as a result of heating effects, coupling, tooling wear, etc.

For information on how to set the power supply registers see [7.4 Configuring the Power Supply Registers](#).

### 7.5.1 Power Bar-Graph Interpretation

The lightning bolt left of the bar-graph indicates ultrasonic power is running. Each of the segments represent 5% increments of the maximum output power. The segments will only appear if the output power has exceeded the value represented. For example if the power is 4% only the lightning bolt will be on. When it reaches 5% the first bar-graph segment will appear.


**Table 7.5** Power Bar-Graph Interpretation Examples

| Description  | Reference   |
|--|---|
| <p>In this example only the lightning bolt appears left of the bar-graph. This means power is between 0% and 5%. If the power supply is 800 W the actual output power is between 0 W and 40 W.</p> |  <p>The image shows a digital LCD display with '100' and a '%' symbol. To the left of the display is a lightning bolt icon. Below the display is a 20-segment bar graph where only the first segment (representing 0-5%) is active, indicated by a small lightning bolt icon.</p> |
| <p>In this example the first six segments appear on the bar-graph. This means power is between 30% and 35%. If the power supply is 800 W, the actual output power is between 240 W and 280 W.</p>  |  <p>The image shows a digital LCD display with '100' and a '%' symbol. To the left of the display is a lightning bolt icon. Below the display is a 20-segment bar graph where the first six segments (representing 0-30%) are active, indicated by six vertical bars.</p>         |




## 7.5.2 Frequency Bar-Graph Interpretation


The actual frequency depends on the power supply's operating frequency. Use tables below to interpret frequency bar-graph readings.

| NOTICE  |   |
|---|---|
|  | <p>If there is a test overload or an external memory reset signal is received, then the 50% segment will be displayed and blinking.</p> |


**Table 7.6** Frequency Bar-Graph Interpretation - 20 kHz (50 Hz Segment)



**Table 7.7** Frequency Bar-Graph Interpretation - 30 kHz (76 Hz Segment)



**Table 7.8** Frequency Bar-Graph Interpretation - 40 kHz (100 Hz/Segment)



**Table 7.9** Frequency Bar-Graph Interpretation Examples

| Description   | Reference |
|---|-----------|
| <p>In this example the bar is located in the 11th segment. If the power supply is a 20 kHz unit, the stack is running in the frequency range of 19,975 Hz to 20,024 Hz.</p> |           |
| <p>In this example the bar is located in the 7th segment. If the power supply is a 20 kHz unit, the stack is running in the frequency range of 19,775 Hz to 19,824 Hz.</p>  |           |


## 7.6 Web Page Interface


The DCX S Power Supply Web Page Interface provides access, via Ethernet connection, to power supply information, diagnostics, and configuration web pages. Communication can be established point-to-point or through a local area network.

### 7.6.1 System Requirements

To connect to the DCX S Power Supply Web Page Interface you will need a PC running a Windows® operating system with an Internet Explorer® web browser software (versions 7 and up).

### 7.6.2 Connecting to the Web Page Interface


| NOTICE  |  |
|---|--|
|  | <p>The DCX S Power Supply is not compatible with network scanning software. If your local network uses these types of programs, the DCX S Power Supply IP address must be placed in an exclusion list.</p> |

| NOTICE  |  |
|---|--|
|  | <p>A shielded Ethernet cable should be used to connect to the DCX S Power Supply Web Page Interface to prevent possible EMI (Electromagnetic Interference) issues.</p> |


#### 7.6.2.1 Point to Point Connection (Windows Vista and Windows 7)

To connect directly to the DCX S Power Supply Web Page Interface using a PC with Windows Vista® or Windows 7® operating system, complete the following steps:


1. Connect the power supply to a computer via the Ethernet port.
2. Turn on the power supply.
3. On your PC, click on the Windows logo on the task bar and select **Control Panel**.
4. Select **View Large Icons** on the top right corner.
5. Select **Network and Sharing Center**.
6. Select **Change adapter settings**.




7. Right click on **Local Area Connection** and select **Properties** to bring up the **Networking** tab.




8. Highlight **Internet Protocol Version 4 (TCP/IPv4)** from the list and click on **Properties**.



9. Use the following IP address:  
**IP address:** 192.168.10.101  
**Subnet mask:** 255.255.255.0



10. Click **OK**. Close the rest of the dialog boxes.  
 11. Open the Internet Explorer web browser (version 7 and up).  
 12. In the address bar type the following address: <http://192.168.10.100>. Press Enter.  
 13. This will bring up the DCX S Power Supply Web Page interface.  
 14. Enter a user ID number (any number up to 9 digits long).




## 7.6.2.2 Point to Point Connection (Windows XP)


1. To connect directly to the DCX S Power Supply Web Page Interface using a PC with Windows XP® operating system, complete the following steps:
2. Connect the power supply to a computer via the Ethernet port.
3. Turn on the power supply.
4. On your PC, select **Start > Control Panel**.
5. Select **Switch to Classic View** on the top left corner.




6. Select **Network Connections**.
7. Right click on **Local Area Connection** and select **Properties** to bring up the **General** tab.




8. Highlight **Internet Protocol (TCP/IP)** from the list and click on **Properties**.



9. Use the following IP address:  
**IP address:** 192.168.10.101  
**Subnet mask:** 255.255.255.0



10. Click **OK**. Close the rest of the dialog boxes.  
 11. Open the Internet Explorer web browser (version 7 and up).  
 12. In the dress bar type the following address: <http://192.168.10.100>. Press Enter.  
 13. This will bring up the DCX S Power Supply Web Page interface.  
 14. Enter a user ID number (any number up to 9 digits long).





### 7.6.3 Using the Web Page Interface

For complete instructions detailing the web page interface consult the DCX Series Web Page Interface Instruction Manual (4000843).

## 7.7 Ultrasonics Test Procedure


The Ultrasonics Test function measures ultrasonic power dissipated by the ultrasonic stack with no load. The ultrasonics test procedure involves an automatic matching of the frequency of the power supply to the frequency of the converter-booster-horn stack.

| WARNING   | High Voltage Hazard  |
|---|--|
|  | <p>Ensure that no one is in contact with the horn when testing the power supply.</p> <p>Do not cycle the welding system if either the RF cable or converter is disconnected.</p> |



| WARNING   | High Voltage Hazard   |
|---|---|
|  | <p>Ensure the power supply is properly connected, as indicated in <a href="#">5.3 Installation Steps</a>.</p> |



## 7.7.1 Using the Front Panel Controls



| NOTICE  |   |
|---|---|
|  | <p>To use the front panel controls, the DCX S Power Supply unit must be in manual mode.</p> |

**Table 7.10** Power Supply Ultrasonic Test Procedure (Front Panel)


| Step | Action   | Reference   |
|------|--|---|
| 15   | <p>Press the test key for 1-2 seconds, then release. The Sonics Active indicator appears while the test key is pressed. If the power supply alarm indicator does not appear, the test procedure is finished.</p> |   |
| 16   | <p>If the alarm indicator appears, press the alarm reset key and repeat step 2 one time only. If the alarm persists, refer to <a href="#">8.5 Troubleshooting</a>.</p>   |  |

## 7.7.2 Using the I/O Connections

**Table 7.11** Power Supply Ultrasonic Test Procedure (User I/O)

| Step | Action  | Reference   |
|------|---|---|
| 1    | Wire the necessary I/O signals as shown on <a href="#">Figure 7.3 Test Connections.</a> , or using a similar setup.   | Refer to <a href="#">Figure 7.3 Test Connections.</a> below.                        |
| 2    | Send an External Test signal for 1-2 seconds. The Sonics Active output will become active and the Sonics Active indicator appears while the External Start Signal is present. If the General Alarm output/ alarm indicator does not become active, the test procedure is finished |   |
| 3    | If the General Alarm output/alarm indicator becomes active, send an External Reset signal and repeat step 2 one time only. If the alarm persists, refer to <a href="#">8.5 Troubleshooting.</a>   |  |

**Figure 7.3** Test Connections.




---


## Chapter 8: Maintenance


---


|            |   |            |
|------------|---|------------|
| <b>8.1</b> | <b>General Maintenance Considerations . . . . .</b> | <b>106</b> |
| <b>8.2</b> | <b>Preventive Maintenance . . . . .</b>             | <b>108</b> |
| <b>8.3</b> | <b>Calibration . . . . .</b>                        | <b>114</b> |
| <b>8.4</b> | <b>Recommended Spare Stock . . . . .</b>            | <b>115</b> |
| <b>8.5</b> | <b>Troubleshooting . . . . .</b>                    | <b>121</b> |
| <b>8.6</b> | <b>Cold Start Procedure . . . . .</b>               | <b>125</b> |


## 8.1 General Maintenance Considerations

| WARNING   | High Voltage Hazard   |
|---|---|
|  | <p>Power supplies produce high voltage. To avoid the possibility of an electrical shock, you should always power down your system prior to repairing any portion of it.</p> |

| CAUTION   | General Warning   |
|---|---|
|  | <p>When performing maintenance on the welder, make sure that no other automated systems are active.</p> |

| NOTICE  |   |
|---|---|
|  | <p>There are no customer replaceable components inside the power supply. Have all servicing done by a qualified Branson technician.</p> |

| NOTICE  |  |
|---|--|
|  | <p>When returning printed circuit boards, make sure to enclose them in an anti-static package.</p> |

| NOTICE  |   |
|---|---|
|  | <p>Connectors may not be keyed and wires may not be color-coded. Therefore, when disconnecting cables and wires, label them so you can reconnect them properly.</p> |

## NOTICE




To prevent circuit damage from electrostatic discharge, always service the power supply on a static-dissipative surface, while wearing a properly grounded wrist strap.

## 8.2 Preventive Maintenance

The following preventive measures help assure long term operation of your Branson DCX S Power Supply equipment.

### 8.2.1 Periodically Clean the Equipment

| NOTICE  |   |
|---|---|
|  | Use only anti-static vacuum cleaners to prevent damage from electrostatic discharge to your power supply. |


Air is continuously drawn into the power supply. Periodically disconnect the unit from power, remove the cover and vacuum out any accumulated dust and debris. Remove material adhering to:

- Power supply heat sink cooling fins
- Transformers
- Circuit boards
- Cooling intake vents
- Exhaust ports

External covers may be cleaned with a damp sponge or cloth using a solution of mild soap and water. Do not allow cleaning solution to enter the unit.

To prevent rust in areas of high humidity, exposed steel surfaces, may require a very light film of rust preventing oil, such as WD-40®.

## 8.2.2 Recondition the Stack (Converter, Booster, and Horn)

| NOTICE  |  |
|---|--|
|  | <p>Never clean the converter-booster-horn stack mating surfaces by using a buffing wheel or by filing.</p> |

Welding system components work most efficiently when the converter-booster-horn stack mating surfaces are flat, in solid contact, and free from fretting corrosion. Poor contact between mating surfaces wastes power output, makes tuning difficult, increases noise and heat, and may cause damage to the converter.

For standard 20 kHz and 30 kHz products, a Branson Mylar polyester film washer should be installed between the horn and booster, and horn and converter. Replace the washer if torn or perforated. Stacks using Mylar plastic film washers should be inspected every three months.

Stacks used with silicone grease, as with certain 20 kHz, 30 kHz and all 40 kHz products, should be periodically reconditioned to eliminate fretting corrosion. A stack using silicone grease should be inspected every two weeks for corrosion. When experience is gained for specific stacks, the inspection interval can be adjusted to a longer or shorter period as required.

### Stack Reconditioning Procedure

To recondition stack mating surfaces, take the following steps:


**Table 8.1** Stack Reconditioning Procedure

| Step | Action   |
|------|--|
| 1    | Disassemble the converter-booster-horn stack and wipe the mating surfaces with a clean cloth or paper towel.   |
| 2    | Examine all mating surfaces. If any mating surface shows corrosion or a hard, dark deposit, recondition it.  |
| 3    | If necessary, remove the threaded stud from the part.  |
| 4    | Tape a clean sheet of #400 (or finer) grit emery cloth to a clean, smooth, flat surface (such as a sheet of plate glass), as in <a href="#">Figure 8.1 Reconditioning Stack Mating Surfaces</a> .  |
| 5    | Place the interface surface on the emery cloth. Grasp the part at the lower end, with your thumb over the spanner-wrench hole, and lap the part in a straight line across the emery cloth. Do not apply downward pressure — the weight of the part alone provides sufficient pressure. |
| 6    | Lap the part, two or three times, in the same direction against the emery cloth. (See <a href="#">Figure 8.1 Reconditioning Stack Mating Surfaces</a> ).   |
| 7    | Rotate the part 120 degrees, placing your thumb over the spanner-wrench hole, and repeat the lapping procedure in step 6.  |

**Table 8.1** Stack Reconditioning Procedure

| Step | Action   |
|------|--|
| 8    | Rotate the part another 120 degrees to the next spanner-wrench hole, and repeat the lapping procedure in step 6.   |
| 9    | Re-examine the mating surface. If necessary, repeat steps 2-5 until you remove most of the contaminant. Remember, this should not require more than two to three complete rotations for an aluminum horn or booster; a titanium component may require more rotations.  |
| 10   | <p>Before re-inserting a threaded stud in an aluminum booster or horn:<br/>Using a file card or wire brush, clean any aluminum bits from the knurled end of the stud.</p> <p>Using a clean cloth or towel, clean the threaded hole.</p> <p>Examine the knurled end of the stud. If worn, replace the stud. Also, examine the stud and threaded hole for stripped threads.</p> <p><b>NOTICE</b><br/>Threaded studs cannot be reused in titanium horns or boosters. Replace all studs in these components.</p> |
| 11   | Assemble and install the stack.  |

**Figure 8.1** Reconditioning Stack Mating Surfaces



**Table 8.2** Reconditioning Stack Mating Surfaces

| Item | Description      |
|------|------------------|
| 1    | Tape             |
| 2    | #400 Emery Cloth |



### 8.2.2.1 Stack Reassembly Process

**Table 8.3** Stack Torque Values

| Frequency | Torque                |
|-----------|-----------------------|
| 20 kHz    | 220 in·lb (24.85 N·m) |
| 30 kHz    | 185 in·lb (21 N·m)    |
| 40 kHz    | 95 in·lb (10.73 N·m)  |

### For a 20 kHz System

**Table 8.4** Stack Reassembly for a 20 kHz System

| Step | Action   |
|------|--|
| 1    | Clean the mating surfaces of the converter, booster, and horn. Remove any foreign material from the threaded holes.  |
| 2    | Install the threaded stud into the top of the booster. Torque to 450 in·lb (50.84 N·m). If the stud is dry, apply 1 or 2 drops of a light lubricating oil before installing. |
| 3    | Install the threaded stud into the top of the horn. Torque to 450 in·lb (50.84 N·m). If the stud is dry, apply 1 or 2 drops of a light lubricating oil before installing.    |
| 4    | Install a single Mylar plastic film washer (matching the size of the washer to the stud) to each interface.  |
| 5    | Assemble the converter to the booster and the booster to the horn.   |
| 6    | Torque to 220 in·lb (24.85 N·m) at each interface.   |

## For a 30 kHz System

**Table 8.5** Stack Reassembly for a 30 kHz System

| Step | Action   |
|------|--|
| 1    | Clean the mating surfaces of the converter, booster, and horn. Remove any foreign material from the threaded holes.  |
| 2    | Install the threaded stud into the top of the booster. Torque to 290 in·lb (32.76 N·m). If the stud is dry, apply 1 or 2 drops of a light lubricating oil before installing. |
| 3    | Install the threaded stud into the top of the horn. Torque to 290 in·lb (32.76 N·m). If the stud is dry, apply 1 or 2 drops of a light lubricating oil before installing.    |
| 4    | Install a single Mylar plastic film washer (matching the size of the washer to the stud) to each interface.  |
| 5    | Assemble the converter to the booster and the booster to the horn.   |
| 6    | Torque to 185 in·lb (21 N·m) at each interface.  |

## For a 40 kHz System

**Table 8.6** Stack Reassembly for a 40 kHz System

| Step | Action  |
|------|---|
| 1    | Clean the mating surfaces of the converter, booster, and horn. Remove any foreign material from the threaded holes.   |
| 2    | Apply a drop of Loctite®* 290 threadlocker (or equivalent) to the studs for the booster and horn.   |
| 3    | Install the threaded stud into the top of the booster. Torque to 70 in·lb (7.91 N·m). Remove excess Loctite 290 threadlocker from the booster face and let cure for 30 minutes. |
| 4    | Install the threaded stud into the top of the horn. Torque to 70 in·lb (7.91 N·m). Remove excess Loctite 290 threadlocker from the horn face and let cure for 30 minutes.       |
| 5    | Coat each interface surface with a thin film of silicon grease - but do not apply silicon grease to a threaded stud or tip.   |
| 6    | Torque to 95 in·lb (10.73 N·m) at each interface.   |

\* Loctite is a registered trademark of Henkel Corporation, U.S.A.

### 8.2.3 Stud Torque Values

**Table 8.7** Stud Torque Values

| Used on | Stud Size              | Torque               | EDP #        |
|---------|------------------------|----------------------|--------------|
| 20 kHz  | 1/2 in x 20 x 1-1/4 in | 450 in·lb, 50.84 N·m | 100-098-370  |
|         | 1/2 in x 20 x 1-1/2 in |                      | 100-098-123  |
| 30 kHz  | 3/8 in x 24 x 1 in     | 290 in·lb, 32.76 N·m | 100-298-170R |
| 40 kHz* | M8X1.25 X 20           | 70 in·lb, 7.91 N·m   | 100-098-790  |

\* Add a drop of Loctite 290 threadlocker to the stud. Torque and let cure for 30 minutes before using.

### 8.2.4 Routine Component Replacement

The lifetime of certain parts is based on the number of cycles the unit has completed, or on hours of operation.

## 8.3 Calibration

This product does not normally require scheduled calibration. However, if you are operating under any type of regulatory requirements, you may need to calibrate the equipment according to that schedule and set of standards. Contact Branson for details.

## 8.4 Recommended Spare Stock

This section provides lists of replacement parts, system cables, and suggested spares.

### 8.4.1 System Cables

You can order the following cables:

**Table 8.8** DCX S Power Supply System Cables

| P/N         | Description                                       |
|-------------|---|
| 100-240-383 | Cable, RF 8 ft (2.5 m)                            |
| 100-240-384 | Cable, RF 15 ft (4.5 m)                           |
| 100-240-385 | Cable, RF 25 ft (7.5 m)                           |
| 100-240-387 | Cable, RF right angle 8 ft (2.5 m)                |
| 100-240-388 | Cable, RF right angle 15 ft (4.5 m)               |
| 100-240-389 | Cable, RF right angle 25 ft (7.5 m)               |
| 100-240-391 | Cable, RF adaptor for CR20 converter 3 ft (0.9 m) |
| 100-240-392 | Cable, User I/O 25 ft (7.5 m)                     |
| 200-240-396 | Cable Ethernet Cat 5e 7 ft (2.1 m)                |

## 8.4.2 Suggested Spares

**Table 8.9** Suggested Spares

| Description                   | EDP#  | 1-4 Units | 6-12 Units | 14+ Units |
|-------------------------------|---|-----------|------------|-----------|
| Converter                     | Refer to <a href="#">Table 8.10 Converters Compatible with the DCX S Power Supply</a> | 0         | 1          | 2         |
| Booster                       | Refer to <a href="#">Table 8.11 DCX S Power Supply Compatible Boosters</a>            | 0         | 1          | 2         |
| Horn                          | As Ordered  | 1         | 1          | 2         |
| Studs                         | Refer to <a href="#">Table 8.12 Other Items used with the DCX S Power Supply</a>      | 4         | 6          | 8         |
| Mylar Plastic Film Washer Kit | Refer to <a href="#">Table 8.12 Other Items used with the DCX S Power Supply</a>      | 1         | 1          | 1         |

### 8.4.3 Converters Compatible with the DCX S Power Supply

**Table 8.10** Converters Compatible with the DCX S Power Supply

| Where used      | Model                  | Connector                             | Part Number  |
|-----------------|------------------------|---------------------------------------|--------------|
| 20 kHz / 4000 W | CR-20*                 | 3-pin MS connector                    | 101-135-060R |
|                 | CR-20S                 | SHV connector                         | 125-135-115R |
|                 | CR-20C                 | SHV connector with 3 ft (0.9 m) cable | 159-135-210R |
|                 | CH-20S<br>(932 AH SPL) | SHV connector                         | 159-135-075R |
|                 | CH-20C                 | SHV connector with 3 ft (0.9 m) cable | 159-135-211R |
|                 | CS-20S                 | SHV connector                         | 159-135-138R |
|                 | CS-20C                 | SHV connector with 3 ft (0.9 m) cable | 159-135-209R |
| 30 kHz / 1500 W | CR-30S                 | SHV connectors                        | 101-135-081R |
|                 | CR-30C                 | SHV connector with 3 ft (0.9 m) cable | 159-135-213R |
|                 | CH-30S                 | SHV connector                         | 101-135-071R |
|                 | CH-30C                 | SHV connector with 3 ft (0.9 m) cable | 159-135-214R |
|                 | CS-30S                 | SHV connector                         | 159-135-110R |
|                 | CS-30C                 | SHV connector with 3 ft (0.9 m) cable | 159-135-212R |
| 40 kHz / 800 W  | 4TR                    | 3-pin MS connector                    | 101-135-042R |
|                 | 4TP                    | SHV connector (platen mount)          | 101-135-068R |
|                 | CR-40S<br>(4TH)        | SHV connector                         | 101-135-067R |
|                 | CR-40C                 | SHV connector with 3 ft (0.9 m) cable | 159-135-215R |

\* Requires a special adaptor cable. See [Table 8.8 DCX S Power Supply System Cables](#).

## 8.4.4 DCX S Power Supply Compatible Boosters

**Table 8.11** DCX S Power Supply Compatible Boosters

| Type of Booster                                 | Description              | Part Number |
|---|--------------------------|-------------|
| Solid Mount<br>(1/2-20 horn stud)<br>20 kHz     | Titanium, 1:0.6 (Purple) | 101-149-095 |
|   | Titanium, 1:1 (Green)    | 101-149-096 |
|   | Titanium, 1:1.5 (Gold)   | 101-149-097 |
|   | Titanium, 1:2 (Silver)   | 101-149-098 |
|   | Titanium, 1:2.5 (Black)  | 101-149-099 |
| Solid Mount<br>(M8 x 1.25 horn stud)<br>40 kHz  | Titanium, 1:0.6 (Purple) | 109-041-178 |
|   | Titanium, 1:1 (Green)    | 109-041-177 |
|   | Titanium, 1:1.5 (Gold)   | 109-041-176 |
|   | Titanium, 1:2 (Silver)   | 109-041-175 |
|   | Titanium, 1:2.5 (Black)  | 109-041-174 |
| Standard Series<br>(1/2-20 horn stud)<br>20 kHz | Aluminum, 1:0.6 (Purple) | 101-149-055 |
|   | Aluminum, 1:1 (Green)    | 101-149-051 |
|   | Aluminum, 1:1.5 (Gold)   | 101-149-052 |
|   | Aluminum, 1:2 (Silver)   | 101-149-053 |
|   | Titanium, 1:0.6 (Purple) | 101-149-060 |
|   | Titanium, 1:1 (Green)    | 101-149-056 |
|   | Titanium, 1:1.5 (Gold)   | 101-149-057 |
|   | Titanium, 1:2 (Silver)   | 101-149-058 |
| Standard Series<br>(3/8-24 horn stud)<br>30 kHz | Titanium, 1:2.5 (Black)  | 101-149-103 |
|   | Titanium, 1:2 (Silver)   | 101-149-104 |
|   | Titanium, 1:1.5 (Gold)   | 101-149-105 |
|   | Titanium, 1:1 (Green)    | 101-149-106 |



**Table 8.11** DCX S Power Supply Compatible Boosters

| Type of Booster                                    | Description              | Part Number  |
|--|--------------------------|--------------|
| Standard Series<br>(M8 x 1.25 horn stud)<br>40 kHz | Aluminum, 1:0.6 (Purple) | 101-149-087  |
|  | Aluminum, 1:1 (Green)    | 101-149-079  |
|  | Aluminum, 1:1.5 (Gold)   | 101-149-080  |
|  | Aluminum, 1:2 (Silver)   | 101-149-081R |
|  | Aluminum, 1:2.5 (Black)  | 101-149-082  |
|  | Titanium, 1:1 (Green)    | 101-149-085  |
|  | Titanium, 1:1.5 (Gold)   | 101-149-086  |
|  | Titanium, 1:2 (Silver)   | 101-149-083  |
|  | Titanium, 1:2.5 (Black)  | 101-149-084  |

## 8.4.5 Other Items used with the DCX S Power Supply

**Table 8.12** Other Items used with the DCX S Power Supply


| Product  | Description  | Part No.     |
|--|--|--------------|
| Silicone grease                                    | For use with 40 kHz systems                        | 101-053-002  |
| Mylar Plastic Film Washers<br>(for 20 kHz systems) | Kit, 10 each (1/2 in and 3/8 in)                   | 100-063-357  |
|  | Kit, 150 each (1/2 in)                             | 100-063-471  |
|  | Kit, 150 each (3/8 in)                             | 100-063-472  |
| Mylar Plastic Film Washers<br>(for 30 kHz systems) | Kit, 10 each (3/8 in)                              | 100-063-632  |
|  | Kit, 150 each (3/8 in)                             | 100-063-712  |
| Tool Kit   | 20 kHz<br>(spanner wrench and 10 pc washer kit)    | 101-063-208R |
|  | 30 kHz<br>(spanner wrench and 10 pc washer kit)    | 101-063-636R |
|  | 40 kHz<br>(spanner wrench and silicone grease)     | 101-063-176R |
| Spanner wrench                                     | 20 kHz   | 101-118-039  |
|  | 30 kHz   | 201-118-033  |
|  | 40 kHz   | 201-118-024  |
| Studs  | 1/2-20 x 1-1/4 (titanium horns)                    | 100-098-370  |
|  | 1/2-20 x 1-1/2 (aluminum horns, 20 kHz boosters)   | 100-098-123  |
|  | 3/8-24 x 1<br>(30 kHz titanium horns and boosters) | 100-298-170R |
|  | M8X1.25 X 20<br>(40 kHz horns and boosters)        | 100-098-790  |
| Connector Block                                    | Detachable connector block                         | 200-029-1108 |

## 8.5 Troubleshooting


If you have a problem operating the DCX S Power Supply, take the following steps:

**Table 8.13** Troubleshooting

| Step | Action   |
|------|--|
| 1    | Make sure the converter-booster-horn stack is properly assembled and installed.  |
| 2    | For instructions on reconditioning stack component surfaces, refer to <a href="#">8.2.2 Recondition the Stack (Converter, Booster, and Horn)</a> |
| 3    | If you need additional help, call your local Branson representative, refer to <a href="#">1.3 How to Contact Branson</a> .                       |

| NOTICE  |   |
|---|---|
|  | DCX S Power Supply should be serviced only by qualified technicians using Branson-approved test and repair equipment, repair procedures, and replacement parts. Unauthorized attempts at repair or modification of the power supply will void the warranty. |

## 8.5.1 Common Electrical Problems

| NOTICE  |  |
|---|--|
|  | <p>If the circuit breaker fails more than once, this usually indicates that another component has failed. Continue troubleshooting other components.</p> |

**Table 8.14** Troubleshooting Common Electrical Problems

| Problem  | Check   | Solution                                       |
|--|---|--|
| Main circuit breaker trips when plugging the power supply into an electrical outlet. | Inspect line connection cables.                   | If failed, replace.                            |
| Main circuit breaker trips during weld cycle.  | Check current rating of the main circuit breaker. | If failed, replace.                            |
| Main circuit breaker fails during power up.  | Check main circuit breaker current rating.        | If incompatible, replace main circuit breaker. |
| When touching a component of the weld system, you get a slight electrical shock.     | Ensure the Ground cable is connected properly.    | N/A  |
|  | Inspect the line cables.                          | If failed, repair or replace.                  |

## 8.5.2 Ultrasonic Power Problems

**Table 8.15** Troubleshooting Ultrasonic Power Problems

| Problem  | Check  | Solution   |
|--|--|--|
| Ultrasonic power delivered to horn; no indication on bar graph.          | Check connector cables, replace if failed.   | Replace defective cables.  |
|  | Test power supply.   | See <a href="#">Chapter 7: Operation 7.7 Ultrasonics Test Procedure</a>                                |
| No ultrasonic power generated when Test key pressed; no Alarm indicator. | Failed or missing stack.   | Replace.   |
|  | RF cable unplugged or failed; replace if failed.   | Plug in or replace.  |
|  | Test power supply ( <a href="#">Chapter 7: Operation 7.7 Ultrasonics Test Procedure</a> ). | If defective, send unit for repair.  |
| Unable to adjust amplitude using the front panel keypad.                 | Register setting configured to "External Amplitude Control"                                | Reset if required, See <a href="#">Chapter 7: Operation 7.4 Configuring the Power Supply Registers</a> |
| Unable to remote control.  | User I/O cable   | Repair or replace.   |
|  | Customer's switching device  | Test/inspect/repair/replace.   |

## 8.5.3 Weld Cycle Problems

**Table 8.16** Troubleshooting Weld Cycle Problems


| Problem   | Check  | Solution   |
|---|--|--|
| Full ultrasonic power not delivered.  | Unsuitable horn or booster selection.                                      | Contact Branson Applications Lab   |
|   | Plastic part material varies.  |  |
|   | Mold release lubricant in weld area.                                       |  |
|   | Unsuitable joint design.   |  |
|   | Unsuitable or misaligned part fixture.                                     |  |
|   | Amplitude setting  | Adjust if required.  |
| No ultrasonic power passed to horn.   | Power supply overheating   | Remove dust and debris.  |
| Alarm indicator illuminates when you press the Test key or during the weld cycle. | Check converter-booster-horn stack interface for fretting corrosion.       | See <a href="#">8.2.2 Recondition the Stack (Converter, Booster, and Horn)</a>           |
|   | Check for loose or failed horn converter or booster.                       | Tighten or replace as needed.  |
|   | Check for loose or failed horn or booster stud.                            |  |
|   | Failed RF cable  | Replace if failed.   |
| Excessively warm horn, booster, and converter; occasional overloads.              | Check converter-booster-horn stack mating surfaces for fretting corrosion. | See <a href="#">8.2.2 Recondition the Stack (Converter, Booster, and Horn)</a> .         |
|   | Be certain proper cooling has been provided.                               | See <a href="#">5.2.1 Installing the DCX S Power Supply Drawers in a Customer Rack</a> . |

## 8.6 Cold Start Procedure

The power supply internal memory stores the system default settings and the registers that you set. It also provides temporary storage to support the power supply internal functions. A cold start clears the Amplitude Setting, the user I/O configuration, the IP address, and restores them to original factory defaults. It is not necessary to perform a cold start during normal operation and servicing, but you might find a cold start helpful when:

- You suspect the system is not operating properly.
- You want to make a new setup.
- Some system memory registers, such as Software version, will not be cleared by this Cold Start procedure.

### 8.6.1 Performing a Cold Start

| NOTICE  |  |
|---|--|
|  | <p>Using the Cold Start procedure will erase the current Amplitude Setting, the IP address and some of the Registers that you set. Be sure you have a record of your setup if you want to retain it or use the system backup feature from the DCX S Power Supply Web Page Interface.</p> |

**Table 8.17** Steps to Perform a Cold Start

| Step | Action   |
|------|--|
| 1    | Turn off the power supply.                                       |
| 2    | Connect together pins 4 and 10 on the 26-pin User I/O Connector. |
| 3    | Turn on the power supply.  |
| 4    | After the power up sequence ends, turn off the power supply      |
| 5    | Disconnect pins 4 and 10 of the 26-pin on User I/O Connector.    |





---


# Appendix A: Signal Diagrams

---

A.1      Signal Diagrams ..... 128

## A.1 Signal Diagrams

Figure A.1 Continuous Mode



\*Inputs/Outputs are configurable on the User I/O Configuration webpage.

--- If Reset Required is unchecked for Overload in Alarm Webpage interface, Ready signal will be enabled after Start switch is released.

---

# Index

---

## A

- about Installation 42
- Actuator 26
- Alarm 26
- alarm
  - configuring 61
  - latching 61
  - modes 61
- Amplitude 26
- amplitude
  - controlling 61
  - start ramp 61
- Amplitude Control 26
- amplitude control 61
- applications 25
- autotune with memory (AT/M) 15
- Autotuning 17

## B

- bar graph 94
  - frequency interpretation 95
  - power interpretation 94
- bend radius 48
- Booster 26
- booster 19
  - dimensions 38, 72
  - part numbers 118

## C

- cables
  - bend radius 48
  - RF 59
  - user I/O 52
- Clamping Force 26
- Cold Start 26
- cold start 125
- components
  - functional description 82
- connecting tip to horn 65
- connection
  - input power 60
  - user I/O 52
- connector
  - line 24
  - RF 24
  - user I/O 24
- controls, front panel 20
- Converter 26

- converter 19, 82
  - cooling 66
  - dimensions 38, 72
  - part numbers 117
- Counters 26

## D

- Degating 26
- Digital Amplitude Setting 17
- drop test 30

## E

- electrical input
  - operating voltages 36
- Energy Director 26
- environmental
  - requirements 47
  - specifications 30
- External Amplitude Control 26
- External Frequency Control 26

## F

- Fixture 26
- Flash 26
- Forming 26
- Frequency 26
- frequency
  - end of weld store 61
  - offset 15
- Frequency Offset 17, 27
- frequency offset
  - setup 61
- Fretting Corrosion 26

## G

- Gain 27

## H

- Horn 27
- horn 19
- Horn Amplitude 27
- Horn Signature 17, 27
- humidity 30, 36, 47

## I

- indicators 20
- input power 59, 60
  - plug 60
  - ratings 36, 47
- inputs
  - analog 56
- Insertion 27
- installation 41
  - requirements 43
  - stack 68

- steps 48
- testing 68
- Interface 27
- inventory of small parts 33

## J

- Joint 27

## L

- LCD 17
  - bar graph 94
    - frequency interpretation 95
    - power interpretation 94
  - description 22
  - viewing angle 49
- line input
  - connector 24
- Line Regulation 17
- line regulation 15
- Load Regulation 17
- load regulation 15

## M

- maintenance 105
  - general considerations 106
- manual set 15
- Membrane Keys 17

## O

- operating voltages 36
- operation 85
  - principle of 25
- output power cable 59
- outputs
  - analog 57
  - digital 56

## P

- Parameter 27
- Parameter Range 27
- parts lists 115
- Passcodes 17
- periodic and preventive maintenance
  - periodically clean the equipment 108
  - recondition the stack 109
  - routine component replacement 115
- Power Supply 27
- power supply
  - configuring 89, 90
  - connections 24
  - continuous duty max. power 37
  - cycle rate 38
  - default settings (cold start) 125
  - front panel controls 20
  - manual set 15

models 14, 15  
mounting 49

## R

Ramp Starting 17  
receiving the equipment 31  
returning equipment 34

## S

safety  
  general precautions 6  
  maintenance 106  
  symbols, meaning 2  
Seek 18, 27  
seek  
  ramp time 61  
  time 61  
  timed 15, 61  
shipping and handling 30  
shock 30  
solid mount boosters 83  
special cable requirements 49  
stack 19, 82  
stack assembly 62  
  20 kHz 64, 111, 112  
  30 kHz 64  
  40 kHz 65  
Staking 27  
Start-up Diagnostics 18  
support 69  
Swaging 27  
System Protection 18  
system requirements, web page interface 97

## T

technical specifications 35, 71  
temperature  
  ambient operating temperature 36, 47  
  shipping and storage 30, 36  
Thermoplastic 27  
Thermoset 27  
Timed Seek 18  
timed seek 15  
Token 27  
troubleshooting  
  electrical problems 122  
  ultrasonic power 123  
  weld cycle problems 124  
True Wattmeter 18

## U

Ultrasonic Power 27  
ultrasonic stack 82  
Ultrasonic Welding 27  
unpacking 32

User ID 17, 27

## **V**

vibration 30

## **W**

Web Page Interface 18

web page interface 15, 102

point-to-point connection

Windows Vista and Windows 7 97

Windows XP 100

Weld System 27

weld system

applications 25

welding systems 25

