# Rosemount 5900S Still-pipe Array Antenna Insert Pipe

## **Benefits**

- Fits any floating roof tank with an existing 8-in. (or larger) gauge still-pipe
- Provides for temperature, level measurement and water level in an existing still-pipe
- The gauge can be provided with a hinged array antenna allowing for full access to the insert pipe for hand dipping, sampling, etc.
- Reduce emissions
- Can be installed without taking the tank out of service
- Measure with highest precision non-contact radar







The Rosemount 5900S with array antenna is a premium non-contact radar level gauge for still-pipe measurement. Typical applications are crude oil tanks with floating roofs and gasoline/ product tanks with or without floating roofs. Most of these tanks are equipped with a standard 8-in. still-pipe. This means adding a multi point temperature probe with water level sensor is not possible without extensive modification to the tank. Using the insert pipe allows for the addition of these auxiliary measurement devices without modifying the tank or taking it out of service. When coupled with the hinged array antenna, the insert pipe allows full access to the tank for hand gauging, sampling, etc.

Figure 1-1. Rosemount 5900s with Array Antenna Is Designed for Installation in New, Existing or Insert Still-pipes



Figure 1-2. Rosemount 5900s with Array Antenna, Hinged Hatch Version



| Specifications for Rosemount 5900S Still-pipe insert pipe |                     |
|---|---------------------|
| Standard lengths  | 15 meters (49 feet) |
|   | 18 meters (59 feet) |
|   | 21 meters (68 feet) |
|   | 24 meters (78 feet) |
| Material of construction                                  | 316 Stainless steel |

### Figure 1-3. Installation Overview 5900S gauge with array antenna (hinged array option shown) 5-in. insert pipe Standard fixed Temperature probe array antenna (shown with optional water level sensor) 8-in. (or larger) gauge pipe Top view Φ $\cap$ Pipe clamp (holds insert pipe section in place) Ο ∩ Spacer (holds insert pipe in excentric position) Standard Deflector plate anchor (eliminates false weight 200 mm (8 in.) echos from tank floor) - Tank floor

The Emerson logo is a trade mark and service mark of Emerson Electric Co. Rosemount and the Rosemount logotype are registered trademarks of Rosemount Inc. PlantWeb is a registered trademark of one of the Emerson Process Management group of companies. HART and WirelessHART are registered trademarks of the HART Communication Foundation All other marks are the property of their respective owners.

© 2015 Rosemount Tank Radar AB. All rights reserved.

#### Emerson Process Management Rosemount Tank Gauging Box 130 45 SE-402 51 Göteborg SWEDEN Tel: +46 31 337 00 00 Fax: +46 31 25 30 22

Fax: +46 31 25 30 22 E-mail: sales.rtg@emerson.com www.rosemount-tg.com

#### Emerson Process Management Rosemount Tank Gauging Middle East & Africa. P. O Box 20048 Manama Bahrain Tel: +973 1722 6610 Fax: +973 1722 7771 E-mail: rtgmea.sales@emerson.com

Emerson Process Management Rosemount Tank Gauging North America Inc. 6005 Rogerdale Road Mail Stop NC 136 77072 TX Houston United States Primary Phone: +1 281 988 4000 Secondary Phone: +1 800 722 2865 E-mail: sales.rtg.hou@emerson.com

#### Emerson Process Management Asia Pacific Pte Ltd 1 Pandan Crescent

SINGAPORE 128461 Tel: +65 6777 8211 Fax: +65 6777 0947 E-mail: specialist-itg.rmt-ap@ap.emersonprocess.com

#### Emerson Process Management Latin America

1300 Concord Terrace, Suite 400 Sunrise Florida 33323 United States Tel: + 1 954 846 5030



