


Type 92B Tandem Safety Working Monitor



- █ INLET PRESSURE
- █ OUTLET PRESSURE
- █ ATMOSPHERIC PRESSURE
- █ LOADING PRESSURE
- █ INTERMEDIATE PRESSURE
- █ FLOOR DRAIN OR CONDENSATE RETURN PRESSURE
- CHECK VALVE

TO FLOOR DRAIN OR
CONDENSATE RETURN