


Type EZR-PRX Wide Open Upstream or Downstream Monitor



- █ INLET PRESSURE
- █ OUTLET PRESSURE
- █ ATMOSPHERIC PRESSURE
- █ LOADING PRESSURE
- █ INTERMEDIATE PRESSURE