



# Type F138 In-Line Excess Flow Valve

Type F138 Open



Type F138 Closed



INLET PRESSURE  
OUTLET PRESSURE